

1500i



The Future of Fume Extraction



## FEATURES

- Clear & informative graphic display
- Highest grade HEPA and carbon technology
- Automatic electronic flow control - maintains a constant extraction rate even as the filter blocks
- Gas and particle sensors to warn the operator
- Adjustable airflow

## SPECIFICATIONS

Voltage	120v	230v
Volume Part Number	0LX1511D	0LX1510D
Vacuum Part Number	021821iD	021820iD
Wattage	3.45kW	2.95kW
Frequency	50Hz / 60Hz	50Hz / 60Hz
Cabinet Height	1400mm	1400mm
Cabinet Width	725mm	725mm
Cabinet Depth	726mm	726mm
Cabinet Weight	150kg	150kg
Sound Level	60dBa	60dBa
Airflow	1500m3/h	1500m3/h

## INCLUDED AS STANDARD...

### FILTERS



**Main Filter**  
**Code**  
110615

**Description**  
HEPA/Chemical



**Pre-filter**  
**Code**  
111037

**Description**  
F6 Labyrinth

Find out more:



[www.purexinc.com](http://www.purexinc.com)



[sales@purexinc.com](mailto:sales@purexinc.com)



**+1 847 348 5203**

***Connection kits are available  
see overleaf for options***

*Machine Supplied With • 1 x Main Filter • 1 x Pre-filter • 1 x 4.5m Fixed Power Cable (no plug) • 1 x Manual*

## OPTIONS

### Main Filter

**Code:**  
110614  
110632  
110610

**Description:**  
HEPA/Twin Chemical  
HEPA/Chemical (Cleanroom)  
Chemical

### Pre-filter

**Code:**  
111099

**Description:**  
F8/F9 Labyrinth

### Connection Kits

Hose End  
Diameter

Hose  
Length


Purex Inlet  
Diameter

**Code:** 120280

150mm

1.5m

150mm




**Code:** 120287

100mm

3m

150mm



315mm

3m

150mm

### Large Extraction Arm

Our 2m long extraction arm with its triple axis can be used in a variety of applications. The flexibility of the arm allows it to be manoeuvred for all the difficult areas. The arm has a 160mm diameter to reduce restriction and has a large hood of 315mm at the inlet.

**Code:** 840197 - Extraction arm  
**Code:** 840198 - Mounting bracket  
**Code:** 840199 - 150mm Connection flange  
**Code:** 120280 - 150mm Hose kit



*If you do not see a connection kit that fits your machine or pipework, please contact Purex or your representative*

### Interfacing



Interfacing can remotely start the Purex machine when the connected machine starts.

Interfacing can also warn the connected machine when the Purex machine is in alarm.

*Take a look through our Interfacing Guide to see our extensive range of options*



Purex Inc  
2246 Palmer Drive, Suite 108  
Schaumburg  
Illinois 60173  
USA