

ClubRoller 250 CT - DMX PROTOCOL ,version 1.0

[illegible]

4	144-153	Gobo 9 <i>Pulse movement between two gobos ,from slow to fast</i>	proportional
	154-161	Hole --> Gobo 1	proportional
	162-167	Gobo 1 --> Gobo 2	proportional
	168-173	Gobo 2 --> Gobo 3	proportional
	174-179	Gobo 3 --> Gobo 4	proportional
	180-185	Gobo 4 --> Gobo 5	proportional
	186-191	Gobo 5 --> Gobo 6	proportional
	192-197	Gobo 6 --> Gobo 7	proportional
	198-203	Gobo 7 --> Gobo 8	proportional
	204-209	Gobo 8 --> Gobo 9	proportional
	210-217	Gobo 9 --> Hole	proportional
	218-229	Gobo wheel rotation from fast to slow (forward)	proportional
	230-231	No rotation	step
	232-243	Gobo wheel rotation from slow to fast (backward)	proportional
	244-249	Random gobo selection by audio control	step
	250-255	Auto random gobo selection from fast to slow	proportional
5	0-127	Gobo rotation Gobo positioning	proportional
	128-190	Forward gobo rotation from fast to slow	proportiona
	191-192	No rotation	step
	193-255	Backward gobo rotation from slow to fast	proportiona
6	0-5	Dimmer,stroke,program trigger Closed	step
	6-85	Dimmer from closed to open	proportional
	86-95	Full open	step
	96-127	Strobe-effect from slow to fast	proportional
	128-139	Reset	step
	140-191	Program time trigger (editable program runs by time control)	step
	192-223	Program audio trigger (editable program runs by audio control)	step
	224-255	Random Audio trigger (random effects run by audio control)	step