

Digital Design & Computer Arch.

Lecture 10a: Instruction Set Architecture

Prof. Onur Mutlu

ETH Zürich

Spring 2020

20 March 2020

Assignment: Required Lecture Video

- Why study computer architecture?
- Why is it important?
- **Future Computing Architectures**
- **Required Assignment**
 - **Watch** Prof. Mutlu's inaugural lecture at ETH and understand it
 - <https://www.youtube.com/watch?v=kgiZISOcGFM>
- **Optional Assignment – for 1% extra credit**
 - **Write a 1-page summary** of the lecture and email us
 - What are your key takeaways?
 - What did you learn?
 - What did you like or dislike?
 - Submit your summary to [Moodle](#) – Deadline: March 25

Extra Assignment: Moore's Law (I)

- **Paper review**
- G.E. Moore. "Cramming more components onto integrated circuits," Electronics magazine, 1965

- **Optional Assignment – for 1% extra credit**
 - **Write a 1-page review**
 - Upload PDF file to Moodle – Deadline: April 1

- I strongly recommend that you **follow my guidelines for (paper) review** (see next slide)

Extra Assignment: Moore's Law (II)

■ Guidelines on how to review papers critically

- **Guideline slides:** [pdf](#) [ppt](#)
- **Video:** <https://www.youtube.com/watch?v=tOL6FANAj8c>

- Example reviews on “Main Memory Scaling: Challenges and Solution Directions” ([link to the paper](#))
 - [Review 1](#)
 - [Review 2](#)

- Example review on “Staged memory scheduling: Achieving high performance and scalability in heterogeneous systems” ([link to the paper](#))
 - [Review 1](#)

Agenda for Today & Next Few Lectures

- LC-3 and MIPS Instruction Set Architectures
- LC-3 and MIPS assembly and programming
- Introduction to microarchitecture and single-cycle microarchitecture
- Multi-cycle microarchitecture

Required Readings


■ This week

- Von Neumann Model, LC-3, and MIPS
 - P&P, Chapters 4, 5
 - H&H, Chapter 6
 - P&P, Appendices A and C (ISA and microarchitecture of LC-3)
 - H&H, Appendix B (MIPS instructions)
- Programming
 - P&P, Chapter 6
- **Recommended:** H&H Chapter 5, especially 5.1, 5.2, 5.4, 5.5

■ Next week

- Introduction to microarchitecture and single-cycle microarchitecture
 - H&H, Chapter 7.1-7.3
 - P&P, Appendices A and C
- Multi-cycle microarchitecture
 - H&H, Chapter 7.4
 - P&P, Appendices A and C

Recall: The Instruction Cycle



Instruction Set Architectures

Recall: The Instruction Set Architecture

- The ISA is the **interface between** what the **software** commands and what the **hardware** carries out
- The ISA specifies
 - The **memory organization**
 - Address space (LC-3: 2^{16} , MIPS: 2^{32})
 - Addressability (LC-3: 16 bits, MIPS: 32 bits)
 - Word- or Byte-addressable
 - The **register set**
 - R0 to R7 in LC-3
 - 32 registers in MIPS
 - The **instruction set**
 - Opcodes
 - Data types
 - Addressing modes

Problem
Algorithm
Program
ISA
Microarchitecture
Circuits
Electrons

Recall: Opcodes in LC-3

	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
ADD ⁺	0001				DR			SR1			0	00		SR2		
ADD ⁺	0001				DR			SR1			1	imm5				
AND ⁺	0101				DR			SR1			0	00		SR2		
AND ⁺	0101				DR			SR1			1	imm5				
BR	0000				n	z	p	PCoffset9								
JMP	1100				000			BaseR			000000					
JSR	0100				1	PCoffset11										
JSRR	0100				0	00		BaseR			000000					
LD ⁺	0010				DR			PCoffset9								
LDI ⁺	1010				DR			PCoffset9								
LDR ⁺	0110				DR			BaseR			offset6					
LEA ⁺	1110				DR			PCoffset9								
NOT ⁺	1001				DR			SR			111111					
RET	1100				000			111			000000					
RTI	1000				000000000000											
ST	0011				SR			PCoffset9								
STI	1011				SR			PCoffset9								
STR	0111				SR			BaseR			offset6					
TRAP	1111				0000			trapvect8								
reserved	1101															

Figure 5.3 Formats of the entire LC-3 instruction set. NOTE: + indicates instructions that modify condition codes

Recall: Opcodes in LC-3b

	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
ADD ⁺	0001				DR				SR1				A	op.spec			
AND ⁺	0101				DR				SR1				A	op.spec			
BR	0000				n	z	p	PCOffset9									
JMP	1100				000				BaseR				000000				
JSR(R)	0100				A	operand.specifier											
LDB ⁺	0010				DR				BaseR				boffset6				
LDW ⁺	0110				DR				BaseR				offset6				
LEA ⁺	1110				DR				PCOffset9								
RTI	1000				000000000000												
SHF ⁺	1101				DR				SR		A	D	amount4				
STB	0011				SR				BaseR				boffset6				
STW	0111				SR				BaseR				offset6				
TRAP	1111				0000				trapvect8								
XOR ⁺	1001				DR				SR1				A	op.spec			
not used	1010																
not used	1011																

Recall: Funct in MIPS R-Type Instructions (I)

Opcode is 0
in MIPS R-
Type
instructions.
Funct defines
the operation

Table B.2 R-type instructions, sorted by funct field

Funct	Name	Description	Operation
000000 (0)	sll rd, rt, shamt	shift left logical	[rd] = [rt] << shamt
000010 (2)	srl rd, rt, shamt	shift right logical	[rd] = [rt] >> shamt
000011 (3)	sra rd, rt, shamt	shift right arithmetic	[rd] = [rt] >>> shamt
000100 (4)	sllv rd, rt, rs	shift left logical variable	[rd] = [rt] << [rs] _{4:0}
000110 (6)	srlv rd, rt, rs	shift right logical variable	[rd] = [rt] >> [rs] _{4:0}
000111 (7)	srav rd, rt, rs	shift right arithmetic variable	[rd] = [rt] >>> [rs] _{4:0}
001000 (8)	jr rs	jump register	PC = [rs]
001001 (9)	jalr rs	jump and link register	\$ra = PC + 4, PC = [rs]
001100 (12)	syscall	system call	system call exception
001101 (13)	break	break	break exception
010000 (16)	mfhi rd	move from hi	[rd] = [hi]
010001 (17)	mthi rs	move to hi	[hi] = [rs]
010010 (18)	mflo rd	move from lo	[rd] = [lo]
010011 (19)	mtlo rs	move to lo	[lo] = [rs]
011000 (24)	mult rs, rt	multiply	{[hi], [lo]} = [rs] × [rt]
011001 (25)	multu rs, rt	multiply unsigned	{[hi], [lo]} = [rs] × [rt]
011010 (26)	div rs, rt	divide	[lo] = [rs]/[rt], [hi] = [rs]%[rt]
011011 (27)	divu rs, rt	divide unsigned	[lo] = [rs]/[rt], [hi] = [rs]%[rt]

(continued)

Recall: Funct in MIPS R-Type Instructions (II)

Table B.2 R-type instructions, sorted by funct field—Cont'd

Funct	Name	Description	Operation
100000 (32)	add rd, rs, rt	add	$[rd] = [rs] + [rt]$
100001 (33)	addu rd, rs, rt	add unsigned	$[rd] = [rs] + [rt]$
100010 (34)	sub rd, rs, rt	subtract	$[rd] = [rs] - [rt]$
100011 (35)	subu rd, rs, rt	subtract unsigned	$[rd] = [rs] - [rt]$
100100 (36)	and rd, rs, rt	and	$[rd] = [rs] \& [rt]$
100101 (37)	or rd, rs, rt	or	$[rd] = [rs] \mid [rt]$
100110 (38)	xor rd, rs, rt	xor	$[rd] = [rs] \wedge [rt]$
100111 (39)	nor rd, rs, rt	nor	$[rd] = \sim([rs] \mid [rt])$
101010 (42)	slt rd, rs, rt	set less than	$[rs] < [rt] ? [rd] = 1 : [rd] = 0$
101011 (43)	sltu rd, rs, rt	set less than unsigned	$[rs] < [rt] ? [rd] = 1 : [rd] = 0$

- Find the complete list of instructions in the appendix

Data Types

- An ISA supports one or several data types
- LC-3 only supports 2's complement integers
 - Negative of a 2's complement binary value $X = \text{NOT}(X) + 1$
- MIPS supports
 - 2's complement integers
 - Unsigned integers
 - Floating point
- Again, **tradeoffs** are involved
 - What data types should be supported and what should not be?

Data Type Tradeoffs

- What is the benefit of **having more or high-level data types** in the ISA?
- What is the disadvantage?
- Think compiler/programmer vs. microarchitect
- Concept of **semantic gap**
 - Data types coupled tightly to the semantic level, or complexity of instructions
- Example: Early RISC architectures vs. Intel 432
 - Early RISC machines: Only integer data type
 - Intel 432: Object data type, capability based machine
 - VAX: Complex types, e.g., doubly-linked list

Addressing Modes

- An addressing mode is a mechanism for specifying where an operand is located
- There five addressing modes in LC-3
 - Immediate or literal (constant)
 - The operand is in some bits of the instruction
 - Register
 - The operand is in one of R0 to R7 registers
 - Three of them are memory addressing modes
 - PC-relative
 - Indirect
 - Base+offset
- In addition, MIPS has pseudo-direct addressing (for j and jal), but does not have indirect addressing

Operate Instructions

Operate Instructions

- In **LC-3**, there are three operate instructions
 - NOT is a **unary operation** (one source operand)
 - It executes bitwise NOT
 - ADD and AND are **binary operations** (two source operands)
 - ADD is 2's complement addition
 - AND is bitwise SR1 & SR2
- In **MIPS**, there are many more
 - Most of **R-type** instructions (they are **binary operations**)
 - E.g., add, and, nor, xor...
 - **I-type** versions (i.e., with one immediate operand) of the R-type operate instructions
 - **F-type** operations, i.e., floating-point operations

NOT in LC-3

■ NOT assembly and machine code

LC-3 assembly


NOT R3, R5

Field Values

OP	DR	SR	
9	3	5	1 1 1 1 1 1

Machine Code

OP	DR	SR	
1 0 0 1	0 1 1	0 0 1	1 1 1 1 1 1
15	12	11	9
		8	6
			5
			0




There is **no NOT in MIPS**. How is it implemented?

Operate Instructions

- We are already familiar with LC-3's ADD and AND with register mode (R-type in MIPS)
- Now let us see the versions with one literal (i.e., immediate) operand
- Subtraction is another necessary operation
 - How is it implemented in LC-3 and MIPS?

Operate Instr. with one Literal in LC-3

■ ADD and AND



- OP = operation
 - E.g., **ADD** = **0001** (same OP as the register-mode ADD)
 - $DR \leftarrow SR1 + \text{sign-extend}(\text{imm5})$
 - E.g., **AND** = **0101** (same OP as the register-mode AND)
 - $DR \leftarrow SR1 \text{ AND } \text{sign-extend}(\text{imm5})$
- SR1 = source register
- DR = destination register
- **imm5** = Literal or immediate (sign-extend to 16 bits)

ADD with one Literal in LC-3

■ ADD assembly and machine code

LC-3 assembly

```
ADD R1, R4, #-2
```


Field Values

OP	DR	SR	imm5
1	1	4	1
			-2

Machine Code


OP	DR	SR	imm5
0001	001	100	1
			11110

15 12 11 9 8 6 5 4 0



Instructions with one Literal in MIPS

- I-type
 - 2 register operands and immediate
- Some operate and data movement instructions



- opcode = operation
- rs = source register
- rt =
 - destination register in some instructions (e.g., `addi`, `lw`)
 - source register in others (e.g., `sw`)
- imm = Literal or immediate

Add with one Literal in MIPS

- Add immediate

MIPS assembly

```
addi $s0, $s1, 5
```

Field Values

op	rs	rt	imm
0	17	16	5

$rt \leftarrow rs + \text{sign-extend}(\text{imm})$

Machine Code

op	rs	rt	imm
001000	10001	10010	0000 0000 0000 0101

0x22300005

Subtract in LC-3

■ MIPS assembly

High-level code

```
a = b + c - d;
```

MIPS assembly

```
add    $t0, $s0, $s1
sub     $s3, $t0, $s2
```

■ LC-3 assembly

High-level code

```
a = b + c - d;
```

LC-3 assembly

```
ADD    R2, R0, R1
NOT     R4, R3
ADD     R5, R4, #1
ADD     R6, R2, R5
```

2's
complement
of R3

■ Tradeoff in LC-3

- More instructions
- But, simpler control logic

Subtract Immediate


- MIPS assembly

High-level code

```
a = b - 3;
```

MIPS assembly

```
subi $s1, $s0, 3
```



Is **subi** necessary in MIPS?

MIPS assembly

```
addi $s1, $s0, -3
```

- LC-3

High-level code

```
a = b - 3;
```

LC-3 assembly

```
ADD R1, R0, #-3
```


Data Movement Instructions and Addressing Modes

Data Movement Instructions

- In **LC-3**, there are seven data movement instructions
 - LD, LDR, LDI, LEA, ST, STR, STI
- Format of load and store instructions
 - Opcode (bits [15:12])
 - DR or SR (bits [11:9])
 - Address generation bits (bits [8:0])
 - Four ways to interpret bits, called **addressing modes**
 - PC-Relative Mode
 - Indirect Mode
 - Base+offset Mode
 - Immediate Mode
- In **MIPS**, there are only **Base+offset** and **immediate modes** for load and store instructions

PC-Relative Addressing Mode

■ LD (Load) and ST (Store)



- OP = opcode
 - E.g., LD = 0010
 - E.g., ST = 0011
- DR = destination register in LD
- SR = source register in ST
- LD: $DR \leftarrow \text{Memory}[PC^{\dagger} + \text{sign-extend}(\text{PCOffset9})]$
- ST: $\text{Memory}[PC^{\dagger} + \text{sign-extend}(\text{PCOffset9})] \leftarrow SR$

[†] This is the incremented PC

LD in LC-3

LD assembly and machine code

LC-3 assembly

```
LD R2, 0x1AF
```


Field Values

OP	DR	PCOffset9
2	2	0x1AF

Machine Code

OP	DR	PCOffset9
0010	010	110101111
15	12	11
9	8	0


The memory address is **only +255 to -256** locations away of the **LD or ST instruction**



Limitation: The **PC-relative addressing mode** cannot address far away from the instruction

Indirect Addressing Mode

■ LDI (Load Indirect) and STI (Store Indirect)



- OP = opcode
 - E.g., LDI = 1010
 - E.g., STI = 1011
- DR = destination register in LDI
- SR = source register in STI
- LDI: $DR \leftarrow \text{Memory}[\text{Memory}[PC^{\dagger} + \text{sign-extend}(\text{PCOffset9})]]$
- STI: $\text{Memory}[\text{Memory}[PC^{\dagger} + \text{sign-extend}(\text{PCOffset9})]] \leftarrow SR$

[†] This is the incremented PC

LDI in LC-3

LDI assembly and machine code

LC-3 assembly


```
LDI R3, 0x1CC
```

Field Values

OP	DR	PCOffset9
A	3	0x1CC

Machine Code


OP	DR	PCOffset9
1 0 1 0	0 1 1	1 1 1 0 0 1 1 0 0
15	12	11 9 8 0



Now the address of the operand can be **anywhere in the memory**

Base+Offset Addressing Mode

■ LDR (Load Register) and STR (Store Register)



- OP = opcode
 - E.g., LDR = 0110
 - E.g., STR = 0111
- DR = destination register in LDR
- SR = source register in STR
- LDR: $DR \leftarrow \text{Memory}[\text{BaseR} + \text{sign-extend}(\text{offset6})]$
- STR: $\text{Memory}[\text{BaseR} + \text{sign-extend}(\text{offset6})] \leftarrow SR$

LDR in LC-3

■ LDR assembly and machine code

LC-3 assembly


```
LDR R1, R2, 0x1D
```

Field Values

OP	DR	BaseR	offset6
6	1	2	0x1D

Machine Code

OP	DR	BaseR	offset6
0110	001	010	011101
15	12	11	9
8	6	5	0



Again, the address of the operand can be **anywhere in the memory**

Base+Offset Addressing Mode in MIPS

- In MIPS, **lw** and **sw** use base+offset mode (or **base addressing mode**)

High-level code

```
A[2] = a;
```

MIPS assembly

```
sw    $s3, 8($s0)
```

Memory[\$s0 + 8] ← \$s3

Field Values

op	rs	rt	imm
43	16	19	8

- **imm** is the 16-bit offset, which is **sign-extended to 32 bits**

An Example Program in MIPS and LC-3

High-level code

```
a      = A[0];  
c      = a + b - 5;  
B[0]   = c;
```

MIPS registers

```
A = $s0  
b = $s2  
B = $s1
```

LC-3 registers

```
A = R0  
b = R2  
B = R1
```

MIPS assembly


```
lw    $t0, 0($s0)  
add   $t1, $t0, $s2  
addi  $t2, $t1, -5  
sw    $t2, 0($s1)
```

LC-3 assembly

```
LDR   R5, R0, #0  
ADD   R6, R5, R2  
ADD   R7, R6, #-5  
STR   R7, R1, #0
```

Immediate Addressing Mode

■ LEA (Load Effective Address)



- OP = 1110
- DR = destination register
- LEA: $DR \leftarrow PC^{\dagger} + \text{sign-extend}(\text{PCOffset9})$

What is the **difference from PC-Relative** addressing mode?

Answer: Instructions with **PC-Relative** mode **access memory**, but **LEA does not** → Hence the name *Load Effective Address*

[†] This is the incremented PC

LEA in LC-3

LEA assembly and machine code

LC-3 assembly


```
LEA R5, #-3
```

Field Values

OP	DR	PCOffset9
E	5	0x1FD

Machine Code

OP	DR	PCOffset9
1 1 1 0	1 0 1	1 1 1 1 1 1 1 0 1
15	12 11 9	8 0



Immediate Addressing Mode in MIPS

- In MIPS, **lui** (load upper immediate) loads a 16-bit immediate into the upper half of a register and sets the lower half to 0
- It is used to assign 32-bit constants to a register

High-level code

```
a = 0x6d5e4f3c;
```

MIPS assembly

```
# $s0 = a  
lui    $s0, 0x6d5e  
ori    $s0, 0x4f3c
```

Addressing Example in LC-3

- What is the final value of R3?

P&P, Chapter 5.3.5

Address	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
x30F6	1	1	1	0	0	0	1	1	1	1	1	1	1	1	0	1	R1 ← PC-3
x30F7	0	0	0	1	0	1	0	0	0	1	1	0	1	1	1	0	R2 ← R1+14
x30F8	0	0	1	1	0	1	0	1	1	1	1	1	1	0	1	1	M[x30F4] ← R2
x30F9	0	1	0	1	0	1	0	0	1	0	1	0	0	0	0	0	R2 ← 0
x30FA	0	0	0	1	0	1	0	0	1	0	1	0	0	1	0	1	R2 ← R2+5
x30FB	0	1	1	1	0	1	0	0	0	1	0	0	1	1	1	0	M[R1+14] ← R2
x30FC	1	0	1	0	0	1	1	1	1	1	1	0	1	1	1	1	R3 ← M[M[x30F4]]

Addressing Example in LC-3

- What is the final value of R3?

P&P, Chapter 5.3.5

Address	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
x30F6	LEA	1	1	0	0	0	1	3	1	1	1	1	1	1	0	1	$R1 = PC - 3 = 0x30F7 - 3 = 0x30F4$
x30F7	ADD	0	0	1	0	1	0	0	0	1	1	0	1	0	1	0	$R2 = R1 + 14 = 0x30F4 + 14 = 0x3102$
x30F8	ST	0	1	1	0	1	0	5	1	1	1	1	1	0	1	0	$M[PC - 5] = M[0x030F4] = 0x3102$
x30F9	AND	1	0	1	0	1	0	0	1	0	1	0	0	0	0	0	$R2 = 0$
x30FA	ADD	0	0	1	0	1	0	0	1	0	1	5	0	1	0	1	$R2 = R2 + 5 = 5$
x30FB	STR	1	1	1	0	1	0	0	0	1	0	0	1	1	1	0	$M[R1 + 14] = M[0x30F4 + 14] = M[0x3102] = 5$
x30FC	LDI	0	1	0	0	1	1	9	1	1	1	1	0	1	1	0	$R3 = M[M[PC - 9]] = M[M[0x30FD - 9]] = M[M[0x30F4]] = M[0x3102] = 5$

- The final value of **R3** is 5

Control Flow Instructions

Control Flow Instructions


- Allow a program to execute **out of sequence**
- Conditional branches and jumps
 - **Conditional branches** are used to **make decisions**
 - E.g., if-else statement
 - In LC-3, three **condition codes** are used
 - **Jumps** are used to implement
 - **Loops**
 - **Function calls**
 - **JMP** in LC-3 and **j** in MIPS

Condition Codes in LC-3

- Each time one GPR (R0-R7) is written, **three single-bit registers** are updated
- Each of these **condition codes** are either set (set to 1) or cleared (set to 0)
 - If the written value is **negative**
 - **N** is set, Z and P are cleared
 - If the written value is **zero**
 - **Z** is set, N and P are cleared
 - If the written value is **positive**
 - **P** is set, N and Z are cleared
- x86 and SPARC are examples of ISAs that use condition codes

Conditional Branches in LC-3

■ BRz (Branch if Zero)



- n, z, p = **which condition code is tested** (N, Z, and/or P)
 - n, z, p : instruction bits to identify the condition codes to be tested
 - N, Z, P: values of the corresponding condition codes
- PCoffset9 = immediate or constant value
- if $((n \text{ AND } N) \text{ OR } (p \text{ AND } P) \text{ OR } (z \text{ AND } Z))$
 - then $PC \leftarrow PC^{\dagger} + \text{sign-extend}(\text{PCoffset9})$
- Variations: BRn, BRz, BRp, BRzp, BRnp, BRnz, BRnzp

[†] This is the incremented PC


Conditional Branches in LC-3

■ BRz

BRz 0x0D9

What if $n = z = p = 1$?*
(i.e., BRnzp)

And what if $n = z = p = 0$?




*n, z, p are the instruction bits to identify the condition codes to be tested

Conditional Branches in MIPS

■ beq (Branch if Equal)

```
beq $s0, $s1, offset
```



- 4 = opcode
- rs, rt = source registers
- offset = immediate or constant value
- if $rs == rt$
 - then $PC \leftarrow PC^+ + \text{sign-extend}(\text{offset}) * 4$
- Variations: beq, bne, blez, bgtz

Branch If Equal in MIPS and LC-3

MIPS assembly

```
beq  $s0, $s1, offset
```

LC-3 assembly

```
NOT  R2, R1
ADD  R3, R2, #1
ADD  R4, R3, R0
BRz  offset
```

**Subtract
(R0 - R1)**

- This is an example of **tradeoff** in the instruction set
 - The same functionality requires **more instructions in LC-3**
 - But, the **control logic** requires **more complexity in MIPS**

Lecture Summary

- Instruction Set Architectures: LC-3 and MIPS
 - Operate instructions
 - Data movement instructions
 - Control instructions
- Instruction formats
- Addressing modes

Digital Design & Computer Arch.

Lecture 10a: Instruction Set Architecture

Prof. Onur Mutlu

ETH Zürich

Spring 2020

20 March 2020