

# P&S Modern SSDs

Fine-Grained Mapping &  
Multi-Plane Operation-Aware Block Management

Dr. Mohammad Sadrosadati

Prof. Onur Mutlu

ETH Zürich

Fall 2022

14 December 2022

# Recap: What We Have Discussed So Far

---

- **SSD Organization**
- **NAND Flash Organization and Operations**
- **Advanced NAND Flash Commands**
- **FTL: Address Translation & Garbage Collection**

# Today's Agenda

---

- Fine-Grained Mapping
- Multi-plane Operation-Aware Blk. Mgmt.

# I/O Mismatch b/w OS and NAND Flash

---

- The **page size** (i.e., minimum I/O unit) of NAND flash memory **has continuously increased**
  - From 256 bytes to **16 KiB**
  - **Low area overhead** and **high bandwidth** (size / latency)
- The **logical block** (or sector) size of file systems **has also increased**
  - From 512 bytes to **4 KiB**
  - To more efficiently work with NAND flash-based SSDs
  - Increasing the block size is **not straightforward**
    - I/O handling is closely related to OS memory management
    - Memory page size = 4 KiB
    - Unnecessary fetch or eviction at the page cache

# Small Write Requests

- Inefficiencies due to the erase-before-write property


Req (LBA: 0x04, Size: 1, DIR: w, Data: A)



0b 0000 0000 0000 0100

16-KiB Page Number 4-KiB Offset

LPA	PPA
0x00	—
0x01	—
0x02	—
0x03	—
0x04	—
0x05	—
...	...



# Small Write Requests

- Inefficiencies due to the erase-before-write property


Req (LBA: 0x04, Size: 1, DIR: w, Data: A)



0b 0000 0000 0000 0100

16-KiB Page Number 4-KiB Offset

LPA	PPA
0x00	—
0x01	—
0x02	—
0x03	—
0x04	—
0x05	—
...	...



# Small Write Requests

- Inefficiencies due to the erase-before-write property


Req (LBA: 0x04, Size: 1, DIR: w, Data: A)



0b 0000 0000 0000 0100

16-KiB Page Number 4-KiB Offset

LPA	PPA
0x00	—
0x01	0x00
0x02	—
0x03	—
0x04	—
0x05	—
...	...



# Small Write Requests

- Inefficiencies due to the erase-before-write property

Req (LBA: **0x01**, Size: 2, DIR: w, Data: **B, C**)

0b 0000 0000 0000 0001  
16-KiB Page Number 4-KiB Offset

LPA	PPA
0x00	—
0x01	0x00
0x02	—
0x03	—
0x04	—
0x05	—
...	...

	PPA
Block 0	0x00
	0x01
	0x02
	0x03
Block 1	0x04
	0x05
	0x06
	...



# Small Write Requests


- Inefficiencies due to the erase-before-write property

Req (LBA: 0x01, Size: 2, DIR: w, Data: B, C)

0b 0000 0000 0000 0001

16-KiB Page Number 4-KiB Offset

LPA	PPA
0x00	—
0x01	0x00
0x02	—
0x03	—
0x04	—
0x05	—
...	...




# Small Write Requests

- Inefficiencies due to the erase-before-write property

Req (LBA: 0x01, Size: 2, DIR: w, Data: B, C)

0b 0000 0000 0000 0001  
16-KiB Page Number 4-KiB Offset

LPA	PPA
0x00	0x01
0x01	0x00
0x02	—
0x03	—
0x04	—
0x05	—
...	...



# Small Write Requests


- Inefficiencies due to the erase-before-write property

Req (LBA: 0x01, Size: 2, DIR: w, Data: B, C)

0b 0000 0000 0000 0001

16-KiB Page Number 4-KiB Offset

LPA	PPA
0x00	0x01
0x01	0x00
0x02	—
0x03	—
0x04	—
0x05	—
...	...



## 1. Why at the middle of the page?

- To keep the 4-KiB offset: mapping table stores only the index of the 16-KiB page!

## 2. Why not using the unused space in physical page 0x00?

- That space is already mapped to logical pages 0x05~0x07 (not written yet).

# Small Write Requests


- Inefficiencies due to the erase-before-write property

Req (LBA: 0x07, Size: 1, DIR: w, Data: D)

0b 0000 0000 0000 0111

16-KiB Page Number 4-KiB Offset

LPA	PPA
0x00	0x01
0x01	0x00
0x02	–
0x03	–
0x04	–
0x05	–
...	...



**Q: Can we use the unused space?**

**A: Not likely, because**

- Data randomization – Cells in the unused space have been already programmed.
- Program-order constraint – Re-programming physical page 0x00 can affect the reliability of the data stored in physical page 0x01.

# Small Write Requests

- Inefficiencies due to the erase-before-write property

Req (LBA: 0x07, Size: 1, DIR: W, Data: D)

0b 0000 0000 0000 0111

16-KiB Page Number 4-KiB Offset

LPA	PPA
0x00	0x01
0x01	0x00


Block 0

PPA

0x00

0x01

0x02



**Small writes cause waste of P/E cycles:**  
**More frequent garbage collections**  
**→ Performance and lifetime degradation**

...	...
-----	-----

...

--


# Small Write Requests

- Inefficiencies due to the erase-before-write property

Req (LBA: 0x07, Size: 1, DIR: w, Data: D)

0b 0000 0000 0000 0111  
16-KiB Page Number 4-KiB Offset

LPA	PPA
0x00	0x01
0x01	0x00
0x02	—
0x03	—
0x04	—
0x05	—
...	...




# Small Write Requests

- Inefficiencies due to the erase-before-write property

Req (LBA: **0x07**, Size: 1, DIR: **w**, Data: **D**)

0b 0000 0000 0000 0111  
16-KiB Page Number 4-KiB Offset

LPA	PPA
0x00	0x01
0x01	0x00
0x02	—
0x03	—
0x04	—
0x05	—
...	...




# Small Write Requests

- Inefficiencies due to the erase-before-write property

Req (LBA: **0x07**, Size: 1, DIR: **w**, Data: **D**)

0b 0000 0000 0000 0111  
16-KiB Page Number 4-KiB Offset

LPA	PPA
0x00	0x01
0x01	0x00
0x02	—
0x03	—
0x04	—
0x05	—
...	...






# Small Write Requests

- Inefficiencies due to the erase-before-write property

Req (LBA: 0x07, Size: 1, DIR: W, Data: D)

0b 0000 0000 0000 0111  
16-KiB Page Number 4-KiB Offset

LPA	PPA
0x00	0x01
0x01	0x02
0x02	-



**Small writes cause read-modify-writes:**  
**Waste of P/E cycles + additional read operations**  
**→ Performance and lifetime degradation**

# Fine-Grained Mapping + Page Buffer

- Write a page only when there are sufficient data blocks

**Req (LBA: 0x04, Size: 1, DIR: w, Data: A)**

Req (LBA: 0x01, Size: 2, DIR: w, Data: B, C)

Req (LBA: 0x07, Size: 1, DIR: w, Data: D)

Page Buffer

--	--	--	--

LPA	PPA
0x00	—
0x01	—
...	—
0x04	—
...	—
0x07	—
...	...

Block 0

Block 1

PPA

0x00	0x01	0x02	0x03
0x04	0x05	0x06	0x07
0x08	0x09	0x0A	0x0B
0x0C	0x0D	0x0E	0x0F
0x10	0x11	0x12	0x13
0x14	0x15	0x16	0x17
0x18	0x19	0x1A	0x0B
...			

# Fine-Grained Mapping + Page Buffer

- Write a page only when there are sufficient data blocks

**Req (LBA: 0x04, Size: 1, DIR: w, Data: A)**

Req (LBA: 0x01, Size: 2, DIR: w, Data: B, C)

Req (LBA: 0x07, Size: 1, DIR: w, Data: D)

Page Buffer

<b>A</b>			
----------	--	--	--

LPA	PPA
0x00	—
0x01	—
...	—
0x04	—
...	—
0x07	—
...	...

Block 0	0x00	0x01	0x02	0x03
	0x04	0x05	0x06	0x07
	0x08	0x09	0x0A	0x0B
	0x0C	0x0D	0x0E	0x0F
Block 1	0x10	0x11	0x12	0x13
	0x14	0x15	0x16	0x17
	0x18	0x19	0x1A	0x1B
	...			

PPA

# Fine-Grained Mapping + Page Buffer

- Write a page only when there are sufficient data blocks

**Req (LBA: 0x04, Size: 1, DIR: w, Data: A)**

Req (LBA: 0x01, Size: 2, DIR: w, Data: B, C)

Req (LBA: 0x07, Size: 1, DIR: w, Data: D)

Page Buffer

<b>A</b>			
----------	--	--	--

LPA	PPA
0x00	—
0x01	—
...	—
0x04	<b>0x00</b>
...	—
0x07	—
...	...

Block 0	0x00	0x01	0x02	0x03
	0x04	0x05	0x06	0x07
	0x08	0x09	0x0A	0x0B
	0x0C	0x0D	0x0E	0x0F
Block 1	0x10	0x11	0x12	0x13
	0x14	0x15	0x16	0x17
	0x18	0x19	0x1A	0x0B
...				

PPA

# Fine-Grained Mapping + Page Buffer

- Write a page only when there are sufficient data blocks

Req (LBA: 0x04, Size: 1, DIR: w, Data: A)

Req (LBA: 0x01, Size: 2, DIR: w, Data: B, C)

Req (LBA: 0x07, Size: 1, DIR: w, Data: D)

Page Buffer

A			
---	--	--	--

LPA	PPA
0x00	—
0x01	—
...	—
0x04	0x00
...	—
0x07	—
...	...

Block 0

Block 1

PPA

0x00	0x01	0x02	0x03
0x04	0x05	0x06	0x07
0x08	0x09	0x0A	0x0B
0x0C	0x0D	0x0E	0x0F
0x10	0x11	0x12	0x13
0x14	0x15	0x16	0x17
0x18	0x19	0x1A	0x0B
...			

# Fine-Grained Mapping + Page Buffer

- Write a page only when there are sufficient data blocks

Req (LBA: 0x04, Size: 1, DIR: w, Data: A)

Req (LBA: 0x01, Size: 2, DIR: w, Data: B, C)

Req (LBA: 0x07, Size: 1, DIR: w, Data: D)

Page Buffer

A	B	C	
---	---	---	--

LPA	PPA
0x00	—
0x01	—
...	—
0x04	0x00
...	—
0x07	—
...	...

Block 0

Block 1

PPA

0x00	0x01	0x02	0x03
0x04	0x05	0x06	0x07
0x08	0x09	0x0A	0x0B
0x0C	0x0D	0x0E	0x0F
0x10	0x11	0x12	0x13
0x14	0x15	0x16	0x17
0x18	0x19	0x1A	0x0B
...			

# Fine-Grained Mapping + Page Buffer

- Write a page only when there are sufficient data blocks

Req (LBA: 0x04, Size: 1, DIR: w, Data: A)

Req (LBA: 0x01, Size: 2, DIR: w, Data: B, C)

Req (LBA: 0x07, Size: 1, DIR: w, Data: D)

Page Buffer

A	B	C	
---	---	---	--

LPA	PPA
0x00	-
0x01	0x01
...	-
0x04	0x00
...	-
0x07	-
...	...

Block 0

Block 1

PPA

0x00	0x01	0x02	0x03
0x04	0x05	0x06	0x07
0x08	0x09	0x0A	0x0B
0x0C	0x0D	0x0E	0x0F
0x10	0x11	0x12	0x13
0x14	0x15	0x16	0x17
0x18	0x19	0x1A	0x0B
...			

# Fine-Grained Mapping + Page Buffer

- Write a page only when there are sufficient data blocks

Req (LBA: 0x04, Size: 1, DIR: w, Data: A)

Req (LBA: 0x01, Size: 2, DIR: w, Data: B, C)

Req (LBA: 0x07, Size: 1, DIR: w, Data: D)

Page Buffer

A	B	C	
---	---	---	--

LPA	PPA
0x00	—
0x01	0x01
...	—
0x04	0x00
...	—
0x07	—
...	...

Block 0	0x00	0x01	0x02	0x03
	0x04	0x05	0x06	0x07
	0x08	0x09	0x0A	0x0B
	0x0C	0x0D	0x0E	0x0F
Block 1	0x10	0x11	0x12	0x13
	0x14	0x15	0x16	0x17
	0x18	0x19	0x1A	0x0B
...				

PPA



# Fine-Grained Mapping + Page Buffer

- Write a page only when there are sufficient data blocks

Req (LBA: 0x04, Size: 1, DIR: w, Data: A)

Req (LBA: 0x01, Size: 2, DIR: w, Data: B, C)

Req (LBA: 0x07, Size: 1, DIR: w, Data: D)

Page Buffer

A	B	C	D
---	---	---	---

LPA	PPA
0x00	—
0x01	0x01
...	—
0x04	0x00
...	—
0x07	—
...	...

Block 0	0x00	0x01	0x02	0x03
	0x04	0x05	0x06	0x07
	0x08	0x09	0x0A	0x0B
	0x0C	0x0D	0x0E	0x0F
Block 1	0x10	0x11	0x12	0x13
	0x14	0x15	0x16	0x17
	0x18	0x19	0x1A	0x0B
PPA	...			

# Fine-Grained Mapping + Page Buffer

- Write a page only when there are sufficient data blocks

Req (LBA: 0x04, Size: 1, DIR: w, Data: A)

Req (LBA: 0x01, Size: 2, DIR: w, Data: B, C)

Req (LBA: 0x07, Size: 1, DIR: w, Data: D)

Page Buffer

A	B	C	D
---	---	---	---

LPA	PPA
0x00	—
0x01	0x01
...	—
0x04	0x00
...	—
0x07	0x03
...	...

Block 0	0x00	0x01	0x02	0x03
	0x04	0x05	0x06	0x07
	0x08	0x09	0x0A	0x0B
	0x0C	0x0D	0x0E	0x0F
Block 1	0x10	0x11	0x12	0x13
	0x14	0x15	0x16	0x17
	0x18	0x19	0x1A	0x0B
...				

PPA

# Fine-Grained Mapping + Page Buffer


- Write a page only when there are sufficient data blocks

Req (LBA: 0x04, Size: 1, DIR: w, Data: A)

Req (LBA: 0x01, Size: 2, DIR: w, Data: B, C)

Req (LBA: 0x07, Size: 1, DIR: w, Data: D)

LPA	PPA
0x00	—
0x01	0x01
...	—



**Fine-grained mapping significantly **reduces** the number of NAND flash operations:**  
**3 writes (+1 read) → 1 writes**

# Drawbacks of Fine-Grained Mapping

---

- Larger mapping table
  - ❑ 16-KiB mapping → 4 bytes per 16-KiB page = 0.025%
  - ❑ 4-KiB mapping → 4 bytes per 4-KiB page = 0.1%
  - ❑ For a 2-TB SSD, 2-GB DRAM is required.
    - Increases the SSD's price and power/energy consumption
- Data durability of written data
  - ❑ Page buffers are implemented by using volatile memory (e.g., SRAM or DRAM).

**Despite non-negligible drawbacks, fine-grained mapping is widely used in modern SSDs due to its high benefits**


# Today's Agenda

---

- Fine-Grained Mapping
- Multi-plane Operation-Aware Blk. Mgmt.

# Recap: Multi-Plane Operations

- Concurrent operations on different planes
  - Recall: Planes share WLs and row/column decoders





- Opportunity: Planes can **concurrently** operate
- Constraints: Only for **the same operations on the same page offset**

# Multi-Plane-Aware Data Placement


- To perform as many multi-plane operations as possible
  - Flush  $N_{\text{plane}}$  pages at once after buffering them

Page buffer *Wait for more writes* *Full!*



# Multi-Plane-Aware Data Placement


- To perform as many multi-plane operations as possible
  - Flush  $N_{\text{plane}}$  pages at once after buffering them






# Multi-Plane-Aware Data Placement

- To perform as many multi-plane operations as possible
  - Flush  $N_{\text{plane}}$  pages at once after buffering them
  - Need to keep the write points of all planes to be the same
    - Superblock-based block management




# Multi-Plane-Aware Block Management

- Recap: For reducing the performance overhead of garbage collection, the FTL can select the block with the largest number of invalid pages (called a greedy policy).




# Multi-Plane-Aware Block Management

- Recap: For reducing the performance overhead of garbage collection, the FTL can select the block with the largest number of invalid pages (called a greedy policy).




# Multi-Plane-Aware Block Management

- Recap: For reducing the performance overhead of garbage collection, the FTL can select the block with the largest number of invalid pages (called a greedy policy).




# Multi-Plane-Aware Block Management

- Recap: For reducing the performance overhead of garbage collection, the FTL can select the block with the largest number of invalid pages (called a greedy policy).




# Multi-Plane-Aware Block Management

- Recap: Planes in the same die can operate in parallel, but only when the page offsets are the same.




# Multi-Plane-Aware Block Management

- Recap: Planes in the same die can operate in parallel, but only when the page offsets are the same.



# Multi-Plane-Aware Block Management


- Recap: Planes in the same die can operate in parallel, but only when the page offsets are the same.






# Multi-Plane-Aware Block Management

- Recap: Planes in the same die can operate in parallel, but only when the page offsets are the same.




# Multi-Plane-Aware Block Management

- Recap: Planes in the same die can operate in parallel, but only when the page offsets are the same.




# Multi-Plane-Aware Block Management

- **Superblock-based management:** groups each block with the same index (i.e., vertical position) in different planes




# Multi-Plane-Aware Block Management

- **Superblock-based management:** groups each block with the same index (i.e., vertical position) in different planes



# Multi-Plane-Aware Block Management

- **Superblock-based management:** groups each block with the same index (i.e., vertical position) in different planes




# Multi-Plane-Aware Block Management

- **Superblock-based management:** groups each block with the same index (i.e., vertical position) in different planes


**Pros:**  
Keep performing  
multi-plane writes

**Cons:**  
More read/write operations  
→ 5 SRs + 1 MR + 3 MWs  
vs. 4 SRs + 1 MW + 2 SWs



# Multi-Plane-Aware Block Management

- Offset management: Die level or SSD level?



**Multi-plane operations can significantly improve SSD performance, but requires proper management in FTL**

# P&S Modern SSDs

Fine-Grained Mapping &  
Multi-Plane Operation-Aware Block Management

Dr. Mohammad Sadrosadati

Prof. Onur Mutlu

ETH Zürich

Fall 2022

14 December 2022