

DISTRIBUTED DIFFERENTIAL COUPLING COMBINED POWER SYSTEM

BACKGROUND OF THE INVENTION

In recent years, energy and noise pollution problems have become more and more serious. A good solution to these problems would be to use electrical power driven vehicles, but development of electrical power driven vehicles has up to now been limited by the capacity of the batteries to achieve a larger moving range. Increasing the battery volume or quantity to increase the range will correspondingly increase the self-weight of the carrier, resulting in higher electrical energy consumption and does not meet economic requirements. Therefore, in the absence of a major breakthrough in solving the battery technical problems, a more practical driving method is to use combined driving structure designs. Current combined driving structure designs include:

(A) Series Combined Power Design: This design is the most typical structure for an electrically driven vehicle. In this design a generator is driven by the engine to generate electricity and charge the battery, after which the battery provides electricity to the driven motor to drive the vehicle. As the energy is converted several times, the overall efficiency of this design is low. An example of this design is the GM HX3 vehicle of General Motors.

(B) Synchronized Power on Common Shaft Design: This design involves directly series combining the engine power output shaft and the rotating shaft of the driven motor, to thereby generate driving and speed controlling functions. An example of this design is West Germany's Volkswagen CHICO sedan.

For the case of the conventional engine and motor described in (B), only one of the engine and motor can be selected for output transmission, and the combination of their power output is not available.

In contrast, the disclosed distributed differential coupling combined power system of the invention permits the output power from the output shaft of an engine (or other rotational power source) to not only drive a front section load, but also to be combined with an electromagnetic coupling device to drive a rear section load. The electromagnetic coupling device is constituted by an AC or DC, brushed or brushless electric machine, and is a two-end structure. It includes a rotational field generating structure and a rotor, and the rotor shaft (or the field rotating shaft) is used as the output shaft to form an electromagnetic coupling device, while the other end is coupled with the engine output shaft through the transmission gear system. This design is capable of adding the power and speed of the engine output to the output generated by the electromagnetic coupling device itself to drive the rear load without being affected by the speed relationship between the two. In general, it has a smaller system volume and saves the cost and space in comparison with other combined power systems.

SUMMARY OF THE INVENTION

The distributed differential coupling combined power distribution system of the invention may be used in driving vehicles, ships, flying machines or other mechanical, industrial, or processing equipment which require a rotational power source. The power system involves the rotational output shaft of an internal combustion engine (or other rotational power sources), and is not only used to drive a

front section load directly or through transmission devices such as transmission gears, belts, chains, or the couplers, but is also coupled with the input shaft of an electromagnetic coupling device to drive the rear section load. The electromagnetic coupling is a two-end structure, and is respectively combined with a stator and rotor structure to be controlled by an operating device for generating motor driving functions when an input current is applied to the electromagnetic coupling device or for operating variable speed coupling functions through the output current when employed as a generator, or for use in starting the engine and as a power regeneration brake, particularly when the engine is the main transmission power source, to charge the battery through the difference between the speed of the rotational field generated by the stator and the speed of the rotor, the speed difference with the rear load section being thereby adjusted by controlling the charging current. The engine can be at a constant speed or at a speed which is partially adjustable to maintain a working speed having a higher operating efficiency and lower pollution, with a portion of the differential speed output power generated through the electromagnetic coupling device being used for driving the load while the remaining part of the power is converted through the generator function of the electromagnetic coupling device to charge the battery. The electromagnetic coupling thereby promotes engine efficiency during variable speed driving at low driving speeds while acquiring charging power for the battery and reducing pollution, and in addition to providing a variable speed coupling, the electromagnetic coupling can also be used as a driving motor to generate a rotational output for driving the load independently of or together with the engine.

BRIEF DESCRIPTION OF THE DRAWINGS

FIG. 1 is a schematic diagram of the system of a first preferred embodiment.

FIG. 2 is a schematic diagram of a first variation of the system of FIG. 1.

FIG. 3 is a schematic diagram of a second variation of the system of FIG. 1.

FIG. 4 is a schematic diagram of a third variation of the system of FIG. 1.

FIG. 5 is a schematic diagram of a fourth variation of the system of FIG. 1.

FIG. 6 is a schematic diagram of a fifth variation of the system of FIG. 1.

FIG. 7 is a schematic diagram of a sixth variation of the system of FIG. 1.

FIG. 8 is a schematic diagram of a seventh variation of the system of FIG. 1.

DETAILED DESCRIPTION OF THE PREFERRED EMBODIMENTS

FIG. 1 shows a preferred embodiment of a distributed differential coupling combined power system, including the following principal elements:

A drive side rotational power source, having an output which is first supplied to control the front section load and then transmitted to the input end of a two-end shaft type electromagnetic coupling device to drive a rear section load;

An electromagnetic coupling device connected by a direct transmission to another load, through a transmission component to another load, or through a differential gear system

to a differentially acting load such as the side rear wheels of a vehicle.

More specifically, the embodiment illustrated in FIG. 1 includes the following elements:

A drive side rotational power unit **P101** in the form of an internal combustion engine or other power source, wherein the rotational output shaft **S102** coupled to a middle transmission device and a control interface **M102** through a clutch **CL102**. Engine **P101** further includes a speed sensor **SD101** for transmitting an engine rotation signal to a central controller **CCU101**, with the controllable fuel valve **CG101** being controlled by the central controller **CCU101** to change the engine speed or to keep the engine maintained at a constant speed;

A middle transmission device and a control interface **M102** made up of an automatic or manual speed change control system similar to one in a conventional front wheel drive system but which can be used to drive the front section load only or to drive front and rear loads. A clutch **CL103** is installed between the middle input shaft **S101** and the front section load to provide the transmission coupling or to cut off the transmission relationship between the middle transmission device and the front wheels, although the clutch **CL103** can also be replaced by a neutral shift or co-installed with the neutral shift when the shift interface is in a neutral shift status. The middle shaft **S101** is coupled at the output end of the clutch **CL102** and is either directly rearwardly extended or connected through a transmission device to cause the rotational speed difference between the middle shaft **S101** and the output presented to have a constant speed ratio or a non-constant speed ratio, in a manner similar to the rear extended rear wheel transmission shaft in a four wheel drive vehicle. A brake **B101** controlled by the central controller **CCU101** is further installed between the middle shaft **S101** and the fixed casing;

A direct driven front section load **W101** made up of one or more than one driven wheels with driven resistance of a load;

An electromagnetic coupling device **M101** in the form of a two-end shaft structure which is made up of a rotational field generating structure and a rotor, and in which the rotational field and the rotor are respectively coupled with the transmission middle shaft **S101** and the input shaft of a rear differential gear box **GB101** through a clutch **CL104**, to thereby drive the differential rear section load **W102** at both sides. The coupling device may be an AC or DC, brushed or brushless electrical machine, and in particular a series excited or auxiliary compound excited electrical machine having the electrical characteristic that its rotational speed increases with a decreasing load, or an AC or DC brush or brushless machine able to perform current control (including constant current control) through the operating control of a drive circuit device **D101** to help provide additional torque on the driven load;

An optional clutch **CL101** controlled by the central controller **CCU101** and installed between the rotational field generating structure and the rotor as required to directly provide a synchronized mechanical interlock between the field and rotor.

A drive circuit device **D101** which is installed between the electromagnetic coupling device **M101** and the battery **BT101** for receiving operating commands from the central controller **CCU101** to control the electromagnetic coupling device functioned so as to function as a generator to charge the battery or supply power to the other load or to provide a current controllable generator output to control the cou-

pling torque, thereby changing the rotation speed in dependence on load conditions:

A central controller CCU101 which follows commands from the operator and monitors the operating status of the drive side rotational power unit P101 to generate corresponding control commands for the drive circuit device D101:

An optional brake B102 can be installed as needed between the casing of the electromagnetic coupling device M101 and the side of a clutch CL104 which is located between the electromagnetic coupling device double acting structure and the coupled rear differential gear box, to thereby drive the front section load, start the engine, or provide power generation at stand-still, at which time the electromagnetic coupling device is driven by the engine to function as a generator to charge the battery or supply power to the other loads. For the case of AC power generation output functions, the electromagnetic coupling device M101 is employed as an electrical machine with AC power generating functions and made up of a permanent magnet or winding excited, variable frequency field type of electrical device, or a brushed alternator type of electrical device, armature winding being commonly installed with the conducting rings for AC output and with the commutators for DC input/output, as a result of which the AC output can be a variable frequency output or a constant frequency output depending on the engine constant speed control;

Finally, the aforesaid direct driven load and the distributed differential load may be made up of one or more than one rotational power sources, or one or more than one direct driven load, or one or more than one double acting electromagnetic coupling device and its driven load groups in sequential series combinations, to form an extended compound series combined structure.

The functions of the preferred embodiment shown in FIG. 1 are illustrated in Table 1 as follows:

F1-A F1-B F1-C F1-D are the various system operations when the engine drives the load at low speed output;

F2 and **F3** are system operations when the electromagnetic coupling device is powered by a battery to drive the load as a motor;

F4-A and **F4-B** are system operations when the electromagnetic coupling device is powered by the battery to be operated as a motor drives the load with the engine together so as to have a large power output due to the addition of output power;

F5, F6 and **F7** are system operations when the electromagnetic coupling device is operated as a generator driven by the feedback mechanical energy of the load to charge the battery or to function as a brake by utilizing the friction damping of the engine itself;

F8 is the system operation when the electromagnetic coupling device is driven by the engine to be operated as a generator to charge the battery. This function can further include a charging timing control to stop automatically at a preset time and AC generating functions as decided above.

F9 is a function in which the electromagnetic coupling device is operated as a motor and is powered by the battery to start the engine;

F10 is a function in which all of the system clutches and brakes are in an "OFF" state to provide low loss sliding operation.

The above system operating functions listed in Table 1 are described in more detail as follows:

F1-A. To achieve this function, the engine fuel valve is controlled to drive the engine from low speed to high speed, as follows:

The internal combustion engine services as the drive side rotational power source and is controlled by the engine fuel valve to drive the rear section load, at which time clutches CL101, CL102, and CL104 are in an ON state while the CL103 is in an OFF state and the brakes B101 and B102 are in an OFF state;

The internal combustion engine serves as the drive side rotational power source and is controlled by the engine fuel valve to drive the front and rear section loads, at which time clutches CL101, CL102, CL103 and CL104 are all in an ON state and the brakes B101 and B102 are in an OFF state;

The internal combustion engine serves as the drive side rotational power source and is controlled by the engine fuel valve to drive the front section load, at which time clutches CL102 and CL103 are in an ON state while the clutches CL101 and CL104 are in an OFF state, and the brakes B101 and B102 are in an OFF state, and the electromagnetic coupling is in a no-load state;

F1-B: To achieve this function, the engine fuel valve and the electromagnetic coupling device M101 is controlled simultaneously to drive the engine from low speed to high speed and to charge the battery simultaneously, as follows:

The internal engine serves as the drive side rotational power source and is controlled by the engine fuel valve to change the engine and operate the electromagnetic coupling device as a generator for charging the battery and driving the rear section load, at which time the clutches CL101 and CL103 are in an OFF state while the clutches CL102 and CL104 are in an ON state and the brakes B101 and B102 are in an OFF state;

The internal combustion engine serves as the drive side rotational power source and is controlled by the engine fuel valve to change the engine speed and operate the electromagnetic coupling device as a generator to charge the battery and to drive the front and rear section loads together with the engine, at which time the clutches CL102, CL103 and CL104 are in an ON state while the CL101 is in an OFF state and the brakes B101 and B102 are in an OFF state;

The internal combustion engine serves as the drive side rotational power source and is controlled by the engine fuel valve to change the engine speed and drive the front section load as well as to operate the electromagnetic coupling device as a generator to simultaneously charge the battery, at which time the clutches CL101 and CL104 are in an OFF state while the CL102 and CL103 are in an ON state; the brakes B101 is OFF and the B102 is in an ON state.

F1-C: To achieve this function, the engine is speed controlled or operated at a constant speed, and the battery charging current from the M101 is controlled to change the output power to the load as follows:

The internal combustion engine serves as the drive side rotational power source, and the engine is controlled by the engine fuel valve and the speed feedback signal to operate at a constant speed as well as to operate the electromagnetic coupling device as a generator to charge the battery and adjust the coupling torque to drive the rear section load, at which time the clutches CL101 and CL103 are in an OFF state while the clutches CL102 and CL104 are in an ON state and the brakes B101 and B102 are in an OFF state;

The internal combustion engine serves as the drive side rotational power source, and the engine speed is con-

rolled by the engine fuel valve and the speed feedback signal to drive the front section load as well as to operate the electromagnetic coupling device as a generator to charge the battery, and to adjust the coupling torque to drive the rear section load, at which time the clutches CL101 is in an OFF state while the clutches CL102, CL103 and CL104 are in an ON state and the brakes B101 and B102 are in an OFF state;

F1-D: To achieve this function, electromagnetic coupling device M101 generates a short current to control the output shaft torque and thereby change the engine speed, as follows:

The internal combustion engine serves as the drive side rotational power source, and the engine fuel valve and the speed feedback signal are utilized to operate the engine at a variable speed or a constant speed and simultaneously to operate the electromagnetic coupling device M101 as a generator and control, based on the generated short circuit, current, the coupled torque, thereby to changing the power distribution between the front and rear section loads, at which time the clutches CL101 and CL103 are in an OFF state while the clutches CL102 and CL104 are in an ON state and the brakes B101 and B102 are in an OFF state;

The internal engine serves as the drive side rotational power source, and the engine fuel valve and speed feedback signal are utilized to control the engine speed and simultaneously to operate the electromagnetic coupling device M101 as a generator and control on a generated short cut circuit current to change the coupled torque, thereby changing the power distribution between the front and rear section loads, at which time the clutch CL101 is in an OFF state while the clutches CL102, CL103 and CL104 are in an ON state and the brakes B101 and B102 are in an OFF state;

F2: To achieve this function, electromagnetic coupling device M101 is powered by the battery to change the speed or the rotation direction of the rear section load, as follows:

The electromagnetic coupling device M101 is powered by the battery to drive the rear section load by operating the electromagnetic coupling device M101 as a motor, while the brake B101 is in an ON state and the brake B102 is in an OFF state, the clutches CL101, CL102 and the clutch CL103 for controlling the front section load are in an OFF state, and the CL104 is in an ON state.

F3: To achieve this function, electromagnetic coupling device M101 is powered by the battery to change the speed or the rotation direction of the front section load, as follows:

The electromagnetic coupling device M101 is powered by the battery to drive the front section load, at which time the electromagnetic coupling device is operated as a motor while the brake B102 is in an ON state, the brake B101 is in an OFF state, the clutches CL101, CL102 and CL104 are in an OFF state, and the clutch CL103 is in an ON state.

F4-A: To achieve this function, the engine is operated at a preset speed while the electromagnetic coupling device M101 is operated as a motor to provide added power output to drive the rear section load as follows:

The internal combustion engine serves as the drive side rotational power source, and is operated at a variable or constant speed while the electromagnetic coupling device M101 is powered by the battery to provide an

added power output for driving the rear section load simultaneously. At this time, the clutches CL101 and CL103 are in an OFF state while the CL102 and CL104 are in an ON state and the brakes B101 and B102 are in an OFF state:

F4-B: To achieve this function, the engine is operated at a preset speed while the electromagnetic coupling device M101 is operated as a motor to provide added power output to drive the front and rear section loads as follows:

The internal engine serves as the drive side rotational power source, and the engine is operated at a variable or constant speed while the electromagnetic coupling device M101 is powered by the battery to provide added power output to drive the front and rear section loads simultaneously. At this time, the clutch CL101 is in an OFF state while the clutches CL102, CL103 and CL104 are in an ON state and the brakes B101 and B102 are in an OFF state:

F5: To achieve this function the electromagnetic coupling device M101 is operated as a generator to charge the battery using the recovered rear section kinetic energy as follows:

The engine speed is reduced or the fuel valve is closed and the electromagnetic coupling device M101 is operated as a generator to convert the rotational mechanical energy of the rear section load into electric power to charge the battery, or to consume the electric power by other loads, thereby obtaining friction damping and, together with the engine piston friction damping, provide a braking friction damping, during the brakes B101 and B102 are in an OFF state, the clutches CL101 and CL103 are in an OFF state, the clutches CL102 and CL104 in an ON state, and the engine can be stopped or slowly operated:

The electromagnetic coupling device M101 is operated as a generator to convert the rotational mechanical energy of the rear section load into electric power to charge the battery, or to consume the electric power by other loads, thereby obtaining friction damping, during which the brake B101 is in an ON state while the brake B102 is in an OFF state, the clutches CL101, CL102 and CL103 are at OFF state, and the engine can be stopped or operated at a slower speed than the sliding speed, and when the CL104 is at ON state, the engine can be operating or stopped.

F6: To achieve this function the electromagnetic coupling device M101 is operated as a generator to charge the battery using the recovered front section kinetic energy, as follows:

The engine speed is reduced or the fuel valve is closed and the electromagnetic coupling device M101 is operated as a generator to convert the rotational mechanical energy of the front section load into electric power to charge the battery, or to consume the electric power by other loads, thereby obtaining friction damping and together with the engine piston friction damping provide a braking friction damping, during which the brake B101 is in an OFF state, the brake B102 is in an ON state, the clutches CL101 and CL104 are in an OFF state, the clutches CL102 and CL103 are in an ON state, and the engine can be stopped or slowly operated:

The electromagnetic coupling device M101 is operated as a generator to convert the rotational mechanical energy of the front section load into electric power to charge the battery, or to consume the electric power by other loads, thereby obtaining friction damping, during

which the brake B102 is in an ON state, the brake B101 is in an OFF state, the clutches CL101, CL102 and CL104 are in an OFF state, the clutch CL103 is in an ON state, and the engine can be stopped or operated at a slower speed than the sliding speed, and when the CL102 is in an OFF state, the engine can be in an operating state or stopped.

F7: To achieve this function, all of the loads are braked by engine friction damping, as follows:

The engine speed is reduced or the fuel valve is closed and the generator is operated to convert the rotational mechanical energy of the front and rear section loads into friction damping and together with the engine piston friction damping provide a braking friction damping, during which brakes B101 and B102 are in an OFF state, the clutch CL101 is in an OFF state, the clutches CL102, CL103 and CL104 are in an ON state, and the engine can be stopped or slowly operated;

F8: To achieve this function, the system is self charged, as follows:

The electromagnetic coupling device M101 is driven by the drive side rotational power source to be operated as a generator to charge the battery or supply power to other loads. At this time, when the engine is started, the brake B101 is in an OFF state, brake B102 is in an ON state, the clutches CL101, CL103, and CL104 are in an OFF state, the clutch CL102 is in an ON state; and the time can be further utilized to preset the engine charging time or control the charging capacity for automatic stop. AC Power generating functions can be included as described above in connection with the description of generator structure.

F9: To achieve this function, the electromagnetic coupling device M101 is operated as a motor to start the engine, as follows:

The electromagnetic coupling device M101 is used to start the drive side engine, at which time brake B102 is in an ON state, brake B101 is in an OFF state, the front section operating interface M102 and the front section coupled clutches CL101, CL103 and CL104 are in an OFF state and clutch CL102 is in an ON state;

F10: Neutral slide: This is the slide function of the system when no power is output and a brake is activated, at which time the engine can be in an operating state or stopped, brakes B101 and B102 are in an OFF state, and the clutches CL101, CL102, CL103 are in an OFF state.

F11: To achieve this function, the engine is used to drive the front section load, and the electromagnetic coupling device M101 is powered by the battery to drive the rear section load, and both are independently operated to drive the respective loads, at which time brake B101 is in an ON state, brake B102 is in an OFF state, clutches CL101, CL105 are in an OFF state, and clutches CL102, CL103 and CL104 are in an ON state;

F12: To achieve this function, the engine is used to drive the front section load and the electromagnetic coupling device M101 is operated as a generator to charge the battery, at which time brake B101 is in an ON state, B102 is in an OFF state, clutches CL101, CL105 are in an OFF state, and clutches CL102, CL103 are in ON state.

The preferred embodiment of the distributed differential coupling combined power system shown in FIG. 1 may have the following variations in practical applications:

FIG. 2 shows the first application of the system of FIG. 1. In this application clutch CL104 and brake B102 are both eliminated, and the system functions are delineated in Table 2.

FIG. 3 shows the second application of the system of FIG. 1. In this application clutch CL104 and brake B102 are both eliminated, and the system functions are delineated in Table 3.

FIG. 4 shows the third application of the system of FIG. 1. It discloses an application in which B102, and clutches CL101 and CL104 are eliminated, and the system functions are delineated in Table 4.

FIG. 5 shows the fourth application of the system of FIG. 1: it discloses an application in which an additional clutch CL105 is installed between the rear section output middle shaft and the middle transmission device while clutch CL103 is reserved for controlling the front section load or replaced by a speed change shift of the middle transmission devices, and the system functions are delineated in Table 5.

FIG. 6 shows the fifth application of the system of FIG. 1. In this application, a clutch CL105 is installed between the rear section output middle shaft and the middle transmission device, clutch CL104 is eliminated, and the system functions are delineated in Table 6.

FIG. 7 shows the sixth application of the system of FIG. 1. In this application a clutch CL105 is installed between the rear section output middle shaft and the middle transmission device, clutch CL104 and brake B102 are eliminated, and the system functions are delineated in Table 7.

FIG. 8 shows the seventh application of the system of FIG. 1. It discloses an application which includes additional clutch CL105 and eliminates clutches CL101, CL104 and brake B102, and the system functions are delineated in Table 8.

The above described application examples are for reference only, and it will be appreciated that other practical applications can be achieved by arranging the front and the rear section loads and distributed coupling structure according to performance requirements without departing from the invention by selecting the appropriate operating and control components.

For the case when the systems of the examples in FIG. 1-8 are applied to vehicles, the angular displacement relationships between the front and rear section loads and the drive power source resulting from the transmission ratio and the wheel outside diameter differences may be as follows: The angular displacement speed of the two loads and the

10

drive side rotational power source are operated according to the wheel system ratio relationships, or the angular displacement relationship between the two loads and their operations with the drive side rotational power source are not according to the wheel system ratio (such as slipping on the road surface). In particular, the relationships between the angular displacement of the rear section load and the drive side power source or between the front and rear section loads can be especially set not to operate according to the wheel system ratio relationship, but to operate through the differential acting adjustment by the electromagnetic coupling device:

The differentially acting adjustment of the electromagnetic coupling device M101 includes an active adjustment based on the input power when functioning as a motor or a passive adjustment to output power when functioning as a generator:

In vehicle driving applications of the aforesaid front section load and the rear section load, the front section load can be the front wheel or the rear wheel, and the rear section load can be the matched front wheel or rear wheel structure with the aforesaid definition;

The distributed differential coupling combined power system has possible numerous operating functions and in the practical applications can be constructed to be provide all or part of those functions.

As summarized from the above descriptions, the distributed differential coupling combined power system of the invention can be applied to vehicles, boats, or other machinery requiring combined driving power. The examples given herein encompass the various applications of the basic distributed differential coupling combined power system concept of the invention and in practical applications, any peripheral components for the output functions can be selected according to need, providing a highly flexible system.

TABLE I

FUNCTIONS	COMPONENTS										REMARK
	B101	B102	P101	CL101	CL102	CL103	CL104	G/M (M101)	BT101		
F1-A	OFF	*OFF **OFF ***OFF	0-MAX	*ON **ON ***OFF	ON	*OFF **ON ***ON	*ON **ON ***OFF	*READY **READY ***READY GEN.	*READY **READY ***READY CHARGE		*Drive the rear section load **Drive the front and rear section loads simultaneously ***Drive the front section load
F1-B	OFF	*OFF **OFF ***ON	0-MAX	*OFF	ON	*OFF **ON ***ON	*ON **ON ***OFF				
F1-C	OFF	OFF	*0-MAX OR CONSTANT SPEED **0-MAX	OFF	ON	*OFF **ON	ON	GEN.	DIS. CHARGE		*Drive the rear section load **Drive the front and rear section loads simultaneously
F1-D	OFF	OFF	*0-MAX OR CONSTANT SPEED **0-MAX	OFF	ON	*OFF **ON	ON	GEN.	READY		*Drive the rear section load **Drive the front and rear section loads simultaneously
F2	ON	OFF	STOP	OFF	OFF	OFF	ON	MOTOR	DIS. CHARGE		
F3	OFF	ON	STOP	OFF	OFF	ON	OFF	MOTOR	DIS. CHARGE		
F4-A	OFF	OFF	0-MAX OR CONSTANT SPEED	OFF	ON	OFF	ON	MOTOR	DIS. CHARGE		
F4-B	OFF	OFF	0-MAX	OFF	ON	ON	ON	MOTOR	DIS. CHARGE		
F5	*OFF **ON	OFF	*SLOW OR STOP **STOP-MAX	OFF	*ON **OFF	OFF	ON	GEN.	CHARGE		*The engine piston friction damping is activated simultaneously **Recovery of the kinetic energy
F6	OFF	ON	*SLOW OR STOP **STOP-MAX	OFF	*ON **OFF	ON	OFF	GEN.	CHARGE		*The engine piston friction damping is activated simultaneously **Recovery of the kinetic energy

TABLE I-continued

FUNCTIONS	COMPONENTS										REMARK
	R101	R102	P101	CL101	CL102	CL103	CL104	G/M (M101)	RT101		
F7	OFF	OFF	SLOW OR STOP	OFF	ON	ON	ON	READY	READY		
F8	OFF	ON	0-MAX OR CONSTANT SPEED	OFF	ON	OFF	OFF	GEN.	CHARGE		
F9	OFF	ON	STOP TO START	OFF	ON	OFF	OFF	MOTOR	DIS-CHARGE		
F10	OFF	OFF	STOP OT 0-MAX	OFF	OFF	OFF	OFF	READY	READY		

Notes:

- 1) CHARGE: current of FI-B is load following distributed
- 2) The M101 is an electromagnetic coupling device
- 3) RT101 is the battery
- 4) GEN: is a generator
- 5) For the case of engine, the P101 is the drive side rotational power source which is employed to drive the front section load and is series combined with the M101 to drive the rear section load
- 6) For the case of AC power output function in F8, the said M101 is selected to employ the electrical machine with AC power generating functions comprised of a permanent magnet or winding excited, varied frequency driven field type electrical device, or a brushed alternator type electrical device, wherein its armature winding is commonly installed the conducting rings for AC output and the commutators for DC input/output.

TABLE 2

FUNCTIONS	COMPONENTS										REMARK
	B101	B102	P101	CL101	CL102	CL103	CL104	G/M (M101)	BT101		
F1-A	OFF	*OFF **OFF ***OFF	0-MAX	*ON **ON ***OFF	ON	*OFF **ON ***ON	*ON **ON ***OFF	*READY **READY ***READY	*READY **READY ***CHARGE	*Drive the rear section load **Drive the front and rear section loads simultaneously ***Drive the front section load	
F1-B	OFF	*OFF **OFF ***ON	0-MAX	*OFF	ON	*OFF **ON ***ON	*ON **ON ***OFF	GEN	DIS-CHARGE	*Drive the rear section load **Drive the front and rear section loads simultaneously	
F1-C	OFF	OFF	*0-MAX OR CONSTANT SPEED **0-MAX	OFF	ON	*OFF **ON	ON	GEN	DIS-CHARGE	*Drive the rear section load **Drive the front and rear section loads simultaneously	
F1-D	OFF	OFF	*0-MAX OR CONSTANT SPEED **0-MAX	OFF	ON	*OFF **ON	ON	GEN	READY	*Drive the rear section load **Drive the front and rear section loads simultaneously	
F2	ON	OFF	STOP	OFF	OFF	OFF	ON	MOTOR	DIS-CHARGE		
F3-A	OFF	OFF	0-MAX OR CONSTANT SPEED	OFF	ON	OFF	ON	MOTOR	DIS-CHARGE		
F3-B	OFF	OFF	0-MAX	OFF	ON	ON	ON	MOTOR	DIS-CHARGE		
F5	*OFF **ON	OFF	*SLOW OR STOP **STOP-MAX	OFF	*ON **OFF	OFF	ON	GEN	CHARGE	*The engine piston friction damping is activated simultaneously **Recovery of the kinetic energy	
F7	OFF	OFF	SLOW OR STOP	OFF	ON	ON	ON	READY	READY		
F8	OFF	ON	0-MAX OR CONSTANT SPEED	OFF	ON	OFF	OFF	GEN	CHARGE		

TABLE 2-continued

FUNCTIONS	COMPONENTS										REMARK
	B101	B102	P101	CL101	CL102	CL103	CL104	G/M (M101)	BT101		
I-9 or to provide varied or constant frequency AC generation output The M101 is operated as a motor to start the engine	OFF	ON	STOP TO START	OFF	ON	OFF	OFF	OFF	OFF	MOTOR	DIS-CHARGE
I-10 Neutral Slide	OFF	OFF	STOP OT 0-MAX	OFF	OFF	OFF	OFF	OFF	OFF	READY	READY

Notes:

- 1) CHARGE: current of F1-B is load following distributed
- 2) The M101 is an electromagnetic coupling device
- 3) BT101 is the battery
- 4) GEN: is a generator
- 5) For the case of engine, the P101 is the drive side rotational power source which is employed to drive the front section load and is series combined with the M101 to drive the rear section load
- 6) For the case of AC power output function in I-8, the said M101 is selected to employ the electrical machine with AC power generating functions comprised of a permanent magnet or winding excited, varied frequency driven field type electrical device, or a brushed alternator type electrical device, wherein its armature winding is commonly installed the conducting rings for AC output and the commutators for DC input/output.

TABLE 3

COMPONENTS									
FUNCTIONS	B101	P101	CL101	CL102	CL103	M101	BT101	REMARK	
F1-A The engine fuel valve is controlled to drive the engine from low speed to high speed	OFF	0-MAX	*ON **ON	ON	*OFF **ON	*READY **READY	*READY **READY	*Drive the rear section load **Drive the front and rear section loads simultaneously ***Drive the front section load	
F1-B The engine fuel valve and the M101 is controlled simultaneously to drive the engine from low speed to high speed and to charge the battery simultaneously	OFF	0-MAX	*OFF **OFF	ON	*OFF **ON ***ON	*READY **READY ***GEN	CHARGE		
F1-C The engine is speed controlled or operated at a constant speed, wherein the battery charging current from the M101 is controlled to change the output power to the load.	OFF	0-MAX OR CONSTANT SPEED **0-MAX	OFF	ON	*OFF **ON	GEN	DIS CHARGE	*Drive the rear section load **Drive the front and rear section loads simultaneously	
F1-D The engine is speed controlled or operated at a constant speed, wherein the M101 generates short cut current to control the output shaft torque, thereby to change the engine speed	OFF	0-MAX OR CONSTANT SPEED **0-MAX	OFF	ON	*OFF **ON	GEN	READY	*Drive the rear section load **Drive the front and rear section loads simultaneously	
F2 The M101 is powered by the battery to change the speed or the rotation direction of the rear section load	ON	STOP	OFF	OFF	OFF	MOTOR	DIS- CHARGE		
F4-A The engine is operated at a preset speed while the M101 is operated as a motor to provide added power output to drive the rear section load	OFF	0-MAX OR CONSTANT SPEED	OFF	ON	OFF	MOTOR	DIS- CHARGE		
F4-B The engine is operated at a preset speed while the M101 is operated as a motor to provide added power output to drive the front and rear section loads	OFF	0-MAX	OFF	ON	ON	MOTOR	DIS- CHARGE		
F5 The M101 is operated as a generator to charge the battery using the recovered rear section kinetic energy	*OFF **ON	*SLOW OR STOP **STOP-MAX	OFF	*ON **OFF	OFF	GEN	CHARGE	*The engine piston friction damping is activated simultaneously **Recovery of the kinetic energy	
F7 All the loads are braked by the engine friction damping	OFF	SLOW OR STOP	OFF	ON	ON	READY	READY		
F8 The system is self charged (It can be supplied at a preset time or controlled by the capacity) through that the M101 is driven by the engine to be operated as a generator to charge the battery	OFF	0-MAX OR (CONSTANT SPEED)	OFF	ON	OFF	GEN	CHARGE when the engine is stopped	The operation is limited and the rear load brake	

is locked.

TABLE 3-continued

FUNCTIONS	COMPONENTS								REMARK
	B101	P101	CL101	CL102	CL103	(M101)	BT101		
F9	OFF	STOP TO START	OFF	ON	OFF	MOTOR	DIS		
F10	OFF	STOP TO 0-MAX	OFF	OFF	OFF	READY	READY		CHARGE

Notes:

- 1) CHARGE current of F1-B is load following distributed
- 2) The M101 is an electromagnetic coupling device
- 3) BT101 is the battery
- 4) GEN is a generator
- 5) For the case of engine, the P101 is the drive side rotational power source which is employed to drive the front section load and is series combined with the M101 to drive the rear section load
- 6) For the case of AC power output function in F8, the said M101 is selected to employ the electrical machine with AC power generating functions comprised of a permanent magnet or winding excited, varied frequency driven field type electrical device, or a brushed alternator type electrical device, wherein its armature winding is commonly installed the conducting rings for AC output and the commutators for DC input/output.

TABLE 4

FUNCTIONS	COMPONENTS										REMARK
	B101	P101	CL101	CL102	CL103	(M101)	BT101				
F1-A	OFF	0-MAX	*ON **ON	ON	*OFF **ON ***ON	*READY **READY ***READY	*READY **READY ***READY				*Drive the rear section load **Drive the front and rear section loads simultaneously ***Drive the front section load
F1-B	OFF	0-MAX	*OFF	ON	*OFF **ON ***ON	GEN	CHARGE				
F1-C	OFF	*0-MAX OR CONSTANT SPEED **0-MAX	OFF	ON	*OFF **ON	GEN	DIS- CHARGE				*Drive the rear section load **Drive the front and rear section loads simultaneously
F1-D	OFF	**0-MAX OR CONSTANT SPEED **0-MAX	OFF	ON	*OFF **ON	GEN	READY				*Drive the rear section load **Drive the front and rear section loads simultaneously
F2	ON	STOP	OFF	OFF	OFF	MOTOR	DIS- CHARGE				
F3-A	OFF	0-MAX OR CONSTANT SPEED	OFF	ON	OFF	MOTOR	DIS- CHARGE				
F3-B	OFF	0-MAX	OFF	ON	ON	MOTOR	DIS- CHARGE				
F5	*OFF **ON	*SLOW OR STOP **STOP-MAX	OFF	*ON **OFF	OFF	GEN	CHARGE				*The engine piston friction damping is activated simultaneously **Recovery of the kinetic energy
F6	OFF	*SLOW OR STOP **STOP-MAX	*ON **OFF	ON	GEN	CHARGE				*The engine piston friction damping is activated simultaneously **Recovery of the kinetic energy	
F7	OFF	SLOW OR	OFF	ON	ON	READY				*The engine piston friction damping is activated simultaneously **Recovery of the kinetic energy READY	
		SLOW OR	OFF	ON	ON	READY				All the loads are braked by	

TABLE 4-continued

FUNCTIONS	COMPONENTS										REMARK
	B101	P101	CL101	CL102	CL103	(M101)	BT101				
F8 the engine friction damping The system is self charged (It can be stopped at a preset time or controlled by the capacity) through that the M101 is driven by the engine to be operated as a generator to charge the battery or to provide varied or constant frequency AC generation output The M101 is operated as a motor to start the engine Neutral Slide	OFF	STOP 0 MAX OR CONSTANT SPEED	OFF	ON	OFF	GEN.	CHARGE when the engine is stopped			The operation is limited and the rear load brake	
F9	OFF	STOP TO START	OFF	ON	OFF	MOTOR	DIS.				
F10	OFF	STOP TO 0-MAX	OFF	OFF	OFF	READY	READY			CHARGE	

Notes:

- 1) CHARGE: current of F1-B is load following distributed
- 2) The M101 is an electromagnetic coupling device
- 3) BT101 is the battery
- 4) GEN: is a generator
- 5) For the case of engine, the P101 is the drive side rotational power source which is employed to drive the front section load and is series combined with the M101 to drive the rear section load
- 6) For the case of AC power output function in F8, the said M101 is selected to employ the electrical machine with AC power generating functions comprised of a permanent magnet or winding excited, varied frequency driven field type electrical device, or a brushed alternator type electrical device, wherein its armature winding is commonly installed the conducting rings for AC output and the commutators for DC input/output.

TABLE 5

FUNCTIONS	COMPONENTS										REMARK
	B101	B102	P101	CL101	CL102	CL103	CL104	G/M (M101)	BT101		
F1-A The engine fuel valve is controlled to drive the engine from low speed to high speed	OFF	*OFF **OFF ***OFF	0-MAX	*ON **ON ***OFF	ON	*OFF **ON ***ON	*ON **ON ***OFF	*READY **READY ***READY GEN.	*READY **READY ***READY CHARGE	*Drive the rear section load **Drive the front and rear section loads simultaneously ***Drive the front section load	
F1-B The engine fuel valve and the M101 is controlled simultaneously to drive the engine from low speed to high speed and to charge the battery simultaneously	OFF	*OFF **OFF ***ON	0-MAX	*OFF **OFF ***OFF	ON	*OFF **ON ***ON	*ON **ON ***OFF	GEN.	DIS- CHARGE	*Drive the rear section load **Drive the front and rear section loads simultaneously	
F1-C The engine is speed controlled or operated at a constant speed, wherein the battery charging current from the M101 is controlled to change the output power to the load;	OFF	OFF	*0-MAX OR CONSTANT SPEED **0-MAX	OFF	ON	*OFF **ON	ON	GEN.	DIS- CHARGE	*Drive the rear section load **Drive the front and rear section loads simultaneously	
F1-D The engine is speed controlled or operated at a constant speed, wherein the M101 generates short cut current to control the output shaft torque, thereby to change the engine speed	OFF	OFF	*0-MAX OR CONSTANT SPEED **0-MAX	OFF	ON	*OFF **ON	ON	GEN.	READY	*Drive the rear section load **Drive the front and rear section loads simultaneously	
F2 The M101 is powered by the battery to change the speed or the rotation direction of the rear section load	ON	OFF	STOP	OFF	OFF	OFF	ON	MOTOR	DIS- CHARGE		
F3 The M101 is powered by the battery to change the speed or the rotation direction of the front section load	OFF	ON	STOP	OFF	OFF	ON	OFF	MOTOR	DIS- CHARGE		
F4-A The engine is operated at a preset speed while the M101 is operated as a motor to provide added power output to drive the rear section load	OFF	OFF	0-MAX OR CONSTANT SPEED	OFF	ON	OFF	ON	MOTOR	DIS- CHARGE		
F4-B The engine is operated at a preset speed while the M101 is operated as a motor to provide added power output to drive the front and rear section loads	OFF	OFF	0-MAX	OFF	ON	ON	ON	MOTOR	DIS- CHARGE		
F5 The M101 is operated as a generator to charge the battery using the recovered rear section kinetic energy	*OFF **ON	OFF	*SLOW OR STOP **STOP-MAX	OFF	*ON **OFF	OFF	ON	GEN.	CHARGE	*The engine piston friction damping is activated simultaneously **Recovery of the kinetic energy	
F6 The M101 is operated as a generator to charge the battery using the removed front section kinetic energy	OFF	ON	*SLOW OR STOP **STOP-MAX	OFF	*ON **OFF	ON	OFF	GEN.	CHARGE	*The engine piston friction damping is activated simultaneously **Recovery of the kinetic energy	

TABLE 5-continued

FUNCTIONS	COMPONENTS										REMARK
	B101	B102	P101	CL101	CL102	CL103	CL104	G/M (M101)	BT101		
F7	OFF	STOP	SLOW OR	OFF	ON	ON	ON	READY	READY		
F8	OFF	ON	0-MAX OR CONSTANT SPEED	OFF	ON	OFF	OFF	GEN	CHARGE		The operation is limited to when the engine is stopped
F9	OFF	ON	STOP TO START	OFF	ON	OFF	OFF	MOTOR	DIS-CHARGE		
F10	OFF	OFF	STOP OT 0-MAX	OFF	OFF	OFF	OFF	READY	READY		
F11	ON	OFF	0-MAX	OFF	ON	ON	ON	OFF	MOTOR	DIS-CHARGE	
F12	ON	OFF	0-MAX	OFF	ON	ON	OFF	GEN	CHARGE		

Notes:

- 1) CHARGE: current of F1-B is load following disinhibited
- 2) The M101 is an electromagnetic coupling device
- 3) BT101 is the battery
- 4) GEN: is a generator
- 5) For the case of engine, the P101 is the drive side rotational power source which is employed to drive the front section load and is series combined with the M101 to drive the rear section load
- 6) For the case of AC power output function in F8, the said M101 is selected to employ the electrical machine with AC power generating functions comprised of a permanent magnet or winding excited, varied frequency driven field type electrical device, or a brushed alternator type electrical device, wherein its armature winding is commonly installed the conducting rings for AC output and the commutators for DC input/output.

TABLE 6

FUNCTIONS	COMPONENTS										REMARK
	B101	B102	P101	CL101	CL102	CL103	CL104	G/M (M101)	BT101		
F1-A The engine fuel valve is controlled to drive the engine from low speed to high speed	OFF	*OFF **OFF	0-MAX	*ON **ON	ON	*OFF **ON	*ON **ON	*READY **READY	*READY **READY	*READY **READY	*Drive the rear section load **Drive the front and rear section loads simultaneously
F1-B The engine fuel valve and the M101 is controlled simultaneously to drive the engine from low speed to high speed and to charge the battery simultaneously	OFF	*OFF **OFF ***ON	0-MAX	*OFF	ON	*OFF **ON ***ON	*ON **ON ***OFF	*READY **READY ***GEN	*READY **READY ***CHARGE	*READY **READY ***CHARGE	**Drive the front section load ***Drive the rear section load
F1-C The engine is speed controlled or operated at a constant speed, wherein the battery charging current from the M101 is controlled to change the output power to the load.	OFF	OFF	*0-MAX OR CONSTANT SPEED **0-MAX	OFF	ON	*OFF **ON	ON	GEN	DIS- CHARGE	DIS- CHARGE	*Drive the rear section load **Drive the front and rear section loads simultaneously
F1-D The engine is speed controlled or operated at a constant speed, wherein the M101 generates short cut current to control the output shaft torque, thereby to change the engine speed	OFF	OFF	*0-MAX OR CONSTANT SPEED **0-MAX	OFF	ON	*OFF **ON	ON	GEN	READY	READY	*Drive the rear section load **Drive the front and rear section loads simultaneously
F2 The M101 is powered by the battery to change the speed or the rotation direction of the rear section load	ON	OFF	STOP	OFF	OFF	OFF	ON	MOTOR	DIS- CHARGE	DIS- CHARGE	
F4-A The engine is operated at a preset speed while the M101 is operated as a motor to provide added power output to drive the rear section load	OFF	OFF	0-MAX OR CONSTANT SPEED	OFF	ON	OFF	ON	MOTOR	DIS- CHARGE	DIS- CHARGE	
F4-B The engine is operated at a preset speed while the M101 is operated as a motor to provide added power output to drive the front and rear section loads	OFF	OFF	0-MAX	OFF	ON	ON	ON	MOTOR	DIS- CHARGE	DIS- CHARGE	
F5 The M101 is operated as a generator to charge the battery using the recovered rear section kinetic energy	*OFF **ON	OFF	*SLOW OR STOP **STOP-MAX	OFF	*ON **OFF	OFF	ON	GEN	CHARGE	CHARGE	*The engine piston friction damping is activated simultaneously **Recovery of the kinetic energy
F7 All the loads are braked by the engine friction damping	OFF	OFF	SLOW OR STOP	OFF	ON	ON	ON	READY	READY	READY	The operation is limited to when the engine is stopped
F8 The system is self charged (It can be stopped at a preset time or controlled by the capacity) through that the M101 is driven by the engine to be operated as a generator to charge the battery	OFF	ON	0-MAX OR CONSTANT SPEED	OFF	ON	OFF	OFF	GEN	CHARGE	CHARGE	

TABLE 6-continued

FUNCTIONS	COMPONENTS										REMARK
	B101	B102	P101	CL101	CL102	CL103	CL104	G/M (M101)	BT101		
F9 or to provide varied or constant frequency AC generation output The M101 is operated as a motor to start the engine	OFF	ON	STOP TO START	OFF	ON	OFF	OFF	MOTOR	DIS-CHARGE		
F10 Neutral Slide	OFF	OFF	STOP OT 0-MAX	OFF	OFF	OFF	OFF	READY	READY		
F11 The engine is used to drive the front section load, and the M101 is used to drive the rear section load, and both are independently operated	ON	OFF	0-MAX	OFF	ON	ON	ON	OFF	MOTOR	DIS-CHARGE	
F12 The engine is used to drive the front section load and the M101 is pulled to be operated as a generator to charge the battery	ON	OFF	0-MAX	OFF	ON	ON	OFF	GEN	CHARGE		

Notes:

- 1) CHARGE: current of F1-B is load following distributed
- 2) The M101 is an electromagnetic coupling device
- 3) BT101 is the battery
- 4) GEN: is a generator
- 5) For the case of engine, the P101 is the drive side rotational power source which is employed to drive the front section load and is series combined with the M101 to drive the rear section load
- 6) For the case of AC power output function in F8, the said M101 is selected to employ the electrical machine with AC power generating functions comprised of a permanent magnet or winding excited, varied frequency driven field type electrical device, or a brushed alternator type electrical device, wherein its armature winding is commonly installed the conducting rings for AC output and the commutators for DC input/output.

TABLE 7

FUNCTIONS	COMPONENTS										REMARK
	B101	P101	CL101	CL102	CL103	CL105	G/M (M101)	BT101			
F1-A The engine fuel valve is controlled to drive the engine from low speed to high speed The engine fuel valve and the M101 is controlled simultaneously to drive the engine from low speed to high speed and to charge the battery simultaneously	OFF	0-MAX	*ON **ON ***OFF	ON	*OFF **ON ***ON	*ON **ON ***OFF	*READY **READY ***READY GEN.	*READY **READY ***READY CHARGE			*Drive the rear section load **Drive the front and rear section loads simultaneously ***Drive the front section load
F1-B The engine is speed controlled or operated at a constant speed, wherein the battery charging current from the M101 is controlled to change the output power to the load;	OFF	*0-MAX OR CONSTANT SPEED	OFF	ON	*OFF **ON	ON	GEN.	DIS- CHARGE			*Drive the rear section load **Drive the front and rear section loads simultaneously
F1-C The engine is speed controlled or operated at a constant speed, wherein the M101 generates short cut current to control the output shaft torque, thereby to change the engine speed	OFF	*0-MAX OR CONSTANT SPEED **0-MAX	OFF	ON	*OFF **ON	ON	GEN.	READY			*Drive the rear section load **Drive the front and rear section loads simultaneously
F2 The M101 is powered by the battery to change the speed or the rotation direction of the rear section load	ON	STOP	OFF	OFF	OFF	ON	MOTOR	DIS- CHARGE			
F3-A The engine is operated at a preset speed while the M101 is operated as a motor to provide added power output to drive the rear section load	OFF	0-MAX OR CONSTANT SPEED	OFF	ON	OFF	ON	MOTOR	DIS- CHARGE			
F3-B The engine is operated at a preset speed while the M101 is operated as a motor to provide added power output to drive the front and rear section loads	OFF	0-MAX	OFF	ON	ON	ON	MOTOR	DIS- CHARGE			
F5 The M101 is operated as a generator to charge the battery using the recovered rear section kinetic energy	*OFF **ON	*SLOW OR STOP **STOP-MAX	OFF	*ON **OFF	OFF	ON	GEN.	CHARGE			*The engine piston friction damping is activated simultaneously **Recovery of the kinetic energy
F7 All the loads are braked by the engine friction damping	OFF	SLOW OR STOP	OFF	ON	ON	ON	READY	READY			The operation is limited to when the engine is stopped and the rear load brake is locked
F8 The system is self charged (It can be stopped at a preset time or controlled by the capacity) through that the M101 is driven by the engine to be operated as a generator to charge the battery	OFF	0-MAX OR CONSTANT SPEED	OFF	ON	OFF	OFF	GEN.	CHARGE			

TABLE 7-continued

FUNCTIONS	COMPONENTS										REMARK
	B101	P101	CL101	CL102	CL103	CL105	G/M (M101)	BT101			
F9 or to provide varied or constant frequency AC generation output The M101 is operated as a motor to start the engine	OFF	STOP TO START	OFF	ON	OFF	OFF	MOTOR	DIS-CHARGE READY MOTOR			
F10 Neutral Slide	OFF	STOP OT 0-MAX	OFF	OFF	OFF	OFF	READY				
F11 The engine is used to drive the front section load, and the M101 is used to drive the rear section load, and both are independently operated	ON	0-MAX	OFF	ON	ON	ON	OFF				DIS-CHARGE
F12 The engine is used to drive the front section load and the M101 is pulled to be operated as a generator to charge the battery	ON	0-MAX	OFF	ON	ON	OFF	GEN.	CHARGE			

Notes:

- 1) CHARGE: current of F1-B is load following distributed
- 2) The M101 is an electromagnetic coupling device
- 3) BT101 is the battery
- 4) GEN- is a generator
- 5) For the case of engine, the P101 is the drive side rotational power source which is employed to drive the front section load and is series combined with the M101 to drive the rear section load
- 6) For the case of AC power output function in F8, the said M101 is selected to employ the electrical machine with AC power generating functions comprised of a permanent magnet or winding excited, varied frequency driven field type electrical device, or a brushed alternator type electrical device, wherein its armature winding is commonly installed the conducting rings for AC output and the commutators for DC input/output.

TABLE 8

FUNCTIONS	COMPONENTS										REMARK
	B101	P101	CL102	CL103	CL105	G/M (M101)	BT101				
F1-A	OFF	0-MAX	ON	*OFF **ON ***ON	*ON **ON ***OFF	READY **READY ***READY	*READY **READY ***READY				*Drive the rear section load **Drive the front and rear section loads simultaneously ***Drive the front section load
F1-B	OFF	0-MAX	ON	*OFF **ON ***ON	*ON **ON ***OFF	GEN	CHARGE				
F1-C	OFF	*0-MAX OR CONSTANT SPEED **0-MAX	ON	*OFF **ON	ON	GEN	DIS- CHARGE				*Drive the rear section load **Drive the front and rear section loads simultaneously
F1-D	OFF	*0-MAX OR CONSTANT SPEED **0-MAX	ON	*OFF **ON	ON	GEN	READY				*Drive the rear section load **Drive the front and rear section loads simultaneously
F2	ON	STOP	OFF	OFF	OFF	MOTOR	DIS- CHARGE				
F4-A	OFF	0-MAX OR CONSTANT SPEED	ON	OFF	ON	MOTOR	DIS- CHARGE				
F4-B	OFF	0-MAX	ON	ON	ON	MOTOR CHARGE	DIS-				
F5	*OFF **ON	*SLOW OR STOP **STOP-MAX	*ON **OFF	OFF	ON	GEN	CHARGE				*The engine piston friction damping is activated simultaneously **Recovery of the kinetic energy
F7	OFF	SLOW OR STOP	ON	ON	ON	READY	READY				The operation is limited to when the engine is stopped and the rear load brake is locked
F8	OFF	0-MAX OR CONSTANT SPEED	ON	OFF	OFF	GEN	CHARGE				

TABLE 8-continued

FUNCTIONS	COMPONENTS							REMARK
	B101	P101	CL102	CL103	CL105	G/M (M101)	BT101	
F-9 or to provide varied or constant frequency AC generation output The M101 is operated as a motor to start the engine	OFF	STOP TO START	ON	OFF	ON	MOTOR	DIS CHARGE READY MOTOR	
F10 Neutral Slide	OFF	STOP TO 0-MAX	OFF	OFF	OFF	READY		
F11 The engine is used to drive the front section load, and the M101 is used to drive the rear section load, and both are independently operated	ON	0 MAX	ON	ON	ON	OFF		DIS. CHARGE
F12 The engine is used to drive the front section load and the M101 is pulled to be operated as a generator to charge the battery	ON	0 MAX	ON	ON	OFF	GEN.	CHARGE	

Notes:

- 1) CHARGE current of F1-B is load following distributed
- 2) The M101 is an electromagnetic coupling device
- 3) BT101 is the battery
- 4) GEN- is a generator
- 5) For the case of engine, the P101 is the drive side rotational power source which is employed to drive the front section load and is series combined with the M101 to drive the rear section load
- 6) For the case of AC power output function in F8, the said M101 is selected to employ the electrical machine with AC power generating functions comprised of a permanent magnet or winding excited, varied frequency driven field, type electrical device, or a brushed alternator type electrical device, wherein its armature winding is commonly installed the conducting rings for AC output and the commutators for DC input/output.