


8271 Nways Ethernet LAN Switch Models 612 and 624 Quick Installation Guide



Installing the Switch



DANGER: 55H7211.


The User's Guide also contains further information on the following steps.

Into a 19-inch rack

Fit the brackets as shown in 1 (below) to each side of the unit. Following the manufacturer's instructions, secure the unit into the rack.

On the wall

Place the unit the right way up on a hard flat surface with the front facing towards you. Fit the brackets as shown in 2 (below) to each side of the unit. Place the base of the unit against the wall, ensuring that the ventilation holes face sidewards and the front panel faces upwards. Secure using suitable screws and fixings (not supplied). The wall surface should be smooth, flat, dry and sturdy. Use a plywood sheet between the unit and wall if necessary.



Powering Up

- 1 As required:
 - a Fit a Transceiver Module
 - **b** Fit a Plug-in Module
 - c Connect network cabling
- 2 Connect the power cord to the IEC socket on the rear of the Switch, and to your mains socket.



The 8271 Model 612/624 Switch has no ON/OFF switch, the only method of connecting or disconnecting mains power is through the power cord.

- **3** The Switch enters a Power On Self Test (POST). The time taken for the test to complete is dependent on the type of POST configured for the unit. For a new Switch that is being installed for the first time, power-up takes approximately 13 seconds.
- 4 Check the status LEDs to ensure the Switch is operating correctly.



Intelligent Flow Management (IFM) should be disabled if the port is connected to a repeated segment where the traffic is mainly local to that segment.

Further information on these steps is available in:

- IBM 8271 Nways Ethernet LAN Switch Models 612 and 624 User's Guide, Part Number 55H7211
- IBM 8271 Nways Ethernet LAN Switch Models 612 and 624 Quick Reference Guide, Part Number 55H7212

Part No. 02L1348 Published October 1997