

Internet Easy Phone

NT-P600S



User's Manual

Table of Contents

❖ Chapter 1: Introduction	1
○ What is Skype?	1
○ What about my NexoTek phone?	1
○ Product Features	1
○ Package Contents	2
○ System Requirements	2
❖ Chapter 2: Setting Up Skype	3
○ Download and Installation	3
○ Creating a New Skype Account	7
○ Making a Test Call	10
❖ Chapter 3: Installing SkyMagic	12
○ Installing the Software	12
❖ Chapter 4: Connecting Your Phone	17
❖ Chapter 5: Getting to Know Your Phone	18
○ Keypad Buttons	18
❖ Chapter 6: Using Your Phone	19
○ General Operation	19
▪ Choosing Your Ring Tone	19
▪ Changing the Face Slip	19
○ Making And Receiving Calls	20
▪ Answering and Refusing Calls	20
▪ Calling From Your Contacts List	20
▪ Calling From Your Call History	21
▪ Calling Using Speed Dial	21
▪ Making SkypeOut Calls	22
○ Advanced Features	23
▪ The Hold Function	23
▪ The Call Waiting Function	23
▪ The Mute Function	23

Chapter 7: Troubleshooting	24
○ SkyMagic Icon Indicators	24
▪ Enabling SkyMagic to use Skype	25
○ Your Computer Audio Settings	27
○ Contacting NexoTek	30
❖ Appendices	31
○ Appendix A: Managing Skype Contacts	31
▪ Adding a Skype Contact	31
▪ Removing a Skype Contact	34
○ Appendix B: Assigning a Speed Dial Number	35
○ Appendix C: Purchasing Skype Credit	37
○ Appendix D: Updating SkyMagic	41

What is Skype?

Skype is a program that essentially turns your computer into a phone and allows you to make calls over the Internet to other Skype users. Because the connection is established over the Web, Skype-to-Skype calls are completely free of charge, and this is why phone companies do not want you to know about Skype. You can use Skype to call people as close by as your neighbors or as far away as someone on the opposite side of the globe. It's simple, efficient, and gets rid of long-distance calling costs.

What about my NexoTek phone?

Your NexoTek phone has been designed to be used with Skype for a more convenient Internet calling experience. The NT-P600S USB Internet Easy Phone provides you with all the basic necessities of an Internet phone at an affordable price, and it is as comfortable to use as your regular home phone. It is a versatile product that supports Windows 2000 or XP, Macintosh OS X, and Linux platforms, and its compact size and changeable face slip make it both a practical and personal model for a variety of users. Additionally, it has hold, call waiting, and mute functions for your convenience. The phone will ring for all of your incoming calls, and it includes five different ring styles each at two volume levels. NexoTek's noise reduction and echo cancellation technology ensure that you will have only the best quality calls.

Product Features

- Supported by Windows 2000 or XP, Macintosh OS X, and Linux platforms
- Changeable face slip for a sleek, personalized look
- Mute, hold, and call waiting functions
- Easy to use and inexpensively priced
- Rings for all incoming calls
- Five different ring styles each at two volume levels
- Noise reduction and echo cancellation technology deliver clear, high-quality calls

Package Contents

Your NT-P600S box contains the following items:

- ✓ NexoTek NT-P600S Internet Easy Phone
- ✓ SkyMagic installation CD
- ✓ Quick Start Guide
- ✓ User Manual on CD
- ✓ Changeable face slip

System Requirements

In order to use your phone and the necessary software that accompanies it, your computer must have the following:

- ✓ One (1) of the following compatible platforms:
 - Windows 2000
 - Windows XP
 - Macintosh OS X
 - Linux (Fedora Core 3)
- ✓ Minimum 400 MHz processor
- ✓ 128 MB RAM
- ✓ 15 MB free disk space
- ✓ One (1) of the following compatible USB ports:
 - USB 1.1
 - USB 2.0
- ✓ Broadband Internet connection: cable, DSL

How do I set up Skype?


In order to use your phone, you will need the Skype program installed on your computer. If you already have Skype installed, please skip to Chapter 3.

There are three main parts of the Skype setup process. First, you must download the program for free from the Internet and install it to your computer. Then you will create a Skype account by picking out a user name and password. Finally, you will make a test call to ensure that Skype is running successfully on your computer.

Download and Installation

The first part of setting up Skype involves downloading the program from the Skype Web site and installing it on your computer. You must be connected to the Internet to do this.

1. To begin, open your Web browser. In the address bar, type in the URL for the Skype home page: `http://www.skype.com` and press your **Enter** key.



2. When the Skype Web page has fully loaded, click on the link that says **Download Skype**.




3. On the next page that loads, press the **Download** button.




4. Another page will load. Press the **Download** button once again.



5. When the download window opens, choose the **Run** option.




6. Your computer will now download a file called `SkypeSetup.exe`. This may take a few seconds.




7. When the download finishes, you will see a window asking what you want to do with the file. Again, press the button that says **Run**.



8. A window containing the Skype End User License Agreement will appear. Check the box that says **Yes, I accept the EULA and I have read the Privacy Statement**. Then click **Install**. The Skype files will now be copied to your computer.




9. You will now see the sign-in window, signifying that you have completed the download and installation of the program. If you already have a Skype account, sign in and skip to Chapter 3. If you do not, continue to the next part of the setup, creating a new account.



Creating a New Skype Account

1. Now you will begin the second part of setting up Skype, creating a new account. You will make a user name and a password to log in and use the program. This is the name exclusive to you that you will use to talk to other people in the Skype community. To set up a new account, begin by clicking on the link in the sign-in window that says **Don't have a Skype Name?**



2. When you do this, a new window titled *Create a New Skype Account* will appear. Enter the required information, taking note to remember what you choose to put in *Choose Skype Name* and *Password*. This is the account name you will use to talk to other Skype users, and you need the password to sign into your account. Check the box indicating that you accept the *Skype End User License Agreement* and the *Skype Privacy Statement*. Then hit **Next >**.




3. In the next window, you have the option of entering your e-mail address and country or region and city of residence. This information is optional. If you choose to give your e-mail address, you also have the option of receiving news and special offers from Skype. You may also choose whether or not you want Skype to sign you in automatically when the program is run. When you have finished configuring your preferences, press the **Sign In** button.




4. You should now be successfully logged in to the Skype program. The Skype icon – a white checkmark on a green background – should appear in your system tray to indicate that Skype is connected to the Internet and that you are signed in.




If the Skype icon has a white 'X' on a grey background, please check your Internet connection and make sure that you have signed into Skype.



5. When you sign in, your main Skype window will appear.



6. A Getting Started window will also pop up. Check the box that says **Do not show this guide at startup** and then close the window. Now you have finished the second of the Skype setup process. Please proceed to the last step, making a test call.



Making a Test Call

1. You are on the final part of the Skype setup process. To confirm that Skype works properly, you can make a test call to its automated user, Echo123. This account name is in your `Contacts` tab as **Skype Test Call**. Select the user by single-clicking on it. Then press the green phone to send the call.



2. The automated voice guides you through making the test call by prompting you to record a message and then playing it back to you. On your screen, you should see a tab for the `Skype Test Call`.



3. When the call is finished, you will be brought back to the `Contacts` tab of your Skype window. If you were able to hear your message played back to you, then you have successfully finished setting up Skype.

If you were not able to hear the message you left, there may be something wrong with your computer's audio devices. Please refer to the Skype Web site for help by going to `http://www.skype.com` in your Internet browser.




What is SkyMagic?

SkyMagic is a piece of software that NexoTek created to be used with Skype. It comes in your phone package on a CD and essentially builds the bridge between your phone and Skype, allowing them to work together so you can make Internet calls with the convenience of your phone.

Installing the Software

Before installing, please be sure that Skype is running and you are signed in. You should see the green Skype icon in your system tray.




If you do not know how to set up Skype and sign in, please refer to Chapter 2.


1. Remove the SkyMagic CD from the package and place it into your computer's CD drive. Your Internet browser should open with the SkyMagic window. Click on the option that says **Install SkyMagic Software**.




2. If a window asking you about running the CD on your computer appears, press the **Yes** button.




3. When the download window appears, choose the **Run** option.




4. A security warning may appear. Again, press the **Run** button.



5. When the `Installing SkyMagic` window appears, you may choose where on your computer you want to save the program files. Then click **Next>**.




6. Next, configure your options about how you would like SkyMagic to run. Then click **Next>**.



7. Installation should take a few seconds. When a window telling you that SkyMagic has been installed successfully appears, press the **Finish** button.




8. After you close this window, SkyMagic will begin running automatically, and a window will pop up saying Another program wants to use Skype. Choose the first option that says **Allow this program to use Skype** and then press **OK**. If you accidentally select the wrong option, please see the **Enabling SkyMagic to use Skype** portion of Chapter 7.



9. The SkyMagic icon should appear in your system tray as a red phone on a light green background. You have now completed installation of SkyMagic and can proceed to connect your phone. You may remove the SkyMagic CD from your computer.



If the SkyMagic icon has a red phone on a grey background, please make sure that Skype is running. If not, log in and run the program. If you are logged in to Skype and the background is still gray, please refer to the **Enabling SkyMagic to use Skype** portion of Chapter 7.



10. Please check the NexoTek Web site to obtain the latest version of SkyMagic. Having the most upgraded version of our software will allow you to enjoy the latest features of your phone. For instructions about how to download the most recent version of SkyMagic, see Appendix D.


How do I connect my phone?

Once you have Skype and SkyMagic up and running, you can hook your phone up to your computer. The phone's cord is designed to plug into an open USB port. Connecting your phone will take only a matter of seconds.

1. Take the cord of the phone and make sure it is oriented correctly to plug into an open USB port on your computer. Then carefully insert it into the port.
2. You will see balloons appear near your system tray indicating that your computer has detected the phone and installed the drivers. This is normal. If you have used a NexoTek phone before, the balloons might not appear because the necessary drivers are already installed.



3. Wait until a balloon appears that says **Your new hardware is installed and ready to use.**



4. You will see the SkyMagic icon become a green phone against a light green background.



What should I know before using my phone?

Once your phone is plugged into your computer and has successfully connected to Skype and SkyMagic, you should take some time to briefly learn about the basics of the keypad buttons before using it. This will enable you to make calls with more efficiency and less confusion.

Keypad Buttons



What can I do with my phone?

Before you can use your phone, you must have Skype and SkyMagic installed and running. Make sure you are logged into Skype and your phone is plugged in. Please refer to Chapters 2 through 4 to learn how to set up these programs and connect your phone.

Your phone can make and receive free Skype-to-Skype calls. You can also use your phone to make SkypeOut calls to any phone number in the world at a lower rate than what phone companies charge.

In addition, you can also utilize the hold, call waiting, and mute functions when making Internet calls. You might also like to choose your ring tone and change the face slip.

General Operation

Choosing Your Ring Tone

Your phone comes equipped with five different ring tones, and each one has a loud or soft volume option. If you want to change the ring tone that your phone plays when it is receiving a call, you can do so with the press of a button.

1. On your phone, press the **RING** button. The ring tone that your phone is currently set to will play.
2. Press the same button again to play the phone's different ring tones. When you have found one that you like, simply stop cycling through them.



Changing the Face Slip

The NT-P600S comes with a face slip already attached and one changeable face slip of a different color. This allows you to personalize the phone and give it a stylish look. Changing the face slip is a quick and easy process.

1. Gently remove the phone's current face slip by detaching it first at the top of the phone, then at the bottom.
2. Carefully secure the new face slip by snapping it into place at the top and bottom of the phone.


Making and Receiving Calls


Skype-to-Skype calls are completely free of charge. Making and receiving calls is easy, especially with your NT-P600S because it behaves like your home phone.

Remember that during any call, you can press   to control the phone's volume.

Answering and Refusing Skype Calls






If it is properly connected and if SkyMagic is running, your phone will always ring when you have an incoming Skype call. You then have the option of either answering the phone and talking to the caller, or refusing it if for some reason you do not want to take the call. This simply hangs up on the caller.

Press  to answer the call.

Press  to refuse the call.






Calling From Your Contact List

In order to call someone from your contact list, you must first add his or her Skype name to your contact list. For instructions about how to add Skype users, refer to Appendix A.

1. Press  to open up the Skype window on the computer screen.
2. Press  until you switch to the `Contacts` tab of your Skype window.
3. Scroll with   to select a contact.
4. Press  to place a call to the desired Skype user.


Calling From Your Call History

If you want to call a Skype contact to whom you spoke recently, you can call him or her from your call history rather than having to scroll through all of the people on your contact list.

1. Press  to open up the Skype window on the computer screen.
2. Press  until you switch to the History tab of your Skype window.
3. Scroll with   to select an entry.
4. Press  to place a call to the desired Skype user.

Calling Using Speed Dial


If there are Skype contacts to whom you talk frequently, using speed dial is the most convenient way of calling them. Speed dial works on your phone like it does on a mobile or home phone. To call someone using speed dial, you must first assign him or her a speed dial number. For instructions about how to do this, see Appendix B.

1. Use the **0-9** numbers on your phone to dial the speed dial number of the Skype contact whom you want to call. Your Skype window will open on your computer.
2. Press  to place a call to the desired Skype user.

Making SkypeOut Calls


SkypeOut is a paid service provided by Skype that lets you call any phone number in the world. Because it uses an Internet connection instead of a phone line, long-distance calling rates are significantly lower. You might want to use SkypeOut if your friends do not have Skype, if they are offline, or if you want to save money on your long-distance calls. To buy Skype Credit to make SkypeOut calls, refer to Appendix C.

1. On your phone, use the ***+** button to dial + and then the **0-9** buttons to dial in the country code and phone number you are trying to reach.

If you accidentally dial an incorrect digit, you may press  to erase the number you have input.

2. Press  to send the call.

For example, to call someone in Edinburgh in the United Kingdom with the phone number (123) 456-7890, you would dial +441234567890 as follows:

+	44	1234567890	
	Country Code	Number	

As another example, say you wanted to call someone with the phone number (123) 456-7890 in Taiwan. You would dial +8861234567890 as follows:


+	886	1234567890	
	Country Code	Number	

- ⇒ If you do not know the country code of the number you wish to contact, visit the Skype Dialing Wizard by opening your Web browser and typing `www.skype.com/products/skypeout/rates/dialing.html` in the address bar. This will guide you through making a SkypeOut call.
- ⇒ Even if you are calling someone in the same country or area code region, you still need to dial the country code and full phone number of your SkypeOut contact.

Advanced Features

The Hold Function





If you are talking on Skype but need to put your call on hold because you have something else to do, your phone gives you the option of doing so.

Press  to place your call on hold.

To un-hold your call, press the same button again

The Call Waiting Function

If you are talking on Skype and want to stay on the line but also take an incoming call, your phone gives you the option of doing so with the call waiting function.

1. Press  to take the incoming call. This answers the incoming call and automatically puts your first call on hold.
2. To switch back to the first call, first press  to put the second call on hold.
3. Now press  to switch to your first call. Press  again to take that call off hold. You will now have resumed your original call.

The Mute Function

You may want to mute the phone during a call. This means that the person to whom you are speaking will not be able to hear you until you un-mute the phone.

To mute your current Skype call, press **MUTE** during the call.

To un-mute your phone, press the same button again.

The Normal SkyMagic Icon



If your SkyMagic icon is a dark green phone on a light green background, your phone and the Skype and SkyMagic software are working properly.


SkyMagic Icon Indicators

If your system tray has one of these SkyMagic icons, the program is telling you that there is something wrong with your phone and/ or your Skype connection. Please follow the corresponding instructions to solve the problem.




- ✓ Make sure your phone is properly connected to your computer
- ✓ Check your Internet connection
- ✓ Make sure Skype is running and you are logged in

⇒ If you are already logged in and the gray background persists, see the **Enabling SkyMagic to use Skype** instructions on the next page.



- ✓ Make sure your phone is properly connected to your computer




- ✓ Check your Internet connection
- ✓ Make sure Skype is running and you are logged in


⇒ If you are already logged in and the gray background persists, see the **Enabling SkyMagic to use Skype** instructions on the next page.

Enabling SkyMagic to use Skype


1. Click on **Tools** in your Skype window and go down to **Options**.




2. When that window opens, choose **Privacy** on the left-hand side and then click the **Manage other programs' access to Skype** link.



3. A window titled `Manage API Access Control` will appear. Select `SKYMAGIC.EXE` and press the **Change** button to allow SkyMagic to use Skype.



4. Another window will pop up asking you to choose what to do with `SKYMAGIC.EXE`. Choose the first option that says **Allow this program to use Skype** and then press **OK**.




5. Click the **OK** button in the remaining open windows and the **Save** button in the `Skype Options` window. The SkyMagic icon in your system tray should now have a light green background. This indicates that Skype and SkyMagic have made a successful connection.

Your Computer Audio Settings


If your phone is working properly, you should be able to make Skype calls at the same time other sounds are coming from your computer. This means that if you are listening to music, watching movies, or playing games on your computer, the sounds from those activities should be coming from your speakers, and you can simultaneously have a Skype call on your phone.

How do I stop sounds from my music, movies, and games from coming through the phone?


1. Go to the **Start** menu of your computer and click on **Control Panel**.



2. Double-click on the **Sounds and Audio Devices** icon.




3. Under the **Audio** tab in the window that appears, set **Sound playback** and **Sound recording** to your computer's sound card, not the USB audio device. Then press **OK**. The problem should be solved.




When I make calls, my friend's voice comes from my computer, not my phone. How do I fix this?

1. In your Skype window, click on **Tools** and then go down to **Options**.



2. In the Options window, choose **Sound Devices** on the left side. Where you see Audio In, Audio Out, and Ringing, change the setting to **USB Audio Device**. Then click the **Save** button. The problem should now be solved.



Contacting NexoTek

If for some reason you are not entirely satisfied with your NexoTek product or have further questions or comments to share, please do not hesitate to contact us.

United States

Address: NexoTek
1212 John Reed Court
City of Industry, CA 91745

E-mail: support@nexotek.com

Web site: www.nexotek.com

China

Address: NexoTek Ji-Da International
Suite 1102 #807
Zhao Jia Bang Road
Shanghai 200032

Tel: 86-21-64278437

Fax: 86-21-64274571


E-mail: chinasales@nexotek.com

Appendix A: Managing Skype Contacts


In order to talk to people through Skype, you need to add their user names to your list of contacts. This keeps your contacts organized, and when you are logged in, it allows you to see whether or not your friends are online and able to talk to you. You can also delete contacts from your list if you no longer speak to them.

Adding a Skype Contact

1. If you are not already logged into Skype, run the program and sign in with your user name and password. You should see the main Skype window. Click on the button in the upper left corner that says **Add Contact**.



2. A window titled `Add a Contact` will appear, asking for the Skype name, full name, or e-mail address of the person you would like to add. Enter the appropriate information that you know about the contact you want to add. Then press **Search**.




3. Multiple results may appear when you search. Select the correct contact by single-clicking on his or her row and press the button that says **Add Selected Contact**.



4. You then have the option of sending a greeting message to the contact. Write something if you desire, then press **OK**. You may close the Add a Contact search window.




5. Now that Skype user has been added to your contact list and should appear on your **Contacts** tab. This contact must authorize you to view his or her information before you can call him or her.




Removing a Skype Contact

1. To remove a Skype user from your contacts list, make sure you are on the **Contacts** tab of the Skype window. Find the user you want to remove from the list and right-click on his or her name. Go down to **Remove from Contacts**.



2. Press the **Remove** button when a window titled **Remove Contact?** appears.




Appendix B: Assigning a Speed Dial Number

Speed dial works on Skype like it does on a home or mobile phone and is especially helpful if you make frequent Skype calls. Before assigning a speed dial number to a Skype user, he or she must be on your contacts list. Please refer to the Appendix A for instructions about adding Skype contacts.


1. When you are logged into Skype, go to the **Contacts** tab in the main Skype window. Right-click on the name of the user whom you want to place on speed dial and go down to **Set Speed-Dial**.



2. When the window titled `Set Speed Dial Number` appears, enter the number you would like to assign to that contact. It must be a number between 1 and 99 Then press **OK**.




3. Now, when you look at your Skype Contacts tab, you should see the speed dial logo – a small lightning bolt – and the speed dial number across from your contact's name.



Appendix C: Purchasing Skype Credit

In order to use the SkypeOut service, which lets you call any phone number in the world from your computer, you first have to purchase Skype Credit. This is done on the Skype Web site.

1. Open your Internet browser and type `http://www.skype.com` into your address bar. Then press your **Enter** key. This brings you to the Skype home page.



2. Scroll down the page. On the left side, you will see a button that says **Buy Skype Credit**. Click on this link.

Calling international phones - SkypeOut


Use Skype to call regular phones. Calls to Japan are free on this weekend, but SkypeOut rates are low all year round. SkypeOut rates to phones in Japan:

- 2.3¢ per minute to fixed lines in Japan.
- 15.4¢ per minute to cell phones in Japan.

[See rates to all countries](#)
[Learn more about SkypeOut](#)

 **Buy Skype Credit**

- The Skype site will ask you to sign in. Do this by entering your Skype user name and password, then pressing **Sign me in**.



Sign in


i You need to sign in with your Skype Name to continue.

If you don't have Skype you can [download it here](#).


Skype Name
joe.friday

Password
●●●●●●●●

Sign me in

 **Secure**
▪ Quick and easy
▪ Manage your account
▪ Change your settings


- Proceed through the Skype Credit purchasing process by accepting the amount of Skype Credit. Click on the **Buy this** link.



Select an amount of Skype Credit

Amount → Address & Credit Card → Details & Confirmation → Complete

Skype Credit \$10

 **Buy this**

This amount of credit could get you almost 7 hours of calls to landlines worldwide*.
Or, you could opt to use the credit to get Skype Voicemail or send text messages as well as calls.

* Call duration amounts will differ depending on location and whether the call is made to a landline or a mobile phone.

Credit balance expires after 180 days of inactivity. See [Terms of Service](#) for information.

5. On the next page that loads, enter your e-mail address and Skype password at the top of the page. Then you may change the currency that you plan to use to pay for your Skype Credit if desired.

soft Internet Explorer

://secure.skype.com/store/buy/register.html

Welcome back, joe.friday! Buy Skype Credit | Your account | Sign out

Amount — Address & Credit Card — Details & Confirmation — Completed Order

Personal Information

Your details

Email address *
joe.friday@mail.com

Skype password *
●●●●●●●●

Change currency

American Dollar Euro

Japanese Yen British Pound

6. When you go down to the bottom of the Web page, check the box that says **I agree to the Skype Terms of Service** and click the **Submit** button.

Terms of Service

IMPORTANT — PLEASE READ CAREFULLY


Before reading the articles below, please note the following preliminary terms, which use some of the definitions specified in Article 1 below:

Entering into this agreement: These Terms of Service apply to the agreement between Skype Communications S.A. and You, as a user, for the use of the VoIP service. You must enter into this Agreement by clicking on the ACCEPT button in order to use the VoIP service. Furthermore, by using Your Account and the VoIP service You agree to be bound by these

I agree to the Skype [Terms of Service](#) *


* Indicates a required field

7. You will then be asked for your billing address. Fill in the appropriate information.



The screenshot shows a web browser window displaying the Skype billing address form. The browser's address bar shows a URL starting with 'secure.skype.com/store/buy/address.html'. The page header includes the Skype logo, a welcome message 'Welcome back, joe.friday!', and links for 'Buy Skype Credit', 'Your account', and 'Sign out'. A progress bar indicates the current step is 'Address & Credit Card'. The main heading is 'Billing name and address', followed by instructions to choose an existing address or create a new one. The form fields are: 'New address' (text input), 'First name *' (text input with 'Joe'), 'Last name *' (text input with 'Friday'), 'Address *' (text input with '4321 Easy St.'), 'Zip/postal code *' (text input with '19106'), 'City *' (text input with 'Philadelphia'), 'State/Province *' (text input with 'PA'), and 'Country/Region *' (dropdown menu with 'United States'). There is also a 'Name this address' field and a note to 'Choose a name you can recognize again.' At the bottom, there are two buttons: 'Save and use it now' and 'Use this address only once'.

8. Next, select your payment method. This is how you will pay for the Skype Credit that you are purchasing. When you have chosen, press the **Continue** button.




The screenshot shows the 'Select your payment method' screen. The title is 'Select your payment method'. There are four radio button options: 'PayPal. Buy your Skype services with PayPal – the safe, fast and easy way to pay online.' (with a PayPal logo), 'Regular Bank Transfer' (with a bank icon), 'With Click&Buy you can use your credit or debit card, or set up a direct debit from your checking account to buy quickly and securely.' (with a Click&Buy logo), and 'Moneybookers' (with a Moneybookers logo). Below these are two more radio button options: 'Eurocard/Mastercard' (with a Eurocard/Mastercard logo) and 'Visa credit card' (with a Visa logo). The 'Visa credit card' option is selected. At the bottom, there is a 'Continue' button and an 'Important!' note: 'You can only purchase services for one Skype Name with one credit card. Further payments for another Skype Name with the same credit card will be rejected and funds will be returned to your credit card. [Read more.](#)'

9. Depending on your payment method, you will finish your purchasing by entering further personal information such as your name, address, credit card number, etc. Now you have successfully purchased Skype Credit and can make SkypeOut calls.


Appendix D: Updating SkyMagic

In order for you to enjoy the full features of your phone, you will want to make sure that you have the latest version of SkyMagic. Checking your SkyMagic version takes a few clicks of your mouse. If in doing so you find that NexoTek has a more recently updated version, you can download it from our Web site.

1. To check your SkyMagic version, you do not have to have Skype or SkyMagic running. Simply find the SkyMagic icon in your system tray and right-click on it. Then go to **About**.



2. In the window that appears, you will see it say the SkyMagic version you have.



3. Now, you need to see if NexoTek has released a newer version. Do this by typing `http://www.nexotek.com/download.html` in your Internet browser and pressing **Enter**.



4. On the Web page that loads, you will see the latest version of SkyMagic that NexoTek has made available for download.

Software Downloads


In order to enjoy the full features of your phone, you will want to have the latest version of NexoTek's software.

You can download the software for Skype, MSN Messenger, and VoipBuster here. Be on the lookout as we update our phones to support even more instant messaging programs!

For Skype

Name	Version	Date	Notes
SkyMagic for Windows	3.0.0.28	8.02.2006	Support All Model
SkypeMate for Mac OS X	1.0.0.9b	5.26.2006	Support P100M, P500, P600S, W1000
SkypeMate for Linux	1.1.0.01	9.28.2005	Fedora Core 3, Support P100M & P600S

5. If this version matches the version of SkyMagic that you have, then you do not need to update your software. You may stop reading. If this is a higher version than you have, you will want to download it. Begin the download by clicking on the version link. When a download window appears, press **Open**.




6. After you wait a few seconds, a window will appear with the SkyMagic program. The icon will say *SkyMagic* and its version number. Double-click on this icon.




7. When a security warning window comes up, choose **Run**.



8. Your computer will let you choose where you want to save the SkyMagic files. When you have made a decision, click **Next>**.



- Installation should take a few seconds. When a window telling you that SkyMagic has been installed successfully appears, press the **Finish** button.



- Now your computer will prompt you to restart in order for the installation to be complete. Click **Yes**, and after your computer restarts, you will be able to use the latest version of SkyMagic.

