

# SPD-3750T/3750/3700T/3700/3350/3310/2510 Speed Dome Camera Accessories Installation Manual

STH-380PO/STH-370PO/STH-360PO STH-370PI/STH-370PE STB-370PC/STH-270PWV/STB-496PPV STB-25PF/STB-30PF/STB-350PPM STB-330PPM/STB-340PCM/STB-270B

### **Cautions and Warnings for Use**

### **Table of Contents**



Samsung Techwin cares for the environment at all product manufacturing stages to preserve the environment, and is taking a number of steps to provide customers with more environment-friendly products. The Eco mark represents Samsung Techwin's will to create environment-friendly products, and indicates that the product satisfies the EU RoHS Directive.

Thank you for purchasing our products.

This product is to be used for the installation of the Samsung Speed Dome Camera series: SPD-3750T, 3700T, 3750, 3700, 3350, 3310, and 2510.

Before installation, please read the user's manual carefully.

- Note that you need to carefully read all contents related to safety and application methods before installation.
- When using the product, the cautions/warnings, usage directions, operating methods, and instructions must all be observed.
- The power and cable connections should be made by a product installation specialist.
- Do not connect and use these accessories to products other than the Samsung Speed Dome Camera Series.
- The locations for installing the accessory housing should be strong enough to fully secure the accessories. All installations need to be carried out by experienced engineers.
- Do not use it for purposes other than the installation mentioned above.
- For product inquiries, please contact the retail shop where you bought the camera. The
  use of equipment such as an aerial ladder while providing after-sales service shall be at
  your expense.

1 Product Catagony	
1. Product Category	. 4
1.1. Housing Accessories	- 4
1.2. Interface Mounting Accessories	. 5
1.3. Mounting Bracket Accessories	. 5
2. Speed Dome Camera Installation Category	
3. Pendant Type Installation	
3.1 Wall Mount Type Installation	
* Camera Wiring Diagram	12
3.2 Ceiling Mount Type Installation	15
3.3 Indoor Flange Mount Type Installation	17
4. On-Ceiling Mount Type Installation	21
5. Indoor Flush Mount Type Installation	25
6. Mounting Accessory Installation	30
	30
Product External Dimensions	24
Product External Dimensions	34
Product External Dimensions  Product Specification	34 36
Product Specification	
Product Specification  Contents By Product Model	36
Product Specification  Contents By Product Model STH-380PO	36
Product Specification  Contents By Product Model STH-380P0 STH-370P0	36
Contents By Product Model STH-380P0 STH-370P0 STH-370P1	36 8
Contents By Product Model STH-380P0 STH-370P0 STH-370P1 STH-370PE	36 8 8 25
Contents By Product Model STH-380P0 STH-370P0 STH-370P1	36 8 8 8
Contents By Product Model  STH-380P0  STH-370P0  STH-370P1  STH-370PE  STH-360P0	36 8 8 8
Contents By Product Model STH-380P0 STH-370P0 STH-370P1 STH-370PE STH-370PE STH-370PO STH-370PO	36 8 8 8
Contents By Product Model  STH-380P0  STH-370P0  STH-370PI  STH-370PE  STH-360P0  STH-270PWV  STB-496PPV	36 8 8 8 8 8
Contents By Product Model  STH-380PO STH-370PO STH-370PE STH-370PE STH-270PWV STB-496PPV STB-370PC STB-350PPM STB-340PCM	36 8 8 8 8 8 8 8
Contents By Product Model  STH-380PO STH-370PO STH-370PE STH-370PE STH-370PE STH-270PWV STB-496PPV STB-370PC STB-350PPM STB-340PCM STB-330PPM	36 8 8 8 8 8 8 8 8
Contents By Product Model  STH-380P0 STH-370P0 STH-370PI STH-370PE STH-360P0 STH-270PWV STB-496PPV STB-370PC STB-350PPM STB-340PCM STB-330PPM STB-330PPM	36 8 8 8 8 8 8 8 8 8 8 8 8
Contents By Product Model  STH-380PO STH-370PO STH-370PE STH-370PE STH-370PE STH-270PWV STB-496PPV STB-370PC STB-350PPM STB-340PCM STB-330PPM	36 8 8 8 8 8 8 8 8 8 8 8 8

### **Product Category**

### ■ 1. Product Category

#### ■ 1.1. Housing Accessories

# STH-380PO/STH-370PO/STH-360PO

: "Outdoor housing" with a built-in install base for the Samsung Speed Dome Camera.

STH-380PO:

Ultra Low-Temperature Heavyweight(-40°C~50°C)

STH-370PO:

Low-Temperature Heavyweight(-20°C~50°C)

STH-360PO:


Low-Temperature Lightweight(-20°C~50°C)



: "Indoor Housing" with a built-in install base for the Samsung Speed Dome Camera.




: "Indoor Flush Mount" with a built-in install base for the Samsung Speed Dome Camera.










#### ■ 1.2. Interface Mounting Accessories




: "On-Ceiling Install Base Mount" for the Samsung Speed Dome Camera.



#### ■ 1.3. Mounting Bracket Accessories




:This "Wall Type Mount" is used for the installation of STH-380PO,STH-370PO,STH-360PO,STH-370PI and STB-25PF of the Samsung Speed Dome Camera.




# STB-496PPV

: This "Ceiling Type Mount" is used for the installation of STH-380PO,STH-370PO,STH-360PO,STH-370PI and STB-25PF of the Samsung Speed Dome Camera.



# STB-25PF

:This "Indoor Flange" for the Samsung Speed Dome Camera is useful to install the camera without a housing.





: "Ceiling Type Flange" for the Samsung Speed Dome Camera.



: Parapet Mount" for the installation of indoor or outdoor housing of Samsung Speed Dome Camera



: "Pole Mount" for the Samsung Speed Dome Camera.





: "Corner Mount" for the Samsung Speed Dome Camera.




: "Setup Box" for the Samsung Speed Dome Camera.














### ■ 2. Speed Dome Camera Installation Category


### Pendant Type








#### **On-Ceiling Mount Type**




### **Indoor Flush Mount Type**



### ■ 3. Pendant Type Installation

■ 3.1 Wall Mount Type Installation


STH-380P0/370P0/370PI/360P0



STH-270PWV

#### 1. Securing Wall Bracket and Wiring

As shown in the picture, secure the wall bracket to the wall, and then pull the wires out of the bracket. Please note that the STH-380PO housing requires an additional installation of the fan heater adapter enclosed with the product.



\* To store the adaptor, the STB-270B Setup Box (Page 31) can be used.




#### **Notes**

- Do not connect the camera to a power outlet until the installation is complete. Supplying power in the middle of the installation may cause fire or damage the product.
- STH-370PO requires an additional installation of the fan heater adapter enclosed with the product. Connecting the fan heater to a power outlet used for the camera can cause fire or accidents.


#### 2. Preparing Housing

Open the hinged door at the bottom of the housing. Hold the knob on the hinged door to open.



#### 3. Connecting Housing and Bracket

To prevent the housing from falling down during the installation process, hook the safety cable on the bracket loop as shown in the picture.




### Notes

- The STH-380 housing's fan heater connector must be connected to its dedicated adapter enclosed with the product.
- Make sure to hook the safety cable on the bracket loop before connecting the housing.
- Neglecting this caution may expose you to injury caused by a fallen housing.


#### 4. Assembling Housing and Bracket

After hooking the safety cable, fit the housing into the fixture grooves on the bracket as shown in the picture. When attaching, locate the "Samsung" logo on the housing facing the center front.




#### 5. Securing Housing

Check if the housing is properly attached to the bracket, secure the housing to the bracket with the enclosed screws.



#### **6. Wiring Terminal Cables**

Connect the cables to the terminal block on the hinged door. Once the wiring is successful, close the hinged door.





\* For the location of the wiring pins, please refer to the "Camera Wiring Diagram" on the next page.

#### \* Camera Wiring Diagram

STH-380P0/370P0/370P1/360P0

This wiring diagram indicates the connection between the interface board and external equipment. For wiring Samsung Techwin's Speed Dome Camera and the accessories, please refer to the Speed Dome Camera user's manual.






**Control Signal Connection** 

### **Notes**

- The maximum capacity of the alarm and AUX output terminals is DC30V 2A.
- Connecting the power connector and GND incorrectly to the NC/NO and COM ports can cause a short circuit which may lead to fire and damage the camera.


#### 7. Preparing Camera

Once the camera wiring is successful, prepare the camera. Every housing-typed camera except the flush model is provided with a dome cover first detach the dome cover from the camera.




#### 8. Setting Up Camera DIP Switches


DIP switches for communication and ID protocols are located on the bottom of the camera. For the switch settings, refer to the appendix of this manual.



#### 9. Connecting Camera Safety Cable and Attaching Camera

Carefully attach the camera to the mount following the alignment guide marks as shown in the picture. First hook the camera's safety cable on the mount, and then attach the camera. The safety cable is coiled inside the install base. As shown in the leftward picture, pull out the safety cable from the install base and then hook it to the mount.






\* To attach the camera to the mount, refer to the alignment guide marks as shown in the picture.



• Make sure to first hook the camera's safety cable to the mount before proceeding. Otherwise you may be exposed to serious injury caused by a fallen camera.

STH-380P0/370P0/370PI/360P0

- \* To attach or detach the camera, refer to the picture.
- \* Attaching the camera: Hold up the camera and push it to the mount as shown in the picture. Push the camera until you hear a "click".
- \* Detaching the camera: To detach the camera, pull the camera downward while pushing the unlock buttons on the camera upward.




#### 10. Assembling Dome Cover

Once the camera is successfully attached, secure the mount with the transparent dome cover. Next, turn on the power.

#### 11. Dome Cover Setting


Once the installation is complete, please optimize the camera focus settings. On the camera's OSD Menu, set the Dome Cover setting to Outdoor. (Directory: Main Menu/Camera Setting/Others)






#### ■ 3.2 Ceiling Mount Type Installation

This guideline is based on the installation of the ceiling flange STB-30PF.



STH-380PO STH-370PO STH-360PO STH-370PI STB-496PPV STB-30PF



#### 1. Preparing Pipe and Ceiling Bracket

STB-30PF requires a SPSS32A/SCH40-sized pipe as shown in the picture. Assemble the screw taps, and then wind a sealing tape around the screw barrel to prevent water leakage. Please note that the STH-380PO housing requires an additional installation of the fan heater adapter enclosed with the product.



STH-380P0/370P0/370P1/360P0

#### **Notes**

• Using unsealed screw taps can cause the product to fall down or allow water leakage that may lead to fire or damage the product. Sealing tape is not enclosed with the product, and needs to be purchased at your expense.

#### 2. Assembling STB-30PF and Pipe

After sealing the screw taps, assemble the STP-30PF flange securely to the pipe.




#### Notes

• Do not connect the camera to a power outlet until the installation is complete. Supplying power in the middle of the installation may cause fire or damage the product.

\* For the next installation procedures, refer to the "Wall Type Housing" installation from step 2.

#### ■ 3.3 Indoor Flange Mount Type Installation

This guideline is based on the installation of the indoor flange STB-25PF and the ceiling exposed mount STB-370PC.




STB-370PC STB-30PF STB-25PF STB-496PPV STB-30PF

### **Pendant Type Installation**

#### 1. Assembling Flange and Ceiling Exposed Mount (STB-370PC)


Wind sealing tape around the barrel of the screw taps, and then secure the STP-25PF flange securely to the mount with the enclosed screws.



#### 2. Opening Hinged Door


STH-380P0/370P0/370PI/360P0


Open the hinged door at the bottom of the housing. Hold the knob on the hinged door to open.



#### 3. Assembling Mount and Flange

First hook the safety cable on the mount, and then fit the housing into the fixture groove on the bracket as shown in the picture. Once the housing is safely attached to the bracket, secure the housing with the enclosed screws.








#### **Notes**

• Do not connect the camera to a power outlet until the installation is complete. Supplying power in the middle of the installation may cause fire or damage the product.

#### 4. Wiring Terminal Cables


Connect the cables to the terminal block on the hinged door. Once the wiring is successful, close the hinged door.



\* For the location of the wiring pins, please refer to the "Camera Wiring Diagram" on Page 12.

#### **5. Setting Up Camera DIP Switches**


DIP switches for communication and ID protocols are located on the bottom of the camera. For the switch settings, refer to the appendix of this manual.



### **Pendant Type Installation**

#### 6. Attaching Camera

Carefully attach the camera to the mount following the alignment guide marks as shown in the picture. First hook the camera's safety cable on the mount, and then attach the camera. The safety cable is coiled inside the install base. As shown in the leftward picture, pull out the safety cable from the install base and then hook it to the mount.




\* To attach the camera to the mount, refer to the alignment guide marks as shown in the picture.




#### Notes

- Make sure to first hook the camera's safety cable to the mount before proceeding. Otherwise you may be exposed to serious injury caused by a fallen camera.
- \* To attach or detach the camera, refer to the picture.
- \* Attaching the camera: Hold up the camera and push it to the mount as shown in the picture. Push the camera until you hear a "click".
- \* Detaching the camera: To detach the camera, pull the camera downward while pushing the unlock buttons on the camera upward.



### ■ 4. On-Ceiling Mount Type Installation


This guideline is based on the installation of the indoor flange STB-370PC.



STB-370PC


#### 1. Attaching Template and Installing STB-370PC

Attach the enclosed template to the ceiling, then drill a hole in the ceiling according to the diameter marked on the template. Drop the camera cables down from the ceiling through the hole. Next, install the Install Base STB-370PC to the ceiling as shown in the picture. Before installing the exposed bracket, open the hinged door at the bottom of the bracket as shown in the picture. Hold the knob on the hinged door to open.



#### 2. Wiring Terminal Cables

Connect the cables to the terminal block on the hinged door. For the location of the wiring pins, please refer to the "Camera Wiring Diagram" on Page 12. Once the wiring is successful, close the hinged door.




### 4

#### **Notes**

• Do not connect the camera to a power outlet until the installation is complete. Supplying power in the middle of the installation may cause fire or damage the product.


#### 3. Setting Up Camera DIP Switches


DIP switches for communication and ID protocols are located on the bottom of the camera. For the switch settings, refer to the appendix of this manual.



#### 5. Connecting Camera Safety Cable and Attaching Camera

Carefully attach the camera to the mount following the alignment guide marks as shown in the picture. First hook the camera's safety cable on the mount, and then attach the camera. The safety cable is coiled inside the install base. As shown in the leftward picture, pull out the safety cable from the install base and then hook it to the mount.





\*To attach the camera to the mount, refer to the alignment guide marks as shown in the picture.




#### Notes

• Make sure to first hook the camera's safety cable to the mount before proceeding. Otherwise you may be exposed to serious injury caused by a fallen camera.

22 SPI


## **On-Ceiling Mount Type Installation**

- \* To attach or detach the camera, refer to the picture.
- \* Attaching the camera: Hold up the camera and push it to the mount as shown in the picture. Push the camera until you hear a "click".
- \* Detaching the camera: To detach the camera, pull the camera downward while pushing the unlock buttons on the camera upward.



### ■ 5. Indoor Flush Mount Type Installation

This guideline is based on the installation of the flush mount STH-370PE.




STH-370PE

### **Indoor Flush Mount Type Installation**

### **Indoor Flush Mount Type Installation**

#### 1. Attaching Flexible Adaptor

To feed the cables through a pipe to a flush housing, attach the flexible adaptor enclosed with the product. To attach the flexible adaptor, the install base must be disassembled as shown in the picture. To disassemble the install base, unscrew the 3 screws on the bottom.




#### 2. Attaching Template

**STH-370PE** 

Attach the enclosed template to a desired location on the ceiling. Drill 3 holes of 50 mm diameter in 120-degree intervals following the marks on the template, and then drill one 200 mm hole in the center of the template.

#### 3. Wiring and Arranging Anti-fall Eyebolts

Attach the enclosed turnbuckle and eyebolts inside the ceiling, and then drop the camera cables down from the ceiling through the hole.




Notes

• Do not connect the camera to a power outlet until the installation is complete. Supplying power in the middle of the installation may cause fire or damage the product.


#### 4. Preparing Housing

Open the hinged door at the bottom of the housing. While pressing the spring lock (1), hold up the lid to open (2).



#### 5. Inserting the flush housing


Arrange the cables and eyebolts as shown in the picture, and then insert the housing into the ceiling hole.



#### 6. Securing Screws or Internal Supports

Two fixture methods are available for the flush mount: screw through or inner support. Depending on the situation, select one of the two methods.

The inner support method unfolds the supports inside the mount when 3 screws on the mount surface are fastened.




STH-370PE

#### 7. Arranging Camera Cables and Closing Hinged Door


Connect the cables to the terminal block on the hinged door.

For the location of the wiring pins, please refer to the "Camera Wiring Diagram" on Page 12. Once the wiring is successful, close the hinged door.



#### 8. Setting Up Camera DIP Switches


DIP switches for communication and ID protocols are located on the bottom of the camera. For the switch settings, refer to the appendix of this manual.




#### 9. Attaching Camera

**STH-370PE** 

Carefully attach the camera to the mount following the alignment guide marks as shown in the picture. First hook the camera's safety cable on the mount, and then attach the camera. The safety cable is coiled inside the install base. As shown in the leftward picture, pull out the safety cable from the install base and then hook it to the mount.






\*To attach the camera to the mount, refer to the alignment guide marks as shown in the picture.

#### **Notes**

 Make sure to first hook the camera's safety cable to the mount before proceeding. Otherwise you may be exposed to serious injury caused by a fallen camera.

#### 10. Assembling Dome Cover


Once the camera is successfully attached, secure the mount with the transparent dome cover.



#### **Notes**

• Be careful to not scratch the transparent cover during the assembly. Scratched dome covers may decrease the graphics quality and overall performance of the camera.


- \* To attach or detach the camera, refer to the picture.
  - \* Attaching the camera: Hold up the camera and push it to the mount as shown in the picture. Push the camera until you hear a "click".
  - \* Detaching the camera: To detach the camera, pull the camera downward while pushing the unlock buttons on the camera upward.





#### SPEED DOME CAMERA ACCESSORIES


### ■ 6. Mounting Accessory Installation

This guideline is to be used for the installation of mounting accessories for the Samsung Speed Dome Camera series.











### ■ STB-270B(Setup Box)


- 1. Using self drilling screws, secure the install bracket.
- 2. Fill unwanted wire holes with mount caps. Secure the mount cap with the mount cap fastener.




3. Place the setup box on the install bracket as shown in the picture.




4. Using hexagon bolts, fasten the setup box to the bracket. Next feed the camera cables into the setup box through the hole in the cover.




- 5. Feed the camera cables through the wall bracket and secure the bracket using 4 screws.
- 6. Lastly, fasten the screws using a hexagon wrench to secure the bracket to the setup box.





### ■ STB-330PPM (Paul Mount)


Compatible Models: STB-270PWV+STH-380PO/370PO/360PO/370PI




- 1. Secure the pole to the mount using a wire or cable.
- 2. Use 4 1/4" screws to secure the STH-270PWV pole mount to the wall.

### ■ STB-340PCM (Corner Mount)

Compatible Models: STB-270PWV+STH-380PO/370PO/360PO/370PI




- 1. Drill 8 anchor bolt holes on the wall according to the holes in the corner mount.
- 2. Using a tool, insert anchor bolts and then set the corner mount on the bolts. Use 8 nuts to fasten the bolts.




3. Use 1/4" screws to secure the STH-270PWV to the corner.

### ■ STB-350PPM (Parapet Mount)


Compatible Models: STB-30PF+STH-380PO/370PO/360PO/370PI



- 1. Drill 8 anchor bolt holes on the wall according to the holes in the parapet mount.
- 2. Using a tool, insert anchor bolts and then set the parapet mount on the bolts. Use 8 nuts to fasten the bolts.




- 3. Feed the cable through the pipe to the other end of the pipe.
- 4. Set PPE on the parapet mount.




- Wind the cable to the direction shown in the picture, and then assemble the PPE cover using screws.
- 6. Adjust the pipe direction, and then secure the pipe using screws.
- 7. Install the camera.

Unit: mm


### **■** Wall Mounting




### **■** Ceiling Mounting



### **■** Ceiling Exposed Mounting



### **■ Indoor Flush Mounting**



Unit: mm


# **Product Specifications**

# **Product Specifications**

Model	CTU 3	9000	CTU 2	7000	CTIL	27001	CTIL 2	7005	CTU 3	econo.
Item	51H-3	880PO	51H-3	370PO	51H	370PI	STH-3	7UPE	51H-3	860PO
Operating Temperature Range	-40℃	~50℃	-20℃	~50℃	-10℃		-10℃		-20℃~50℃	
Humidity	0 to 9	0%RH	0 to 9	0%RH		0%RH idensing)	1 to 90 (non-con		0 to 9	0%RH
Materials	Housing Outdoor	ALDC 12	Housing Outdoor	ALDC 12	Housing Outdoor	ALDC 12	Embedded Housing	E.G.I (1.2t)	Housing Outdoor	AL
	Ring Decoration	ALDC 12	Ring Decoration	ALDC 12	Ring Decoration	ALDC 12	Ring Decoration	ABS	Ring Decoration	ALDC 12
	Dome Cover	Poly Carbonate	Dome Cover	Poly Carbonate	Dome Cover	Poly Carbonate			Dome Cover	Poly Carbonate
							SAFETY WIRE (1EA)	SUS (Ф1.2x 2000)	-	-
Components (mm)	-	-	-	-	-	-	Turn Buckle1EA	Eye Bolt 2EA		
							WIRE JOINT(4EA)	-		
							Silicon cap(1EA)	-		
Miscellaneous	Fan(2EA)	DC12V 0.06A Operating Temp More than 45°C Less than 10°C	Fan(2EA)	DC12V 0.06A Operating Temp More than 45°C Less than 10°C	-	-	-	-	Fan(1EA)	DC12V 0.06A Operating Temp More than 45°C Less than 10°C
	Heater	AC 24V 46W Operating Temp less than 10°C	Heater	AC 24V 33W Operating Temp less than 10°C	-	-	-	-	Heater	AC 24V 33W Operating Temp less than 10°C
Antivibration/ Waterp roof	IP 67		IP 67		IP 67		-		IP 66	
Weight (Net)	3.2kg		3.2kg		3.2kg		740g		2.1kg	
Weight (Gross)		²kg	4.2kg		4.1kg		1.2kg		3.2kg	
Dimensions (mm)	Ф 242	x284.5	Ф 242	x284.5	Φ 242x284.5		Ф 190x188.5		Φ 242x284.5	

Model Item	STH-27	70PWV	STB-4	96PPV	STB-3	70PC	STB-	25PF	STB-270B	
Operating Temperature Range	-40℃	~50℃	-40℃	~50℃	-10℃	-50℃	-10℃	~50℃	-40℃~50℃	
Humidity		0%RH idensing)	0 10 5	0%RH idensing)	0 to 90 (non-con	, , , , , , , ,		0%RH densing)	1 to 90%RH (non-condensing)	
	Wall Type	ALDC 12	Ceiling Flange	ALDC 12	On-Ceiling Installation	ALDC12	Housing Flange	E.G.I 2.0t	DOOR FRONT	ALDC 12
Materials Components	Mount	ALDC 12	Ceiling Pipe	SPPS32A /SCH 40	COVER	PC+ABS	Adaptor Housing	AL	BASE HOUSING	ALDC 12
(mm)	Ceiling	E.G.I. 2.0t	Ceiling Bracket	E.G.I. 2.0t	COVER	PC+ABS	Ceiling	SUS	INSTALL BRACKET	C.R.2.0t
	Bracket	E.G.I. 2.0t	Ceiling Plate	SPCC	COVER	rctabs	Support		JOINT MOUNT	1EA
Miscellaneous	Screw (4EA)	Self Drilling Screw #8xL38 (FZY)	Screw (4EA)	Self Drilling Screw #8xL38 (FZY)	Screw (3EA)	BH MS M3xL6	Screw (3EA)	PH MS M4x8 SUS	MOUNT CAP	5EA
	Screw (3EA)	PH MS M4xL14	Screw (3EA)	PH MS M4xL14					Hexagon Bolt	4EA
Antivibration/ Waterproof									Screw (6EA)	#8x38 (FZY)
Weight (Net)		-		-	-			-	-	
Weight (Gross)	1.3	Bkg	1.8	Bkg	935g		420g		3kg	
Dimensions (mm)	1.3	Bkg	21	kg	1.4kg		490g		3.3kg	
Operating Temperature Range	270x1	75x140	150	x496	Φ183	x48.5	183	х37	218x18	32x92.5

Model Item	STB-	30PF	STB-340PCM		STB-33	ОРРМ	STB-350PPM		
Operating Temperature Range	-40℃	~50℃	-40℃	~50℃	-40℃	-50℃	-40°C~50°C		
Humidity	0 to 90%RH (non-condensing)		0 to 90%RH (non-condensing)		0 to 90%RH (non-condensing)		0 to 90%RH (non-condensing)		
Materials Components (mm)	Ceiling Flange	ALDC 12	Corner	SPCC	Pole Bracket	SPCC	Parapet Pipe	PF 1 1/4 (32A)	
	Ceiling Bracket	E.G.I. 2.0t	Bracket						
							Parapet Plate	SUS	
							Pipe Cover	SUS	
na' II	Screw (3EA)	PH MS M4xL14	Screw (4EA)	1/4"	Screw (4EA)	1/4"	Set Anchor-6 (8EA)	1/4"	
Miscellaneous			Set Anchor-6 (8EA)	1/4"			Screw (2EA)	M16x20(SUS)	
Antivibration/ Waterproof							Screw (2EA)	PH MS M13x10(SUS)	
Weight (Net)	-		-		-		-		
Weight (Gross)	380g		1.3kg		580g		8kg		
Dimensions (mm)									
Operating Temperature Range	126x66		306x194x185		185x155x48		680x930x63		



### **SAMSUNG TECHWIN**



#### **SALES NETWORK**

#### • SAMSUNG TECHWIN CO.,LTD.

145-3, Sangdaewon-dong, Jungwon-gu, Seongnam-si, Gyeonggi-do, 462-120, Korea TEL: +82-31-740-8151~8 FAX: +82-31-740-8145

#### · SAMSUNG TECHWIN AMERICA.LTD.

1480 Charles Willard St. Carson, CA 90746, UNITED STATES TEL: +1-310-632-1234 FAX: +1-310-632-2195

#### · SAMSUNG OPTO-ELECTRONICS UK,LTD.

Samsung House, 1000 Hillswood Drive, Hillswood Business Park Chertsey Surrey KT16 OPS

TEL:+44-1932-45-5308 FAX:+44-1932-45-5325