

\$3.00



July 1981


No. 1


TABLE OF CONTENTS

Contributing to Micro Cornucopia	3
Power to the Big Board	4
Ram Protection Circuit.....	6
Video Wiggle.....	6
Disk Formatter & Listing.....	7
PFM-80 Monitor & Listing	9

REGULAR FEATURES

Letters.....	2
New Products	2
Notes from Garland.....	3
Book Reviews	5





MICRO CORNUCOPIA

July 1981

The Journal of the Big Board Users

No. 1

MICRO CORNUCOPIA
11740 N.W. West Road
Portland, Oregon 97229
503-645-3253

Editor & Publisher

David J. Thompson

Technical Editor

Ruth Fredine-Burt

Graphic Design

Sandra Thompson

Typography

Patti Morris & Martin White
Irish Setter

Cover Illustration

Gerald Torrey

MICRO CORNUCOPIA is published six times a year by Micro Cornucopia of Oregon, 11740 N.W. West Road, Portland, Oregon 97229.

SUBSCRIPTION RATES:

1 yr. (6 issues) \$12.00
1 yr. (Canada) \$15.00
1 yr. (other foreign) \$20.00

All subscription orders payable in United States funds only, please.

ADVERTISING RATES: Available on request.

CHANGE OF ADDRESS: Please send old label and new address.

SOFTWARE, HARDWARE, AND BOOK VENDORS: Micro Cornucopia is establishing a group of reviewers. We would very much like to review your Big Board compatible products for Micro C. Please send material to Review Editor, Micro Cornucopia.

WRITER'S GUIDELINES: All items should be typed, double-spaced on white paper or better yet, on disk. (Your disk will be returned promptly.) Payment is in contributor's copies.

LETTERS TO THE EDITOR: Please sound off.

CP/M is a trademark of Digital Research, Inc.

Copyright 1981 by Micro Cornucopia.
All rights reserved.



Hi, Y'all!

Welcome to the Premier Issue!

It was hard to imagine what this magazine would even look like on March 15th when we decided to start a publication supporting the Big Board. And now it's really exciting to see it take form.

Starting a new magazine is kind of a scary thing. You need interesting things to put in magazine so people will want to read it. You need people willing to take a chance and subscribe to a new publication, sight unseen. You need lots and lots of hours alone, staring at a video monitor, trying to generate ideas and direction. You need people who are willing to donate time and ideas to a dream. And you need a wife who is not only understanding but who does graphic design, accounting, paste-up, technical illustrating and schematic drafting. So thanks to all you folks, I get to say "Welcome."

Our typesetters, Patty Morris and Martin White are super people to work with (they are getting a Big Board to use for text editing). And Ruth, our technical editor is probably as excited as anyone about Micro C.

Then there are the people who have already submitted material for publication. I talked to Don Retzlaff while I was still deciding whether or not to jump in. His excitement about a user's group and his offer to write some very interesting things really made a publication look feasible. Don's first article appears in this issue. Thanks Don.

John Jones wrote such interesting things on his subscription form that I had to call him. He has a number of useful utilities, including the disk formatting program in this issue. More from John in future issues.

Plus, I have just received a really incredible disk from AB computers including a complete hardware and software interface for minifloppies, a reverse video cursor, and more. Stay tuned, because these super people, and you, are doing some great things with the Big Board.

David Thompson
Editor & Publisher

Dear Editor,

I am thinking of using one parallel port as an address bus to tell peripherals when to access the other parallel port. One bit would set the direction and then seven bits would remain to address up to 128 peripherals. These could include A/D's, D/A's, plotters, CRT vector graphics, and so on. I would like to see a standard scheme so we can trade designs within the group.

Frank Gentges
9251 Wood Glade Dr
Great Falls, VA 22066

Editor's Note:

I think Frank has an excellent idea. In fact, how does everyone feel about using port A for data and port B for address and control? Bit 7 (PB7) on port B could be the control bit. What say?

What would be super now, would be for someone to write a simple little general purpose parallel port driver that would reside up with the PFM monitor and could be called via the CP/M punch or directly. If someone did such a thing, it would run in the September issue, guaranteed.

And, if someone came up with a latch for translating 8 bits of port A into 16 bits of address and 8 bits of data why there'd be the start of a PROM burner or an S-100 bus interface etc.

Dear Folks,

I would like to locate Jim Rea, designer of PolyVue/80 or Micro Concepts the outfit that marketed Poly Vue. Has anyone done a modem interface for SIO port A? Or, has anyone configured Modem7 from the CPMug for the Big Board?

The Editor.

Dear Editor,

Why doesn't "clear to end of screen" work on the three boards I've seen?

Cole Chevalier
17862 Fitch
Irvine, CA 92714

Dear Editor,

I need: (1) modem driver for BB, (2) parallel printer driver, (3) to contact other users in my local area.

Daryl Coulhart
532 Lake Bayview Ct
Shoreview, MN 55112

VEDIT—Text editor.

I have Vedit up and running on my Big Board and once you figure out a couple of idiosyncrasies it is easy to customize and install. Get the CRT version rather than the memory mapped and just follow the directions for the ADM-3A.

However: Do not enter "Carriage Return" for the "COMMON 2ND CHARACTER IN THE ESCAPE SEQUENCE." The only character I've found that works is ESC (again). After this you have to use ESC W or something rather than ESC ESC to leave visual mode, and for some reason you have to use the default for the "command iteration brackets." These brackets are < and > rather than [and] by the way.

Once you have it up and running, however, it is a small (10K), but very powerful text editor. (I am using it now to do my text editing).

SMALL C and SMALL C+

If you want to get your feet wet in C and still generate source code that will run on PDP-11s running Bell Labs' C, then these two packages are worth considering. I purchased Small C from the Code Works, Box 550 Boleta, CA 93017. I mean, \$15 for a CP/M disk—how could I go wrong? It is neat, kind of like starting out using integer basic. Plus, it is public domain! Several of the fellows at Tektronix are working on it now, doing some optimizing, etc. The printed document is pretty minimal but when combined with the book, "The C Programming Language" by Kernighan and Ritchie, it is sufficient. The source for Small C, also written in Small C (it compiles itself) is also on the disk. Small C generates assembly code which can be assembled by ASM.

I picked up Small C+ at the Computer Faire from Alpha Omega Computer Systems, P.O. Box U, Corvallis, OR 97330. They say they have fixed numerous bugs in Small C and have added for-loops, do-while, and case statements, among other things. Small C+ requires M80 and L80 to compile the assembly code it generates.

Since small C+ is also public domain, I plan to make it available as part of a group exchange disk. Small C+ also compiles itself and can be compiled by the original Small C. The source and the documentation are on the disk. Two programmers at Alpha Omega did the extension pretty much as a personal project and I hope to talk to them about Small C+ in the near future.

PASCAL/MT+

I learned Pascal on a big system, I mean a BIG system (60 bits/word), and after using some of the small subset languages commonly available for micros (Small C, ALGOL/M, ...) I didn't really expect much more than a usable subset of Pascal. I was wrong. Pascal/MT+ is playing with a full deck.

I have tried it on some small "gee I wonder if it will" type programs, and it did. Hopefully I will have a chance to look at it more thoroughly in the near future. Manual and all, it is an impressive package. MT Microsystems has also put out an editor and debugger package to use with Pascal/MT+ (I've heard). If it is anything like the language package, the combination should be hard to beat for someone doing serious application programming. Contact MT Microsystems, 1562 Kings Cross Dr., Cardiff-by-the-sea, CA 92007.

Crowe Z80 Assembler

Byte's Nybbles made available a Z80 assembler by Patrick Crowe. The assembler uses standard Zilog Z80 mnemonics as defined in the "Zilog Z-80 Assembly Language Programming Manual." Byte originally made this program available for \$4.00 as a printed listing. I'm checking now to see if it is still available or if we can make it available, this time on disk instead of as a 60-page listing.

What makes this piece of software particularly interesting is that John Jones did the I/O linking for the Big Board and has supplied the source of that. And it works very well. More about all this as I get information from Byte. (All kinds of exciting things! Thanks, John.) ■ ■ ■

Now for the news you have all been waiting for, the latest, greatest from Digital Research Computers.

New ROMs for old.

Jim Tanner is now shipping the Big Board with character ROMs created by yours truly. And, he will reburn (for free) any of the old style upper case and smaller upper case ROMs you send him. If you can't part with your old character ROM for a few days then send him \$10.00 and he will send you a new ROM.

New video rocks for free.

For those of you who haven't appreciated the wiggle you get on the video display, here's relief. (No, you don't have to give up drinking.) Any registered owner who sends in his serial number and date of purchase to Jim will receive, free, a 13.9776 MHZ crystal. Take out the old 14.318 video crystal and replace it with the new one and the wiggle will be gone. Not even a genie could do better than that.

4 MHz the easiest way of all.

- Step 1. Remove U96
- Step 2. Jumper what was pin 4 of U96 to pin 4 of U97.
- Step 3. DON'T replace U96.

That's it, no crystals to buy and no board runs to cut. However, it won't work on all boards because of the precharge requirements on the RAM.

First of all, you probably need 200ns RAM chips. Big Boards have been shipped with 300ns, 250ns, and 200ns chips. About 40% were 300ns, 40% 250ns, and the other 20% were 200ns. This mod generates a clock that is more like 60/40 rather than 50/50 High/Low so even the 200ns RAM is just barely making it.

Out of three boards that they have modified at Digital Research two worked and one didn't, though they all had 200ns RAM. On most of the boards it is pretty easy to tell how fast the RAM is. The number on the chip will be 4116-X where X is probably 20, 25 or 30. 20 stands for 200ns, 25 stands for 250ns and 30 stands for 300ns. The National chips have a -4

(continued next column)

How do you contribute to Micro C? What are we interested in? What should you send, disk, printer output, post card, papaya leaf? What if you can't write? What if the thing you are doing is pretty basic or maybe too advanced? Well, here is the information.

Form: Send articles on paper, (double-spaced) or, even better, on disk. If you send a disk, we will copy the contents of the latest Big Board user's group disk onto your disk before we return it.

It's easier on us if you don't include any formatting characters in the text. These characters may help your text formatter but they have to be removed before Patti and Martin can typeset the article.

Programs: Here a disk is a super way to go. Please include at least a few paragraphs of introduction. If the program requires compiling or

Notes from Garland continued

for 250ns and a -3 for 200ns. Any others you should look up in a parts book.

If you are among the folks who have done a successful mod to speed up the Big Board, please send it in and I'll publish it (for those of us who don't have 200ns RAM or can't get this mod to work). In fact, if I get 20 different mods for speeding up the Big Board, I'll publish them all. Why not?

Double double density density.

Jim has someone working on a three-chip board which will plug into the 1771 socket. It will do single and double density on 8 inch and mini floppies (according to Tanner). I would guess that they are aiming for availability sometime late summer or early fall but no one's making any promises.

The chips will be Western Digital and the main controller will be the 1795. (Hooray, it's NOT the 1791.) Perhaps those of you struggling with the idiosyncrasies of the 1791 should write to Western Digital for a new data book.

■ ■ ■

assembling please include a COM file along with the source. And if the compiler or assembler is public domain please include it and anything else needed to do the compilation. Most of the software contributed will be placed in a group disk and made available to everyone in the group.

Personal information: Please include some information about yourself (like raising bees and running your big board off wind power) and about how you are using the Big Board.


What to write about: We're looking for anything on the following list, along with just about anything not on the following list.

- **Hardware interfacing**, complete with schematics (we can redraw them if it's needed) and comments about what the circuit does and how it does it.
- **Software drivers** or other mods to the operating system. This time include a listing, etc. (See "Programs" above.)
- **Reviews of software** take a critical look at how easy it is to learn, how powerful it is, and how easy it is to use once you've learned it. Note: part of the user interface is determined by the quality of the documentation and part by the structure of the software.
- **Reviews of languages** take a critical look at the language for particular applications, systems, etc. What are its weaknesses (size, speed) and it's strengths (floating point, string manipulation, documentation, for instance). The primary languages I'm looking for are, C, Pascal, assembly, Fortran, Forth, Lisp, APL, ADA.
- **Inside scoops** on the latest, greatest rumors from the industry. It sometimes takes a little yellow journalism to keep the industry on its toes. If you would like to use a pen name like ZOSO does, let me know and presto, the Micro Cornucopia shadow can strike fear into the hearts of those wearing their three-piece-vested-interests.
- **And anything else** (which covers a lot of things).

■ ■ ■

Power to the Big Board

By David Thompson



Schematic of +12V Regulator

Picking a power supply these days can be a problem. Everyone and his kid brother are building them in variations that read like the marquee at an ice cream parlor. So the following may be a little help, both in the selection of a supply and in understanding the consequences of a poor choice.

A group of us in Portland are using the Power One model CP 384. This is a simple linear supply with three outputs, +5V at 9 amp, -12V at about an amp, and +24V at .7 amp average or 5 amp peak. The price for this unit is about \$120 in single unit quantities. It includes over-voltage and over-current protection.


This supply is made to power 8-inch disk drives but if you add a simple 3-terminal regulator for +12V, it will also supply all the power for the Big Board.

To add +12V, tie the input of the regulator to the + lead of either of the two 60V electrolytics. The connecting post marked 24V return is ground (in fact, I just tied all the return posts together and ran them to the aluminum frame on the supply). The + lead on the electrolytics is at about 38V above ground which is higher than a standard 12V regulator (7812) is rated for. One member of our group is using a 7812 anyway and it is working fine. The LM317, however, is supposed to handle 38 volts just fine and it has a variable output to boot. Its output is designed to be 1.2V above the adj. lead, so by having approximately 1/10 of the drop between the output and the reference and 9/10 between the reference and ground you should get 12V. It comes out pretty close.

Mount the regulator against the frame with a mica insulator. Be sure to use silicon grease because it has to dissipate up to 13 watts.

Double check yourself.

It's a good idea to put a resistor load on the supply and then use a digital voltmeter to double check the outputs before connecting it up to your system. I have heard some pretty gruesome stories about folks accidentally putting outrageous voltages on their systems. Sometimes the systems have gone down permanently, other times they have gone temporarily insane, while a few have miraculously survived. It's best, obviously, to check the supply thoroughly.



LM 317 Regulator

Also, check to see that the supply will deliver 24V at 5 amps. The Power One's current limit is set at 1 amp at the factory. It will work in the circuit that way until you try to write something on the disk. The drive can then get very strange, generating random CRC errors and in some cases rendering a disk unusable.

If you a having drive problems, check the 24V line during a write operation. It shouldn't drop below 22V. (If the 24V line drops below 15V, you will probably get a buzz as the relay tries to load the head.)

To adjust the 24V current limit on the Power One Supply, locate the small screwdriver pot marked "24V I.LIMIT" and turn the control fully clockwise. It should now give you 5 amps at a rock solid 24V.

If you have had experience with other power supplies, let me know and I'll pass the word along here in Micro C. ■ ■ ■

Notes on Book Reviews

A good book or manual is a conversation with the author. At first it is a story, the reader sharing experiences with the author through the transparency of the written word. Later when the reader has questions about the material covered, the conversation turns to question and answer and the book becomes a reference volume.

Conversation: The tone of the conversation is very important. No one would freely choose to sit through hour upon hour of impersonal lecture if there were any easier way to get the same information. And yet some authors get mired in pages of third person passive.

Transparency: When the words move you smoothly and easily from idea to idea, then what you see are the ideas, not the words. The words have become transparent. If the sentences are too long and confusing or are short. Choppy. Broken up. Or if the ideas don't fit well together, then the conversation is reduced to one word at a time.

Asking questions: Technical books are generally used for two primary purposes. First, they are learning tools (the original conversation) and second, they are references as questions arise. Many technical books are arranged as training manuals only or as reference manuals only (sometimes for very good reason).

For instance, Microsoft's Basic 80 manual is primarily an alphabetical list of commands, which is fine if you know what commands you need to use and just need syntax examples. Kernighan and Ritchie's C book, on the other hand, is a well written introduction to the language, but if you want to look up a command you will have to start at the index and then refer to three or more places scattered through the book. At least they did an index.

And finally all the things you normally notice when reading a book:

- Content. Is the information appropriate to this group. Is the book a bargain in terms of information content.

(continued next page)

Three Books on CP/M

David Thompson Reviews

**Using CP/M,
A Self-Teaching Guide**
by Fernandez and Ashley
John Wiley & Sons
ISBN 0 471 08011-X

"Using CP/M" is the book that introduced me to CP/M. I purchased this text immediately after ordering the Big Board and by the time I had my system running I was pretty comfortable with the simpler portions of its operating system. But then I had already read the book cover to cover at least three times in anticipation.

The authors use an informal, conversational, writing style that's clear and easy to read. The text comes in short chunks. Each half-page or so, is followed by approximately a half-page of questions about the material just covered. I just skipped the questions, which meant that I skipped about half the total book. If you're really into questions you can use mine.

The book starts at a beginning level and stays there. It goes over and

over the basics; spending 9 pages, for instance, on how to enter generalized filenames (*.*) . And then it covers DDT in 10 lines.

Graphically speaking, "Using CP/M" doesn't make it. The writers organized the material pretty well but that organization disappears into a forest of sameness. Even the question sections are not visually separated well from the text, so it is sometimes hard for your eye to skip to the next piece of text. And skimming through the text to find a particular command is nearly impossible.

The only prayer this book has as a reference is the index. But if something didn't make the index you're in real trouble. Try to find the CP/M line editing commands (not ED). I gave up trying.

All in all, this text is reasonable for someone who is just starting out and wants to do a lot of light reading.



The CP/M Handbook with MP/M
by Rodnay Zaks
Sybex
ISBN 0 89588 048 2

I got "The CP/M Handbook" after trying to use "Using CP/M" for a reference, so most of my experience with this text is for reference work. It's a real improvement. This book is full of tables, charts, reference guides and appendices. The chapters are organized in logical manner. The design and many illustrations (and index) help the reader locate specific information.

All of Zak's books that I've seen have been easy to read. The book starts at a beginning level and then progresses to such things as reconfiguring CP/M for different system sizes. Advanced topics such as DDT and ASM, however, are covered just enough for the reader to access the programs. DDT gets about 2½ pages and ASM gets about 3. The reader is then referred to the user's guide from Digital Research.

This is a good text for someone using CP/M for running applications

programs. PIP is pretty thoroughly covered in its own chapter and ED gets the detailed look it needs to keep the reader from losing his cursor entirely. So, for those not digging heavily into CP/M itself, this book is a definite option.



Osborne CP/M User Guide
By Thom Hogan
Osborne McGraw-Hill
ISBN 0 931988-44-6

The "Osborne CP/M User Guide" is the latest book to jump on the CP/M bandwagon and is the most technical of the three books. The introduction for beginners is relatively brief; and PIP, for instance, is presented in 21 pages of formatted text rather than a chapter in standard paragraph form.

This book contains a complete chapter on assembly language utilities, a subject skimmed over by the other texts. In fact, DDT and ASM each get 12 pages of remarkably thorough coverage. Like the Sybex book, Hogan makes extensive use of appendices for command summaries, etc. but he also adds some extra goodies like an annotated bibliography and addresses of companies supplying CP/M based products. (Hooray!)

Hogan's writing style is variable. Generally it is friendly but there are places where it is more formal than Zaks or Fernandez/Ashley. And he uses very few illustrations. However, the graphic layout of the material is very well done. In fact, you probably won't notice the dearth of illustrations because of the excellent use of type and layout to make the organization obvious. The combination of graphic design and index make this a first class reference work for CP/M.

This book is definitely the best book I've seen for someone using CP/M on a day-to-day basis. A beginner, however, might seriously consider starting with Zaks' book and then moving up to this one as he gains experience.



Notes on Book Reviews continued


- Organization. Is the way the author progresses into the subject obvious? Is it easy to go back and find the information you need?
- Graphic design. Is the book visually appealing? Can you skim through glancing at the headlines and the illustrations and follow the book's progression through the subject?
- Illustrations. Are the illustrations well thought out and technically accurate or just afterthoughts to pretty up the page?
- Author's command of the subject. It's fun to catch a mistake in print. It's sort of like Moses messed up when chipping the rock, but too many errors cast doubt on the validity of the whole book.

So if you have books that are interesting to you and might be interesting to others in the group then by all means put the information down on a disk or paper or post card or whatever and let us know.



RAM Protection Circuit

By David Thompson



Schematic of RAM Protection Circuit

The RAM chips used on the Big Board (4116s) require three voltages for operation, +5V, +12V and -5V.

The +12V and -5V are used for device operation while the -5V provides an internal protective bias to keep the +12V from breaking down the chip. Isolation between some regions is provided by reverse biased diode junctions and the -5V provides the reverse bias.


So, the device manufacturers strongly recommend that the -5V be available before the +12V. And they recommend that the -5V be available after the 12V goes away.

Most personal computers (TRS-80 etc.) have gotten around the problem by providing a slightly longer time constant for the +12V on power-up and a shorter time constant on power-down. But if the -5V supply ever shuts down momentarily or doesn't come up for some reason then the owner gets to buy new RAM. The Big Board, on the other hand is at the mercy of the supply.

The documentation recommends that you use a quality supply but there are many other reasons why -5V might not be available.

The following circuit takes care of the problem and has already saved our group a couple of sets of 4116s. The parts are mounted on the underside of the board and only one run (the +12V) has to be cut. Nothing is critical. The NPN is just a small, plastic, half-watt transistor with a DC gain of about 100. The PNP is a larger tab-style package and has a DC gain of 10 or more. Since the PNP is either saturated or off, it doesn't dissipate enough to require heat-sinking.

It is easy enough to check the whole thing out on the bench before installing it on the Big Board. When the -5V line drops down to about -3.5V the NPN should stop pulling current out of the base circuit of the PNP. As the PNP base rises, the PNP shuts off, removing the +12V from the RAM. ■ ■ ■



Example Installation of RAM Protection Circuit

Video Wiggle

The Cause and Cure

Quite a number of folks have noted on their subscription forms that they are bothered by wiggle on their video displays.

Well, the wiggle is caused by a frequency difference between your power line and the vertical output in the video generator. The video generator is 1 Hertz off (It's 61 Hz) and when it beats against power supply ripple in a Leedex monitor (for instance) you get wiggle. Many monitors also have trouble maintaining vertical sync because the frequency is outside their normal operating range.

To completely cure the problem, change the frequency of the CRT display generator crystal. Jim Tanner now has new crystals available free for Big Board owners. See "Notes From Garland, Texas" for more information.

A partial cure requires adding additional power supply filtering to the monitor. One additional 6000 ufd capacitor on the 12V DC line makes quite an improvement.

On the other hand, if your monitor accepts separate vertical, horizontal, and sync signals then you probably won't have any trouble. I've tried it both ways and my ancient Tektronix monitor with its separate inputs is as solid as a rock (it's also about that heavy).

■ ■ ■

Disk Formatter Listing

```

*
* TITLE 'SSSD DISKETTE FORMATTER'
*
* THIS PROGRAM IS DESIGNED TO FORMAT A SINGLE DENSITY
* SINGLE SIDED SOFT SECTORED 8" DISKETTE INTO STANDARD
* 128 BYTE SECTORS. IT IS DESIGNED TO RUN ON
* THE FERGUSON BIG BOARD Z-80 COMPUTER. IT TAKES
* ADVANTAGE OF THE WD-1771 FLOPPY DISK CONTROLLER'S
* CAPABILITIES FOR SEMI-AUTOMATIC FORMATTING.
*
* WRITTEN: J.P. JONES 4/20/81
* MODIFIED: J.P.J. 5/14/81
*
* ORG 100H ;STD CP/M COM PROGRAM
*
* BOOT 0 ;CP/M BOOT
* MONITR 0F000H ;WILL USE SOME OF PFM-80
* WDSTAT 10H ;1771 STATUS ADDR
* WDCTL EQU WDSTAT ;CONTROL = STATUS WRITE
* WDATA 13H ;1771 DATA I/O
* HOME EQU MONITR+1EH ;DISK HOME ROUTINE
* SEEK EQU MONITR+21H ;SEEK TRACK ROUTINE
* SELECT EQU MONITR+1BH ;SELECT DRIVE ROUTINE
*
* FIRST, SET UP ONE TRACK'S DATA IMAGE
*
* LD HL, DATA ;POINT TO DATA AREA OF DISK IMAGE
* LD DE, DATA+1
* LD (HL), 0E5H ;E5 = BLANK VALUE
* LD BC, 127 ;FILL DATA AREA
* LDIR
*
* COPY ONE SECTOR 25 TIMES
*
* LD HL, SECT1 ;START OF SECTOR 1 DATA
* LD DE, SECT2 ;ADD UNTO END
* LD BC, 186*25 ;186 BYTES PER SECTOR
* LDIR ;FILL THAT MEMORY
*
* NOW SET UP SECTOR NUMBER IN PROPER POSITIONS
*
* LD HL, SECTNO ;POINT TO SLOT IN FIRST IMAGE
* LD DE, 186 ;OFFSET TO NEXT SECTOR
* LD BC, 26*256+1 ;B=COUNTER, C=SECTOR #
*
* SECTID LD (HL), C ;STORE SECTOR #
* INC C ;INCREMENT SECTOR #
* ADD HL, DE ;POINT TO NEXT SECTOR DATA
* DJNZ SECTID ;DO ALL 26
*
* NOW PUT TRAILER OF FF'S AFTER WHOLE TRACK
*
* LD HL, SECT1+4836 ;POINT AFTER DATA
* LD A, -1 ;NEED 247 BYTES OF FF 50
* LD B, 0 ;DO 256 BYTES FOR INSURANCE
* INC HL ;C POINTS TO 1771 DATA PORT
* DJNZ ENDRK ;WRITE TRACK COMMAND
* ENDRK
*
*

```

(continued next column)

Disk Formatter

By John P. Jones

5826 Southwest Ave.
St. Louis, MO 63139

Like most of the routines I use, this is nothing fancy but it gets the job done.

Since memory is not a problem on the Big Board, an entire track's data image is set up in memory. The WD-1771's write track command can then be used for formatting the disk. The listing is reasonably well commented so the only additional point I'll make is that the same basic method used in PFM-80 to eliminate the need for DMA is used in this routine.

The routine was tested with a deliberately "trashed" disk (totally wiped out with a magnet). In fact, the disk I sent with this article was re-formatted after deliberately being destroyed. The routine does no prompting or error reporting. To use it, place the disk to be formatted in drive B and enter FORMAT.

Editor's note: This program really works! If you don't have something like M80 to assemble this with then hang on. The COM version will be on the group disk plus I'm trying to make the Crowe Z80 assembler available.

```

*
* SET UP TO FORMAT DISK IN DRIVE 'B'
*
* LD C, 1 ;B IS DRIVE #1
* CALL SELECT
*
* NOW DO SETUP FOR FORMATTING
*
* LD A, (66H) ;GET BYTE AT NMI VECTOR
* PUSH AF
* LD A, 0C9H ;RET INSTRUCTION
* LD (66H), A ;STORE RETURN
*
* DO THE FORMAT
*
* DI ;CANNOT INTERRUPT
* LD C, 0 ;START WITH TRACK 0
* LD B, 26 ;26 SECTORS PER TRACK
* PUSH BC ;NEED THEM LATER
*
* SEEK NEXT TRACK IN SEQUENCE
*
* CALL SEEK
*
* POP EC ;TRACK # AND SECTOR CTR BACK
* PUSH EC ;WILL NEED AGAIN
*
* PUT TRACK ID'S IN PROPER PLACE IN TRACK IMAGE
*
* LD HL, TRKNO ;POINT TO POSITION IN IMAGE
* LD DE, 186 ;OFFSET FOR EACH SECTOR
* LD (HL), C ;STORE CURRENT TRACK NO.
* ADD HL, DE ;POINT TO NEXT SECTOR
* DJNZ TRAKID
*
* DO THE TRACK WRITE
*
* LD HL, LEADER ;POINT TO DATA
* LD D, 30 ;20 * 256 + 36 = TOTAL BYTES
* LD B, 36 ;C POINTS TO 1771 DATA PORT
* LD C, WDATA ;WRITE TRACK COMMAND
* LD A, 0F4H ;SEND COMMAND
* OUT (WDCTL), A
*

```

(continued next page)

New Character ROM

Sometime after the first of this year, Jim Tanner began shipping the Big Board with a new character ROM. The ROM has true lower case characters rather than the smaller upper case/larger upper case ROM shipped in the early boards.

- The ROM uses a 5 by 8 dot matrix so it has one-dot descend-ers.
- It contains the standard character set for 00(hex) through 7F(hex). (Even though the Big Board only displays 20—7F.)
- And I like it because I designed it and gave it to Jim.
- However, It isn't perfect.

So, for a week or so I worked on the g, y, t, f, and q characters until . . . well, if it isn't perfect now, I give up because I'm absolutely tickled.

If your board has true upper/lower case but you would like to have the absolute latest greatest, then send me a ROM and \$5.00.

If you have one of the old upper case/smaller upper case ROMs you have a choice. Send a ROM to Jim Tanner at Digital Research Computers of Texas and he will burn a copy of my first character ROM (the one he's using in the new boards) for you, free. Or you can send me the ROM and \$5.00 and get the deluxe version.

Price

- \$5.00 if you send a 350ns 2716 and a self-addressed, stamped package I can ship it back in.
- Or instead of \$5.00 you can submit something to the magazine, a program, a book or software review, a schematic and comments, a page or two about what you are doing with the Big Board, etc., along with your ROM and SASE and presto, you get fame AND a new character set, free! (And those who contributed to this issue also qualify for a free burn.)

Make checks payable to Micro Cornucopia. If you don't agree that it's a \$5.00 improvement, I'll send you the \$5.00 back.

PFM-80 Monitor

By Don Retzlaff

6435 Northwood
Dallas, Texas 75225

The PFM-80 Monitor is the primary control program for your Big Board computer. It was burned into the EPROM that is installed in the first ROM socket (U67).

PFM and CBIOS were written by Russell Smith, who is an exceptional young programmer who operates his own software house in Denton, Texas. He has helped me immeasurably in understanding PFM and implementing my programs on the Big Board. As time goes on I will pass along some of this expertise to you, through this column.

If your curiosity is like mine you want to know what PFM stands for. I was informed that PFM is the abbreviation of the profound literal description of what the monitor is: "PRETTY F——KIN' MAGIC."

When the computer is turned on or the reset button is pressed, the Big Board automatically starts executing the COLD START BOOT program in the monitor ROM. The first five instructions in the ROM (starting at location 0000H) copy the PFM monitor program from the ROM into upper memory starting at location F000H and continuing through F7E6H. The RAM locations starting at location FF00H through FFA8H are used as monitor data storage locations.

After PFM has been booted into RAM the monitor starts executing and goes through the cold start initialization routine that does the following:

1. Initializes data storage pointers.
2. Clears the scratch RAM with zeros.
3. Fills CRT storage with blanks.
4. Initializes values in memory.
5. Initializes programmable I/O devices.
6. Waits for input from keyboard or terminal.
7. Sets baud rate for SIO input if input from there.
8. Displays sign-on message on the appropriate device.
9. Displays monitor prompt *
10. Waits for input.

At this point PFM is up and operating.

I think that it is important to note that whenever an RS-232 serial terminal is connected to SIO PORT B, PFM automatically determines the BAUD rate of the terminal by analyzing the input from the single carriage return. It then sets up the baud rate generator to the correct frequency.

In future articles we will get deeper into the monitor.

Now let's discuss the monitor entry point table. Starting at location F000H you will find a series of jump instructions. These provide a fixed address that can be used as entry points to the various monitor routines. These will be useful in software routines that you write. This table will provide a constant jump location for these routines even if updates are made to the monitor. Thus, changes in addresses of the internal routines will not affect your software.

I plan to cover the various features of PFM and CBIOS which work together to control your Big Board. In succeeding articles I will lead you through the assembly language listings of both PFM and CBIOS, pointing out the features of each and how you can make the most from each.

In the next issue we will discuss the mechanics of modifying the monitor.

■ ■ ■



Editor's Note: The first installment of the PFM monitor listing begins on the following page. We will continue the listing in the September issue.

PFM Monitor Listing

```

0001 : *****
0002 : *
0003 : * BIGBOARD MONITOR ROM, NON-RELOCATABLE VERSION *
0004 : * Russell Smith *
0005 : *
0006 : *****
0007 :
0008 :
0009 : PSECT ABS
0010 : ROM OF000H ; START OF 2K ROM
0011 : RAM OFF00H ; START OF 256 BYTE RAM
0012 : CRTMEM EQU 3000H ; BASE OF 4K CRT MEMORY
0013 :
0014 :
0015 : DRG ROM
0016 : INCLUDE INIT.ASM
0017 : *****
0018 : *
0019 : * COLD START INITIALIZATION ROUTINE FOR *
0020 : * CONFIGURING THE SYSTEM AFTER A POWER-ON *
0021 : * OR PUSHBUTTON RESET. *
0022 : * 1B-Oct-80 *
0023 : *
0024 : *****
0025 : *
0026 : *
0027 : -- MONITOR ENTRY POINT TABLE --
0028 :
0029 C32AF0 JP INIT ; MONITOR COLD ENTRY POINT
0030 C32BF1 JP PROMPT ; MONITOR WARM ENTRY POINT
0031 C331F4 CONST: JP KBDST ; CONSOLE STATUS VECTOR
0032 C339F4 JP KBDIN ; CONSOLE INPUT VECTOR
0033 C320F5 JP CRTOUT ; CRT OUTPUT VECTOR
0034 C320F6 JP CRTOUT ; CRT OUTPUT VECTOR
0035 C3EBF4 JP SIDST ; SID CHANNEL B STATUS VECTOR
0036 C3F0F4 JP SIDIN ; SID CHANNEL B INPUT VECTOR
0037 C3FEF4 JP SIDOUT ; SID CHANNEL B OUTPUT VECTOR
0038 C3B1F5 JP SELECT ; DISK DRIVE SELECT
0039 C3E9F6 JP HOME ; HOME R/W HEAD
0040 C3FBF6 JP SEEK ; SEEK TO TRACK
0041 C32AF7 JP READ ; READ SECTOR
0042 C31FF7 JP WRITE ; WRITE SECTOR
0043 :
0044 :
0045 :
0046 : DO A SHORT POST-RESET TIME DELAY. ALSO INITIALIZES THE
0047 : STACK POINTER AND FILLS THE MONITOR SCRATCH RAM WITH ZEROS
0048 :
0049 INIT: DJ
0050 F3 HL, RAM ; POINT TO START OF MONITOR RAM
0051 F2 LD (HL), 0 ; FILL 256 BYTE SPACE WITH ZEROS
0052 F9 LD SP, HL ; SOMETHING USEFUL TO ADD DELAY
0053 2C INC L
0054 05A JR NZ, INIT1-$ ; LOOP TAKES 4 MILLISECONDS
0055 :
0056 : INITIALIZE THE Z-80 FOR INTERRUPT MODE #2
0057 :
0058 :
0059 LD A, H
0060 7C

```

```

F08A 21CAF0
F08D 23
F08E 17
F08F 30FC
F091 7E
F092 D30C
F094 D30F4
F097 3E01
F099 D307
F09B 3E1C
F09D D307
F09F 21FEF4
F0A2 220DF0
;
0122 BAUD3:
0123 BAUD3:
0124 RLA
0125 JR
0126 LD
0127 OUT
0128 CALL
0129 LD
0130 OUT
0131 LD
0132 OUT
0133 LD
0134 LD
;
0135 ;
0136 ; PRINT SIGNON MESSAGE
0137 ;
0138 SIGNON: EI
0139 CALL FNETX
0140 DEFM CR, LF
0141 DEFM "... system monitor 3.3 ...?"
;
F0A5 FB
F0A6 CDECF3
F0A9 0D0A
F0AB 2E2E2E20
73797374
65D206D
6F6E6974
6F722033
2E33202E
2E2E
F0C5 0D0A
F0C7 04
F0C8 C303F0
;
0142 DEFS CR, LF
0143 DEFB EDI
0144 WARM
0145 :
0146 :
0147 :
0148 ; BAUD RATE CONSTANTS FOR COM 8116 BAUD RATE GENERATOR
0149 :
0150 RATES: DEFB 0101B ; 300 BAUD
0151 DEFB 0110B ; 600 BAUD
0152 DEFB 0111B ; 1200 BAUD
0153 DEFB 1010B ; 2400 BAUD
0154 DEFB 1100B ; 4800 BAUD
0155 DEFB 1110B ; 9600 BAUD
0156 DEFB 1111B ; 19200 BAUD
0157 DEFB 1111B ; 19200 BAUD
0158 :
0159 :
0160 INTAB EQU $ ; INITIALIZATION DATA TABLES
0161 :
0162 :
0163 ; INITIALIZE THE Z-80 'I' REGISTER INTERRUPT VECTOR TABLE
0164 :
0165 DEFB 2
0166 DEFW SYSVEC+2
0167 DEFW KEYSRV ; PARALLEL KBD INTERRUPT VECTOR
0168 :
0169 DEFB 2
0170 DEFW CTCVEC+6
0171 DEFW TIMER ; 1 SEC TIMER INTERRUPT VECTOR
0172 :
0173 DEFB 4
0174 DEFW SIDVEC+4
0175 DEFW SIDINT ; SID RECEIVE INTERRUPT VECTOR
0176 DEFW SIDERR ; SID PARITY, OVERRUN & FRAPING ERROR
;
0177 ;
0178 ; INITIALIZE DISK I/O DRIVER VARIABLES
0179 ;
0180 DEFB 8
F0E4 0B

```

HL, RATES-1
HL ; INDEX INTO BAUD RATE TABLE
; USING COUNT DERIVED IN A
NC, BAUD3-\$
A, (HL)
; GET BAUD RATE CONTROL BYTE FROM
(BAUDR), A ; TBL & OUTPUT TO COM-8116 TIMER
; DISCARD 1ST SERIAL INPUT CHAR
A, 1
(SIDCPB), A ; RE-PROGRAM SID B TO GENERATE
A, 0011100B; INTERRUPTS ON RECEIVED DATA.
(SIDCPB), A ; PARITY DOES NOT AFFECT VECTOR
HL, SIDOUT
(CONOUT+1), HL ; RE-DIRECT CONSOLE OUTPUT
TO SID

```

F035 ED47 LD I,A ;LOAD I REG WITH MSB OF VECTOR
;TABLE
F037 ED5E IM 2 ;AND SELECT INTERRUPT MODE 2
F039 CDECF5 CALL CLRSCRN ;FILL THE CRT MEMORY WITH BLANKS
;STORE ANY NON-ZERO VALUES FOR VARIABLES IN MEMORY
F03C 21D3F0 LD HL,INTAB ;POINT TO DEFAULT VAR TABLE
F03F 0600 LD B,0
F041 4E C,(HL) ;BC=DATA BLOCK BYTECOUNT
F042 23 INC HL
F043 5E LD E,(HL) ;DE=DESTINATION FOR DATA
F044 23 INC HL
F045 56 LD D,(HL)
F047 ED60 LDIR ;COPY DATA @ HL TO VAR @ DE
F049 CB7E BIT ;LOOP AGAIN IF NOT END OF TABLE
F04B 2BF2 JR ;INITIALIZE THE PROGRAMMABLE I/O DEVICES
;
F04D 23 INC HL ;POINT TO I/O INIT DATA TABLE
F04E 46 LD B,(HL) ;B=INIT LOOP BYTECOUNT
F04F 23 INC HL
F050 4E C,(HL) ;C=DEVICE CONTROL PORT#
F051 23 INC HL
F052 ED63 DTIR ;SEND DATA @ HL TO PORT @ C
F054 CB7E BIT ;TEST FOR TABLE END MARKER
F056 2BF6 JR ;LOOP AGAIN IF NOT AT END
;
F058 ;DETERMINE IF CONSOLE I/O CONFIGURATION WILL BE FOR THE
F059 ;ON-BOARD CRT AND KEYBOARD OR AN EXTERNAL SERIAL TERMINAL.
F061 ;
F062 0092 IN A,(C) ;TEST SIO READ REG 2 TO CHECK
F063 FE06 CP 00000110B ;IF THE SIO IS INSTALLED
F064 2012 JR NZ,FARALL-#;SKIP CONFIG TEST IF NO SIO
F065 DB1E IN A,(KBDSTAT) ;MAKE SURE KBD P10 'READY'RESET
F066 0610 LD B,00010000B ;B=RESET SIO EXT STATUS COMMAND
F067 ED41 OUT (C),B ;TEST FOR ARRIVAL OF A SERIAL
F068 0098 IN A,(C) ;INPUT CHAR START BIT
F069 CB67 BIT 4,A ;INPUT CHAR START BIT
F06A DB1C JR NZ,BAUD-$ ;EXIT LOOP IF START BIT DETECTED
F06B 0101 IN A,(BITDAT)
F06C CB5F BIT 3,A ;TEST FOR DATA RDY STROBE FROM
F06E 20F2 JR NZ,DECIDE-#;PARALLEL KBD, LOOP IF INACTIVE
F070 DE1E IN A,(KBDSTAT) ;DISCARD FIRST KEYBOARD C-CHAR
F072 3E83 LD A,10000011B
F074 D31F OUT (KBDCTL),A ;ENABLE INTERRUPTS FROM KBD P10
F076 1E2D JR SIGNON-$ ;SIGNCN WITH BUILT-IN CONSOLE I/O
;
F078 AF ;AUTOMATIC BAUD RATE SETTING ROUTINE FOR S10
F079 ED41 XOR A
F07E ED50 LD B,A
F07F CF62 IN D,(C)
F07F 2BF3 BIT 4,D ;READ SIO STATUS REGISTER
F081 3C JR Z,BAUD1-$ ;TEST THE SYNC/HUNT BIT
;LOOP UNTIL IT CHANGES STATE
F082 ED41 INC A
F084 ED50 OUT (C),B ;REPEAT REGISTER #0 FLAGS AGAIN
F086 CB62 IN D,(C) ;&LOOP TIMING THE SYNC/HUNT BIT
F08B 20F7 BIT 4,D
F08B 20F7 JR NZ,BAUD2-$ ;REPEAT UNTIL BIT CHANGES AGAIN
;
F059 0059 LD I,A ;LOAD I REG WITH MSB OF VECTOR
;TABLE
F060 0060 IM 2 ;AND SELECT INTERRUPT MODE 2
F061 0061 CALL CLRSCRN ;FILL THE CRT MEMORY WITH BLANKS
;STORE ANY NON-ZERO VALUES FOR VARIABLES IN MEMORY
F062 0062 LD HL,INTAB ;POINT TO DEFAULT VAR TABLE
F063 0063 LD B,0
F064 0064 C,(HL) ;BC=DATA BLOCK BYTECOUNT
F065 0065 LD E,(HL) ;DE=DESTINATION FOR DATA
F066 0066 INC HL
F067 0067 LD D,(HL)
F068 0068 LDIR ;COPY DATA @ HL TO VAR @ DE
F069 0069 BIT ;LOOP AGAIN IF NOT END OF TABLE
F070 0070 JR ;INITIALIZE THE PROGRAMMABLE I/O DEVICES
;
F071 0071 INC HL ;POINT TO I/O INIT DATA TABLE
F072 0072 LD B,(HL) ;B=INIT LOOP BYTECOUNT
F073 0073 INC HL
F074 0074 C,(HL) ;C=DEVICE CONTROL PORT#
F075 0075 INC HL
F076 0076 DTIR ;SEND DATA @ HL TO PORT @ C
F077 0077 BIT ;TEST FOR TABLE END MARKER
F078 0078 JR ;LOOP AGAIN IF NOT AT END
;
F079 0079 ;DETERMINE IF CONSOLE I/O CONFIGURATION WILL BE FOR THE
F080 0080 ;ON-BOARD CRT AND KEYBOARD OR AN EXTERNAL SERIAL TERMINAL.
F081 0081 ;
F082 0082 IN A,(C) ;TEST SIO READ REG 2 TO CHECK
F083 0083 CP 00000110B ;IF THE SIO IS INSTALLED
F084 0084 JR NZ,FARALL-#;SKIP CONFIG TEST IF NO SIO
F085 0085 IN A,(KBDSTAT) ;MAKE SURE KBD P10 'READY'RESET
F086 0086 LD B,00010000B ;B=RESET SIO EXT STATUS COMMAND
F087 0087 OUT (C),B ;TEST FOR ARRIVAL OF A SERIAL
F088 0088 IN A,(C) ;INPUT CHAR START BIT
F089 0089 BIT 4,A ;INPUT CHAR START BIT
F090 0100 JR NZ,BAUD-$ ;EXIT LOOP IF START BIT DETECTED
F091 0101 IN A,(BITDAT)
F092 0102 BIT 3,A ;TEST FOR DATA RDY STROBE FROM
F093 0103 JR NZ,DECIDE-#;PARALLEL KBD, LOOP IF INACTIVE
F094 0104 IN A,(KBDSTAT) ;DISCARD FIRST KEYBOARD C-CHAR
F095 0105 LD A,10000011B
F096 0106 OUT (KBDCTL),A ;ENABLE INTERRUPTS FROM KBD P10
F097 0107 JR SIGNON-$ ;SIGNCN WITH BUILT-IN CONSOLE I/O
;
F098 0108 ;AUTOMATIC BAUD RATE SETTING ROUTINE FOR S10
F099 0109 XOR A
F100 0110 LD B,A
F101 0111 IN D,(C)
F102 0112 BIT 4,D ;READ SIO STATUS REGISTER
F103 0113 JR Z,BAUD1-$ ;TEST THE SYNC/HUNT BIT
;LOOP UNTIL IT CHANGES STATE
F104 0114 INC A
F105 0115 OUT (C),B ;REPEAT REGISTER #0 FLAGS AGAIN
F106 0116 IN D,(C) ;&LOOP TIMING THE SYNC/HUNT BIT
F107 0117 BIT 4,D
F108 0118 JR NZ,BAUD2-$ ;REPEAT UNTIL BIT CHANGES AGAIN
;
F087 0187 ;INITIALIZE THE CRT DISPLAY CURSOR
F088 0188 ;
F089 0189 ;
F090 0190 DEFW 2
F091 0191 DEFW CHR$AV
F092 0192 DEFW
F093 0193 DEFW
F094 0194 ;SET DEFAULT 'SOFTWARE' INTERRUPT VECTORS
F095 0195 ;
F096 0196 ;
F097 0197 DEFW 6
F098 0198 DEFW TIKVEC
F099 0199 DEFW DISKTRM
F100 0200 DEFW STASH
;POINT TO 1ST LOC AFTER MONITOR
F099 44F4 DEFW STASH
;
F101 0201 DEFW
;
F102 0202 ;SET FREE MEMORY POINTER
F103 0203 ;
F104 0204 ;
F105 0205 DEFW 2
F106 0206 DEFW FREPTR
F107 0207 DEFW ROMEND
;
F108 0208 ;
F109 0209 ;
F110 0210 DEFW -1
;END OF VARIABLE INIT TABLE
;
F101 0211 ;
F102 0212 ;
F103 0213 ;
F104 0214 BAUDA EQU 00H ;CHANEL A BAUD RATE GENETATOR
F105 0215 S10 EQU 04H ;DUAL SERIAL I/O
F106 0216 GENP10 EQU 08H ;GENERAL PURPOSE PARALLEL I/O
F107 0217 BAUDB EQU 0CH ;CHANEL B BAUD RATE GENERATOR
F108 0218 WD1771 EQU 10H ;WEST DIGITAL DISK CONTROLLER
F109 0219 SCROLL EQU 14H ;CRT SCROLL MEM SCROLL REGISTER
F110 0220 CTC EQU 18H ;QUAD COUNTER/TIMER CIRCUIT
F111 0221 SYSP10 EQU 1CH ;SYSTEM PARALLEL I/O
;
F101 0222 ;INITIALIZE SYSTEM P10 FOR USE AS BANK-SWITCH.
F102 0223 ;DISK DRIVE SELECT AND PARALLEL KEYBOARD INPUT
F103 0224 ;
F104 0225 ;
F105 0226 BITDAT EQU SYSP10+0
F106 0227 BITCTL EQU SYSP10+1
F107 0228 KBDCTL EQU SYSP10+2
F108 0229 KBDCTL EQU SYSP10+3
;
F103 0230
F104 0231 DEFW 3,BITCTL
F105 0232 DEFW 11001111B ;PUT SYSTEM P10 IN BIT MODE
F106 0233 DEFW 00011000B ;MAKE BITS 4 AND 3 BE INPUTS
F107 0234 DEFW 01000000B ;DISABLE INTERRUPTS
;
F108 0235 ;
F109 0236 DEFW 1,BITDAT
F110 0237 DEFW 00000000B ;DE-SELECT ROMS, ENABLE DRIVE 0
;
F101 0238 ;
F102 0239 DEFW 2,KBDCTL
F103 0240 DEFW 01001111B ;PUT KBD PORT IN INPUT MODE
F104 0241 DEFW SVSVEC+2 ;LOAD KEYBOARD INTERRUPT VECTOR
F105 0242 ;
F106 0243 ;

```

(continued next page)

(continued on top of page 10)

PFM Monitor Listing (continued)

```

0244 ; INITIALIZE CHANNELS 2 AND 3 OF THE CTC
0245 ; TO GENERATE ONE SECOND INTERRUPTS FROM CTC3
0246 ;
0247 CTC0 EQU CTC+0 ; CTC CHANNEL 0 FOR #
0248 CTC1 EQU CTC+1 ; CTC CHANNEL 1
0249 CTC2 EQU CTC+2 ; CTC CHANNEL 2
0250 CTC3 EQU CTC+3 ; CTC CHANNEL 3
0251
0252 DEFN 1,CTCO ;BASE INTERRUPT VECTOR FOR CTC
0253 CTCVEC
0254 ;
0255 DEFN 2,CTC2 ;PUT CTC2 IN TIMER MODE
0256 DEFN 00100111B ;CTC2 PERIOD=105*256*400 NS
0257 DEFN 105
0258 ;
0259 DEFN 2,CTC3 ;PUT CTC3 IN COUNTER MODE
0260 DEFN 110000111B ;CTC3 PERIOD=999936 uS
0261 DEFN 93
0262 ;
0263 ;
0264 ; INITIALIZE SID CHANNEL B FOR ASYNCHRONOUS SERIAL
0265 ; INTERFACE TO PRINTER OR TERMINAL
0266 ;
0267 SIDCPA EQU SID+0 ;SID DATA PORT A
0268 SIDDPB EQU SID+1 ;SID DATA PORT B
0269 SIDCPA EQU SID+2 ;SID CONTROL/STATUS PORT A
0270 SIDCPB EQU SID+3 ;SID CONTROL/STATUS PORT B
0271
0272 DEFN 1,BAUDE ;SET COM 8:16 TO 300 BD DEFAULT
0273 DEFN 0101B
0274
0275 DEFN 11,SIDCPB ;SELECT REGISTER #4
0276 DEFN 4 ;16X CLK,1 STOP BIT,ODD PARITY
0277 DEFN 010000101B ;SELECT REGISTER #1
0278 DEFN 1 ;STATUS AFFECTS VECTOR.
0279 DEFN 000000100R ;NO INTERRUPTS
0280 DEFN 3 ;SELECT REGISTER #3
0281 DEFN 010000001B ;7 BITS/RX CHAR
0282 DEFN 5 ;SELECT REGISTER #5
0283 DEFN 10101010B ;7 BITS/TX CHAR, ASSERT DTR
0284 DEFN 2 ;SELECT REGISTER #2
0285 DEFN SIDVEC ;LOAD INTERRUPT VECTOR BASE
0286 DEFN 2 ;SELECT READ REG#2 FOR SIC TEST
0287
0288 DEFN -1 ;END-OF-TABLE
0289 ;
0290 ; INIT DONE
0291 ;
0292 ;
0293 ;
0294 ; ***** INCLUDE MONITOR.ASM *****
0295 ; *****
0296 ; ***** BASIC HEX MONITOR FOR Z-80 PROCESSORS *****
0297 ; ***** 3-Aug-80 *****
0298 ; *****
0299 ; *****
0300 ; *****
0301 ; *****
0302 ; *****
0303 ; *****

```

```

F19F 20F3
F1A1 BDF1
>0021
0366
0367
0368
0369 DMSIZ EDU $-CMDTAB
0370 ;
0371 ; *****
0372 ; *****
0373 ; *****
0374 ; *****
0375 ; *****
0376 ; *****
0377 ; *****
0378 ; *****
0379 ; *****
0380 ; *****
0381 ; *****
0382 ; --- DISK BOOT LOADER COMMAND ---
0383 ;
0384 ROOT: LD C,0 ;SELECT DRIVE 0 FOR BOOT LOAD
0385 CALL SELECT
0386 NZ,DSKERR-$
0387 CALL HOME ;HOME HEAD TO TRACK 0
0388 NZ,DSKERR-$;ERROR IF NOT READY OR AT TR0
0389 HL,0080H ;POINT TO CP/M READ BUFFER
0390 LD C,1 ;SELECT SECTOR 1
0391 CALL READ ;READ TRACK 0/ SECTOR 1
0392 NZ,DSKERR-$
0393 JR AF ;CLEAN UP STACK
0394 FDF JP ;60 EXECUTE LOADER
0395 ;
0396 ;
0397 ; --- DISK SECTOR READ COMMAND ---
0398 ;
0399 DSKCMD: CP 3 ;CHECK PARAMETER COUNT
0400 SCF
0401 RET
0402 LD C,L ;USE FIRST ARG AS UNIT#
0403 CALL SELECT
0404 NZ,DSKERR-$
0405 HL,PARAM2
0406 LD C,(HL) ;USE SECOND ARG AS TRACK#
0407 CALL SEEK
0408 NZ,DSKERR-$
0409 JR HL,PARAM3 ;USE THIRD ARG AS SECTOR#
0410 LD C,(HL)
0411 HL,0080H
0412 CALL READ
0413 SET O,A ;MARK ERROR BYTE AS DUE TO READ
0414 JR NZ,DSKERR-$
0415 LD HL,0080H
0416 LD DE,B
0417 JP DUMP ;DUMP DISK READ BUFFER & RETURN
0418 ;
0419 ;
0420 DSKERR: LD C,A ;SAVE 1771 STATUS
0421 PNEXT
0422 DEFN 'disk error'
0423
0424
0425
0426
0427
0428
0429
0430
0431
0432
0433
0434
0435
0436
0437
0438
0439
0440
0441
0442
0443
0444
0445
0446
0447
0448
0449
0450
0451
0452
0453
0454
0455
0456
0457
0458
0459
0460
0461
0462
0463
0464
0465
0466
0467
0468
0469
0470
0471
0472
0473
0474
0475
0476
0477
0478
0479
0480
0481
0482
0483
0484
0485
0486
0487
0488
0489
0490
0491
0492
0493
0494
0495
0496
0497
0498
0499
0500
0501
0502
0503
0504
0505
0506
0507
0508
0509
0510
0511
0512
0513
0514
0515
0516
0517
0518
0519
0520
0521
0522
0523
0524
0525
0526
0527
0528
0529
0530
0531
0532
0533
0534
0535
0536
0537
0538
0539
0540
0541
0542
0543
0544
0545
0546
0547
0548
0549
0550
0551
0552
0553
0554
0555
0556
0557
0558
0559
0560
0561
0562
0563
0564
0565
0566
0567
0568
0569
0570
0571
0572
0573
0574
0575
0576
0577
0578
0579
0580
0581
0582
0583
0584
0585
0586
0587
0588
0589
0590
0591
0592
0593
0594
0595
0596
0597
0598
0599
0600
0601
0602
0603
0604
0605
0606
0607
0608
0609
0610
0611
0612
0613
0614
0615
0616
0617
0618
0619
0620
0621
0622
0623
0624
0625
0626
0627
0628
0629
0630
0631
0632
0633
0634
0635
0636
0637
0638
0639
0640
0641
0642
0643
0644
0645
0646
0647
0648
0649
0650
0651
0652
0653
0654
0655
0656
0657
0658
0659
0660
0661
0662
0663
0664
0665
0666
0667
0668
0669
0670
0671
0672
0673
0674
0675
0676
0677
0678
0679
0680
0681
0682
0683
0684
0685
0686
0687
0688
0689
0690
0691
0692
0693
0694
0695
0696
0697
0698
0699
0700
0701
0702
0703
0704
0705
0706
0707
0708
0709
0710
0711
0712
0713
0714
0715
0716
0717
0718
0719
0720
0721
0722
0723
0724
0725
0726
0727
0728
0729
0730
0731
0732
0733
0734
0735
0736
0737
0738
0739
0740
0741
0742
0743
0744
0745
0746
0747
0748
0749
0750
0751
0752
0753
0754
0755
0756
0757
0758
0759
0760
0761
0762
0763
0764
0765
0766
0767
0768
0769
0770
0771
0772
0773
0774
0775
0776
0777
0778
0779
0780
0781
0782
0783
0784
0785
0786
0787
0788
0789
0790
0791
0792
0793
0794
0795
0796
0797
0798
0799
0800
0801
0802
0803
0804
0805
0806
0807
0808
0809
0810
0811
0812
0813
0814
0815
0816
0817
0818
0819
0820
0821
0822
0823
0824
0825
0826
0827
0828
0829
0830
0831
0832
0833
0834
0835
0836
0837
0838
0839
0840
0841
0842
0843
0844
0845
0846
0847
0848
0849
0850
0851
0852
0853
0854
0855
0856
0857
0858
0859
0860
0861
0862
0863
0864
0865
0866
0867
0868
0869
0870
0871
0872
0873
0874
0875
0876
0877
0878
0879
0880
0881
0882
0883
0884
0885
0886
0887
0888
0889
0890
0891
0892
0893
0894
0895
0896
0897
0898
0899
0900
0901
0902
0903
0904
0905
0906
0907
0908
0909
0910
0911
0912
0913
0914
0915
0916
0917
0918
0919
0920
0921
0922
0923
0924
0925
0926
0927
0928
0929
0930
0931
0932
0933
0934
0935
0936
0937
0938
0939
0940
0941
0942
0943
0944
0945
0946
0947
0948
0949
0950
0951
0952
0953
0954
0955
0956
0957
0958
0959
0960
0961
0962
0963
0964
0965
0966
0967
0968
0969
0970
0971
0972
0973
0974
0975
0976
0977
0978
0979
0980
0981
0982
0983
0984
0985
0986
0987
0988
0989
0990
0991
0992
0993
0994
0995
0996
0997
0998
0999
1000

```

```

F128 CDECF3 0304 PROMPT: CALL FNEXT
F129 000A 0305 DEFB CR,LF
F130 2A20 0306 DEFN *
F131 04 0307 DEFB ED
F132 2186FF 0308 HL,LINBUF
F133 0E20 0309 LD C,32
F134 03BF3 0310 CALL GETLN
F135 3035 0311 JR C,WHAT-$
F136 0312
F137 0313
F138 AF 0314 XDR
F139 3284FF 0315 LD LD
F140 CDFCF3 0316 CALL (ESCFLG),A
F141 3AB8FF 0317 LD DRLF$
F142 FE0D 0318 CP A,(LINEUF)
F143 28E0 0319 JR Z,PROMPT-$
F144 2182F1 0320 LD Z,PROMPT-$
F145 010B00 0321 LD HL,CMDTAB
F146 CD60F3 0322 LD BC,CMD$IZ/3
F147 201C 0323 CALL SEARCH
F148 05 0324 JR NZ,WHAT-$
F149 FD2189FF 0325 LD BC
F150 CD6AF3 0326 LD IY,LINBUF+1
F151 DDE1 0327 JR C,WHAT-$
F152 3810 0328 LD PARAMS
F153 2470FF 0329 LD HL,(PARAM1)
F154 ED5B7E7F 0330 LD DE,(PARAM2)
F155 ED4B80FF 0331 LD BC,(PARAM3)
F156 CD80F1 0332 CALL CALLX
F157 30B9 0333 JR NC,PROMPT-$
F158 CDECF3 0334 CALL CALL SUBROUTINE @ IX
F159 20776B61 0335 DEFN * what ?
F160 74203F
F161 07 0336 DEFB *G'-64
F162 04 0337 DEFB ED
F163 18AB 0338 JR PROMPT-$
F164 0339
F165 0340
F166 0341 CALLX: JP (IX)
F167 0342
F168 0343
F169 0344
F170 0345 CMDTAB: DEFB *R'
F171 52 0346 DEFB *D'
F172 49 0347 DEFB *I'
F173 47 0348 DEFB *B'
F174 54 0349 DEFB *T'
F175 46 0350 DEFB *F'
F176 4D 0351 DEFB *M'
F177 43 0352 DEFB *C'
F178 42 0353 DEFB *B'
F179 44 0354 DEFB *D'
F180 53 0355 DEFB *S'
F181 29F3
F182 05F2 0356 DEFN SWITCH
F183 A3F1 0357 DEFW MEMDMP
F184 E6F2 0358 DEFW BOOT
F185 57F2 0359 DEFW BLOCK
F186 DBF2 0360 DEFW VIEW
F187 BDF2 0361 DEFW FILL
F188 B1F2 0362 DEFW TEST
F189 FEF2 0363 DEFW GOTO
F190 0364 DEFW INCMD
F191 0365
F192 0366
F193 0367
F194 0368
F195 0369
F196 0370
F197 0371
F198 0372
F199 0373
F200 0374
F201 0375
F202 0376
F203 0377
F204 0378
F205 3D MEMDMP: DEC A
F206 2B06 JR Z,MDMP2-$
F207 3D DEC A
F208 2B08 JR Z,MDMP3-$
F209 2B08 LD HL,(LAST)
F210 2B66FF LD DE,16
F211 180D JR MDMP3B-$
F212 0444
F213 EB MDMP3: EX DE,HL
F214 ED52 SBC HL,DE
F215 0604 LD B,4
F216 CB3C LD H
F217 CB1D RR L
F218 10FA DJNZ MDMP3A-$
F219 23 INC HL
F220 EB EX DE,HL
F221 CD27F2 MDMP3E: CALL DUMP
F222 2286FF LD (LAST),HL
F223 C9 RET
F224 09
F225 09
F226 C9
F227 E5 PUSH HL
F228 CDCDF3 CALL PUT4HS
F229 CD02F4 CALL SPACE
F230 0610 LD B,16
F231 7E LD A,(HL)
F232 23 INC HL
F233 CD02F3 CALL PUT2HS
F234 10F9 DJNZ DUMP2-$
F235 E1 POP HL
F236 0610 LD B,16
F237 7E LD A,(HL)
F238 23 INC HL
F239 7E LD A,(HL)
F240 CBBF RES 7,A
F241 FE20 CP 20H
F242 3804 JR C,DUMP4-$
F243 FE7F CP 7FH
F244 3802 JR C,DUMP5-$
F245 3E3E LD A,
F246 CD15F4 DUMP4: LD A,
F247 10ED DUMP5: CALL OUTPUT
F248 CD02F3 DJNZ DUMP3-$
F249 C0 CALL DRLF$
F250 1B RET NZ
F251 1B DEC DE
F252 7A LD A,D
F253 83 OR E
F254 20D1 JR N7,DUMP-$
F255 C9 RET
F256 C9
F257 EDCEFF 0491 VIEW: CALL MDATA
F258 CD07F4 0492 CALL ECHO
F259 FE0D 0493 CP CR
F260 FE20 0494 JR Z,VIEW4-$
F261 FE2D 0495 CP
F262 2B19 0496 JR Z,VIEW5-$
F263 2B19 0497 VIEW2: CALL ASCHEX
F264 CDEDF3
F265
F266
F267
F268
F269
F270
F271
F272
F273
F274
F275
F276
F277
F278
F279
F280
F281
F282
F283
F284
F285
F286
F287
F288
F289
F290
F291
F292
F293
F294
F295
F296
F297
F298
F299
F300
F301
F302
F303
F304
F305
F306
F307
F308
F309
F310
F311
F312
F313
F314
F315
F316
F317
F318
F319
F320
F321
F322
F323
F324
F325
F326
F327
F328
F329
F330
F331
F332
F333
F334
F335
F336
F337
F338
F339
F340
F341
F342
F343
F344
F345
F346
F347
F348
F349
F350
F351
F352
F353
F354
F355
F356
F357
F358
F359
F360
F361
F362
F363
F364
F365
F366
F367
F368
F369
F370
F371
F372
F373
F374
F375
F376
F377
F378
F379
F380
F381
F382
F383
F384
F385
F386
F387
F388
F389
F390
F391
F392
F393
F394
F395
F396
F397
F398
F399
F400

```

PFM Monitor Listing

(continued)

```

F268 3F 049B DCF
F269 D0 0499 RET NC
F26A 07 0500 RLCA
F26B 07 0501 RLCA
F26C 07 0502 RLCA
F26D 07 0503 RLCA
F26E 4F 0504 LD C,A
F26F CD07F4 0505 CALL ECHO
F272 CD8DF3 0506 CALL ASCHEX
F275 3F 0507 CDF
F276 D0 0508 RET NC
F277 B1 0509 DR C
F278 77 0510 VIEW3: LD (HL),A
F279 CDB9F2 0511 CALL CHECK
F27C 23 0512 VIEW4: INC HL
F27D 23 0513 INC HL
F27E 28 0514 VIEW5: DEC HL
F27F 18D6 0515 JR VIEW-#
0516 ;
0517 ;
0518 ;
0519 ;--- JUMP TO MEMORY LOCATION COMMAND ---
0520 ;
F281 3D 0521 BOTO: DEC A ;CHECK PARAMETER COUNT
F282 37 0522 SCF
F283 C0 0523 RET NZ
F284 E5 0524 PUSH HL
F285 DDE1 0525 POP IX
F287 CD86F1 0526 CALL CALLX
F28A B7 0527 DR A
F28B C9 0528 RET
0529 ;
0530 ;
0531 ;
0532 ;--- MEMORY READ/WRITE DIAGNOSTIC COMMAND ---
0533 ;
F28C FE02 0534 TEST: CP Z ;CHECK PARAMETER COUNT
F28E C0 0535 SCF
F28F C0 0536 RET NZ
F290 13 0537 INC DE
F291 5A 0538 LD E,D
F292 54 0539 LD D,H
F293 0600 0540 LD E,0
F295 62 0541 TEST1: LD H,D
F296 2E00 0542 LD L,0
F298 7D 0543 TEST2: LD A,L
F299 4C 0544 XOR H
F29A AB 0545 XOR B
F29B 77 0546 LD (HL),A
F29C 23 0547 INC HL
F29D 7C 0548 LD A,H
F29E BB 0549 CP E
F29F 20F7 0550 JR NZ,TEST2-#
0551 ;NOW READ BACK EACH BYTE & COMPARE
0552 LD H,D
0553 LD L,0
F2A4 7D 0554 TEST3: LD A,L
F2A5 AC 0555 XOR H
F2A6 AB 0556 XOR B
F2A7 CDB9F2 0557 CALL CHECK
F2AA C0 0558 RET NZ
    
```

```

F2F7 EB F2F7 DE,HL ;HL & DE FOR BYTECOUNT
F2F8 D5 DE
F2F9 C5 PUSH
F2FA D1 POP
F2FB C1 POP
F2FC 03 INC
F2FD C9 RET
0623 ;
0624 ;
0625 ;
0626 ;
0627 ;
0628 ;
0629 ;
0630 ;
0631 ;
0632 ;
0633 ;
0634 ;--- READ FROM INPUT PORT COMMAND ---
0635 ;
0636 INCMD: DEC A ;CHECK IF PARAMETER COUNT=1
0637 SCF
0638 RET NZ
0639 LD C,L ;POINT C TO INPUT PORT
0640 IN1: CALL CRLFS
0641 LD A,C
0642 CALL PUT2HS
0643 IN A,(C)
0644 CALL PUT2HS
0645 ECHO
0646 CP CR
0647 JR Z,IN2-#
0648 CP ;
0649 JR Z,IN3-#
0650 DR A
0651 RET
0652 ;
0653 IN2: INC C
0654 INC C
0655 IN3: DEC C
0656 JR IN1-#
0657 ;
0658 ;
0659 ;
0660 ;--- WRITE TO OUTPUT PORT COMMAND ---
0661 ;
0662 OUTCMD: CP Z ;CHECK IF PARAMETER COUNT=2
0663 SCF
0664 RET NZ
0665 LD C,L ;POINT C TO OUTPUT PORT
0666 ED59 OUT (C),E ;OUTPUT DATA PASSED IN E
0667 DR A
0668 RET
0669 ;
0670 ;
0671 ;--- SWITCH CONSOLE OUTPUT DEVICE COMMAND ---
0672 ;
0673 SWITCH: LD HL,COFLAG ;TOGGLE CONSOLE OUT TYPE FLAG
0674 INC (HL)
0675 BIT 0,(HL)
0676 LD HL,SIOOUT
0677 JR Z,SWITZ-# ;JUMP IF ZERO TO ONE TRANSITION
0678 LD HL,CRYOUT
0679 SWITZ: LD (CONOUT+1),HL ;STORE NEW CNSL OUT ADDR
0680 DR A
0681 ;
0682 ;
0683 ;*****
0684 ;* CONSOLE I/O PACKAGE AND UTILITY ROUTINES *
0685 ;*
0686 ;*
0687 ;*****
0688 ;
0689 ;
    
```



```

F2A8 23      0559      HL          ;ELSE GO ON TO NEXT BYTE
F2AC 7C      0560      A,H
F2AD BB      0561      E
F2AE 20F4    0562      NZ,TEST3-$ ;CHECK FOR END OF BLOCK
F2B0 04      0563      B
F2B1 3E2B    0564      A, '+'
F2B3 CD15F4  0565      CALL       ;PRINT '+' AND ALLOW FOR EXIT
F2B6 28DD    0566      JR        ;DO ANOTHER PASS IF NO ESCAPE
F2B8 C9      0567      RET
          0568      ;
          0569      ;
          0570      ;
          0571      ;
          0572      ;
          0573      ;
          0574      ;
          0575      ;
          0576      ;
          0577      ;
          0578      ;
          0579      ;
          0580      ;
          0581      ;
          0582      ;
          0583      ;
          0584      ;
          0585      ;
          0586      ;
          0587      ;
          0588      ;
          0589      ;
          0590      ;
          0591      ;
          0592      ;
          0593      ;
          0594      ;
          0595      ;
          0596      ;
          0597      ;
          0598      ;
          0599      ;
          0600      ;
          0601      ;
          0602      ;
          0603      ;
          0604      ;
          0605      ;
          0606      ;
          0607      ;
          0608      ;
          0609      ;
          0610      ;
          0611      ;
          0612      ;
          0613      ;
          0614      ;
          0615      ;
          0616      ;
          0617      ;
          0618      ;
          0619      ;
          0620      ;
          0621      ;
          0622      ;
          0623      ;
          0624      ;
          0625      ;

F20E FE03     0577      DEF B
F20A F1      0578      POP
F208 C3D2F3  0579      JP
          0580      ;
          0581      ;
          0582      ;
          0583      ;
          0584      ;
          0585      ;
          0586      ;
          0587      ;
          0588      ;
          0589      ;
          0590      ;
          0591      ;
          0592      ;
          0593      ;
          0594      ;
          0595      ;
          0596      ;
          0597      ;
          0598      ;
          0599      ;
          0600      ;
          0601      ;
          0602      ;
          0603      ;
          0604      ;
          0605      ;
          0606      ;
          0607      ;
          0608      ;
          0609      ;
          0610      ;
          0611      ;
          0612      ;
          0613      ;
          0614      ;
          0615      ;
          0616      ;
          0617      ;
          0618      ;
          0619      ;
          0620      ;
          0621      ;
          0622      ;

F20E FE03     0577      DEF B
F20A F1      0578      POP
F208 C3D2F3  0579      JP
          0580      ;
          0581      ;
          0582      ;
          0583      ;
          0584      ;
          0585      ;
          0586      ;
          0587      ;
          0588      ;
          0589      ;
          0590      ;
          0591      ;
          0592      ;
          0593      ;
          0594      ;
          0595      ;
          0596      ;
          0597      ;
          0598      ;
          0599      ;
          0600      ;
          0601      ;
          0602      ;
          0603      ;
          0604      ;
          0605      ;
          0606      ;
          0607      ;
          0608      ;
          0609      ;
          0610      ;
          0611      ;
          0612      ;
          0613      ;
          0614      ;
          0615      ;
          0616      ;
          0617      ;
          0618      ;
          0619      ;
          0620      ;
          0621      ;
          0622      ;

F2E6 FE03     0608      BLOCK: CP 3
F2E8 37      0609      SCF
F2E9 C0      0610      RET
F2EA CDEF2   0611      CALL BLOCAD
F2ED 79      0612      LD A,C
F2EE B0      0613      OR B
F2EF C8      0614      RET Z
F2F0 ED80    0615      LDIR
F2F2 C9      0616      RET
          0617      ;
          0618      ;
          0619      ;
          0620      ;
          0621      ;
          0622      ;

F2F3 EB      0620      BLOCAD: EX DE,HL
F2F4 E7      0621      OR A
F2F5 ED52    0622      SBC HL,DE
          0623      ;
          0624      ;
          0625      ;
          0626      ;
          0627      ;
          0628      ;
          0629      ;
          0630      ;
          0631      ;
          0632      ;
          0633      ;
          0634      ;
          0635      ;
          0636      ;
          0637      ;
          0638      ;
          0639      ;
          0640      ;
          0641      ;
          0642      ;
          0643      ;
          0644      ;
          0645      ;
          0646      ;
          0647      ;
          0648      ;
          0649      ;
          0650      ;
          0651      ;
          0652      ;
          0653      ;
          0654      ;
          0655      ;
          0656      ;
          0657      ;
          0658      ;
          0659      ;
          0660      ;
          0661      ;
          0662      ;
          0663      ;
          0664      ;
          0665      ;
          0666      ;
          0667      ;
          0668      ;
          0669      ;
          0670      ;
          0671      ;
          0672      ;
          0673      ;
          0674      ;
          0675      ;
          0676      ;
          0677      ;
          0678      ;
          0679      ;
          0680      ;
          0681      ;
          0682      ;
          0683      ;
          0684      ;
          0685      ;
          0686      ;
          0687      ;
          0688      ;
          0689      ;
          0690      ;
          0691      ;
          0692      ;
          0693      ;
          0694      ;
          0695      ;
          0696      ;
          0697      ;
          0698      ;
          0699      ;
          0700      ;
          0701      ;
          0702      ;
          0703      ;
          0704      ;
          0705      ;
          0706      ;
          0707      ;
          0708      ;
          0709      ;
          0710      ;
          0711      ;
          0712      ;
          0713      ;
          0714      ;
          0715      ;
          0716      ;
          0717      ;
          0718      ;
          0719      ;
          0720      ;
          0721      ;
          0722      ;
          0723      ;
          0724      ;
          0725      ;
          0726      ;
          0727      ;
          0728      ;
          0729      ;
          0730      ;
          0731      ;
          0732      ;
          0733      ;
          0734      ;
          0735      ;
          0736      ;
          0737      ;
          0738      ;
          0739      ;
          0740      ;
          0741      ;
          0742      ;
          0743      ;
          0744      ;

F33B 41      0690      F33B 41
F33C CD07F4  0691      F33C CD07F4
F33F FE0D    0692      F33F FE0D
F341 280E    0693      F341 280E
F343 FE08    0694      F343 FE08
F345 280C    0695      F345 280C
F347 FE20    0696      F347 FE20
F349 DB      0697      F349 DB
F34A 77      0698      F34A 77
F34B 23      0699      F34B 23
F34C 0D      0700      F34C 0D
F34D 20ED    0701      F34D 20ED
F34F 37      0702      F34F 37
F350 C9      0703      F350 C9
          0704      ;
          0705      ;
          0706      ;
          0707      ;
          0708      ;
          0709      ;
          0710      ;
          0711      ;
          0712      ;
          0713      ;
          0714      ;
          0715      ;
          0716      ;
          0717      ;
          0718      ;
          0719      ;
          0720      ;
          0721      ;
          0722      ;
          0723      ;
          0724      ;
          0725      ;
          0726      ;
          0727      ;
          0728      ;
          0729      ;
          0730      ;
          0731      ;
          0732      ;
          0733      ;
          0734      ;
          0735      ;
          0736      ;
          0737      ;
          0738      ;
          0739      ;
          0740      ;
          0741      ;
          0742      ;
          0743      ;
          0744      ;

F353 2B      0709      F353 2B
F354 DDEF3   0710      F354 DDEF3
F357 200B    0711      F357 200B
F359 04      0712      F359 04
F35A 0C      0713      F35A 0C
F35B 7B      0714      F35B 7B
F35C 91      0715      F35C 91
F35D 30DD    0716      F35D 30DD
F35F C9      0717      F35F C9
          0718      ;
          0719      ;
          0720      ;
          0721      ;
          0722      ;
          0723      ;
          0724      ;
          0725      ;
          0726      ;
          0727      ;
          0728      ;
          0729      ;
          0730      ;
          0731      ;
          0732      ;
          0733      ;
          0734      ;
          0735      ;
          0736      ;
          0737      ;
          0738      ;
          0739      ;
          0740      ;
          0741      ;
          0742      ;
          0743      ;
          0744      ;

F360 EDB1    0721      F360 EDB1
F362 C0      0722      F362 C0
F363 09      0723      F363 09
F364 09      0724      F364 09
F365 09      0725      F365 09
F366 4E      0726      F366 4E
F367 23      0727      F367 23
F368 46      0728      F368 46
F369 C9      0729      F369 C9
          0730      ;
          0731      ;
          0732      ;
          0733      ;
          0734      ;
          0735      ;
          0736      ;
          0737      ;
          0738      ;
          0739      ;
          0740      ;
          0741      ;
          0742      ;
          0743      ;
          0744      ;

F36A 010000  0734      F36A 010000
F36D FD7E00  0735      F36D FD7E00
F370 FE0D    0736      F370 FE0D
F372 200B    0737      F372 200B
F374 AF      0738      F374 AF
F375 C9      0739      F375 C9
          0740      ;
          0741      ;
          0742      ;
          0743      ;
          0744      ;

F376 0C      0741      F376 0C
F377 0C      0742      F377 0C
F378 CB59    0743      F378 CB59
F37A 37      0744      F37A 37

```

(continued next issue)

SUBSCRIPTION FORM

(It's OK to brag!)

- I own a big board (Hooray!)
- I don't own a Big Board but am very interested (There's hope)

	EXPERTISE Guru=5 Novice=0	INTEREST Fanatic=5 None=0
Software Systems	<input type="checkbox"/>	<input type="checkbox"/>
Software Applications	<input type="checkbox"/>	<input type="checkbox"/>
Languages 1. _____	<input type="checkbox"/>	<input type="checkbox"/>
2. _____	<input type="checkbox"/>	<input type="checkbox"/>
3. _____	<input type="checkbox"/>	<input type="checkbox"/>
Hardware	<input type="checkbox"/>	<input type="checkbox"/>

Are you willing to be a resource in the areas where your expertise is 4 or 5?

- love to
- probably
- maybe
- no

How are you using the Big Board?

- Home System
- Business System
- Software Development
- OEM
- Education
- Other _____

What kinds of information do you need right now?

What are your hardware/software needs now?

In the near future? _____

What kind of exciting adventure (misadventure) are you working on?

If you get the idea that this document is as interested in enlisting your aid and ideas as it is in getting a subscription, you're right. Lots of people are willing to subscribe, lots of people have ideas - and we'd like to encourage lots of people (especially you) to take an hour or two and put ideas and needs and accomplishments down on paper or disk. Then we can pass them along to others and that's what this journal is all about.

Send me six issues (1 yr.) of MICRO CORNUCOPIA. I understand that I can cancel at any time and receive a refund for the balance of the subscription. (Issue #1 was published in August 1981.)

U.S.

- \$16.00
- \$20.00 (1st class mail)
- Back issues, Specify #s _____ \$3.00 each

Canada & Mexico

- \$20.00 (U.S. funds)
- Back issues, Specify #s _____ \$3.00 each (U.S. funds)

Other Foreign

- \$26.00 (U.S. funds)
- Back issues, Specify #s _____ \$5.00 each (U.S. funds)


NAME _____ PHONE (?) _____

ADDRESS _____

CITY _____ STATE _____ ZIP _____

Renewal

MICRO CORNUCOPIA • 11740 N.W. West Rd • Portland, Oregon • 97229



MICRO CORNUCOPIA

Journal of the Big Board Users Group

P. O. BOX 223
BEND, OREGON 97709