




SAVE THIS USE AND CARE BOOK

10-Cup Drip Coffeemaker



(DCM903WH Shown)



1-800-231-9786

QUESTIONS? Please call us TOLL FREE!

**MODELS DCM200C, DCM703C,
DCM900WH, DCM900BK,
DCM902WH, DCM903WH,
DCM912BK, DCM913BK**

**IMPORTANT:
PLEASE WASH
CARAFE BEFORE
FIRST USE!**

IMPORTANT SAFEGUARDS


When using electrical appliances, in order to reduce the risk of fire, electric shock, and/or injury to persons, basic safety precautions should always be followed, including the following:

- Please read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock and injury to persons, do not immerse cord, plug, or coffeemaker base in water or other liquid.
- To prevent fire or electric shock, do not remove bottom cover from coffeemaker base. There are no user-serviceable part inside. Repair should be done by authorized service personnel only.
- Close supervision is necessary when any appliance is used by or near children.
- Allow to cool before putting on or taking off parts and before cleaning the coffeemaker.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Return the appliance to the nearest Black & Decker (U.S.) Inc., Household Appliance Company-Owned or Authorized Service Center for examination, repair, or adjustment.
- The use of an accessory not evaluated for use with this coffeemaker may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter or touch hot surfaces.
- Do not place on or near a hot gas or electric burner or in a hot oven.
- Do not use coffeemaker for other than intended use.
- Keep lid on carafe while serving coffee.
- The carafe is designed for use with this coffeemaker. It must never be used on a range top or in a microwave oven.
- Do not set a hot carafe on a wet or cold surface.
- Do not use a cracked carafe or a carafe with a loose or weakened handle.
- Do not clean carafe with cleansers, steel wool pads, or other abrasive material.
- Remember to place carafe on the "Keeps Hot" Plate before brewing and when using the automatic timer on clock models.
- Do not pour liquid other than water or the cleaning solution specified in this manual into the water reservoir.
(See "Mineral Deposits and Cleaning," page 11.)
- Do not move entire unit when carafe contains hot liquid.

- Do not operate in the presence of explosive and/or flammable fumes.
- This appliance is intended FOR HOUSEHOLD USE ONLY and not for commercial or industrial use.

SAVE THESE INSTRUCTIONS

- 1 Water Reservoir Lid
- 2 Filter Basket
- 3 10-Cup Level Mark on Handle
- 4 Carafe
- 5 "Keeps Hot" Plate (Under Carafe)
- 6 Power "On" Light (Red)
- 7 Brew Later Light (Green)
- 8 Clock/Control Panel
- 9 Carafe Lid
- 10 Drip Stop (Under Basket)
- 11 Water Reservoir



POLARIZED PLUG

This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse it. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

TAMPER-RESISTANT SCREW

This appliance is equipped with a tamper-resistant screw to prevent removal of the outer cover. To reduce the risk of fire or electric shock, **do not attempt to remove the outer cover**. There are no consumer serviceable parts inside. Repair should be done only by authorized service personnel (see pages 13-14 for a list of Black & Decker Company-Owned Service Centers).

How To Use

SETTING THE CLOCK (MODEL DCM703C/ DCM903WH/ DCM913BK)




Figure A

NOTE: It is not necessary to set the clock before brewing.

1. Plug the Coffeemaker into a standard electrical outlet. The Clock will flash 12:00 a.m. It will remain flashing until either the Up or Down Buttons are pressed (Figure A).
2. To move the clock quickly to the correct time, push and hold either the Up or Down Button until the current time of day, a.m. or p.m., is reached. (You must hold the Button for a few seconds before the time shown begins to change.)
3. To move forward or backward one minute at a time, push and release the Up or Down Button as many times as necessary until the desired time is reached.

NOTE: Before brewing coffee, the inside of your Coffeemaker and carafe must be cleaned.

BEFORE BREWING COFFEE

1. Brew 10 cups of fresh water only. Follow the instructions under "Brewing Coffee - With or Without Clocks" (pages 4 - 6), but do not add coffee grounds to the paper filter.
2. When all the water has brewed into the Carafe, turn the Coffeemaker off.
3. Wait 10 minutes, discard the water from the Carafe, then repeat steps 1 and 2.
4. Wash and dry the Filter Basket, Carafe, and Carafe Lid.

BREWING COFFEE - MODELS WITH CLOCK (DCM703C/ DCM903WH/ DCM913BK)

1. Flip up the Carafe Lid to fill the Carafe with cold water to the level for the desired number of cups.
2. Open the Water Reservoir Lid and pour the water from the Carafe into the Water Reservoir. Close the Water Reservoir Lid.


3. Remove the Filter Basket and place a standard cupcake-style paper coffee filter in it.
4. Put coffee grounds in the filter, using 1 level tablespoon of drip grind coffee for each cup (5 oz.) of brewed coffee.

NOTE: Use more or less grounds per cup to suit your taste. When brewing 2-4 cups, use slightly more grounds per cup (20 tablespoons maximum).

5. Shake the Filter Basket to spread the grounds, and place the Filter Basket back in the Coffee-maker. Be sure the Filter Basket is pushed all the way into the unit.
6. Place the Carafe on the "Keeps Hot" Plate, making sure the Carafe Lid is on the Carafe.
7. Depress the ON/OFF Button. A red Power "On" Light will glow showing the unit is brewing and the "Keeps Hot" plate will automatically come on.
8. To serve coffee, remove the Carafe from the "Keeps Hot" Plate. Always keep the Carafe Lid on the Carafe when pouring.
9. To keep coffee hot, place the Carafe back on the "Keeps Hot" Plate when not serving.
10. The "Keeps Hot" Plate will remain on for two hours then will shut off automatically. If you wish to turn the Coffeemaker off sooner, depress the ON/OFF Button and the red Power "On" Light will turn off.
11. If you'd like to extend the "Keeps Hot" after the auto shut-off, press the ON/OFF Button to turn the "Keeps Hot" Plate on for two more hours.

NOTE: The amount of coffee in the Carafe may be slightly less than the amount of water placed in the Water Reservoir, since some water is absorbed by the coffee grounds during brewing.

SNEAK-A-CUP™ INTERRUPT FEATURE



The **clock** models have a Sneak-A-Cup™ Interrupt Feature – an automatic drip stop. During the brewing cycle, the Carafe can be removed to pour a cup of coffee from the Carafe. (Figure B)

IMPORTANT: *The Carafe must be replaced under the Brew Basket in less than a minute to prevent the Brew Basket from overflowing.*

BREWING COFFEE - MODELS WITHOUT CLOCKS - (DCM200C, DCM902WH, DCM912BK)

1. Remove the Carafe Lid to fill the Carafe with cold water to the level for the desired number of cups. Open the Water Reservoir Lid, and pour the water from the Carafe into the Water Reservoir. Close the Water Reservoir Lid.
2. Remove the Filter Basket and place a standard, cupcake-style paper coffee filter in it.
3. Put coffee grounds in the filter, using 1 level tablespoon of drip grind coffee for each cup (5 oz.) of brewed coffee.

NOTE: Use more or less grounds per cup to suit your taste. When brewing 2-4 cups, use slightly more grounds per cup (20 tablespoons maximum).

4. Shake the Filter Basket to spread the grounds, and place the Filter Basket back in the Coffee-maker. Be sure the Filter Basket is pushed all the way into the unit.
5. Place the Carafe on the “Keeps Hot” Plate making sure the Carafe Lid is on the Carafe.




Figure C

6. **Models DCM902WH, DCM912BK:** Flip the OFF/ ON Switch to the right to turn the Coffeemaker on. (Figure C)

7. **Models DCM200C, DCM900WH, DCM900BK:** Slide the Switch to the right and a red indicator will be visible next to the Switch. (Figure D) The “Keeps Hot” plate will automatically come on when the brewing begins.




Figure D

8. Let all the brewed coffee drip from the Filter Basket before removing the Carafe.

NOTE: The amount of coffee in the Carafe may be slightly less than the amount of water placed in the Water Reservoir, since some water is absorbed by the coffee grounds during brewing.

9. To serve coffee, remove the Carafe from the “Keeps Hot” Plate. Always keep the Carafe Lid on the Carafe when pouring.
10. To keep coffee hot, place the Carafe back on the “Keeps Hot” Plate when not serving.
11. **Models DCM902WH, DCM912BK:** To turn the Coffeemaker off when the Carafe is empty or you no longer want to keep the coffee hot, flip the Switch to the left.
12. **Models DCM200C, DCM900WH, DCM900BK:** Slide the Switch to OFF. The “Keeps Hot” plate will go off when the unit is turned off.

PROGRAMMING THE COFFEEMAKER TO BREW LATER (MODELS DCM703C/ DCM903WH/DCM913BK)






Figure E

1. Press and release the Brew Later Button under the Program heading on the Coffeemaker. A clock symbol () will appear on the right side of the display indicating you are in the Brew Later Program mode. (Figure E)

NOTE: The first time the Program Brew Later Button is pressed after the Coffeemaker has been plugged in, the display will show a colon, 3 broken lines, and the clock symbol (- : - - ). This indicates the Timer has no Brew Later time programmed into its memory. Press the Up or Down Buttons to program a Brew Later time. This condition will also occur if the Coffeemaker is unplugged or there is a power outage for more than 30 seconds.

2. Press and hold either the Up or Down Button until the desired Brew Later start time - a.m. or p.m. - is reached.
3. The clock will return to the current time of day within a few seconds.

NOTE: If the Clock symbol disappears before pressing the Up or Down Buttons, the display will go back to the current time of day. Press the Brew Later Button again to reactivate the Program mode.




Figure F

BREWING LATER USING THE AUTOMATIC TIMER

1. Be sure the Coffeemaker is ready to brew coffee. (See "Brewing Coffee - Models with Clock," page 4.)
2. Press the Brew Later Button next to the ON/OFF Button. The green light above the Button will glow indicating the Coffeemaker will brew when the current time of day is the same time as the Brew Later programmed time. (Figure F)
3. When the current time of day reaches the Brew Later programmed time, the red Power "On" Light will glow and the Coffeemaker will begin brewing.

CANCELING OR RESETTNG BREW LATER

Brew Later can be canceled at any time by pressing the Brew Later Button. This will turn off the green Brew Later Light, but no change will be made to the currently stored Brew Later set time. To change the stored Brew Later time, follow the procedures in "Programming the Coffeemaker to Brew Later" on pg. 8.

AUTOMATIC POWER OUT BACK-UP

Models with clocks are equipped with an automatic 30-second power out back-up function. If you should lose power (or if you unplug the unit to relocate it once it has been programmed), the unit will automatically save the pre-set brew time and the current time of day as long as power is restored within 30 seconds. If power is out longer than 30 seconds, you will have to reset the time of day and re-program your brew-later timer.

NOTE: To view the currently stored Brew Later time, push the **Program** Brew Later Button and the stored time will display. After a few seconds, the present time of day will be displayed again.

TO REHEAT LEFTOVER COFFEE

1. Pour the coffee into a saucepan and heat on a range top using a low to medium setting. Heat until the coffee is hot but not boiling; boiling will affect the coffee's flavor.
2. **IMPORTANT:** Never pour brewed coffee back into the Water Reservoir. Do not place the Carafe on a cooking surface or in a microwave oven.

Care Guide

CLEANING AFTER BREWING COFFEE

NOTE: Do not place anything other than water or the cleaning solution specified in this book into the Water Reservoir.

To clean your Coffeemaker after brewing coffee, be sure the Coffeemaker is turned OFF and is cool. Discard the paper filter, and clean each part as follows:

Filter Basket, Glass Carafe, and Carafe Lid:

Dishwasher - top rack only; or hot, sudsy water.

Coffeemaker: Wipe with soft, damp cloth and dry.

Do not use abrasive soaps or scouring pads.

Parts washed in a dishwasher may appear to fade. The original color may be restored by polishing with a soft, dry cloth.

CARING FOR YOUR CARAFE

A damaged Carafe may result in possible burns from hot liquid. To avoid breaking Carafe:

- Do not allow all liquid to evaporate from Carafe while on the "Keeps Hot" Plate or heat Carafe when empty. If this happens, discard Carafe.
 - Discard Carafe if damaged in any manner. A chip or crack could result in breakage.
 - Never use abrasive scouring pads or cleansers as they will scratch and weaken the glass.
 - Do not place Carafe on or near a hot gas or electric burner, in a heated oven, or in a microwave oven.
 - Avoid rough handling and sharp blows.
-

MINERAL DEPOSITS AND CLEANING

Mineral deposits left by water can clog your Coffeemaker. It is necessary to regularly clean your Coffeemaker to flush out these deposits.

Clean your Coffeemaker about every 1 - 3 months. Frequency of cleaning will be affected by water hardness. If you live in a hard water area, you may have to clean the Coffeemaker more frequently.

Excessive steaming or a prolonged brewing cycle are signs that cleaning is needed.

During cleaning, more steaming occurs than when brewing coffee.

1. Pour white vinegar into the Carafe up to the "6" cup level mark and add cold water up to the 10-cup level.
 2. Pour this cleaning solution into the Water Reservoir. Place the Carafe on the "Keeps Hot" Plate making sure the Carafe Lid is on the Carafe.
 3. Remove the Filter Basket and place a standard cupcake-style paper coffee filter in it. Put the Filter Basket back in the Coffeemaker.
 4. Turn the Coffeemaker on.
 5. Let 1/2 the cleaning solution brew into the Carafe, then turn the Coffeemaker off.
 6. Let the Coffeemaker cool for 15 minutes to soften the deposits.
 7. Pour the liquid that brewed into the Carafe back into the Water Reservoir.
 8. Turn the Coffeemaker on and let all the cleaning solution brew into the Carafe.
 9. Turn the Coffeemaker off and discard the cleaning solution and soiled paper filter.
 10. Fill the Coffeemaker with fresh water; follow the steps in "Before Brewing Coffee" (page 4) to flush out the remaining cleaning solution.
 11. Wash the filter Basket, Carafe and Lid as instructed in "Cleaning After Brewing" on pg. 10.
-

Need Help?

ELECTRICAL CORD

The cord length of this appliance was selected to reduce safety hazards that may occur with a longer cord. If more cord length is needed, an extension cord may be used. It should be rated not less than 10 amperes, 120 volts, and should have Underwriters Laboratories listing. A properly rated extension cord may be purchased from a Black & Decker (U.S.) Inc., Household Appliance Company-Owned or Authorized Service Center. When using a longer cord, be sure that it does not drape over a working area or dangle where it could be pulled on or tripped over. Handle cord carefully for longer life; avoid jerking or straining it at outlet and appliance connections.

SERVICE OR REPAIR

Service, if necessary, must be performed by a Black & Decker (U.S.) Inc., Household Appliance Company-Owned or Authorized Service Center. The Service Center nearest you can be found in the yellow pages of your phone book under "Appliances - Small - Repairing."

If mailing or shipping your Coffeemaker, clean, dry, and pack it carefully in its original carton or any sturdy carton with enough packing material to prevent damage. Include a note describing the problem to our Service Center and be sure to give your return address. We also suggest that you insure the package for your protection.

Consumer-replaceable parts and accessories are available at Black & Decker (U.S.) Inc., Household Appliance Company-Owned or Authorized Service Centers.

BLACK AND DECKER COMPANY-OWNED SERVICE CENTERS

ALABAMA

BIRMINGHAM — 2412 Green Springs, Hwy., 35209
205-942-0838
MOBILE — 3831 Airport Blvd., 36608 205-343-6624

ALASKA

ANCHORAGE — 910 West International Airport Rd.,
99518 907-563-4664

ARIZONA

MESA — 535 South Dobson Rd., Suite 7, 85202
602-461-1074
PHOENIX — 4501 N. 7th Ave., 85013 602-279-6414
TUCSON — 4845 E. Speedway Blvd., 85712
602-323-3388

ARKANSAS

LITTLE ROCK — 519 W. Seventh St., 72201 501-372-3040

CALIFORNIA

ANAHEIM — 540 South State College Blvd., 92806
714-772-4050
CHULA VISTA — 309 Broadway, 91911 619-420-6350
CONCORD — 1500 Monument Blvd., #C2, 94520
510-682-4880
FRESNO — 5412 North Blackstone Ave., 93710 209-435-0810
LONG BEACH — 2011 South St., 90805 310-422-5825
LOS ANGELES — 4820 South Eastern Ave., Suite "L"
90040
213-720-1834
RIVERSIDE — 6215 Magnolia Ave., Suite B, 92506
714-787-9700
SACRAMENTO — 2033 Fulton Ave., 95825 916-972-9090
SAN DIEGO — 9270 Clairmont Mesa Blvd., 92123
619-279-2011
SAN JOSE — 1185 South Bascom Ave., 95128 408-293-7350
SAN LEANDRO — 15206 East 14th St., 94578 510-276-1610
VAN NUYS — 14920 Victory Blvd., 91411 818-787-5531

COLORADO

DENVER — 1171 South Federal Blvd., Box 19220, 80219
303-922-8325

CONNECTICUT

HARTFORD — 662 Silas Deane Hwy., 06109 203-563-5800
ORANGE — 481 Boston Post Rd., 06477 203-795-3583

DISTRICT OF COLUMBIA

COLMAR MANOR, MD — 4153 Bladensburg Rd., 20710
301-779-3808
FALLS CHURCH, VA — 344 W. Broad St., 22046
703-533-7313

FLORIDA

FT. LAUDERDALE — 799 East Oakland Pk. Blvd., 33334
305-566-5102
FT. MYERS — 5224 Bank St., 33907 813-278-1188
JACKSONVILLE — 920 Cassat Ave., 32205 904-781-2253
MIAMI — 13345 North West Seventh Ave., 33168
305-681-6658
MIAMI — 12233 South Dixie Hwy., 33156 305-232-9497
ORLANDO — 3807 East Colonial Dr., 32803 407-894-7011
ST. PETERSBURG — 5635 49th St. North, 33709
813-525-0273
TAMPA — 3432 West Kennedy Blvd., 33609 813-872-8317
WEST PALM BEACH — 310 South Military Trail, 33415
407-689-3247

GEORGIA

ATLANTA (South) — 5330 Old National Hwy., 30349 404-762-8844
SMYRNA — 2550 Cobb Parkway South, 30080 404-956-0869
STONE MOUNTAIN — 5723 Memorial Dr., 30083 404-292-4714

HAWAII

HONOLULU — Unit No. 106, Sand Island Access Rd.,
96819 808-847-7447

ILLINOIS

CHICAGO (Lincolnwood) — 6710 North Crawford Ave.,
60646 708-673-0923
DES PLAINES — 1277 South Elmhurst Rd., 60018 708-364-5220
LISLE — 2950 Ogden Ave., Unit H, 60532 708-717-1075
MOLINE — 4433 23rd Ave., 61265 309-762-3000
OAK LAWN — 6343 W. 95th St., 60453 708-423-7212
WAUKEGAN — 39 S. Greenbay Rd., 60085 703-249-4390

INDIANA

EVANSVILLE — 307 First Ave., Crescent Ctr., 47710 812-425-4269
HAMMOND — 7103 Kennedy Ave., 46323 219-845-5100
INDIANAPOLIS (Speedway) — 5999 Crawfordsville Rd.,
46224 317-243-8308

IOWA

DES MOINES — 3427 Merle Hay Rd., 50310 515-270-1340

KANSAS

WICHITA — 155 South West St., 67213 316-943-1271

KENTUCKY

LOUISVILLE — 5211 Preston Hwy., 40213 502-968-7100

LOUISIANA

BATON ROUGE — 11859 Florida Blvd., 70815 504-272-8111
HARVEY — 2500 Lapalco Blvd., 70058 504-366-8676
METAIRIE (New Orleans) — 3504 North Causeway
Blvd., 70002 504-837-2550
SHREVEPORT — 7710-7714 Jewella Rd., 71108 318-688-1553

MARYLAND

BALTIMORE — 4712 Erdman Ave., 21205 410-485-5550
BALTIMORE — 29-31 Cranbrook Rd., Cockeysville, 21030
410-666-5966
COLMAR MANOR (Wash. D.C.) — 4153 Bladensburg
Rd., 20722 301-779-3808
PASADENA — 8220 Ritchie Hwy., 21122 410-647-8456

MASSACHUSETTS

BRIGHTON (Boston) — 12 Market St., 02135 617-782-6264
SEEKONK — 120 Highland Ave., 02771 508-336-6510

MICHIGAN

GRAND RAPIDS — 3040 28th St., SE, 49512 616-949-8331
LANSING — 3203 W. Saginaw Hwy., 48917 517-323-4181
WARREN — 27035 Van Dyke Blvd., 48093 313-756-6711
WESTLAND — 8067 N. Wayne Rd., 48185 313-427-1520

MINNESOTA

BLOOMINGTON — 9517 Lyndale Ave., South, 55420
612-884-9191

MISSOURI

KANSAS CITY — 4324 Main St., 64111 **816-531-0629**
ST. ANN — 3637 North Lindbergh Blvd., 63074
314-739-4661
ST. LOUIS — 12852 Manchester Rd., 63131 **314-821-8740**

NEBRASKA

OMAHA — 4225 South 84th St., 68127 **402-592-5666**

NEVADA

LAS VEGAS — 3411 East Charleston Blvd., 89104
702-641-6555

NEW JERSEY

CHERRY HILL — 1444 East Marlton Pike (Rt. 70), 08034
609-429-2822
LITTLE FALLS — 1189 U.S. Hwy. 46, 07424 **201-256-9373**
SCOTCH PLAINS — 2520 Route #22 East, 07076 **908-233-5665**

NEW MEXICO

ALBUQUERQUE — 5617 Menaul Blvd., N.E., 87110
505-884-1002

NEW YORK

ALBANY (Latham) — 836 Troy-Schenectady Rd., 12110
518-785-1867
BUFFALO — 881 West Delavan Ave., 14209 **716-884-6220**
CENTEREACH LI. — 2061-63 Middle Country Rd., 11720
516-737-4706
NEW YORK (Elmhurst) — 77-20 Queens Blvd., 11373
718-335-1042
NEW YORK (Manhattan) — 50 West 23rd St., 10010
212-929-6450
NEW YORK (Westbury, LI.) — 1061 Old Country Rd.,
11590 **516-997-6140**
ROCHESTER — 2969 W. Henrietta Rd., 14623 **716-424-1310**
SYRACUSE — 3485 Erie Blvd., East, 13214 **315-446-3086**

NORTH CAROLINA

CHARLOTTE — 3007 East Independence Blvd., 28205
704-374-1779
GREENSBORO — 3716 High Point Rd., 27407 **919-852-1300**
RALEIGH — 2930 Capital Blvd., 27604 **919-878-0357**

OHIO

CINCINNATI — 2310 East Sharon Rd., 45241 **513-772-3111**
COLUMBUS — 3975 East Livingston Ave., 43227
614-237-0461
DAYTON — 2898 South Dixie Drive, 45409 **513-298-1951**
MAYFIELD HEIGHTS — 5881 Mayfield Rd., 44124
216-449-2770
PARMA HEIGHTS (Cleveland) — 6483 Pearl Rd., 44130
216-842-9100
TOLEDO — 3231 Dorr St., 43607 **419-531-8921**

OKLAHOMA

OKLAHOMA CITY — 1318 Linwood Blvd., 73106
405-232-7515
TULSA — 3120 S. Sheridan Rd, 74145 **918-622-5666**

OREGON

PORTLAND — 1640 NW Johnson St., 97209
503-228-8631

PENNSYLVANIA

ALLENTOWN (Whitehall) — 2242 MacArthur Rd., 18052
215-435-9544
EVANS CITY — Cranberry Town Center Plaza, 20808 Rt.
19 N., 16033 **412-779-9600**

HARRISBURG — 6080 Allentown Blvd., 17112 **717-545-0651**

LANCASTER — 118 Keller Ave., 17601 **717-393-5251**

PHILADELPHIA — 9977-81 Bustleton Ave., 19115

215-464-7771

PHILADELPHIA — 333 North 20th St., 19103 **215-564-5520**

PITTSBURGH — 5437 Baum Blvd., 15232 **412-362-2700**

WILKES-BARRE — 759 Kidder St., 18702 **717-824-5704**

PUERTO RICO

GUAYNABO — "C" Street # 14, Rexco Industrial Park,
00922-1924 **809-783-3535**

RHODE ISLAND

SEEKONK, MA — 120 Highland Ave., 02771 **508-336-6510**

SOUTH CAROLINA

GREENVILLE — 1557 Laurens Rd., 29607 **803-232-3038**

TENNESSEE

CHATTANOOGA — Perimeter Place Shopping Ctr., Sp.
E, 6231 Perimeter Dr., 37421 **615-894-5957**

KNOXVILLE — 4118 North Broadway, 37917 **615-688-0921**

MEMPHIS — 1085 East Brooks Rd., 38116 **901-332-3444**

NASHVILLE — 4811 Nolensville Rd., 37211 **615-833-8277**

TEXAS

AMARILLO — 3008 West 6th Ave., 79106 **806-373-1531**

AUSTIN — 6549 Burnet Rd., 78757 **512-459-1133**

DALLAS — 2257 Royal Lane, 75229 **214-620-8655**

EL PASO — 6822 Gateway East, 79915 **915-778-9769**

FORT WORTH — 721 North Beach St., 76111 **817-831-3828**

GARLAND — 78 West Centerville Rd., 75043 **214-686-9302**

HOUSTON — 536 East Tidwell Rd., 77022 **713-692-7111**

SAN ANTONIO — 500 Culebra Ave., 78201 **210-732-1221**

WEBSTER — 100 East Nasa Road One, Ste. 75, 77598
713-338-4556

UTAH

SALT LAKE CITY — 1541 S. Third West St., 84115 **801-486-5828**

VIRGINIA

FALLS CHURCH — 344 W. Broad St., 22046 **703-533-7313**

HAMPTON — 3416 W. Mercury Blvd., 23666 **804-826-9382**

NORFOLK — 7631 Sewells Point Rd., 23513 **804-480-3333**

RICHMOND — 1424 Chamberlayne Ave., 23222 **804-649-9245**

WASHINGTON

SEATTLE — 421 S. Michigan, 98108 **206-763-2010**

SPOKANE — N. 7011 Division St., 99208 **509-467-8190**

TACOMA — 2602 S. 38th St., 98409 **206-473-6040**

WEST VIRGINIA

CHARLESTON — 1638 Sixth Ave., 25312 **304-343-0289**

WISCONSIN

MILWAUKEE (Wauwatosa) — 10424 W. Bluemound Rd.,
53226 **414-453-4240**

REV: 8/94

Quick Tips

QUESTIONS & ANSWERS

1. Do I have to set the clock in order to brew coffee?

No. You don't have to set the clock or the automatic timer to brew coffee. Simply follow the regular brewing instructions and press the "On/Off" Button to begin brewing.

2. Do I have to wait until my coffeemaker shuts off automatically to extend the "Keeps Hot" plate for another two hours?

No. You can extend the "Keeps Hot" plate time for two more hours on the clock models any time during operation by pressing the "On/Off" Button twice — once to turn the unit off and again to turn it back on.

3. If there is a power outage, will I lose the brew time I programmed in?

If the power returns within 30 seconds, the automatic power back-up will save the pre-set brew time and the current time of day on clock models. If the outage lasts longer than 30 seconds, you will have to re-program your clock and timer.

4. I have a black model and I noticed a dusty film on the unit. What should I do?

The black coffeemakers are made of a durable plastic that occasionally develop a thin white film. This is normal. To restore the original black sheen, simply wipe the unit with a soft, dry cloth.

5. Will coffee drip from the basket when I remove the carafe during brewing?

No. The Sneak-A-Cup™ Interrupt Feature on clock models has a drip stop that keeps the coffee from dripping when the carafe is removed to "sneak-a-cup" during brewing. However, be sure to return the carafe to the "Keeps Hot" plate within 60 seconds to avoid overflow from the brew basket.

ACCESSORIES OR REPLACEMENT PARTS

Accessories or parts are available at most Black & Decker Company-Owned Service Centers (see list on pgs. 13-14). However, you may order parts or accessories by phone.

**To place an order by phone, call
TOLL-FREE: 1-800-258-6003**

Orders may be called in 8:00 a.m. to 4:30 p.m. EST Monday thru Friday. We accept VISA, MasterCard, American Express, or Discover. Offer good only in the United States. Allow 3-4 weeks for delivery.

**FULL
TWO-YEAR
WARRANTY**

Black & Decker (U.S.) Inc. warrants this product against any defects that are due to faulty material or workmanship for a two-year period after the original date of consumer purchase or receipt as a gift. This warranty does not include damage to the product resulting from accident or misuse. If the product should become defective within the warranty period, we will repair it or elect to replace it free of charge. We will return your product, transportation charges prepaid, provided it is delivered prepaid to any Black & Decker (U.S.) Inc., Household Appliance Company-Owned or Authorized Service Center.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Answers to any questions regarding warranty or service locations may be obtained by calling toll free, 1-800-231-9786, or by writing:

Consumer Assistance and Information
Black & Decker (U.S.) Inc.
626 Hanover Pike
Hampstead, MD 21074-0618



Listed by Underwriters Laboratories Inc.
Copyright © 1989, 1994 Black and Decker
Pub. No. 168638-10-RV03
Printed in U.S.A.
