



Printed in China  
GH68-37234B  
English. 09/2012. Rev. 1.0

www.samsung.com

Please read this manual before operating your headset, and keep it for future reference. Understand all safety precautions before using your headset to ensure safe and proper use. Graphics used in this manual are for illustration purposes. The actual products may vary.

## Safety precautions

When using your headset while driving, follow local regulations in the region you are in.

- Never disassemble or modify your headset for any reason. Doing this may cause the headset to malfunction or become combustible. Bring the headset to an authorized service center to repair it.
- Keep your device and all accessories out of the reach of small children or animals. Small parts may cause choking or serious injury if swallowed.
- Avoid exposing your device to very cold or very hot temperatures (below 5 °C or above 35 °C). Extreme temperatures can cause the deformation of the device and reduce the charging capacity and life of your device.
- Do not allow your device to get wet — liquids can cause serious damage. Do not handle your device with wet hands. Water damage to your device can void your manufacturer's warranty.
- Avoid using your device's light close to the eyes of children or animals.
- Do not use the device during a thunderstorm. Thunderstorms can cause the device to malfunction and increase the risk of electric shock.

Excessive exposure to loud sounds can cause hearing damage. Exposure to loud sounds while driving may distract your attention and cause an accident. Use only the minimum volume setting necessary to hear your conversation.


## Instructional icons

Before you start, familiarize yourself with the icons you will see in this manual:

- Warning**—situations that could cause injury to yourself or others
- Caution**—situations that could cause damage to your device or other equipment
- Note**—notes, usage tips, or additional information

## Getting started

### Your headset overview



- Make sure you have the following items: headset, travel adapter, ear hook, ear rubbers and user manual. The supplied items may vary.

### Button functions

Button	Function
<b>Power switch</b>	<ul style="list-style-type: none"> <li>Slide to turn the headset on or off.</li> </ul>
<b>Talk</b>	<ul style="list-style-type: none"> <li>Press and hold for 3 seconds to enter Pairing mode.</li> <li>Press to answer or end a call.</li> <li>Press and hold to reject an incoming call.</li> <li>Press and hold to place a call on hold.</li> <li>Press and hold to switch between calls.</li> </ul>
<b>Volume</b>	<ul style="list-style-type: none"> <li>Press to adjust the volume.</li> <li>Press and hold to turn the microphone on or off during a call.</li> </ul>

### Turning the headset on or off

#### To turn the headset on

Slide the Power switch on. The blue indicator light flashes 4 times.

- Turning the headset on for the first time, it will automatically enter Pairing mode for approx. 3 minutes.

#### To turn the headset off


Slide the Power switch off. The indicator light flashes blue and red then turns off.

### Charging the headset

This headset has a rechargeable internal battery which is non-removable. Make sure the headset is fully charged before using it for the first time.

- Use only Samsung-approved chargers. Unauthorized or Non-Samsung chargers could cause damage to the headset or in extreme circumstances an explosion, it could also invalidate any warranty on the product.

- 1 Connect the travel adapter to the charging socket on the headset.
- 2 Plug the travel adapter in to the wall outlet. During charging, the indicator light will turn red. If charging does not begin, unplug the travel adapter and plug it in again.
- 3 When the headset is fully charged, the red indicator light changes to blue. Unplug the travel adapter from the wall outlet and the headset.



- Repeatedly charging and discharging of the headset, over time will cause the battery performance to diminish. This is normal for all rechargeable batteries.
- Never make or receive calls while charging, always disconnect your headset from the charger and answer the call.

### Checking the battery level

To check the battery level, press and hold the Volume down button and the Talk button at the same time. Depending on the battery level, the indicator light flashes 5 times in one of the following colors:


Battery level	Indicator light color
Above 80%	Blue
80 ~20%	Violet
Below 20%	Red

### When the headset battery is low

The headset indicator light flashes red and you can hear beeps. If the headset powers off during a call, the call will be automatically transferred to the phone.

### Wearing the headset

Depending on which ear you are going to wear the headset, simply adjust the ear hook accordingly.



- You can also use the optional ear rubbers instead of the ear hook. Remove the earpiece cover and attach the ear rubber. Then, rotate the ear rubber left or right slightly depending on which ear you are going to wear the headset.

### Turning the indicator light on or off

The Headset status light is there to show you the current status of your headset, but if it bothers you at night, you can turn it off.

- Press and hold both Volume buttons simultaneously to turn the indicator light on or off.
- You cannot switch the indicator off while in Pairing mode.
- The indicator light will always work when the headset is turned on or off, when a call is received, in Pairing mode and when the battery is low.

## Using your headset

- Activated functions and features may differ depending on the phone type.
- Some devices, especially those that are not tested or approved by the Bluetooth Special Interest Group (SIG), may be incompatible with your headset.

### To ensure you get the best performance from your headset

- Keep the distance between your headset and device as small as possible and avoid placing your body or other objects in the signals path.
- If you usually use your mobile phone with your right hand, wear the headset on your right ear.
- Covering your headset or device could effect its performance so keep contact to a minimum.

### Pairing and connecting the headset

Pairing means a unique and encrypted wireless connection between two Bluetooth devices when they agree to communicate with each other.

In Pairing mode, two devices should be placed close enough.

#### Near Field Communication (NFC) Pairing

With NFC-enabled phone, pairing is simple.

- 1 Activate the NFC feature on your phone.
  - Make sure your phone is unlock mode.
- 2 With the headset turned on, touch your headset's front side to the phone's NFC antenna.
- 3 Hold the headset to the phone until NFC pairing completes.

- Check devices specification for NFC pairing. Some of NFC enable devices may not support this feature.
- For details on NFC, see your phone's user manual.

#### Manual Pairing

- 1 Enter Pairing mode. (The blue indicator light stays lit and stays for 3 minutes.)
  - With the headset turned on, press and hold the Talk button for 3 seconds.
- 2 Activate the Bluetooth feature on your phone and search for the headset (see your phone's user manual).
- 3 Select the headset (HM3300) from the list of devices found by your phone.
  - If requested, enter the Bluetooth PIN 0000 (4 zeros) to pair and connect the headset to your phone.
  - Once pairing is completed, the headset will attempt to reconnect each time you turn it on.

#### Pairing via the Active pairing feature

With the Active pairing feature, your headset automatically looks for a Bluetooth device within range and tries to make a connection with it.

Make sure the phone's Bluetooth visibility option is set on.

- In Pairing mode, press and hold the Talk button on the headset. The indicator light color changes to violet from blue. The headset will attempt active pairing for up to 20 seconds.
- The Bluetooth phone you want to connect with must not be paired with other devices. If the phone is already connected to another device, end the connection and restart the Active pairing feature.
- This feature may not be supported on some devices.

#### Connecting with two Bluetooth phones

With the Multi-point feature activated, your headset can be connected to 2 Bluetooth phones at the same time.


To turn Multi-point feature on	To turn Multi-point feature off
In Pairing mode, press and hold the Volume up button. The blue indicator light flashes twice.	In Pairing mode, press and hold the Volume down button. The red indicator light flashes twice.

- 1 After connecting with the first Bluetooth phone, enter Pairing mode again.
- 2 Activate the Bluetooth feature on the second Bluetooth phone and search for the headset (see your phone's user manual).
- 3 Select the headset (HM3300) from the list of devices found by the second Bluetooth phone.
- 4 If requested, enter the Bluetooth PIN 0000 (4 zeros) to connect the headset to the second Bluetooth phone.
- 5 Reconnect to the headset from the first Bluetooth phone.

- Some phones may not be able to connect as a second Bluetooth phone.

## Connecting the headset with a music device


You can also pair and connect your headset with a music device such as an MP3 player. The process of connecting to a music device is the same as for connecting with a phone. When connected to both devices (phone and music device) you can make or receive a call on the phone while listening to music from the music device.

 You cannot control playback using your headset.

## Reconnecting the headset

If the connection is lost while in use:


- Press the Talk button on the headset or use the Bluetooth menu on your phone.

 When the headset is paired with a phone, it will attempt to automatically reconnect each time you turn it on. If the Multi-point feature is activated, your headset will attempt to reconnect to the two most recently connected devices. This feature may not be supported on some devices.

## Disconnecting the headset

Turn off the headset or use the Bluetooth menu on your phone.

## Using call functions

-  Available call functions may differ from phone to phone.
- Some functions are only available when using the Hands-Free profile.

## Making a call


### Redialing the latest number

To redial the last number dialed on the primary phone:

- Press and hold the Talk button.


To redial the last number dialed on the secondary phone:

- Press the Talk button twice.

 Some phones open the call log list on the first press of the Talk button. Press the Talk button again to dial the selected number.

## Dialing a number by voice

Press the Talk button.


 This function is only available on the primary phone.

## Answering a call

Press the Talk button to answer a call when a call comes in.

## Rejecting a call

Press and hold the Talk button to reject a call when a call comes in.

 If you receive calls on both connected phones at the same time you can only answer or reject the call on the primary phone.

## Ending a call


Press the Talk button to end a call.

## Options available during a call

You can use the following functions during a call.

### Adjusting the volume

Press the Volume up or down button to adjust the volume.

 You will hear a beep when the volume level of the headset reaches it's lowest or highest level.

## Muting the microphone

Press and hold the Volume up or down button to turn the microphone off so that the person with whom you are speaking cannot hear you. When the microphone is turned off, the headset beeps at regular intervals. Press and hold the Volume up or down button again to turn the microphone back on.

## Transferring a call from the phone to the headset

Press the Talk button on the headset to transfer a call from the phone to the headset.

## Placing a call on hold

Press and hold the Talk button to place the current call on hold.

## Answering a second call

- Press the Talk button to end the first call and answer a second call.
- Press and hold the Talk button to place the first call on hold and answer a second call. To switch between the current call and the held call, press and hold the Talk button.

## Using voice prompts

Voice prompts will inform you about the current status of the headset and usage instructions. If you can't hear any voice prompts, make sure the voice prompt feature is turned on.

## Turning the voice prompts on or off

### To turn the voice prompts on

In Pairing mode, press and hold the Volume up button for 3 seconds. You will hear *"Voice prompt is on"*.

### To turn the voice prompts off

In Pairing mode, press and hold the Volume down button for 3 seconds. You will hear *"Voice prompts is off"*.

## Changing the language

Supported languages may vary depending on the region in which it was purchased.

- In Pairing mode, press and hold both volume buttons simultaneously to select a language.

## List of voice prompts

Status	Voice prompt
When you turn the headset on or off	<i>"Power on"</i> or <i>"Power off"</i>
When you enter Pairing mode	<i>"Ready to pair. Search for the headset from the Bluetooth menu"</i>
When you turn Multi-point feature on or off	<i>"Multi-point mode is on"</i> or <i>"Multi-point mode is off"</i>
When you connect the headset to the devices	<i>"Device is connected"</i> or <i>"Two devices are connected"</i>
When you disconnect the headset from a device	<i>"Device is disconnected"</i>
When you reject or end a call	<i>"Call terminated"</i>


\* Voice prompt content may vary depending on the region in which it was purchased.

## Resetting the headset

When the headset is paired with a device, it automatically saves connection and feature settings, such as the Bluetooth address or device type of the mobile phone.

If you want to reset the connection settings in the headset:

- In Pairing mode, press and hold both Volume buttons and Talk button at the same time for 3 seconds. The blue indicator light flashes 4 times.

 When you reset the headset, all connection settings in the headset will be deleted and the connection with your phone will be lost. In order to use the headset, you will have to pair it again.

# Appendix

## Specifications

Item	Specifications and description
Bluetooth version	3.0
Support profile	Headset Profile, Hands-Free Profile, Advanced Audio Distribution Profile
Operating range	Up to 10 meters
Standby time	Up to 140 hours*
Talk time	Up to 4 hours*
Play time	Up to 3.5 hours*
Charging time	Approximately 2 hours

\* Depending on the phone type and usage, the actual time may vary.

## Frequently asked questions

<b>The headset does not fully charge.</b>	The headset and the travel adapter may not have been connected properly. Separate the headset from the travel adapter, reconnect, and charge the headset.
<b>I cannot use all the features described in the manual.</b>	Available features may vary depending on the connected device. If your headset is connected to two devices at once, some features may be unavailable.
<b>Will my headset work with laptops, PCs, and PDAs?</b>	Your headset will work with devices that support your headset's Bluetooth version and profiles.
<b>Why do I hear an echo while on a call?</b>	Adjust the headset volume, or move to another area and try again.
<b>Why do I hear static or interference while on a call?</b>	Appliances such as cordless phones and wireless networking equipment may cause interference, which usually sounds like static. To reduce any interference, keep the headset away from other devices that use or produce radio waves.

<b>Will my headset interfere with my car's electronics, radio, or computer?</b>	Your headset produces significantly less power than a typical mobile phone. It also only emits signals that are in compliance with the international Bluetooth standard. Therefore, you should not expect any interference with standard consumer-grade electronics equipment.
<b>Can other Bluetooth phone users hear my conversation?</b>	When you pair your headset to your Bluetooth phone, you are creating a private link between only these two Bluetooth devices. The wireless Bluetooth technology used in your headset is not easily monitored by third parties because Bluetooth wireless signals are significantly lower in radio frequency power than those produced by a typical mobile phone.
<b>How do I clean my headset?</b>	Wipe it with a soft dry cloth.

## Certification and Safety approvals

## FCC

### FCC ID: A3LHM3300

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- this device must accept any interference received, including interference that may cause undesired operation.

The device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

Users are not permitted to make changes or modify the device in any way.

Changes or modifications not expressly approved by Samsung will void the user's authority to operate the equipment.

## UL certified travel adapter

The travel adapter for this headset has met applicable UL safety requirements.

Please adhere to the following safety instructions per UL guidelines.


FAILURE TO FOLLOW THE INSTRUCTIONS OUTLINED MAY LEAD TO SERIOUS PERSONAL INJURY AND POSSIBLE PROPERTY DAMAGE.

IMPORTANT SAFETY INSTRUCTIONS – SAVE THESE INSTRUCTIONS.

DANGER – TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, CAREFULLY FOLLOW THESE INSTRUCTIONS.

FOR CONNECTION TO A SUPPLY NOT IN NORTH AMERICA, USE AN ATTACHMENT PLUG ADAPTOR OF THE PROPER CONFIGURATION FOR THE POWER OUTLET.

THIS POWER UNIT IS INTENDED TO BE CORRECTLY ORIENTATED IN A VERTICAL OR HORIZONTAL OR FLOOR MOUNT POSITION.



## Copyright

Copyright © 2012 Samsung Electronics

This user manual is protected under international copyright laws.

No part of this user manual may be reproduced, distributed, translated, or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording, or storing in any information storage and retrieval system, without the prior written permission of Samsung Electronics.

## Trademarks


- SAMSUNG, and the SAMSUNG logo are registered trademarks of Samsung Electronics.
- Bluetooth® is a registered trademark of the Bluetooth SIG, Inc. worldwide. More information about Bluetooth is available at [www.bluetooth.com](http://www.bluetooth.com).
- All other trademarks and copyrights are the property of their respective owners.

**SAMSUNG**

Bluetooth®

# Headset

## Warranty card



www.samsung.com

08/2012. Rev. 2.0

(g) defects or damage from external causes such as collision with an object, or from fire, flooding, sand, dirt, windstorm, lightning, earthquake, or from exposure to weather conditions, or battery leakage, theft, blown fuse, or improper use of any electrical source; (h) defects or damage caused by cellular signal reception or transmission, or viruses or other software problems introduced into the Product; (i) any other acts which are not the fault of SAMSUNG; or (j) Product used or purchased outside the United States. This Limited Warranty covers batteries only if battery capacity falls below 80% of rated capacity or the battery leaks, and this Limited Warranty does not cover any battery if (i) the battery has been charged by a battery charger not specified or approved by SAMSUNG for charging the battery, (ii) any of the seals on the battery are broken or show evidence of tampering, or (iii) the battery has been used in equipment other than the SAMSUNG phone for which it is specified.

## STANDARD LIMITED WARRANTY

### What is Covered and For How Long?

SAMSUNG TELECOMMUNICATIONS AMERICA, LLC ("SAMSUNG") warrants to the original purchaser ("Purchaser") that SAMSUNG's phones and accessories ("Products") are free from defects in material and workmanship under normal use and service for the period commencing upon the date of purchase and continuing for the following specified period of time after that date:

Phone	1 Year
Batteries	1 Year
Case/Pouch/Holster	90 Days
Other Phone Accessories	1 Year

### What are SAMSUNG's Obligations?

During the applicable warranty period, SAMSUNG will repair or replace, at SAMSUNG's sole option, without charge to Purchaser, any defective component part of Product. To obtain service under this Limited Warranty, Purchaser must return Product to an authorized phone service facility in an adequate container for shipping, accompanied by Purchaser's sales receipt or comparable substitute proof of sale showing the original date of purchase, the serial number of Product and the sellers' name and address. To obtain assistance on where to deliver the Product, call Samsung Customer Care at 1-888-987-4357. Upon receipt, SAMSUNG will promptly repair or replace the defective Product. SAMSUNG may, at SAMSUNG's sole option, use rebuilt, reconditioned, or new parts or components when repairing any Product or replace Product with a rebuilt, reconditioned or new Product. Repaired/replaced cases, pouches and holsters will be warranted for a period of ninety (90) days. All other repaired/replaced Product will be warranted for a period equal to the remainder of the original Limited Warranty on the original Product or for 90 days, whichever is longer. All replaced parts, components, boards and equipment shall become the property of SAMSUNG. If SAMSUNG determines that any Product is not covered by this Limited Warranty, Purchaser must pay all parts, shipping, and labor charges for the repair or return of such Product.

### What is Not Covered?

This Limited Warranty is conditioned upon proper use of Product by Purchaser.

This Limited Warranty does not cover: (a) defects or damage resulting from accident, misuse, abnormal use, abnormal conditions, improper storage, exposure to moisture or dampness, neglect, unusual physical, electrical or electromechanical stress, or defects in appearance, cosmetic, decorative or structural items, including framing, and any nonoperative parts unless caused by SAMSUNG; (b) defects or damage resulting from excessive force or use of a metallic object when pressing on a touch screen; (c) equipment that has the serial number or the enhancement data code removed, defaced, damaged, altered or made illegible; (d) any plastic surfaces or other externally exposed parts that are scratched or damaged due to normal use; (e) malfunctions resulting from the use of Product in conjunction or connection with accessories, products, or ancillary/peripheral equipment not furnished or approved by SAMSUNG; (f) defects or damage from improper testing, operation, maintenance, installation, service, or adjustment not furnished or approved by SAMSUNG;

### What Are the Limits On SAMSUNG's Liability?

EXCEPT AS SET FORTH IN THE EXPRESS WARRANTY CONTAINED HEREIN,

PURCHASER TAKES THE PRODUCT "AS IS"; AND SAMSUNG MAKES NO WARRANTY OR REPRESENTATION AND THERE ARE NO CONDITIONS, EXPRESS OR IMPLIED, STATUTORY OR OTHERWISE, OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT, INCLUDING BUT NOT LIMITED TO:

- THE MERCHANTABILITY OF THE PRODUCT OR ITS FITNESS FOR ANY PARTICULAR PURPOSE OR USE;
- WARRANTIES OF TITLE OR NON-INFRINGEMENT;
- DESIGN, CONDITION, QUALITY, OR PERFORMANCE OF THE PRODUCT;
- THE WORKMANSHIP OF THE PRODUCT OR THE COMPONENTS CONTAINED THEREIN; OR
- COMPLIANCE OF THE PRODUCT WITH THE REQUIREMENTS OF ANY LAW, RULE, SPECIFICATION OR CONTRACT PERTAINING THERETO.

NOTHING CONTAINED IN THE INSTRUCTION MANUAL SHALL BE CONSTRUED TO CREATE AN EXPRESS WARRANTY OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT. ALL IMPLIED WARRANTIES AND CONDITIONS THAT MAY ARISE BY OPERATION OF LAW, INCLUDING IF APPLICABLE THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE HEREBY LIMITED TO THE SAME DURATION OF TIME AS THE EXPRESS WRITTEN WARRANTY STATED HEREIN. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION

MAY NOT APPLY TO YOU. IN ADDITION, SAMSUNG SHALL NOT BE LIABLE FOR ANY DAMAGES OF ANY KIND RESULTING FROM THE PURCHASE, USE, OR MISUSE OF, OR INABILITY TO USE THE PRODUCT OR ARISING DIRECTLY OR INDIRECTLY FROM THE USE OR LOSS OF USE OF THE PRODUCT OR FROM THE BREACH OF THE EXPRESS WARRANTY, INCLUDING INCIDENTAL, SPECIAL, CONSEQUENTIAL OR SIMILAR DAMAGES, OR LOSS OF ANTICIPATED PROFITS OR BENEFITS, OR FOR DAMAGES ARISING FROM ANY TORT (INCLUDING NEGLIGENCE OR GROSS NEGLIGENCE) OR FAULT COMMITTED BY SAMSUNG, ITS AGENTS OR EMPLOYEES, OR FOR ANY BREACH OF CONTRACT OR FOR ANY CLAIM BROUGHT AGAINST PURCHASER BY ANY OTHER PARTY. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE.

THIS LIMITED WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL PURCHASER OF THIS PRODUCT AND STATES PURCHASER'S EXCLUSIVE REMEDY. IF ANY PORTION OF THIS LIMITED WARRANTY IS HELD ILLEGAL OR UNENFORCEABLE BY REASON OF ANY LAW, SUCH PARTIAL ILLEGALITY OR UNENFORCEABILITY SHALL NOT AFFECT THE ENFORCEABILITY FOR THE REMAINDER OF THIS LIMITED WARRANTY WHICH PURCHASER ACKNOWLEDGES AND WILL ALWAYS BE CONSTRUED TO BE LIMITED BY ITS TERMS OR AS LIMITED AS THE LAW PERMITS. THE PARTIES UNDERSTAND THAT THE PURCHASER MAY USE THIRD-PARTY SOFTWARE OR EQUIPMENT IN CONJUNCTION WITH THE PRODUCT. SAMSUNG MAKES NO WARRANTIES OR

REPRESENTATIONS AND THERE ARE NO CONDITIONS, EXPRESS OR IMPLIED, STATUTORY OR OTHERWISE, AS TO THE QUALITY, CAPABILITIES, OPERATIONS, PERFORMANCE OR SUITABILITY OF ANY THIRD-PARTY SOFTWARE OR EQUIPMENT, WHETHER SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT IS INCLUDED WITH THE PRODUCT DISTRIBUTED BY SAMSUNG OR OTHERWISE, INCLUDING THE ABILITY TO INTEGRATE ANY SUCH SOFTWARE OR EQUIPMENT WITH THE PRODUCT. THE QUALITY, CAPABILITIES, OPERATIONS, PERFORMANCE AND SUITABILITY OF ANY SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT LIE SOLELY WITH THE PURCHASER AND THE DIRECT VENDOR, OWNER OR SUPPLIER OF SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT, AS THE CASE MAY BE.

This Limited Warranty allocates risk of Product failure between Purchaser and SAMSUNG, and SAMSUNG's Product pricing reflects this allocation of risk and the limitations of liability contained in this Limited Warranty. The agents, employees, distributors, and dealers of SAMSUNG are not authorized to make modifications to this Limited Warranty, or make additional warranties binding on SAMSUNG. Accordingly, additional statements such as dealer advertising or presentation, whether oral or written, do not constitute warranties by SAMSUNG and should not be relied upon.

### Recycling Direct

To dispose electronics properly, follow the recycling process regulated in your area or go to Samsung website to find the nearest recycling location:

www.samsung.com/recyclingdirect

Or call, (877) 278-0799.

### Samsung Telecommunications America, LLC

1301 E. Lookout Drive  
Richardson, Texas 75082  
Phone: 1-800-SAMSUNG  
Phone: 1-888-987-HELP (4357)

©2012 Samsung Telecommunications America, LLC. All rights reserved.

No reproduction in whole or in part allowed without prior written approval. Specifications and availability subject to change without notice.

## GARANTÍA LIMITADA ESTÁNDAR

### ¿Qué está cubierto y durante cuánto tiempo?

SAMSUNG TELECOMMUNICATIONS AMERICA, LLC (“SAMSUNG”) garantiza al comprador original (“Comprador”) que los teléfonos y accesorios de SAMSUNG (“Productos”) no tendrán defectos en el material y la mano de obra bajo condiciones normales de uso y servicio por un periodo contado a partir de la fecha de compra, cuya duración será la que se indica a continuación a partir de dicha fecha:

Teléfono 1 año

Baterías 1 año

Bolsa/Portateléfono de cuero/Estuche 90 días

Otros accesorios telefónicos 1 año

### ¿Cuáles son las obligaciones de SAMSUNG?

Durante el período aplicable de garantía, SAMSUNG reparará o reemplazará, a su discreción única, sin cargo al comprador, cualquier pieza componente defectuosa del Producto. Para obtener servicio en virtud de esta garantía limitada, el comprador debe enviar el Producto a una instalación de servicio autorizada en un paquete adecuado para su envío, acompañado por el recibo de compra del Comprador o una evidencia de compra comparable donde aparezca la fecha de compra, el número de serie del Producto y el nombre y la dirección del vendedor. Para obtener información sobre a dónde puede enviar el Producto, llame al Centro de Atención al Cliente de Samsung al 1-888-987-4357. Al recibirlo, SAMSUNG reparará o reemplazará el Producto defectuoso oportunamente. SAMSUNG puede, a su discreción única, usar piezas o componentes reacondicionados, reconstruidos o nuevos para las reparaciones de cualquier Producto o bien, reemplazarlo con un producto reacondicionado, reconstruido o nuevo. Los estuches, las bolsas y los portateléfonos de cuero que se hayan reparado o reemplazado estarán garantizados por un periodo de noventa (90) días. Los otros Productos reparados o reemplazados tendrán una garantía por un período equivalente al resto de la Garantía Limitada original del producto original o por 90 días, lo que sea más. Todas las piezas, los componentes, las tarjetas y el equipo de reposición pasarán a ser propiedad de SAMSUNG. Si SAMSUNG determina que un producto no está cubierto por esta Garantía Limitada, el comprador deberá pagar todos los cargos por concepto de piezas, envío y mano de obra por la reparación o devolución de dicho Producto.

DE DICHO COMPRADOR. SI ALGUNA PORCIÓN DE ESTA GARANTÍA LIMITADA FUERA ILEGAL O NO PUDIERA HACERSE VALER JUDICIALMENTE DEBIDO A ALGUNA LEY, DICHA ILICITUD PARCIAL O LA INCAPACIDAD DE HACER VALER JUDICIALMENTE UNA PARTE DE ESTA GARANTÍA LIMITADA NO AFECTARÁ NI IMPEDIRÁ QUE EL RESTO DE ESTA GARANTÍA LIMITADA SE PUEDA HACER VALER JUDICIALMENTE Y EL COMPRADOR RECONOCE QUE ESTA GARANTÍA LIMITADA ESTÁ LIMITADA A LO ESTABLECIDO EN SUS TÉRMINOS O TAN LIMITADA COMO LA LEY LO PERMITA Y QUE SIEMPRE SE INTERPRETARÁ COMO TAL. LAS PARTES ENTIENDEN QUE EL COMPRADOR PUEDE USAR EL SOFTWARE O EQUIPO DE TERCEROS EN CONJUNTO CON EL PRODUCTO. TERCEROS EN CONJUNTO CON EL PRODUCTO. SAMSUNG NO OTORGA GARANTÍAS NI HACE REPRESENTACIONES Y NO HAY CONDICIONES, EXPLÍCITAS NI IMPLÍCITAS, ESTABLECIDAS POR LA LEY O DE OTRO TIPO, EN CUANTO A LA CALIDAD, CAPACIDADES, OPERACIONES, DESEMPEÑO O ADECUACIÓN DEL SOFTWARE O EQUIPO DE CUALQUIER TERCERO, YA SEA QUE EL SOFTWARE O EQUIPO DE ESE TERCERO ESTÉ INCLUIDO CON EL PRODUCTO QUE SAMSUNG DISTRIBUYE O NO, INCLUYENDO LA CAPACIDAD DE INTEGRAR DICHO SOFTWARE O EQUIPO CON EL PRODUCTO. LA CALIDAD, CAPACIDADES, OPERACIONES, DESEMPEÑO O ADECUACIÓN DE CUALQUIER SOFTWARE O EQUIPO DE DICHO TERCERO RECAE EXCLUSIVAMENTE EN EL COMPRADOR Y EL VENDEDOR DIRECTO, PROPIETARIO O PROVEEDOR DE DICHO SOFTWARE O EQUIPO DE TERCEROS, SEGÚN CORRESPONDA.

### ¿Qué no goza de cobertura?

Esta garantía limitada está condicionada a que el Comprador use adecuadamente el Producto. Esta garantía limitada no cubre: (a) defectos o daños que sean consecuencia de accidentes, uso inadecuado o anormal del Producto, negligencia, sometimiento del Producto a condiciones anormales, almacenamiento inapropiado o exposición a humedad; tensión física, eléctrica o electromecánica excepcional, defectos de las piezas decorativas o estructurales (incluido el armazón) y de cualquier parte que no sea operativa, a menos que sean causados por SAMSUNG; (b) defectos o daños que sean consecuencia del uso de fuerza excesiva o del uso de objetos metálicos durante la utilización de la pantalla táctil; (c) equipos cuyos números de serie o códigos de datos hayan sido eliminados, borrados, dañados, alterados o se hayan vuelto ilegibles;(d) todas las superficies plásticas y otras piezas expuestas externamente que se rayen o dañen debido al uso normal; (e) el mal funcionamiento que resulte de usar el Producto junto con accesorios, productos o equipos periféricos o auxiliares que SAMSUNG no haya suministrado o aprobado; (f) defectos o daños debidos a pruebas, funcionamiento, mantenimiento, instalación, servicio o ajuste inapropiados;

### ¿CUÁLES SON LOS LÍMITES DE RESPONSABILIDAD

#### Y GARANTÍA DE SAMSUNG?

EXCEPTO SEGÚN SE ESTABLECE EN LA GARANTÍA EXPLÍCITA QUE APARECE EN LA PRESENTE, EL COMPRADOR ADQUIERE EL PRODUCTO “TAL CUAL”Y SAMSUNG NO OFRECE GARANTÍA NI PROMESA ALGUNA Y NO HAY CONDICIONES, NI EXPLÍCITAS O IMPLÍCITAS, ESTABLECIDAS POR LA LEY O DE OTRA FORMA, ABSOLUTAMENTE DE NINGÚN TIPO CON RESPECTO AL PRODUCTO, INCLUIDA, ENTRE OTRAS:

- LA DE CONDICIONES APTAS PARA LA VENTA Y LA • DE QUE EL PRODUCTO SE ADAPTA A LOS FINES O USOS ESPECÍFICOS PARA LOS QUE SE ADQUIRIÓ;
- LA DE GARANTÍAS DE TÍTULO O DE NO-TRANSGRESIÓN DE DERECHOS DE TERCEROS;
- LA DE DISEÑO, CONDICIÓN, CALIDAD O DESEMPEÑO DEL PRODUCTO;
- LA MANO DE OBRA DEL PRODUCTO O LOS COMPONENTES CONTENIDOS EN EL MISMO; NI
- LA DE CUMPLIMIENTO CON LOS REQUISITOS DE LEY, NORMA, ESPECIFICACIÓN O CONTRATO ALGUNO RELACIONADOS CON ÉSTOS.

NADA DE LO CONTENIDO EN EL MANUAL DE INSTRUCCIONES DEBERÁ INTERPRETARSE COMO QUE SE OTORGA UNA GARANTÍA EXPLÍCITA DE ABSOLUTAMENTE NINGÚN TIPO CON RESPECTO AL PRODUCTO. TODAS LAS CONDICIONES Y GARANTÍAS IMPLÍCITAS QUE PUDIERAN SURGIR POR OPERACIÓN DE LA LEY, INCLUIDA, SI CORRESPONDE, LA DE CONDICIONES APTAS PARA LA VENTA O LA DE QUE EL PRODUCTO SE ADAPTA A

Esta Garantía Limitada distribuye el riesgo de las fallas del Producto entre el Comprador y SAMSUNG y la estructura de precios de los Productos SAMSUNG refleja esta asignación distribuida de riesgo y las limitaciones de la responsabilidad contenidas en esta Garantía Limitada. Los representantes, empleados, distribuidores y concesionarios de SAMSUNG no están autorizados para modificar esta Garantía Limitada ni para otorgar garantías adicionales vinculantes para SAMSUNG. Asimismo, las declaraciones adicionales como publicidad o presentaciones de distribuidores, ya sean orales o escritas, no constituyen garantías de SAMSUNG y no se debe confiar en ellas.

(g) defectos o daños por factores externos, como golpes, fuego, agua, arena, polvo, tormentas de viento, relámpagos, terremotos, exposición a condiciones meteorológicas, goteo de baterías, robo, quema de fusibles o uso inadecuado de cualquier fuente eléctrica; (h) defectos o daños causados por la transmisión o recepción de señales inalámbricas, virus u otros problemas de software que puedan afectar el Producto; (i) cualquier otro hecho que no sea responsabilidad de SAMSUNG; o (j) Productos que se hayan comprado fuera de los Estados Unidos. Esta garantía limitada cubre las baterías únicamente si la capacidad de las mismas disminuyera a menos del 80% de la capacidad nominal o si la batería goteara, y esta garantía limitada no cubre batería alguna si (i) la batería se hubiera cargado con un cargador que SAMSUNG no haya especificado o aprobado; (ii) cualquiera de los sellos de la batería estuvieran rotos o mostraran evidencia de manipulación o (iii) la batería se hubiera usado en un equipo que no fuese el teléfono SAMSUNG para el cual está especificada.

LOS FINES O USOS ESPECÍFICOS PARA LOS QUE SE ADQUIRIÓ, POR LA PRESENTE SE LIMITAN A LA MISMA DURACIÓN QUE LA DE LA GARANTÍA EXPLÍCITA OTORGADA EN LA PRESENTE. ALGUNOS ESTADOS O PROVINCIAS NO PERMITEN QUE SE LIMITEN LAS GARANTÍAS IMPLÍCITAS, DE MANERA QUE LA LIMITACIÓN ANTES MENCIONADA PODRÍA NO APLICARSE A USTED. ADEMÁS, SAMSUNG NO SE HACE RESPONSABLE POR DAÑO ALGUNO DE NINGÚN TIPO QUE RESULTE DE LA COMPRA, EL USO, EL MAL USO O LA INCAPACIDAD DE USO DEL PRODUCTO, NI QUE SURJA DIRECTA O INDIRECTAMENTE DEL USO O INCAPACIDAD DE USO DEL PRODUCTO O DE CONTRAVENIR LA GARANTÍA EXPLÍCITA, INCLUIDOS LOS DAÑOS INCIDENTALES, ESPECIALES, RESULTANTES O SIMILARES, NI POR LA PÉRDIDA DE GANANCIAS O BENEFICIOS ESPERADOS NI POR LOS DAÑOS QUE SURJAN DE CUALQUIER RESPONSABILIDAD EXTRA CONTRACTUAL (INCLUIDA LA NEGLIGENCIA O LA CULPA GRAVE POR NEGLIGENCIA) O FALTA COMETIDA POR SAMSUNG, SUS REPRESENTANTES, AGENTES O EMPLEADOS, NI POR CUALQUIER INCUMPLIMIENTO DE CONTRATO NI POR RECLAMACIÓN O PROCESO JUDICIAL ALGUNO QUE TERCEROS ENTABLEN CONTRA LA PERSONA QUE COMPRÓ EL PRODUCTO. ALGUNOS ESTADOS/PROVINCIAS NO PERMITEN LA EXCLUSIÓN NI LAS LIMITACIONES DE LOS DAÑOS INCIDENTALES O RESULTANTES, DE MANERA QUE LA LIMITACIÓN O EXCLUSIÓN ANTES MENCIONADA PODRÍA NO APLICARSE A USTED. ESTA GARANTÍA LE OTORGA DERECHOS LEGALES ESPECÍFICOS Y TAMBIÉN PODRÍA TENER OTROS DERECHOS QUE VARIAN DE UN ESTADO A OTRO Y DE UNA PROVINCIA A OTRA. ESTA GARANTÍA LIMITADA NO SE EXTIENDE A NINGUNA PERSONA QUE NO SEA EL COMPRADOR ORIGINAL DE ESTE PRODUCTO Y DECLARA EL REMEDIO EXCLUSIVO

### Reciclaje directo

Para desechar electrónicos correctamente, siga el proceso de reciclaje regulado en su área o visite el sitio web de Samsung para encontrar el establecimiento de reciclaje más cercano:

[www.samsung.com/recyclingdirect](http://www.samsung.com/recyclingdirect)

O llame al (877) 278-0799.

### Samsung Telecommunications America, LLC

1301 East Lookout Drive  
Richardson, Texas 75082  
Teléfono: 1-800-SAMSUNG  
Teléfono: 1-888-987-HELP (4357)

©2012 Samsung Telecommunications America, LLC. Reservados todos los derechos. Queda prohibida la reproducción total o parcial sin aprobación previa por escrito. Las especificaciones y la disponibilidad están sujetas a cambio sin previo aviso.