

# **TABLE OF CONTENTS**

Sec	tion		<u>Pa</u>	ıge
1.0	WARNIN	GS		1
2.0	SCOPE.			2
3.0	DESCRI	PTION		2
4.0	INSTALL	ATION		2
5.0	MODELS	3		.13
6.0	OPTION	AL ACCESS	ORIES	.13
7.0	WARRAN	NTY AND RE	TURN	.14
			LIST OF ILLUSTRATIONS	
<u>Figu</u>	re		<u>Page</u>	
1 2 3 4 5 6 7 8 9 10 11	Installa Installa Alarm I Installa Wiretro Installa Wiretro Installa Rack P Pin Ma	tion Configuration Configuration Configuration Configuration Configuration Configuration Configuranel Mountirpping for the	nel Assembly Information–VA6000 Series ation and Pin Mapping for 4/8 Alarm Inputs-VA6000 Alarm Breakout Panel ation and Pin Mapping for 12/20 Alarm Inputs-VA6000 Alarm Breakout Panel nel Assembly Information–CM8500 Series ration and Pin Mapping for the CM8500 Alarm Breakout Panel Panel Assembly Information–CM8500 Series ration and Pin Mapping for the CM8500 Wiretron Breakout Panel Panel Assembly Information–CM8500 Series ration for the CM8500 Wiretron Breakout Panel panel Assembly Information–CM8500 Series ration for the CM8500 Wiretron Breakout Panel and Plate Dimensions CM8500 Relay Breakout Panel aber Ordering Tables	4 6 7 8 9 10 11
REV	ISION H	ISTORY		
Man	ual #	<u>Date</u>	<u>Comments</u>	
C842	2M	9/96	Original version created per ECO 96-044, 96-042.	

# INSTALLATION/OPERATION MANUAL BREAKOUT PANELS FOR VA6000 SERIES SWITCHER AND CM8500 MATRIX SYSTEM

#### 1.0 WARNINGS

Prior to installation and use of this product, the following WARNINGS should be observed.

- Installation and servicing should only be done by Qualified Service Personnel and conform to all Local codes.
- 2. Unless the unit is specifically marked as a NEMA Type 3, 3R, 3S, 4, 4X, 6, or 6P enclosure, it is designed for indoor use only and it must not be installed where exposed to rain and moisture.
- 3. Only use replacement parts recommended by Pelco.

## This product may bear the following marks:

This symbol indicates that dangerous voltage constituting a risk of electric shock is present within this unit.



# **CAUTION:**

TO REDUCE THE RISK OF ELECTRICAL SHOCK, DO NOT REMOVE COVER. NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

This symbol indicates that there are important operating and maintenance instructions in the literature accompanying this unit.



### **CAUTION:**

RISK OF ELECTRIC SHOCK.
DO NOT OPEN.

Please thoroughly familiarize yourself with the information in this manual prior to installation and operation.

### 2.0 SCOPE

The information contained within this manual covers the installation and operation of the Alarm Breakout Panels for the VA6000 Series Switcher and the Alarm, Wiretron and Relay Breakout Panels for the CM8500 Matrix system.

### 3.0 DESCRIPTION

## VA6000

The Breakout Panels for the VA6000 Series provide a convenient method for physically telescoping up to 20 alarm inputs down into the most appropriate of two headers existing on the Alarm Breakout Panel board for convenient connection to "D" type connectors on the rear of the VA6000.

A ribbon cable connects one of the two available header types (15-pin or 25-pin header) to the appropriate "D" type connector, depending on alarm input population, on the rear of the VA6000. Basically, two classes of ribbon cable are available: one for use with 4 and 8 alarm input models and another for 12 or 20 alarm input models. Cables are further differentiated by length–24 inch (.609 m) or 120 inch (3.048 m) lengths are available.

Additionally, each breakout panel assembly is shipped from the factory installed on a single mounting plate with appropriate mounting hardware. You should automatically receive the correct breakout panel, ribbon cable, mounting plate and hardware if you use Table 1 in Figure 12 as a guide while referencing all other appropriate figures provided in the manual.

### CM8500

The Breakout Panels for the CM8500 Matrix System likewise provide a convenient method for physically telescoping Alarm, Wiretron or Relay inputs down into appropriate headers for eventual connection to "D" type subconnectors on the rear of the CM8500 Matrix bay.

Unlike the VA6000 which is populated with two headers, each with different pin-outs on one breakout panel, the CM8500 utilizes three different breakout panels populated with only one header, with header pin-out configurations for the type of breakout panel being used: Alarm, Wiretron or Relay. For the CM8500, Breakout panels for Alarm and Wiretron inputs utilize, in each case, a single 40-pin header, while Relay Breakout panels incorporate a single 50-pin header.

As was the case for the VA6000, all telescoped inputs for breakout panels used with the CM8500 are connected via the appropriate onboard header to existing "D" type connectors on the rear of the CM8500 Matrix bay via ribbon cables.

The 24 inch (.609 m) and 120 inch (3.048 m) length ribbon cable assemblies for the 40-pin header type connectors have the same configuration and can be used with either the Wiretron Breakout Panel or the Alarm Breakout Panel.

The ribbon cable used with the 50-pin header (also available in the same lengths) is used only with the Relay Breakout Panel for the CM8500 system. Reference Table II, Figure 12 as a guide for ordering information related to CM8500 breakout panels while referencing other appropriate figures in the manual.

**NOTE:** When working with a CM8500 Matrix System, additional subassemblies may be required (if not already installed) on the CM8500 side of the installation in order to utilize the Alarm, Wiretron and Relay connectors on the rear of the CM8500 Matrix bay. These are:

CM8506 Communication circuit card to allow the CM8500 to communicate with Wiretron receiver/drivers.

Mounts to Buffer Card.


CM8532 32 alarm/32 relay circuit card kit to allow for direct monitoring of 32 alarms and the use of 32 relay outputs programmable in software.


Consult your CM8500 manual (C501M) for installation requirements and any related information, if needed.

## 4.0 INSTALLATION

Breakout panels come from the factory installed on single mounting plates; an appropriate ribbon cable is included with the assembly. The Breakout panel and plate can be mounted in any convenient, accessible location. Once mounted, all user supplied wiring inputs (alarm, wiretron or relay) can be connected and then the supplied ribbon cable can be run between the header on the breakout panel and the appropriate "D" type connector on the equipment being used, whether VA6000 or CM8500.

Once the panels are physically mounted and all wires and cables are run, the product is ready for use.






The table below lists the pin-out relationship between the alarm panel header, J2, and the 15-pin connector on the rear of the VA6000 switcher for 8 input alarms. The pattern serves equally well for VA models with 4 input alarms: the first 4 Pin Numbers correspond to like numbered ALM numbers, with pins 5-10 unused and pins 11-15 serving the same functions as in the 8 input VA6000 Switcher model.

Alaı	m Pin-outs 1-8/VA6000	J2 Header Pin-out on Alarm Breakout
R	ear Panel Connector	for VA6000
ALM #	15-Pin Female Conn. on Switcher	Pin Numbers
	Pin Numbers	
1	1	1
2	2	3
3	3	5
4	4	7
5	5	9
6	6	11
7	7	13
8	8	15
not used	9	2 (not used)
not used	10	4 (not used)
K1 - NO	11	6
K1 -COM	12	8
K1 - NC	13	10
Ext.Trig.	14	12
Comm	15	14

Figure 2. Installation Configuration and Pin Mapping for 4/8 Alarm Inputs-VA6000 Alarm Breakout Panel



The table below lists the pin-out relationship between the alarm panel header, J1, and the 25-pin connector on the rear of the VA6000 switcher for 20 input alarms. The pattern serves equally well for VA models with 12 input alarms: the first 12 Pin Numbers correspond to like numbered ALM numbers with pins 13-20 unused and pins 21-25 serving the same functions as in the 20 input VA6000 Switcher models.

Alarm Pin-o	uts 1-16/CM8500 Rear Panel-P4	J1 Header Pin-out on Alarm Breakout for CM8500	
ALM #	25-Pin Female Conn. on Switcher	Pin Number	
	Pin Number		
	T III TTAITIOCI		
1	1 1	1	
2	2	3	
3	3	5	
4	4	7	
5	5	9	
6	6	11	
7	7	13	
8	8	15	
9	9	17	
10	10	19	
11	11	21	
12	12	23	
13	13	25	
14	14	2	
15	15	4	
16	16	6	
17	17	8	
18	18	10	
19	19	12	
20	20	14	
K1 - NO	21	16	
K1 -COM	22	18	
K1 - NC	23	20	
Ext.Trig.	24	22	
Comm	25	24	

Figure 3. Installation Configuration and Pin Mapping for 12/20 Alarm Inputs-VA6000 Alarm Breakout Panel





Figure 4. Alarm Breakout Panel Assembly Information-CM8500 Series



The table below lists the pin-out relationship between the alarm panel header, J1, and P4 on the CM8500 for the first 16 alarms. The pattern serves equally well for alarms 17-32: P4 becomes P3 and the listed alarms go from 17-32 instead of 1-16.

Alarm Pin-o	outs 1-16/CM850	00 Rear Panel-P4	J1 Header Pin-out on Alarm Breakout for CM8500	
ALM #	Pin Number		Pin Number	
	Alarm Com			
1	1		1	
'	·	20	2	
2	2		3	
		21	4	
3	3		5	
4	4	22	6 7	
4	<del></del>	23	8	
5	5		9	
		24	10	
6	6		11	
	25		12	
7 7 26			13 14	
8 8			15	
O	·	27	16	
9	9		17	
		28	18	
10	10		19	
		29	20	
11	11		21	
12	12	30	22 23	
12		31	23 24	
13	13		25	
		32	26	
14	14		27	
		33	28	
15	15		29	
16		34	30	
16	16		31	
		35	32	

Figure 5. Installation Configuration and Pin Mapping for the CM8500 Alarm Breakout Panel





Figure 6. Wiretron Breakout Panel Assembly Information-CM8500 Series



The table below lists the pin-out relationship between the wiretron panel header, J1, and P5 on the CM8500 for the first 16 wire control positions. The pin mappings serve equally well for wire controls 17-32: P5 becomes P6 and the listed WIR numbers go from 17-32 instead of 1-16.

	Pin-outs 1-16	/CM8500	J1 Header Pin-out on Wiretron Breakout Panel for CM8500	
Rear Panel-P5			<u> </u>	
WIR#	Pin Number		Pin Number	
ļ.	+	_		
1 1	1		1	
·		2	3	
2	3		5	
_		4	7	
3	5		9	
	•••	6	11	
4	7		13	
		8	15	
5	9		17	
0		10	19	
6	6 11 12		21 23	
7	13		25	
, , <u>, , , , , , , , , , , , , , , , , </u>		 14	27	
8 15			29	
		16	31	
9	20		2	
		21	4	
10	22		6	
		23	8	
11	24		10	
12	26	25	12	
12		 27	14	
13	28		18	
	20	29	20	
14	30		22	
		318	24	
15	32		26	
		33	28	
16	34		30	
		35	32	

Figure 7. Installation Configuration and Pin Mapping for the CM8500 Wiretron Breakout Panel




Figure 8. Wiretron Breakout Panel Assembly Information-CM8500 Series




Figure 9. Installation Configuration for the CM8500 Wiretron Breakout Panel




Figure 10. Rack Panel Mounting Plate Dimensions

The table below lists the pin-out relationship between the relay panel header, J1, and P1 on the CM8500 for the first 16 relay output positions. The pin mappings serve equally well for relay outputs 17-32: P1 becomes P2 and the listed RELAY numbers go from 17-32 instead of 1-16.

Relay 1-16 Pin-outs CM8500 Rear Panel-P1				J1 Header Pin-out on Relay Breakout Panel for CM8500
RELAY #	Pin Number			Pin Number
1	NC 1 	NO  2	COM 	1 2
2	4 	 5 	3   6	3 4 5 6
3	7 	 8	  9	7 8 9
4	10 	 11 	  12	10 11 12
5	13. 	 14 	  15	13 14 15
6	16 	 17 	  18	16 17 18
7	19  	 20 	  21	19 20 21
8	22  	 23 	  24	22 23 24
9	25  	 26 	  27	25 26 27
10	28 	 29 	  30	28 29 30
11	31  	 32 	  33	31 32 33
12	34  	 35 	  36	34 35 36
13	37  	 38 	  39	37 38 39
14	40 	 41 	  42	40 41 42
15	43 	 44 	  45	43 44 45
16	46 	 47 	  48	46 47 48

Figure 11. Pin Mapping for the CM8500 Relay Breakout Panel

5.0 MODELS CM8500-WPNL-2 Wiretron breakout panel for up to 16 outputs/panel; 2-foot (.609 VA6008-APNL-2 VA6000 alarm breakout panel m) inter connecting ribbon cable for up to 8 alarm inputs; 2-foot supplied. (.609 m) interconnecting ribbon cable supplied. CM8500-WPNL-10 Same as CM8500-WPNL-2, except 10-foot (3.048 m) intercon-VA6008-APNL-10 Same as VA6008-APNL-2, exnecting ribbon cable. cept 10-foot (3.048 m) interconnecting ribbon cable. CM8500-RPNL-2 Relay breakout panel for up to 16 outputs/panel; 2-foot (.609 m) interconnecting ribbon cable sup-VA6020-APNL-2 VA6000 alarm breakout panel for up to 20 alarm inputs; 2-foot plied. (.609 m) interconnecting ribbon cable supplied. CM8500-RPNL-10 Same as CM8500-RPNL-2, except 10 foot (3.048 m) intercon-VA6020-APNL-10 Same as VA6020-APNL-2 exnecting ribbon cable. cept 10-foot (3.048 m) intercon-**6.0 OPTIONAL ACCESSORIES** necting ribbon cable. **RK-1PNL** CM8500-APNL-2 Rack kit for mounting one Alarm breakout panel for up to breakout panel (see Figure 10). 16 alarm inputs/panel; 2-foot (.609 m) interconnecting ribbon RK-4PNL cable supplied. Rack kit for mounting up to four breakout panels (see Figure 10).

Same as CM8500-APNL-2, except 10-foot (3.048 m) intercon-

necting ribbon cable.

# Of Inputs Cable Length	4 or 8 Alarm Inputs	12 or 20 Alarm Inputs
24 in (.609 m) cable	VA6008-APNL-2	VA6020-APNL-2
120 in (3.048 m) cable	VA6008-APNL-10	VA6020-APNL-10

# Table II. Breakout Panel Assembly Part Numbers for CM8500 Matrix System

Input Type Cable Length	Alarm Inputs	Wiretron Control Outputs	Relay Outputs
24 in (.609 m) cable	CM8500-APNL-2	CM8500-WPNL-2	CM8500-RPNL-2
120 in (3.048 m) cable	CM8500-APNL-10	CM8500-WPNL-10	CM8500-RPNL-10

Figure 12. Simplified Part Number Ordering Tables

CM8500-APNL-10

## 7.0 WARRANTY AND RETURN INFORMATION

#### **WARRANTY**

Pelco will repair or replace, without charge, any merchandise proved defective in material or workmanship for a period of one year after the date of shipment.

Exceptions to this warranty are as noted below:

- Five years on FT/FR8000 Series fiber optic products.
- Three years on Genex® Series products (multiplexers, server, and keyboard).
- Three years on Camclosure® and fixed camera models, except the CC3701H-2, CC3701H-2X, CC3751H-2, CC3651H-2X, MC3651H-2, and MC3651H-2X camera models, which have a five-year warranty.
- · Two years on standard motorized or fixed focal length lenses.
- Two years on Legacy®, CM6700/CM6800/CM9700 Series matrix, and DF5/DF8 Series fixed dome products.
- Two years on Spectra®, Esprit®, ExSite™, and PS20 scanners, including when used in continuous motion applications.
- Two years on Esprit® and WW5700 Series window wiper (excluding wiper blades).
- Eighteen months on DX Series digital video recorders, NVR300 Series network video recorders, and Endura™ Series distributed network-based video products.
- One year (except video heads) on video cassette recorders (VCRs).
   Video heads will be covered for a period of six months.
- Six months on all pan and tilts, scanners or preset lenses used in continuous motion applications (that is, preset scan, tour and auto scan modes).

Pelco will warrant all replacement parts and repairs for 90 days from the date of Pelco shipment. All goods requiring warranty repair shall be sent freight prepaid to Pelco, Clovis, California. Repairs made necessary by reason of misuse, alteration, normal wear, or accident are not covered under this warranty.

Pelco assumes no risk and shall be subject to no liability for damages or loss resulting from the specific use or application made of the Products. Pelco's liability for any claim, whether based on breach of contract, negligence, infringement of any rights of any party or product liability, relating to the Products shall not exceed the price paid by the Dealer to Pelco for such Products. In no event will Pelco be liable for any special, incidental or consequential damages (including loss of use, loss of profit and claims of third parties) however caused, whether by the negligence of Pelco or otherwise.

The above warranty provides the Dealer with specific legal rights. The Dealer may also have additional rights, which are subject to variation from state to state

If a warranty repair is required, the Dealer must contact Pelco at (800) 289-9100 or (559) 292-1981 to obtain a Repair Authorization number (RA), and provide the following information:

- 1. Model and serial number
- 2. Date of shipment, P.O. number, Sales Order number, or Pelco invoice number
- 3. Details of the defect or problem

If there is a dispute regarding the warranty of a product which does not fall under the warranty conditions stated above, please include a written explanation with the product when returned.

Method of return shipment shall be the same or equal to the method by which the item was received by Pelco.

Pelco, the Pelco logo, Camclosure, Esprit, Genex, Legacy, and Spectra are registered trademarks of Pelco.
Endura and ExSite are trademarks of Pelco.

© Copyright 1996, Pelco. All rights reserved.

#### **RETURNS**

In order to expedite parts returned to the factory for repair or credit, please call the factory at (800) 289-9100 or (559) 292-1981 to obtain an authorization number (CA number if returned for credit, and RA number if returned for repair).

All merchandise returned for credit may be subject to a 20% restocking and refurbishing charge.

Goods returned for repair or credit should be clearly identified with the assigned CA or RA number and freight should be prepaid. Ship to the appropriate address below.

If you are located within the continental U.S., Alaska, Hawaii or Puerto Rico, send goods to:

Service Department Pelco 3500 Pelco Way Clovis, CA 93612-5699

If you are located outside the continental U.S., Alaska, Hawaii or Puerto Rico and are instructed to return goods to the USA, you may do one of the following:

If the goods are to be sent by a COURIER SERVICE, send the goods to:

Pelco

3500 Pelco Way

Clovis, CA 93612-5699 USA

If the goods are to be sent by a FREIGHT FORWARDER, send the goods to:

Pelco c/o Expeditors 473 Eccles Avenue South San Francisco, CA 94080 USA Phone: 650-737-1700 Fax: 650-737-0933

### Pelco

3500 Pelco Way, Clovis, CA 93612-5699 (559) 292-1981 • (800) 289-9100 FAX (800) 289-9150 or (559) 292-3827

International customers call 1-559-292-1981 or FAX 1-559-348-1120

(Product specifications subject to change without notice.)

#### **C842M**