

FOLD

FOLD

FOLD

LIMITED WARRANTY

What your warranty covers:

- Any defect in materials or workmanship.

For how long after your purchase:

- One year. (The warranty period for rental units begins with the first rental or 45 days from date of shipment to the rental firm, whichever comes first.)

What we will do:

- Provide you with a new or, at our option, a refurbished unit.
- The exchange unit is under warranty for the remainder of the original product's warranty period.

How to make a warranty claim:

- Properly pack your unit. Include any cables, etc., which were originally provided with the product. We recommend using the original carton and packing materials.
- Include in the package evidence of purchase date such as the bill of sale. Also print your name and address and a description of the defect. Send standard UPS or its equivalent to:

Thomson Consumer Electronics, Inc.
Product Exchange Center
32 Spur Drive
El Paso, Texas 79906

- Pay any charges billed to you by the Exchange Center for service not covered by the warranty.
- Insure your shipment in case of loss or damage. Thomson accepts no liability in case of damage or loss.
- A new or refurbished unit will be shipped to you prepaid freight.

What your warranty does not cover:

- Customer instruction. (Your Owner's Manual provides information regarding operating instructions and user controls. For additional information, ask your dealer.)
- Installation and set-up service adjustments.
- Batteries.
- Damage from misuse or neglect.
- Products which have been modified or incorporated into other products.
- Products purchased or serviced outside the USA.
- Acts of God, such as but not limited to lightning damage.

Product Registration:

- Please complete and mail the Product Registration Card packed with your unit. It will make it easier to contact you should it ever be necessary. The return of the card is not required for warranty coverage.

How state law relates to this warranty:

- This warranty gives you specific legal rights, and you may have other rights which vary from state to state.

If you purchased your product outside the USA:

- This warranty does not apply. Contact your dealer for warranty information.

THOMSON CONSUMER ELECTRONICS

© 1998 Thomson Consumer Electronics, Inc. 2-9120/21/22/23/24/26/27
 P.O. BOX 1976, Indianapolis, IN 46206 2-9130/31/33/34/36/37
 Trademark(s) ® Registered 20909690
 Marca(s) Registrada(s) 98-08
 Printed in Malaysia

6

7

FOLD

FOLD

FOLD

2-9120/30 Color Series (Folded size 80 x 175 mm)
 20909690
 Sheet 1 of 2 (Double-side printing with 3 Folds)

FOLD

FOLD

FOLD

FOLD

FOLD

FOLD

FOLD

FOLD

FOLD

2-9120 /2-9130 Color Series



Telephone User's Guide

2-9120	2-9130
2-9121	2-9131
2-9122	2-9133
2-9123	2-9143
2-9124	2-9136
2-9126	2-9137
2-9127	

INTERFERENCE INFORMATION

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference; and (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna (that is, the antenna for radio or television that is "receiving" the interference).
 - Reorient or relocate and increase the separation between the telecommunications equipment and receiving antenna.
 - Connect the telecommunications equipment into an outlet on a circuit different from that to which the receiving antenna is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- If these measures do not eliminate the interference, please consult your dealer or an experienced radio/television technician for additional suggestions. Also, the Federal Communications Commission has prepared a helpful booklet, "How To Identify and Resolve Radio/TV Interference Problems." This booklet is available from the U.S. Government Printing Office, Washington, D.C. 20402. Please specify stock number 004-000-00345-4 when ordering copies.

HEARING AID COMPATIBILITY

This telephone system meets FCC standards for Hearing Aid Compatibility.

FCC NUMBER IS LOCATED ON THE CABINET BOTTOM
 REN NUMBER IS LOCATED ON THE CABINET BOTTOM



We bring good things to life.


FOLD

FOLD

FOLD


MODULAR JACK REQUIREMENTS

You need an RJ11 type modular jack, which is the most common type of phone jack and might look like the one pictured here. If you don't have a modular jack, call your local phone company to find out how to get one installed.



INSTALLATION

DESKTOP OR TABLETOP INSTALLATION




1. Remove telephone line cord from the pocket on the bottom of the phone.
2. Run telephone line cord through the guides on the bottom of the phone.
3. Connect the telephone line cord to a modular telephone jack.
4. Slide the RINGER switch (on the side of the handset) to ON.
5. Set PULSE/TONE switch (on the side of the handset) to TONE for touch-tone service, or set it to PULSE for rotary service. If you don't know which type of service you have, check with the phone company.


2

WALL MOUNT INSTALLATION


- 1a. If the modular phone jack is in the base plate on the wall where you're going to mount your phone, just plug the telephone line cord into the jack; mount the phone on the posts; and set the RINGER switch and PULSE/TONE switch (described in detail below).



- 1b. If the modular phone jack is near the floor and you want to mount the phone on the wall, remove the telephone line cord from the pocket that is on the bottom of the phone. Wrap the phone cord around the circular guide on the bottom of the phone.



2. Plug telephone line cord into the modular jack.
3. Slip mounting holes on the bottom of the telephone over the wall plate posts and slide the base down until the phone is firmly in place. (Wall plate is not included.)
4. Slide the RINGER switch (on the side of handset) to ON.
5. Set PULSE/TONE switch (on the side of the handset) to TONE for touch-tone service, or set it to PULSE for rotary service. If you don't know which type of service you have, check with the phone company.



3

USING THE TELEPHONE FEATURES

AUTOMATIC REDIAL

To automatically redial the last number you called:


1. Pick up the handset to get a dial tone.
2. Press REDIAL.

FLASH

Press the FLASH button instead of the hook switch to activate custom calling services such as call waiting or call transfer. Custom calling services are provided by the phone company.

TEMPORARY TONE

If you have pulse service, you can temporarily change from pulse to tone service in order to access services that require tone dialing (such as getting information from a local bank). After dialing the telephone number, press and release the tone button, marked with an asterisk (*). When you hang up, your phone telephone returns to pulse service.



SERVICE

FCC requires this product to be serviced only by the manufacturer or its authorized service agents. In accordance with FCC requirements, changes or modifications not expressly approved by Thomson Consumer Electronics could void the user's authority to operate this product. For instructions on how to obtain service, call 1-800-448-0329.

Attach your sales receipt to the booklet for future reference or jot down the date this product was purchased or received as a gift. This information will be valuable if service should be required during the warranty period.

Purchase date _____ Name of store _____

TROUBLESHOOTING TIPS

Problem	Solution
No dial tone. Won't dial out	<ul style="list-style-type: none"> • Check hook switch to make sure it pops up. • Make sure PULSE/TONE is set to correct position.
Phone doesn't ring	<ul style="list-style-type: none"> • Make sure RINGER switch is set to ON. • You might have too many phones on one line.
Feedback when dialing in PULSE mode.	<ul style="list-style-type: none"> • This is normal. Power fluctuates with phone outpulsing.
Can't be heard by other party	<ul style="list-style-type: none"> • Make sure phone cord is securely plugged in. • Make sure other phones aren't off the hook at the same time you're using the phone. It is normal for the volume to drop when additional phones are used at the same time.

4

5

FOLD

FOLD

FOLD