

Portable Floor Pull-Up Screen

Elite ez Cinema Plus Series


FOR MODELS: F68XWS1 / F60XWV1 / F84XWV1 / F74XCH1 / F84XCH1

USER'S GUIDE




M Warning! Physical injuries can result from operation errors and damage to the screen if the following precautions are not taken seriously.

Do not place screen near or beside a fireplace or high temperature bjects such as a gas stove to avoid damage to the screen or prevent a fire.





Place the screen beyond the reach of children.



NOTE:


Installation

The screen should be installed in an area free of very strong wind

and away from any fire activity such as a fireworks display.


1. Extending base feet:

Locate the base feet on the bottom of the box cover of each end and rotate the footboard until it forms a right angle between the footboard and the cover box.




2. Open the box cover:


Unlock the buckles on both sides of the box to open the box cover.



3. Pulling out the screen:

Carefully lift the screen with the handle and stop at the desired position.






Note: The screen will only stop shortly after the bottom black rise has been exposed.


Putting screen away

Retracting screen into case:
 Press the screen's handle slowly in a downward motion to allow the screen to retract back into the housing.




2. Draw the base feet back:

Slightly lift one end of the box and turn the two feet at the bottom of the box till they are in a parallel line with the box.




3. Closing it up:

Lastly, snap the buckles in place on both sides to secure screen closure.



4. Storing the screen:

The recommended place for storage would be a corner spot or in a closet, but the ultimate choice is up to you.



The following points should be noted to assure the sound performance of the screen

- 1. Never use your hand to touch the screen surface
- 2. Never scrabble on the screen
- 3. Don't scratch the screen with hard pieces.

4. Please use clean cotton cloth or soft fur brushes to remove the dust on the screen.

Warranty Policy - Manual, Tripod, Pull-up Floor, and Fixed Frame Screens

- One (1) year warranty parts and labor from purchase date as follows (except for refurbished units as specified below):
- Refurbished units carry a 90-day parts and labor warranty.
- Demo units or open box items are AS IS items and do not carry a warranty.
- Each party will be responsible for one way shipping during the warranty period.
- DOA (Defective On Arrival): Must be reported within 7 business days of receipt. A RMA (Return Merchandise Authorization) number must be issued in order to process a replacement. Elite Screens will replace the DOA (Defective On Arrival) unit with a brand new replacement *(see exceptions below) after the DOA unit is received and/or confirmed defective. Once the product is received, Elite Screens will send out a new *unit to the customer by ground service (subject to inventory availability). Should a problem be reported after the 7-day grace period, the item must be shipped to us for warranty repair.
- Missing Parts must be reported within the 7-day (DOA) grace period. If reported after 7 days, customer will be only be responsible for shipping and handling fees. If reported after 30 days of receipt, customer is responsible for cost of the parts and shipping & handling fees.

Please visit link below for full warranty information

http://www.elitescreens.com/services.html

*A new or refurbished replacement will be sent out to the customer depending on the type of purchase (new or refurbished) or based on stock availability.

Fill this in!!

For the convenience of service, record the following information in the space below. The serial number can be located on the packaging box or inside the screen's box.

Screen Model:

Serial Number:

Date of Purchase:

Dealer / Reseller Purchased from:

EliteSCREENS

Tel: 562-483-8198 www.elitescreens.com service@elitescreens.com