

READ AND SAVE THESE INSTRUCTIONS!

 ALWAYS place the humidifier in an area that is out of the reach of children.

 Before using the humidifier, extend the cord and inspect for any signs of damage. DO NOT use the product if the cord has been damaged.

- ALWAYS UNPLUG AND EMPTY the humidifier when it is not in operation or while it is being cleaned.
- Do not use water bottles greater than 22 oz.
- This product is intended for residential use only. DO NOT use outdoors.
- This device complies with part 18 of the FCC Rules.

Initial Setup:

- 1. Unravel and straighten the cord before use.
- 2. Set the unit on a flat, waterproof surface.
- 3. Drop one demineralization tablet into your water bottle. (note: The tablet will remove minerals from the water to prevent dust accumulation. The benefits of each tablet
- will last up to one week between humidifier cleanings.) 4. Use the water cap that came with your humidifier and press it down over the mouth of your water bottle firmly.
- 5. Turn your water bottle upside down and insert into the water reservoir.



Failure to ensure the tank is seated correctly could cause

the unit to leak water from the tank. 6. Insert the power adapter into the bottom right side of the unit, then plug

the adapter into a wall outlet.



Operation:


To turn the humidifier on, turn the humidity adjustment knob clockwise until you feel the knob click. At this time the unit should be on and you can adjust the amount of mist the unit outputs by continuing to turn the knob clockwise. To turn the unit off, turn the humidity adjustment knob counter-

Maintenance:

clockwise until it clicks.

- 1. Turn off the humidifier and unplug the power adapter from the wall and the unit. Remove the water bottle from the unit and remove
 - the cap.
 - Empty the water from the bottle.
- 4. Rinse the humidifier cap thoroughly with warm water. Replace the water bottle if necessary. Remove the reservoir cover from the humidifier and
- empty any remaining water.
- 6. Wipe any mineral deposits from the cover and base with a soft cloth.
- 7. Replace the cover onto the base. Align the notch on the cover with the groove on the base. The mist exhaust should be 45° to the right of the humidity adjustment knob.





Problem:

Humidifier not working

Solution: 1. Make sure the humidity knob is not set to OFF.

Technical Support

If you need any assistance with setup, operation, or technical support staff is ready to help!

Time. You may also contact us over the Internet at

www.hunterfan.com or register your product at www.hunterfan.com/register and select your product under

product registration.

 THE EXCLUSION OR LIMITATION OF DIRECT, INDIRECT, The Hunter Fan Company, Inc. makes the following warranty SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES; to the original residential user or consumer purchaser of the THE EXCLUSION OR INVALIDITY OF EXPRESS OR IMPLIED WARRANTIES IF THE USER CEASES TO OWN THE HUMIDIFIER:

ultrasonic humidifier: If any part of The ultrasonic humidifier fails during the first

year from the date of purchase due to a defect in material

charge. If no replacement part can be provided, we will replace your Humidifier.

IF THE ORIGINAL RESIDENTIAL USER OR CONSUMER PURCHASER CEASES TO OWN THE ULTRASONIC HUMIDIFIER, THIS WARRANTY AND ANY IMPLIED WARRANTY WHICH THEN REMAINS IN EFFECT, INCLUDING

BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF

AMERICAN STATES AND CANADIAN PROVINCES DO NOT

PRICE OF THE HUMIDIFIER. YOUR SOLE REMEDY WILL BE REPAIR OR REPLACEMENT AS PROVIDED ABOVE. SOME

ALLOW:

LASTS;

INCIDENTAL DAMAGES IN EXCESS OF THE PURCHASE

Hours of operation are from 7:00 am to 7:00 pm Monday - Friday and 8:00 am to 5:00 pm on Saturday, Central

parts for your new Hunter Humidifier, please call us, our USA: 1-888-830-1326 Canada: 1-866-268-1936

the bubbling has stopped, set the unit to the desired speed. 3. Clean any components that have mineral build-up.

1. Check the humidity knob to make sure it is set to the

purchased and used in the USA or Canada.

This warranty excludes and does not cover defects,

malfunctions, or failures of the humidifier which were caused

establishes proof of purchase.

will return the humidifier freight prepaid to you. The humidifier

should be properly packaged to avoid damage in transit since

purchaser must present the sales receipt or other document that

we will not be responsible for any such damage. Proof of purchase is required when requesting warranty service. The

IN NO EVENT SHALL HUNTER FAN COMPANY BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, CONSEQUENTIAL OR

LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY

THE LIMITATION OF THE REMEDIES AND RECOURSES

AVAILABLE TO THE PURCHASER; OR THE INVALIDITY OF

BY BRAND NAME IS NOT USED (UNLESS SPECIFIC

AN EXPRESS WARRANTY WHEN A PRODUCT IDENTIFIED

SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS AND

YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM

MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE VOIDED. THIS WARRANTY IS IN LIEU OF ALL

OTHER EXPRESS WARRANTIES. THE DURATION OF ANY

IMPLIED WARRANTY, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS

FOR A PARTICULAR PURPOSE IS EXPRESSLY LIMITED TO THE

PERIOD OF THE EXPRESS WARRANTY SET FORTH ABOVE.

This warranty is voided if your ultrasonic humidifier is not

by repairs by persons not authorized by us, use of parts, or accessories not authorized by us, mishandling, modifications,

or damage to the humidifier while in your possession, or unreasonable use, including failure to provide reasonable and necessary maintenance. This warranty does not cover humidifiers used in commercial applications. There are no express or implied warranties as to commercial purchasers or

To obtain service, contact the nearest Hunter authorized service center or the Hunter Fan Company Service Department, 7130

Goodlett Farms Pkwy., Suite 400, Memphis, TN 38016, 1-888-830-1326. You will be responsible for insurance and freight or other transportation to our factory service center. We

when the water bottle is full and running. If there are bubbles, turn the unit OFF until the bubbling stops. When

2. Check the water bottle to make sure there are no bubbles

desired humidity level and speed.

2. Ensure the power supply is firmly plugged into the unit.

Problem: Humidity output and water usage decreased

Troubleshooting:

Solution:

Limited 1 Year Warranty

or workmanship, we will provide a replacement part free of

20120628

STATE TO STATE OR PROVINCE TO PROVINCE.

CONDITIONS ARE FULFILLED);

APPLY TO YOU.

©2012 Hunter Fan Co.