Preface Remarks before using **Unit Features Unit Illustrations Unit Illustrations** Thank you for choosing iPYLE PiFMPK9 Car FM Transmitter with Ipod To protect unit's excellent functions, avoid using it in the following 1. No need to change any equipment of car. Just plug the cigar head into 6. Large size LCD digital display for frequency. Blue backlight design is environment: docking. This device is a full band Car FM Transmitter with frequency convenient for operation in the dark place. cigarette lighter socket. 1. Frequency up/down 5. 3.5mm audio input jack 1. Too much moisture range from 88.1MHz to 107.9MHz. Totally there are 199 selectable 7. Transmitting range is more than 8M. 2. Function keys: 2. Special port for Ipod with charge function. 6. 3.5mm audio output jack 2. Too high temperature frequencies. Up to 10 frequently used frequencies can be stored into adjust/store frequency 3. It is perfect for all kinds of Ipod such as Ipod mini, Ipod nano, Ipod Video. 8. 3.5mm audio input jack for connecting external audio device with 3. At direct sunlight 7. Cigar head memory for future use. It has power off memory. The last used frequency 4. To be easy to fall off 3. LCD digital display 3.5mm plug such as MP3, MP4, portable CD, DVD, etc. 4. Built-in FM stereo wireless transmitter transmits the music from Ipod to 8. Polarity "-" before power off can be kept in memory. When you use this unit next time, 4. Ipod connector car radio for playing. PLL circuit to ensure stability of frequency and 9. 3.5mm audio output jack can output audio signal to other audio devices 9. Polarity "+" the last used frequency will be displayed automatically. Pay attention in the listening: such as recording equipment. prevent the frequency from skipping fast. 1. To avoid harm to your ear, please choose suitable volume level. 10. Power off frequency memory function. 5. Full band to avoid interference. Frequency range is from 88.1MHz to 2. To adjust the volume, please don't turn up to very high level to avoid To use this unit correctly, smoothly and comfortably, please read this 11. Auto ON when receive any audio signal. Auto OFF when no audio damage to your car speaker system. 107.9MHz. Frequency interval is 0.1MHz. Up to 10 channels can be stored instruction manual carefully before operation. 3. Please be more careful or stop using in any environment with potential signal received in 50 seconds. in memory. danger operation instructions operation instructions operation instructions operation instructions **Specifications** 7. To keep regular used frequency in memory, please set 5. If any interference, please press CH+/CH- to Frequency Range: 88.1MHz-107.9MHz (frequency interval is 0.1MHz) 1. Plug cigar head into car cigarette lighter socket. 3. Press frequency up/down to set a suitable one for \vdash **CLPYLE** it as current frequency. Press down P for seconds until choose another suitable frequency. Slightly press LCD display lights up and shows current SENTE BRIMHZ using. LCD display shows the frequency in using. CH NO flashes to enter CH saving mode. Adjust Frequency Stability: +10PPM (-10°C~+50°C) BB.1MHz OH P OH CH+/CH-, frequency will go up or down 0.1MHz. frequency. CH+, CH- to choose the location(CH NO.) for the Noise Limitation: ≥60dB Press CH+/CH- for few seconds to fast forward frequency you want to save. Press P to keep both CH PiFMPK9 or backward frequency. Frequency deviation: ≤75KHz NO and frequency in memory. Trasnmitting range: ≥8M **Ipod Car FM Transmitter** 6. Press "P" to select previous stored channel. The Audio input bandwidth: 100~15000Hz 2. Plug Ipod into special port for Ipod. Press "play" 4. Turn on car radio. Adjust the frequency to the same frequency will cycle from CH01 to CH10, LCD Power Supply: DC12V 8. If use MP3, MP4, portable CD, DVD or other 3.5mm SB.1MHz SB.1MHz SI- / P \ SI+ CEPPLE BB.1MH: CP P CS will display first the selected CH NO and then to start playing. one as transmitter manually or use AUTO SCAN Instruction Manual BB.1 MHz frequency after one second. audio input, please connect the 3.5mm audio cable function to set the frequency. to 3.5mm input jack. -7--10--11www.pyleaudio.com