

# Samsung GALAXY Note<sup>®</sup> 8.0

W I - F I T A B L E T

## User Manual

Please read this manual before operating your  
tablet, and keep it for future reference.



## **Intellectual Property**

All Intellectual Property, as defined below, owned by or which is otherwise the property of Samsung or its respective suppliers relating to the SAMSUNG Phone, including but not limited to, accessories, parts, or software relating there to (the "Phone System"), is proprietary to Samsung and protected under federal laws, state laws, and international treaty provisions. Intellectual Property includes, but is not limited to, inventions (patentable or unpatentable), patents, trade secrets, copyrights, software, computer programs, and related documentation and other works of authorship. You may not infringe or otherwise violate the rights secured by the Intellectual Property. Moreover, you agree that you will not (and will not attempt to) modify, prepare derivative works of, reverse engineer, decompile, disassemble, or otherwise attempt to create source code from the software. No title to or ownership in the Intellectual Property is transferred to you. All applicable rights of the Intellectual Property shall remain with SAMSUNG and its suppliers.

### **Open Source Software**

Some software components of this product incorporate source code covered under GNU General Public License (GPL), GNU Lesser General Public License (LGPL), OpenSSL License, BSD License and other open source licenses. To obtain the source code covered under the open source licenses, please visit:

<http://opensource.samsung.com>.

### **Disclaimer of Warranties; Exclusion of Liability**

EXCEPT AS SET FORTH IN THE EXPRESS WARRANTY CONTAINED ON THE WARRANTY PAGE ENCLOSED WITH THE PRODUCT, THE PURCHASER TAKES THE PRODUCT "AS IS", AND SAMSUNG MAKES NO EXPRESS OR IMPLIED WARRANTY OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT, INCLUDING BUT NOT LIMITED TO THE MERCHANTABILITY OF THE PRODUCT OR ITS FITNESS FOR ANY PARTICULAR PURPOSE OR USE; THE DESIGN, CONDITION OR QUALITY OF THE PRODUCT; THE PERFORMANCE OF THE PRODUCT; THE WORKMANSHIP OF THE PRODUCT OR THE COMPONENTS CONTAINED THEREIN; OR COMPLIANCE OF THE PRODUCT WITH THE REQUIREMENTS OF ANY LAW, RULE, SPECIFICATION OR CONTRACT PERTAINING THERETO. NOTHING CONTAINED IN THE INSTRUCTION MANUAL SHALL BE

CONSTRUED TO CREATE AN EXPRESS OR IMPLIED WARRANTY OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT. IN ADDITION, SAMSUNG SHALL NOT BE LIABLE FOR ANY DAMAGES OF ANY KIND RESULTING FROM THE PURCHASE OR USE OF THE PRODUCT OR ARISING FROM THE BREACH OF THE EXPRESS WARRANTY, INCLUDING INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES, OR LOSS OF ANTICIPATED PROFITS OR BENEFITS.

### **Modification of Software**

SAMSUNG IS NOT LIABLE FOR PERFORMANCE ISSUES OR INCOMPATIBILITIES CAUSED BY YOUR EDITING OF REGISTRY SETTINGS, OR YOUR MODIFICATION OF OPERATING SYSTEM SOFTWARE.

USING CUSTOM OPERATING SYSTEM SOFTWARE MAY CAUSE YOUR DEVICE AND APPLICATIONS TO WORK IMPROPERLY. YOUR CARRIER MAY NOT PERMIT USERS TO DOWNLOAD CERTAIN SOFTWARE, SUCH AS CUSTOM OS.

©2013 Samsung Electronics Canada, Inc.

Do you have questions about your Samsung Mobile tablet? For 24 hour information and assistance, we offer a new FAQ/ARS System (Automated Response System) at: <http://www.samsung.com/us/support>



Nuance<sup>®</sup>, VSuite<sup>™</sup>, T9<sup>®</sup> Text Input, and the Nuance logo are trademarks or registered trademarks of Nuance Communications, Inc., or its affiliates in the United States and/or other countries.


The Bluetooth<sup>®</sup> word mark, figure mark (stylized "B Design"), and combination mark (Bluetooth word mark and "B Design") are registered trademarks and are wholly owned by the Bluetooth SIG.

microSD<sup>™</sup> and the microSD logo are Trademarks of the SD Card Association.

Openwave<sup>®</sup> is a registered Trademark of Openwave, Inc.

LTE is a trademark of ETSI.

 and  are trademarks of SRS Labs, Inc. CS Headphone and WOW HD technologies are incorporated under license from SRS Labs, Inc.

, DivX<sup>®</sup>, DivX Certified<sup>®</sup> and associated logos are trademarks of Rovi Corporation or its subsidiaries and are used under license.

DivX Certified<sup>®</sup> to play DivX<sup>®</sup> video up to HD 720p, including premium content.

ABOUT DIVX VIDEO: DivX<sup>®</sup> is a digital video format created by DivX, LLC, a subsidiary of Rovi Corporation. This is an official DivX Certified<sup>®</sup> device that has passed rigorous testing to verify that it plays DivX video. Visit [www.divx.com](http://www.divx.com) for more information and software tools to convert your files into DivX videos.

ABOUT DIVX VIDEO-ON-DEMAND: This DivX Certified<sup>®</sup> device must be registered in order to play purchased DivX Video-on-Demand (VOD) movies. To obtain your registration code, locate the DivX VOD section in your device setup menu (tap **Apps > Settings > About device > Legal information > License settings > DivX<sup>®</sup> VOD > Register**).

Go to [vod.divx.com](http://vod.divx.com) for more information on how to complete your registration.

Google, the Google logo, Android, the Android logo, Google Play, Gmail, Google Mail, Google Maps, Google Music, Google Talk, Picasa, YouTube and other marks are trademarks of Google Inc.

Wi-Fi is a registered trademark of the Wireless Fidelity Alliance, Inc.

Swype and the Swype logos are trademarks of Swype, Inc. © 2010 Swype, Inc. All rights reserved.

## IC Notice

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

# Table of Contents

---

## Section 1: Getting Started ..... 1

Understanding This User Manual .....	1
Battery .....	2
Turning Your Device On and Off .....	4
Setting Up Your Device .....	4
Creating a New Google Account .....	5
Creating a Samsung Account .....	5
Retrieving Your Google Account Password .....	6
Memory Card .....	6
Locking and Unlocking the Touch Screen .....	7
Troubleshooting .....	7

## Section 2: Understanding Your Device ..... 8

Features .....	8
Front View .....	9
Home Screen .....	11
Navigating Your Device .....	13
S Pen .....	14
Notifications .....	17
Status Details .....	17

Quick Settings .....	17
Status Bar .....	21
Primary Shortcuts .....	22
Widgets .....	22
App Shortcuts .....	22
Folders .....	23
Wallpapers .....	24
Using the Multi Window .....	25
Apps Screen .....	29
Memory Card .....	30

## Section 3: Contacts and Accounts ..... 31

Accounts .....	31
Contacts .....	32
Groups .....	35
Favourites .....	37

## Section 4: Entering Text ..... 39

Text Input Methods .....	39
Using the Samsung Keyboard .....	39
Using the Handwriting Feature .....	42

Using Google Voice Typing .....	43	Bluetooth .....	82
<b>Section 5: Messaging .....</b>	<b>45</b>	Managing Downloads .....	84
Types of Messages .....	45	Kies Via Wi-Fi .....	84
Gmail .....	45	Synchronizing with Windows Media Player .....	85
Email .....	48	Connecting as a Mass Storage Device .....	86
Google Talk .....	51	<b>Section 9: Applications .....</b>	<b>87</b>
Google+ .....	55	Updating Applications .....	87
Messenger .....	55	GPS Applications .....	87
ChatON .....	55	Alarm .....	88
<b>Section 6: Music .....</b>	<b>57</b>	aNote HD .....	89
Listening to Music .....	57	Calculator .....	91
Google Play Music .....	57	Calendar .....	91
Music Player .....	58	Camera .....	93
<b>Section 7: Photos and Video .....</b>	<b>63</b>	ChatON .....	94
Camera .....	63	Chrome .....	94
Video Player .....	70	Contacts .....	94
Gallery .....	72	Downloads .....	94
<b>Section 8: Connections .....</b>	<b>77</b>	Dropbox .....	95
Internet .....	77	Email .....	95
Wi-Fi .....	79	Flipboard .....	95
Wi-Fi Direct .....	80	Gallery .....	95
		Game Hub .....	95

Gmail	96	S Note	104
Google Search	96	S Voice	104
Google Settings	97	Samsung Apps	105
Google+	97	Samsung Link	105
Group Play	97	Settings	108
Help	98	Smart Remote	108
Internet	98	Talk	108
Learning Hub	98	Video Hub	109
Local	99	Video Player	109
Maps	99	Voice Search	109
Messenger	100	World Clock	109
Music Player	100	YouTube	110
My Files	100	<b>Section 10: Settings</b>	<b>111</b>
Navigation	101	Accessing Settings	111
Paper Artist	101	Wi-Fi	111
Play Books	102	Bluetooth	113
Play Magazines	102	Data Usage	114
Play Movies	102	More Settings	114
Play Music	102	Home screen mode	117
Play Store	103	Sound	118
Polaris Office	104	Display	119
Readers Hub	104	Storage	120

Power Saving Mode	121
Battery	121
Application Manager	121
Location Services	123
Lock Screen	124
Security	126
Language and Input	128
Cloud	131
Back Up and Reset	132
Accounts	133
Motion	134
S Pen	135
Accessory	136
Date and Time	137
Accessibility	137
Developer Options	140
About Device	141
<b>Section 11: Health and Safety</b>	<b>144</b>
Getting the Most Out of Your Reception	144
Maintaining Safe Use of and Access to Your Phone	144
Caring for the Battery	146

Acknowledging Special Precautions and Industry Canada Notice	147
Owner's Record	149
<b>Index</b>	<b>150</b>



## Section 1: Getting Started

---

This section helps you to quickly start using your device.

### Understanding This User Manual

The sections of this manual generally follow the features of your device. A robust index for features begins on page 150.

Also included is important safety information, beginning on page 144, that you should know before using your device.

This manual gives navigation instructions according to the default display settings. If you select other settings, navigation steps may be different.

Unless otherwise specified, all instructions in this manual assume that you are starting from a Home screen. To get to a Home screen, you may need to unlock the device. For more information, refer to “*Locking and Unlocking the Touch Screen*” on page 7.

---

**Note:** Instructions in this manual are based on default settings and may vary from your device depending on the software version on your device and any changes to the device’s settings.

---

---

**Note:** Unless stated otherwise, instructions in this user manual start with the device unlocked, at the Home screen.

All screen images in this manual are simulated. Actual displays may vary depending on the software version of your device and any changes to the device’s settings.

---

### Special Text

In this manual, some text is set apart from the rest. This special text is intended to point out important information, share quick methods for activating features, define terms, and more. The definitions for these methods are as follows:

- **Notes:** Presents alternative options for the current feature, menu, or sub-menu.
- **Tips:** Provides quick or innovative methods or useful shortcuts.
- **Important:** Points out important information about the current feature that could affect performance.
- **Warning:** Brings important information to your attention that can help to prevent loss of data or functionality or damage to your device.

## Text Conventions

This manual provides condensed information about how to use your device. To make this possible, the following text conventions are used to represent often-used steps:

- Arrows are used to represent the sequence of selecting successive options in longer, or repetitive, procedures. For example:

From a Home screen, touch  Apps →  Settings  
→ Display → Screen timeout.

## Battery

Your device is powered by a rechargeable, standard Li-Ion battery. A Wall/USB Charger (Charging Head and USB cable) are included with the device for charging the battery.

---

**Note:** The battery comes partially charged. You must fully charge the battery before using your device for the first time.

After the first charge, you can use the device while charging.


---

---

**Warning!** Use only approved charging devices. Approved accessories are designed to maximize battery life. Using other accessories may invalidate your warranty and may cause damage.

---

## Battery Indicator

The Battery icon  in the Status Bar shows the battery power level. When battery power is 15% or less, your device prompts you to charge the battery. If you continue to operate the device without charging, the device powers off. For battery use information, see “About Device” on page 141.

---

**Tip:** Touch the Time field to display battery charge status.

---

## Charging the Battery

Your device comes with a Wall/USB Charger (Outlet Connector, Charging Head, and USB cable) to charge your device from any standard AC power outlet.


---

**Note:** The battery comes partially charged. You must fully charge the battery before using your device for the first time.


After the first charge, you can use the device while charging.

---

1. Insert the USB cable into the Charging Head.



2. Insert the USB cable into the device's Charger/Accessory Port.



3. Plug the Charging Head into a standard AC power outlet.

---

**Warning!** While the device is charging, if the touch screen does not function due to an unstable power supply, unplug the USB power adapter from the power outlet or unplug the USB cable from the device.

---


4. When charging is complete, unplug the Charging Head from the power outlet and remove the USB cable from the device.

## Turning Your Device On and Off

### Turning Your Device On

- Press and hold the **Power/Lock Key** .

**Note:** Your device's internal antenna is located along the top back of the device. Do not block the antenna; doing so may affect signal quality and may cause the device to operate at a higher power level than is necessary. For more information, refer to "GPS Applications" on page 87.



### Turning Your Device Off

1. Press and hold the **Power/Lock Key** .

2. At the prompt, touch **Power off** → **OK**.

## Setting Up Your Device



When you first turn on your device, you are asked to set up a few things. To do that, the following screens display. Some screens can be skipped (touch **Skip**) or re-displayed (touch **Back**). Some screens display depending on the options you choose.

1. When you first turn on your tablet, the **Welcome!** screen displays.
2. The default language for your tablet is English. If you would like to select French, tap the drop-down box then tap **Français**.
3. If you are visually impaired or hard of hearing, tap **Accessibility** to change the accessibility settings.
4. Tap **Next**.
5. Read and follow the instructions on each screen to set up your tablet.

## Creating a New Google Account

In order to utilize your device to the fullest extent, you will need to create a Google™ Account when you first use your device. With a Google Account, Google applications will always be in sync between your tablet and computer.

If you did not create a new account during the setup procedure when you first turned your tablet on, follow these steps:

1. From the Home screen, tap  → **Settings**  → **Add account** → **Google**.

The **Add a Google Account** screen displays.

2. Tap **New** to create a new Google account.  
– or –

If you already have a Google account, tap **Existing** to sign in and add the account to your tablet.

3. Follow the on-screen instructions to add a Google Account.






---

**Note:** Once you have created a Google account, you only need to sign in.

---

## Creating a Samsung Account

An active Samsung account is required to begin accessing applications such as ChatON and Samsung Hub. If you did not create a Samsung account when you first set up your tablet, follow these steps:

1. From the home screen, tap  → **Settings**  → **Add account**.
2. Tap  **Samsung account**.
3. Tap **Create new account**.
4. Select your Country or region.
5. Tap **Terms and conditions** to read them and tap .
6. Tap **Privacy policy** to read it and tap .
7. Tap the **I accept all the terms above** checkbox.
8. Tap **Agree**.
9. Enter the required information and tap **Sign up**.  
Your Samsung account is created.

## Retrieving Your Google Account Password

A Google account password is required for Google applications. If you misplace or forget your Google Account password, follow these instructions to retrieve it:

1. From your computer, use an Internet browser to navigate to <http://google.com/accounts>.
2. Once the URL loads, click on the **Can't access your account?** link and follow the on-screen instructions.


## Memory Card

Your device supports removable microSD, microSDHC or microSDXC memory cards with maximum capacities of 64 GB (depending on the memory card manufacturer and type). Memory cards are used to store music, photos, videos, and other files.

### Installing a Memory Card

1. Open the Memory Card Slot cover and turn to expose the slot.
2. With the gold contacts facing down, carefully slide the memory card into the slot, pushing gently until it clicks into place.

3. Replace the Memory Card Slot cover.





### Removing a Memory Card

---


**Important!** To prevent damage to information stored on the memory card, unmount the card before removing it from the device.

---



1. From a Home screen, touch  **Apps** →  **Settings** → **Storage**.
2. Under **SD card**, touch **Unmount SD card** and then touch **OK**.

3. Open the Memory Card Slot cover and turn to expose the slot.
4. Gently press in on the memory card (1), so that it pops out from the slot, and carefully pull the card out (2).
5. Replace the Memory Card Slot cover.

For more information, refer to “Memory Card” on page 30.



## Locking and Unlocking the Touch Screen

1. Press  to lock the touch screen.
2. Press  again to display the lock screen then swipe your finger across the screen to unlock.

---

**Note:** Swipe is the default screen locking method. To change your screen lock, see “Screen Lock” on page 124.

---


---

**Tip:** From the Lock screen, touch and swipe one of the app shortcut icons to launch that application.

---

## Troubleshooting

If your device has fatal errors, hangs up, or freezes, you may need to reset the device to regain functionality.

- If your device is frozen and unresponsive, press and hold the **Power/Lock Key**  for 8 to 10 seconds.

## Section 2: Understanding Your Device

---

This section outlines key features of your device and describes the screen and the icons that appear when the device is in use. It also shows how to navigate through the device.

### Features

- 8.0-inch WXGA (1280x800) TFT (PLS) LCD touch screen
- Android Version 4.1.2
- 4G Network with 1.6 GHz quad-core processor
- Full HTML Web Browser
- Bluetooth 4.0 Wireless technology. For more information, refer to “*Bluetooth*” on page 113.
- Built-in Wi-Fi technology (802.11 a/b/g/n)
- 5 Megapixel camera and camcorder, plus 1.3 Megapixel forward-facing camera for video chat
- Full integration of Google applications (Gmail, YouTube, Google Maps, and Voice Search)
- Photo Gallery that supports GIF, AGIF, JPEG, PNG, BMP, WBMP, and WEBP formats
- HD Video Player (1080p)
- DivX Certified<sup>®</sup> to play DivX<sup>®</sup> video up to HD 720p, including premium content
- Supports HDMI/MHL connections to connect electronic devices to high-definition televisions (HDTVs) and displays.
- Music player that supports MP3, AAC/AAC+/EAAC+, WMA, OGG (vorbis), FLAC, AC-3
- 2 GB RAM memory and 16GB on-board memory, which is used for data storage and access
- Support for microSD, microSDHC and microSDXC Memory Cards
- S Pen for writing and playing games
- Preloaded applications such as Google Play Books, Google Play Store and Polaris Office. For more information, refer to “*More Application Information*” on page 29.



## Front View

The following items can be found on the front of your device as illustrated.

1. **External Speakers:** Used in music or video playback, notification tones, and for other sounds.
2. **Light Sensor:** Used to control screen brightness automatically and when taking photos with the front-facing Camera.
3. **Front-facing Camera Lens:** Used when taking photos or recording videos.
4. **Display Screen:** The orientation of the display screen rotates with the tablet as you turn it. You can turn this feature on and off. For more information, refer to “*System Accessibility*” on page 137.



## Back View

1. **3.5mm Headset Jack:** Plug in for headphones.
2. **Power/Lock Key:** Press and hold to turn the device on or off. Press to lock the device or to wake the screen for unlocking.
3. **Volume Key:** From a Home screen, press to adjust Master Volume. During music playback, press to adjust volume.
4. **Infrared Blaster:** Used to emit infrared signals used for controlling external devices. For more information, refer to “*Smart Remote*” on page 108.
5. **S Pen:** A built-in stylus that allows you to perform various functions. For more information, refer to “*S Pen*” on page 14.
6. **Charger/Accessory Port:** Plug in a USB cable for charging or to sync music and files.
7. **Memory Card Slot:** Install a memory card for storage of files.
8. **Camera Lens:** Used when taking photos or recording videos.



## Home Screen

The Home screen is the starting point for using your device.

**Note:** Unless stated otherwise, instructions in this user manual start with the device unlocked, at the Home screen.



1. **Widgets:** Applications that run on the Home screen. Some widgets are found on the Home screen by default. For more information, refer to “*Widgets*” on page 22.
2. **Google Quick Search bar:** a shortcut to Google Search that allows you to search for items on the internet.
3. **Home screen:** The starting point for using your device. Place shortcuts, widgets, and other items to customize your device to your needs.
4. **App Shortcuts:** Shortcuts to common applications. For more information, refer to “*App Shortcuts*” on page 22.
5. **Primary Shortcuts:** Shortcuts to common features. These shortcuts are found on the Home screen by default. For more information, refer to “*Primary Shortcuts*” on page 22.
6. **Apps:** Display the Apps screen.
7. **Current screen indicator:** Indicates which Home screen is being displayed. For more information, refer to “*Extended Home Screen*” on page 12.
8. **Time:** Displays the current time.
9. **Status Icons:** Indicate the status of your tablet. For more information, refer to “*Status Bar*” on page 21.

## Extended Home Screen

The Home screen consists of the Home panel, plus four panels that extend beyond the display width to provide more space for adding shortcuts and widgets.

Slide your finger horizontally across the screen to scroll to the left or right side panels. As you scroll, the indicator at the top of the display shows your current position.

---

**Note:** The center panel displays when you touch  Home.

---

## Customizing the Home Screens

To customize the Home screens to suit your preferences:

1. Navigate to one of the Home screen panels.
2. Touch and hold on the screen until the **Home screen** pop-up displays.

– or –

Use the S Pen to touch and hold on the screen until the **Home screen** pop-up displays.

3. Touch **Set wallpaper** to change the Home screen wallpaper. For more information, refer to “*Wallpapers*” on page 24.
4. Under **Add to Home screen** touch:

- **Apps and widgets** to add app or widget shortcuts on the Home screen.
- **Folder** to add a folder on a Home screen. For more information, refer to “*Folders*” on page 23.
- **Page** to add a Home screen.

## Display Settings

You can customize display screen settings to your preferences. For more information, refer to “*Display*” on page 119.

## Adding and Removing Home Screen Panels

Your device comes with five Home screen panels. You can customize the Home screen by removing or adding panels.


---

**Note:** The panel in the center position displays when you touch  Home.

---

1. From a Home screen, pinch the screen from the left and right side to the center to display the editing screen.

**Tip:** Touch and hold on the screen until the **Home screen** pop-up displays. Under **Add to Home screen**, touch **Page** to add a Home screen.



2. Use these controls to configure panels:




**Remove:** Touch and drag a panel to the Trash Can to remove the panel from the Home screen. It will turn red.



**Add:** Touch to add a new panel, up to a total of seven. This option is available when less than seven panels have been added.



**Default Home Page:** Touch the Home icon at the upper right corner of a panel to set it as the default home screen.


3. To rearrange the order of panels, touch and drag a panel to a new location.
4. Touch  **Back** to return to the Home screen

## Navigating Your Device

Use command buttons and the touch screen to navigate.

### Command Buttons

#### Back

Touch  **Back** to return to the previous screen, option, or step.

- Touch an option in the list.

#### Application Bar

The Application Bar is the area along the top of various application screens. It usually contains the Search and Menu icons, as well as other icons that are used to display options and settings.

## Screen Navigation

### Touch

Touch items to select or launch them. For example:

- Touch the on-screen keyboard to enter characters or text.
- Touch a menu item to select it.
- Touch an application's icon to launch the application.

### Touch and Hold

Activate on-screen items. For example:

- Touch and hold a widget on the home screen to move it.
- Touch and hold on a field to display a pop-up menu of options.

### Swipe, Flick, or Slide

Swipe, flick, or slide your finger vertically or horizontally across the screen. For example:

- Unlocking the screen.
- Scrolling the Home screens or a menu.

### Pinch

Use two fingers, such as your index finger and thumb, to make an inward pinch motion on the screen, as if you are picking something up, or an outward motion by sweeping your fingers out.



For example:

- Pinch a photo in Gallery to zoom in.
- Pinch a webpage to zoom in or out.

## S Pen

The S Pen is a stylus that assists you in performing different functions. By using the Pen button, you can minimize having to switch between touch and pen input.



1. **Pen button:** by pressing the Pen button, you can add functionality to the S Pen. For more information, refer to “Using the S Pen” on page 16.
2. **Stylus tip:** the tip of the S Pen is used for tapping the screen.

## S Pen Settings

There are several settings available that control the behavior of the S Pen. For example, you can choose a sound that will play when you remove the S Pen from or return it to the slot in your device.

Instead of the default menu of shortcuts that displays when you remove the S Pen from your device, you can change the setting so that the S Note, Calendar, or Polaris Office app launches.

Also, there is a setting to display a hovering pen icon on the screen when the pen tip is near the screen.

Plus, there is a setting that helps to conserve battery power by causing your tablet not to try to detect the S Pen when it is in its slot in your tablet.


For more information, refer to “S Pen” on page 135.

## Removing the S Pen From Your Device

The S Pen is conveniently stored in your device to make it easy to find.

To remove the S Pen, follow these steps:

1. Locate the S Pen at the lower right corner of the device. Use your fingernail or a sharp object to pull the end of the S Pen out of the device.(1)
2. Pull the S Pen out of the device (2).






## Using the S Pen

There are several different functions you can perform by using the S Pen.

### S Pen Screen Operations

The S Pen can be used for various screen operations.

- Touch a command button, such as  **Back**, or icons, such as  **Apps** or  **Email**, with the S Pen instead of your finger. The result is the same.
- To sweep to the next screen, touch and drag the screen to the left or right.

### Launch Popup Note Mini App


To take quick notes or jot down ideas, you can launch the Popup Note Mini App from the default menu of shortcuts that displays when you remove the S Pen from your device. You can also launch the Popup Note Mini App from any screen with the S Pen.

To open the Popup Note Mini App:

- Hold the S Pen button and double-tap the screen.



---

**Tip:** Touch  to launch the S Note app. For information on using your S Pen with the S Note app, see “S Note” on page 104.

---



## S Pen Screen Capture

To capture a screen image, hold the S Pen button and press and hold the S Pen anywhere on the screen. Files are saved in the **Screenshots** folder.



## Notifications

When you receive a notification, the Notification icon displays in the System Bar, to the left of the time. Notifications indicate the arrival of Gmail, Email, alarms, and more.

## Status Details



To display the current date and time, battery status, and Wi-Fi connectivity status, open Status Details.

1. Tap and swipe down the top of the screen to see the Quick Settings, Recommended shortcuts using your S Pen and any notifications.

---

**Note:** Recommended shortcuts for your S Pen are only displayed when the S Pen is removed from your tablet.

---


2. Touch a notification summary to respond to it.
3. Press  **Home** or  **Back** or use the S Pen and swipe upwards to close the Status Details screen.

## Quick Settings

To view and control the most common settings for your tablet, as well as accessing the complete Settings application, and viewing your notifications, open the Quick Settings panel.

1. Tap and swipe down the top of the screen to see the Quick Settings.

## The Quick Settings pop-up displays.



---




**Note:** Recommended shortcuts (S Pen) is also displayed when the S Pen is removed from your tablet.

---

### 2. The Quick Settings are:

- **Wi-Fi:** Touch to enable or disable Wi-Fi. For more information, refer to “*Wi-Fi*” on page 79.

- **GPS:** Touch to enable or disable Standalone GPS services. For more information, refer to “*Use GPS Satellites*” on page 123.
  - **Reading mode:** Touch this to optimize the screen for reading.
  - **Sound / Vibrate / Mute:** Touch to enable or disable sound mode.
  - **Screen rotation:** When On the screen rotates automatically from landscape to portrait and vice versa. When Off the screen is fixed in the current mode, either portrait or landscape. For more information, refer to “*System Accessibility*” on page 137.
  - **Bluetooth:** Touch to enable or disable Bluetooth. For more information, refer to “*Bluetooth*” on page 82.
- Sweep the pop-up to the left to see additional settings.
- **Blocking mode:** When enabled, notifications for selected features will be disabled.
  - **Sync:** Synchronizes your device with the network. Synchronizes contacts, email, time, and a variety of accounts.
  - **Multi window:** When enabled, multiple screens may display at one time.

3. Touch the **Brightness** slider and drag it to set the brightness or touch **Auto** to allow the device to set brightness automatically based on available light and battery charge status.
4. Touch  **Settings** to open the Settings application. For more information, refer to “*Settings*” on page 111.
5. **Notifications** displays system notifications. Touch a notification entry to display the details. Touch **Clear** to remove Notification Icons from the System Bar.  
For more information, refer to “*Notifications*” on page 17.
6. Press  or  or use the S Pen and swipe up to close the Status Details screen.

Notifications display in the System Bar and, in some cases, under the Notifications heading in the Quick Settings to alert you to activity on the tablet such as new messages, application downloads, software updates, and more. The following table lists those icons.



**System Alert:** Check under the Notifications heading in the Quick Settings for alerts.



**Download:** An application or file is being downloaded or has been downloaded to the device.



**Download Successful:** A recent application download or update completed successfully.



**New Email Message:** You have new email. Touch Reply to view and answer the email.



**New Gmail Message:** You have new Gmail. Touch the icon for additional information.



**Google Talk Invitation:** Someone has invited you to chat using Google Talk.



**Music player:** Music is playing. Touch the Music icon or touch the Status Details to see the song title and music player controls. For more information, refer to “*Music Player*” on page 58.



**Music App:** A song is playing in the Music app. Touch the Music icon or touch the Status Details to see the song title and music player controls. For more information, refer to “*Google Play Music*” on page 57.



**Wi-Fi networks available:** An open Wi-Fi network is in range.



**GPS Active:** Displays when GPS is active.



**Software update:** There may be a software update available for this device. For more information, refer to “*Software Update*” on page 142.



**Updates Available:** Updates to the applications you have downloaded are available.



**Set up input methods:** When the keyboard is being displayed, touch this icon to display a menu of quick keyboard settings.



**Wi-Fi Direct:** Displays when Wi-Fi Direct is active and your tablet is connected to another device. For more information, refer to “*Wi-Fi Direct*” on page 80.



**Screenshot Captured:** A screenshot has been captured. For more information, refer to “*S Pen Screen Capture*” on page 17.



**Nearby Devices:** The Nearby devices setting is enabled. For more information, refer to “*Nearby Devices*” on page 116.



**Blocking Mode:** Notifications for selected features are disabled. For more information, refer to “*Blocking Mode*” on page 117.



**Event:** This is a notification for one or more events. For more information, refer to “*Creating an Event or Task*” on page 92.



**Navigation Active:** The Navigation App is active. For more information, refer to “*Navigation*” on page 101.



**USB Connected:** Device is connected to a computer using a USB cable.

## Status Bar

The Status Bar is part of the System Bar and displays icons to show network status, battery power, and other details.



**Battery Level:** Shown fully charged.



**Charging Indicator:** Battery is charging.



**Device Power Critical:** Battery has only three percent power remaining. At about 15 percent power remaining, a pop-up is displayed to remind you to charge immediately.



**USB Connection Indicator:** The device is connected to a computer using a USB cable, but it is not charging. The battery is only charged while connected to a computer, if the device is turned off. When the device is off, press the Power/Lock key to see the battery charging indicator.



**Battery Fully Charged:** When the battery is fully charged, this indicator is displayed.



**Flight Mode:** Indicates that the Flight Mode is active, which allows you to use many of your device's features, but it cannot access online information or applications.



**Bluetooth Active:** Bluetooth is turned on. For more information, refer to “*Bluetooth*” on page 82.



**Bluetooth Connected:** Your device is connected to a Bluetooth device.



**Wi-Fi Active:** Wi-Fi is connected, active, and communicating with a Wireless Access Point (WAP).



**Alarm Set:** Displays when you set an alarm to ring at a specified time. For more information, refer to “*Alarm*” on page 88.



**Smart stay:** Set the screen to stay on as long as you look at it. For more information, refer to “*Display*” on page 119.

## Primary Shortcuts

Primary Shortcuts display at the bottom of the main Home screen.

---

**Tip:** The default for the main Home screen is the center Home screen.


---

The default Primary Shortcuts are: Contacts, Messaging, Calendar, Internet and Apps.

## Widgets

When you first turn on your tablet, there are various widgets on the center Home screen. They can also appear on the Home screens to the left and right of the center Home screen. Widgets are self-contained applications that you can place on the Home screens to access your favorite features.

### Adding Widgets to a Home screen

1. Navigate to the Home screen on which you want to place the Widget and touch  **Apps**.
2. Touch the **Widgets** tab.

---

**Note:** Swipe across the screen horizontally to view all Widgets.

---


3. Touch and hold the widget's icon until the Home screen displays, then slide your finger where you want to place the icon and release it.

---

**Note:** There must be room on the screen where you want to place the widget, otherwise the widget will not be added to the Home screen.

---

## Removing Widgets

- Touch and hold the Widget until the  **Remove** icon displays, then drag the widget to the **Remove** icon.


---

**Note:** This action does not actually delete the Widget, it just removes it from the current Home screen.

---

## App Shortcuts

Use App Shortcuts for quick access to applications or features, such as Email or other applications.

1. Navigate to the Home screen on which you want to place the App Shortcut.
2. Touch  **Apps**.  
– or –


Touch and hold on the screen until the **Home screen** options pop-up displays and then touch **Apps and widgets**.

3. Touch the **Apps** tab.
4. Touch and hold the application icon until the Home screen displays, then slide your finger where you want to place the icon and release it.

For more information, refer to “*Apps Screen*” on page 29.

5. Touch and hold the App Shortcut and then drag the application icon to reposition it on the Home screen.

## Removing App Shortcuts

- Touch and hold the App Shortcut until  **Remove** displays, then drag the App Shortcut to the **Remove** icon.

## Folders

Place Folders on a Home screen to organize items together.

### Adding Folders

To create a folder on a Home page:

1. Navigate to the desired Home screen.

2. Touch and hold on the screen until the **Home screen** pop-up displays and then touch **Folder**.

The Create folder pop-up displays.

3. Touch the **Unnamed folder** field, use the keyboard to enter a name for the folder, and touch **OK**.

A new folder displays on the Home screen.

## Managing Folders

To rename a folder:

- Touch the folder, touch the current name, and use the keyboard to enter a new name for the folder.


To add an App shortcut to a folder:

1. Add the App shortcut to the Home screen that the folder is on.
2. Touch and hold the App shortcut, drag it to the folder, and drop it.

To remove an App shortcut from a folder:

1. Touch the folder to view the contents.
2. Touch the App shortcut, drag it out of the folder, and drop it on the Home screen.

## Removing a Folder

- Touch and hold the folder until the  **Remove** icon displays, then drag the folder to the **Remove** icon.

---



**Note:** Any App shortcuts in the folder are also removed.

---

## Wallpapers

You can choose a picture to display on the Home Screen, Lock screen, or on both the Home and Lock screens. Choose from preloaded wallpaper images or select a photo you have downloaded or taken with the Camera.

1. From a Home screen, touch and hold on the screen.  
The **Home screen** options pop-up displays.
2. Touch **Set wallpaper**.  
The Set wallpaper pop-up displays.
3. Touch **Home screen**, **Lock screen**, or **Home and lock screens**.  
The **Select wallpaper from** pop-up displays the following options:

- **Gallery:** Access the Gallery to select a photo. Touch a photo to select it. Crop and resize the picture, if desired. Touch **Done** to save the picture as wallpaper. Touch **Cancel** to cancel.
- **Live wallpapers:** Choose from pre-loaded interactive animated wallpapers. Touch a wallpaper to see an example. If available, touch **Settings** to view options for the selection. Touch **Set wallpaper** to save your choice. Touch  **Back** to return to the Live wallpapers menu.
- **Wallpapers:** Choose from pre-loaded wallpaper images. Touch an image to view it. Touch **Set wallpaper** to save it as wallpaper. Touch  **Back** to return to the Home screen.

---

**Note:** Live wallpapers is not available for the Lock screen.

---



## Using the Multi Window



This feature allows you to run multiple applications on the current screen at the same time.

---

**Note:** Only applications found within the Multi window panel can be active atop another current application on the screen. When launching applications that contain multimedia files (music/video), audio from both files will be played simultaneously.


---

### Turn on Multi window

The Multi window function is turned off by default. To turn it on, from the Home screen tap From a Home screen, touch  **Apps** →  **Settings** → **Display** → **Multi window**.

### Activating and Deactivating Multi window


**To activate Multi window:**

1. Press and hold the **Back key** (). The Multi window tab appears (by default) on the left side of the screen.


---

**Note:** Initially open activation, the entire apps panel is briefly displayed, then minimized to only show the tab.

---

2. Tap the tab  to open the application panel showing all the available Multi window apps.


**To deactivate Multi window:**

- Press and hold the **Back key** (). This action hides the Multi window tab from view.

### Repositioning the Multi Window

The Multi window contains two components: tab and apps panel. The tab can be manually moved across the screen. The apps panel (containing the scrollable apps) can be relocated to lock onto the different sides of the screen (top/bottom/left/right).

**To move the tab:**

1. Activate the Multi window feature.
2. In a single motion, touch and hold the tab  for approximately one second, then slowly drag it to its new location **along the current screen edge**.

---

**Note:** This is a quick way to get the tab out of the way if you can't get to a button or option behind it.

---




**To relocate the Multi window apps panel:**

1. Activate the Multi window feature.
2. Tap the tab to display the apps panel (containing the scrollable apps).

---

**Note:** Notice that when the apps are visible, the tab turns a dark grey. Its only in this state that the entire panel can be relocated.

---

3. In a single motion, touch and hold the tab  for approximately one-second to detach it from the screen (1), then slowly drag it to its new location **along any other** available screen edge (2). You can move it to the top, bottom, or either side.



## Customizing the Multi Window apps

The applications found within the apps panel of the Multi window can be organized by either being rearranged or removed.

### To rearrange the Multi window applications:

1. Activate the Multi window feature.
2. Tap the tab to display the apps panel (containing the scrollable apps).
3. In a single motion, touch and hold a desired app until it detaches from the panel, then carefully drag it to a new location in the list of apps. Lift your finger or stylus off the screen to let go of the app and drop it into its new location.

### To remove a Multi window application:

1. Activate the Multi window feature.
2. Tap the tab to display the apps panel (containing the scrollable apps).
3. Tap the **Edit** button (located at the bottom of the list) to reveal a staging area that can house any removed applications from the Multi window panel.

4. Tap **Done** once you have completed the removal process.

### To restore a Multi window application:

1. Activate the Multi window feature.
2. Tap the tab to display the apps panel (containing the scrollable apps).
3. Tap the **Edit** button (located at the bottom of the list) to reveal the staging area containing any previously removed apps.
4. Locate the desired application.
5. In a single motion, touch and hold a desired app until it detaches from the staging area, then carefully drag it to a new location in the current list of apps.

## Using Multi Window to run multiple apps on the same screen

Any of the apps found within the Multi window panel can be run at the same time as a current on-screen app.

Once multiple apps are running on the same screen, you can then choose to either swap their positions or maximize a desired app.


---

**Note:** Only applications found within the Multi-window panel can be active atop another current application on the screen.

When launching applications that contain multimedia files (music/video), audio from both files will be played simultaneously.

---

In this example we will be launching both the Internet and Maps applications.


1. Launch an application such as Maps.
  - From the Home screen, tap **Internet** .
2. Activate the Multi window feature.
3. Tap the tab to display the apps panel.
4. Touch and hold the desired app, such as Maps, until it detaches from the panel.
5. In a single motion, drag it over the current app and drop the new Multi window app over either the top or bottom area of the current on-screen app.


---

**Note:** Once two applications are running, the device displays a split screen view containing both the initial app and the new Multi window app. Each application is still independent of the other.

---

**To switch the arrangement of the applications:**



1. With the two applications shown in a split screen, tap the Border bar to show the on-screen icons.
2. Tap the desired application area (top or bottom).
3. Locate and tap  (**Switch app location**). The current apps are switched.



To increase the size of a desired application window:

1. With the two applications shown in a split screen, locate the Border bar indicating the edge of the app window.
2. In a single motion, touch and hold the Border bar then drag it to resize the desired window.


To split the current applications:



1. With the two applications shown in a split screen, tap the Border bar to show the on-screen icons.
2. Tap the desired application area (top or bottom).
3. Locate and tap  (**Maximize the app**). The current apps are the both maximized.
  - To exit the Multi window app, tap .

## Apps Screen

The **Apps** screen displays all applications installed on your wireless device. Applications that you download and install from Google Play or from the web are also added to a Home screen.

The Apps icons are arranged in a Alphabetical grid. To arrange the Apps icons in any order you choose, follow these steps:



1. From a Home screen, touch  **Apps**.

2. Touch  **Menu** → **View type**.
3. Touch **Customizable grid**.
4. Touch  **Menu** → **Edit**.
5. Touch and hold an icon and drag it to a new position.
6. Touch **Save** to save the changes.

You can place shortcuts to applications on the Home screen for quick access to the application. For more information, refer to “*App Shortcuts*” on page 22.

## Application Information

To view information about an App, such as the amount of storage it uses, force the App to stop, uninstall updates, and clear data:

1. From a Home screen, touch  **Apps** →  **Settings** → **Application manager**.
2. Touch the **All** tab, scroll through the apps list, and touch the app to open a screen with details about the App.

## More Application Information

For more information, refer to “*Applications*” on page 87.

In the Applications section, each application that is available on the Applications screen is listed and described. If the application is also described in another section of this user manual, then a cross reference to that particular section is provided. Various widgets are also described.

## Memory Card

Your device supports removable microSD, microSDHC and microSDXC memory cards for storing music, photos, videos, and files.

### Installing and Removing a Memory Card

For more information about installing and removing a memory card, see “*Memory Card*” on page 6.

---



**Important!** To prevent damage to information stored on the memory card, always unmount the card before removing it from the device.

---

### Formatting a Memory Card

Formatting erases all content from the memory card and prepares it for use with your device.

#### Formatting a Memory Card Using Your Device

1. From a Home screen, touch  **Apps** →  **Settings**  
→ **Storage**.

2. After mounting the SD card, touch **Format SD card**.
3. Follow the prompts to confirm the formatting of the card.

#### Formatting a Memory Card Using Your Computer

Consult your computer and/or memory card reader documentation for information about formatting memory cards.

## Section 3: Contacts and Accounts

---

This section explains how to manage contacts and accounts.



### Accounts

Your device can synchronize with a variety of accounts. With synchronization, information on your device is updated with any information that changes in your accounts.

- **Samsung account:** Add your Samsung account.
- **ChatON:** Add your ChatON account. For more information, refer to “*ChatON*” on page 55.
- **Dropbox:** Add your Dropbox account. For more information, refer to “*Dropbox*” on page 95.
- **Email:** Add an Email account to sync Contacts. For more information, refer to “*Email*” on page 48.
- **Facebook:** Add your Facebook account to sync Contacts.
- **Google:** Add your Google account to sync your Contacts, Calendar, and Gmail. For more information, refer to “*Gmail*” on page 45.
- **LDAP:** Add an LDAP account to find entries in an LDAP directory server.
- **Microsoft Exchange ActiveSync:** Add your Exchange account to sync Contacts, Calendar, and Email.

### Setting Up Your Accounts

Set up and manage your synchronized accounts with the **Accounts** setting.



1. From a Home screen, touch  **Apps** →  **Settings** → **Add account**.
2. Touch the account type.
3. Follow the prompts to enter your account credentials to complete the set-up process.

Your tablet communicates with the appropriate account servers to set up your account. When complete, your account displays in the **Accounts** area of the Settings screen.





## Contacts





Store contact information for your friends, family, and colleagues to quickly access information or to send a message.

To access Contacts:

- From a Home screen, touch  **Apps**  
→  **Contacts**.

## Creating Contacts

1. From a Home screen, touch  **Apps**  
→  **Contacts** → .  
The **Save contact** pop-up displays.
2. Touch **Device**, **SIM**, or an account that you have already set up.
3. Touch the Contact photo to set up a photo to identify the contact.
4. Touch contact fields to display the keyboard and enter information:
  - Some fields have preset values. Touch the field and touch the desired value. For example, touch the  Label tab and touch a label for the field.

- Other fields have to be input. Touch the field and use the on-screen keyboard to input information.
  - Touching the check box next to some fields may make additional fields available.
  - Touch  to add additional fields. Touch  to remove an unused field. Also, touch **Add another field** to add other fields.
  - Touch the screen and swipe up or down to display additional fields or touch **Next** on the keyboard to move to the next field.
5. Touch **Done** to remove the keyboard.
  6. When you finish entering information, touch  **Save**.  
– or –  
Touch  **Cancel** to cancel and discard changes.



---

**Tip:** Display a contact's record and touch the **Email** field to send an email, the **Address** field to display the address on a map, or the **Website** field to link to the website.


---

## Updating Contacts

To update an existing contact:




1. From a Home screen, touch  **Apps**  
→  **Contacts**.



2. Touch a contact in the Contacts list to view its information.
3. Touch  **Edit**.
4. Continue entering contact information. For more information, refer to “*Creating Contacts*” on page 32.




## Deleting Contacts

To delete a contact:

1. From a Home screen, touch  **Apps**  
→  **Contacts**.
2. Touch a contact in the **Contacts** list to view its information, and then touch  **Delete**. At the prompt, touch **OK**.





## Managing Photo IDs

To remove or update a contact’s Photo ID:

1. From a Home screen, touch  **Apps**  
→  **Contacts**.
2. Touch  **Edit**.
3. Touch the Contact photo, then touch **Remove, Image, Take picture, S Note, Pictures by people**.

## Contacts Display Options

There are various ways to display your Contacts and general Contacts settings.




1. From a Home screen, touch  **Apps**  
→  **Contacts**.
2. Touch **Groups, Favourites, or Contacts**, above the Contacts List, to view contacts various ways:
  - **Groups**: Displays the possible Groups, such as Co-workers, Family, Friends, or groups you have created. The number of contacts in the group is displayed next to the group name. Touch a group name to show only contacts in that group. For more information, refer to “*Creating a New Group*” on page 35.
  - **Favourites**: Show only your favourite, or starred, contacts. For more information, refer to “*Favourites*” on page 37.
  - **Contacts**: Show all your contacts. Touch the **Search** field and enter a keyword to list contacts that contain that keyword.
3. From the **Groups, Favourites, or Contacts** list, touch  **Menu** to display the options for each grouping.
4. From the **Contacts** list, touch  **Menu** → **Settings** to display and manage Contacts settings.

## Linked Contacts

Your device can synchronize with multiple accounts, including Google, Corporate Exchange, and other email providers. When you synchronize contacts from these accounts with your device, you may have multiple contacts for one person.

Linking, or joining, imported contact records allows you to see all the contact's numbers and addresses together in one contact entry. Linking also helps you keep your contacts updated, because any changes that your contacts make to their information in the respective accounts is automatically updated the next time you synchronize with the account.





## Joining Contacts

1. From a Home screen, touch  **Apps**  
→  **Contacts**.
2. Touch a contact in the **Contacts** list to view its information.
3. Touch  **Menu** → **Join contact**.
4. Touch the contact you want to Join.

The joined contact's information is displayed with the original contact's information.

5. Repeat Steps 3 and 4 to join other contacts.

## Separating Contacts

1. From a Home screen, touch  **Apps**  
→  **Contacts**.
2. Touch a contact in the **Contacts** list to view its information.
3. Touch  **Menu** → **Separate contact**.  
A list of Joined contacts displays.
4. Touch  → **OK** to separate a joined contact.  
The contact is removed from the list.




## Sharing Contact Information

You can send a contact's information by way of Bluetooth to other Bluetooth devices or in an Email or Gmail as an attachment.

---

**Note:** Not all Bluetooth devices accept contacts and not all devices support transfers of multiple contacts. Check the target device's documentation.

---

1. From a Home screen, touch  **Apps**  
→  **Contacts**.
2. Touch  **Menu** → **Share namecard via**.

---

**Tip:** Set up a contact record for yourself to share your information with others.

---

1. At the prompt, choose a sending method such as Bluetooth.
4. Follow the prompts to send the contact information.

### Importing and Exporting Contacts

To back up and restore your contacts information, you can export your contacts list to a storage device, such as a PC, or import your contacts list (previously exported) from a storage device.




1. Use the USB cable to connect your device to the storage device.
2. From a Home screen, touch  **Apps** →  **Contacts**.
3. Touch  **Menu** → **Import/Export**.  
The Import/Export contacts pop-up displays.
4. Touch an option and then follow the prompts to complete the operation.

## Groups

Assign contacts to Groups to make searching for contacts faster or to quickly send messages to group members.

### Creating a New Group

Create a new group when you add or edit a contact.

1. From a Home screen, touch  **Apps** →  **Contacts**.
2. Touch **Groups** then touch .
3. Touch the **Group name** field and use the keyboard to enter a new Group name.
4. Touch the **Add member** and place a  **Done** next to the contacts to be assigned to this group.
5. Touch  **Save** to save the new group name.

---





**Tip:** Contacts can belong to more than one group. Just touch the contact's **Groups** field and touch each group.

---

Once you create a new group, the Contacts List can be set to display only the contacts in that group. For more information, refer to “*Contacts Display Options*” on page 33.




## Renaming a Group


To rename a group that you created:

1. From a Home screen, touch  **Apps**  
→  **Contacts**.
2. Touch **Groups** and then touch the group you want to rename.
3. Touch  **Menu** → **Edit**.
4. Touch the **Group name** field and use the keyboard to enter a new Group name.
5. Touch  to save the new group name.

## Deleting Groups

To delete a group that you created:





1. From a Home screen, touch  **Apps**  
→  **Contacts**.
2. Touch **Groups** and then touch any group you want to delete.
3. Touch  **Menu** → **Delete groups**.  
The groups that can be deleted display.

4. Touch **Select all** or the name of each group to delete.
5. Touch  **Delete** to delete the groups. Choose from **Group only** or **Group and group members**.

## Adding Group Members





To add a contact to a group, just Edit a contact's Group field. For more information, refer to "Updating Contacts" on page 32.

To add multiple contacts to a group:

1. From a Home screen, touch  **Apps**  
→  **Contacts**.
2. Touch **Groups** and then touch the group to which you want to add members.
3. Touch  **Menu** → **Add member**.  
The contacts that can be added display.
4. Touch **Select all** or the name of each contact to add.
5. Touch  **Done** to add the contacts to the group.

## Removing Group Members

To remove contacts from a group:

1. From a Home screen, touch  **Apps**  
→  **Contacts**.
2. Touch **Groups** and then touch the group from which you want to remove members.
3. Touch  **Menu** → **Remove member**.
4. Touch **Select all** or the name of each contact to remove.
5. Touch  **Done** to remove the contacts.



Contacts are removed from the group and the group name is removed from each contact's **Group** field.



## Favourites

Mark contact records with a  gold star to identify them as favourites.

### Adding Favourites

To add a contact to the Favourites list:

1. From a Home screen, touch  **Apps**  
→  **Contacts**.
2. Touch a contact to display it.

3. Touch the  **Star** next to the contact name so that it turns gold .



---

**Tip:** You do not have to edit the contact to change the Starred status.

---





### Accessing Favourites

To view your favourites list:





1. From a Home screen, touch  **Apps**  
→  **Contacts**.
2. Touch **Favourites** above the Contacts List.  
Only your starred contacts display.

### Removing Favourites

To remove one or more contacts from your favourites list:

1. From a Home screen, touch  **Apps**  
→  **Contacts**.
2. Touch **Favourites** above the Contacts List.
3. Touch  **Menu** → **Remove from favourites**.
4. Touch **Select all** or the name of each contact to remove.
5. Touch  **Done** to remove the contacts.

To remove one contact from your favourites list:

1. From a Home screen, touch  **Apps**  
→  **Contacts**.
2. Touch a contact to display it.
3. Touch the  **Star** next to the contact's name so that it turns gray  to remove it from the Favourites list.

## Section 4: Entering Text

---

This section describes how to select the desired text input method when entering characters into your tablet. This section also describes the predictive text entry system that reduces the amount of key strokes associated with entering text.

Your tablet comes equipped with an orientation detector that can tell if the tablet is being held in an upright (Portrait) or sideways (Landscape) orientation. This is useful when entering text.

### Text Input Methods

There are three text input methods available:

- **Google Voice typing:** allows you to enter text by speaking.
- **Samsung keyboard (default):** Samsung's on-screen QWERTY keypad that can be used in portrait or landscape orientation.

You can set a default text entry method in Settings. For more information, refer to “*Keyboards and Input Methods*” on page 128.

To choose a text input method while entering text:

1. Open the Quick Settings panel and tap **Choose input method**.
2. Touch an input method to activate it.

### Using the Samsung Keyboard

The Samsung keyboard is a custom virtual QWERTY keyboard, featuring optional predictive text or continuous input. Input characters by touching the on-screen keys with your finger or use speech recognition.

You can enable predictive text, to have the Samsung keyboard match your key touches to common words and displays them. The Personalization option learns from Gmail, Facebook and Twitter. Log into these applications to enable the Samsung keyboard to learn from your text input.

### Keyboard Types


In addition to the default QWERTY keyboard, there are two other types of the Samsung keyboard: a **Floating** keyboard and a **Split** keyboard.

To change the keyboard type:

1. Use two fingers, such as your index finger and thumb, to make an inward pinch motion on the screen, where the keyboard is displayed.



A pop-up displays the three keyboard types.



2. Touch one of the keyboard types to display it.

The Split keyboard can be moved up and down and the Floating keyboard can be moved anywhere.


- Tap and hold with two fingers to move the Floating or Split keyboard.

## Configuring the Samsung Keyboard

You can configure the Samsung keyboard to your preferences. While entering text:

- Open the Quick Settings panel, tap **Choose input method** and then select **Set up input methods** in the pop-up.


– or –

Touch and hold  on the keyboard and then select from the pop-up menu.

The Samsung keyboard settings screen displays.

For more information, refer to “Samsung Keyboard Settings” on page 129.


## Entering Upper and Lower Case Letters


The default case is initial capital (Abc). Enter upper and lower case alphabet letters by touching the Shift key  to toggle the case, before touching the letter key(s).

- Touch once to switch from Abc to ABC mode. When ABC mode is enabled, the Shift key background turns blue.
- Touch twice to switch to abc mode.

## Entering Symbols and Numbers

The number keys are displayed at the top of the keyboard and are always available.

To enter common symbols, touch  to switch to symbol mode, then touch the corresponding key.

There are two pages of symbols. Touch  to switch to the next page.

Touch and hold a vowel key (A, E, I, O, U, or Y) or the C, N, or S key to open a small window where you can choose an accented vowel or other alternate letter. Slide to the letter until it is highlighted, and release.

Touch and hold the Period key ( . ) to open a small window with a set of common symbols.



## Using Predictive Text

By using Predictive text, you can have next-letter prediction and regional error correction, which compensates for pressing the wrong keys on the QWERTY keyboard.

---


**Note:** Enable Predictive text in Samsung keyboard settings. For more information, refer to “*Samsung Keyboard Settings*” on page 129.

---

While entering characters, potential word matches display in the Predictive text area above the keyboard.

- Touch a word to insert it into your text.

---

**Tip:** Touch  to display more words.

---

## Samsung Keyboard Settings

For information on how you can configure your Samsung keyboard settings, see “*Samsung Keyboard Settings*” on page 129.

## Using Google Voice Typing from the Samsung Keyboard

When you enable the Google voice typing setting, you can use your voice to enter text instead of the keyboard.


For more information about enabling Voice input, see “*Using Google Voice Typing*” on page 43

## Editing Text

You can edit the text you enter in text fields by cutting, copying, or pasting text. These operations can be performed within and across apps. However, some apps do not support editing some or all of the text displayed while others may offer their own way to select text.



## Editing Existing Text

To edit text that you have entered:

1. Touch the text at the point you want to edit.  
The **Cursor** displays at the point you touched.
2. Touch and drag the **Cursor** to a better position, if necessary.
3. Enter additional text or delete text by repeatedly touching the  **Delete** key.

## Copying, Deleting, or Replacing Text

To select and copy, delete, or replace text:

1. Touch and hold the text or word you want to select.  
The selected text is highlighted with a   tab at each end of the selection.

2. Touch and drag either tab to select more or less text.

---

**Tip:** Touch **Select all** in the Application bar to select all text in the field. Touch on another area of the screen or touch **Done** to deselect the text.

---

3. Depending on the action you want to take for the selected text, in the Application bar touch:
  - **Select all** to highlight all text in the field.
  - **Cut** to remove the selected text.
  - **Copy** to save the selected text to the clipboard.

– or –

Enter text by typing or speaking to replace the selection with what you type.


## Pasting Text

To paste previously copied text:

1. Touch the text at the point you want to paste the copied text.  
The **Cursor** displays at the point you touched.
2. Touch the **Cursor**.  
A pop-up displays.

3. Touch **Paste** in the pop-up.

To paste text directly from the clipboard:

1. Touch the  **Clipboard** key to display the text saved to the clipboard.
2. Touch a text block to paste that text where the **Cursor** is positioned.



## Closing the Keyboard

To close the keyboard:

- Touch  **Close Keyboard**.

## Using the Handwriting Feature




You can enter text simply by using your finger or the S Pen to handwrite letters on your screen.

1. From a screen where you can enter text, activate the keyboard by touching a text input field on the screen.
2. If necessary, open the Quick Settings panel, tap **Choose input method** and then touch **Samsung keyboard**.  
The Samsung keyboard displays.
3. Touch and hold  on the keyboard and then select  from the pop-up menu.  
The handwriting pad displays.

4. Use your finger tip or the S Pen to write out each character. You can print or use cursive.


As you write, suggestions are offered in the word options area in case the correct letters were not recognized.

## Handwriting Tips

- For uppercase letters, write the letter larger than the lowercase letters.
- Write a dash (horizontal line) to add a space.
- Delete letters by sweeping from right to left.
- To display numbers and symbols, touch  and then touch a number or symbol key. Touch the button marked 1/2 or 2/2 to see more symbols and emoticons. Touch  to exit the numbers and symbols keyboard.
- To return to the Samsung keyboard, touch .


## Handwriting Settings

To change the Handwriting settings:

1. Open the Quick Settings panel, tap **Choose input method** and then touch **Set up input methods**. The Language and input settings screen displays.
2. Touch  next to Samsung keyboard to display Samsung keyboard settings.

3. Touch **Handwriting**.

For more information, refer to “Samsung Keyboard Settings” on page 129.



4. Press  repeatedly to return to your message.

## Using Google Voice Typing

You can use your voice to enter text using the Google voice typing feature.


While entering text:

1. Open the Quick Settings panel, tap **Choose input method**. and then touch **Google voice typing**.  
– or –

Touch and hold  on the keyboard and then select  from the pop-up menu.

For more information, refer to “Keyboards and Input Methods” on page 128.

2. At the **Speak now** prompt, speak clearly and distinctly into the microphone.  
The software converts your voice to text, which is displayed in the message.
3. Keep speaking to add more text.

4. Touch  to display the Samsung keyboard.

## Section 5: Messaging

---

This section describes how to send and receive messages and other features associated with messaging.

### Types of Messages

Your device supports these types of messages:

- **Gmail:** Send and receive Gmail from your Google account.
- **Email:** Send and receive email from your email accounts, including Corporate Exchange mail.
- **Google Talk:** Chat with other Google Talk users.
- **Google Messenger:** Use Google Messenger to bring groups of friends together into a simple group conversation.
- **ChatON:** Use ChatON to send and receive instant messages from any device that has a mobile phone number.



### Gmail

Send and receive email with Gmail, Google's web-based email.

---

**Tip:** To set up your Google account on your device, use **Accounts** settings. For more information, refer to "Accounts" on page 133.


---

- From a Home screen, touch  **Apps** →  **Gmail**.





### Setting Up Your Gmail Account

If you did not set up a Google account during the initial configuration, the first time you launch Gmail, your device prompts you to set up your Google account.

---


**Note:** You can use more than one Google account on your device. To add another account, touch  **Menu** → **Settings** → **ADD ACCOUNT**.

---

1. From a Home screen, touch  **Apps** →  **Gmail**. The Add a Google Account screen displays.
2. Touch **Existing** to sign in to an existing account.
  - At the **Sign in** screen, use the on-screen keyboard to enter your Google **Email** name and **Password**, then touch  .
  - or –
  - Touch **New** to create a new account.
  - At the **Your name** screen, enter your first and last name, and touch  .




- At the **Choose username** follow the prompts to create a new account.

The Backup and restore screen displays.

3. Read the backup and restore information, touch the option to enable or disable it, and then touch .
4. The device communicates with the Google server to set up your account and synchronize your email. When complete, your Gmail displays in the Inbox.




## Refreshing Your Gmail Account

Refresh your account to update your device from the Gmail servers.

1. From a Home screen, touch  **Apps** →  **Gmail**.
2. Touch  **Menu** → **Refresh**.

## Managing Your Gmail Account








Use menu options to manage your Gmail account.


1. From a Home screen, touch  **Apps** →  **Gmail**.
2. Touch  **Menu** for these options:
  - **Refresh**: Update your device from the Gmail servers.
  - **Manage labels**: Determine settings for each label.

- **Settings**: Configure settings. For more information, refer to “Gmail Account Settings” on page 48.
- **Send Feedback**: Fill out a Google feedback form.
- **Help**: Learn about using Gmail.

## Managing Your Gmail Conversations

In addition to managing your Gmail account, there are options for changing the status of one or more Gmail conversations in an account.


1. From a Home screen, touch  **Apps** →  **Gmail**.
2. Touch the coloured box to the left of one or more conversations and then choose one of the following options:
  - **Archive**  : Archive the selected conversation. Archived conversations are moved to the Archive folder.
  - **Mark as Read**  / **Mark as Unread**  : Mark the conversations as read or unread. When a conversation is marked as read, the title text is no longer bold. Touch  **DONE** to remove the check marks.
  - **Move to**  : Move the conversation to a message folder.

- **Change labels** : Relocate the conversations to the **Inbox, Personal, Receipts, Travel,** or **Work** folder and then touch **OK**.

---






**Tip:** To move a conversation to another folder, touch and drag it to the folder tab.

---

3. Touch  **Menu** for these options:
  - **Delete:** Delete the conversations. Deleted conversations are moved to the Trash folder.
  - **Add star / Remove star:** Mark (or unmark) conversations with a yellow star. Starred conversations are listed in the Starred folder.
  - **Mark important / Mark not important:** Change the importance indicator . Yellow indicates important.
  - **Mute:** New messages added to muted conversations bypass your inbox so that the conversation stays archived in the All Mail folder.
  - **Report spam:** Report the conversations as spam, which are emails that violate the Gmail Program Policies and/or Terms of Use.

- **Report phishing:** Report the conversations as potential phishing to acquire information such as usernames, passwords and any other sensitive content.




## Composing and Sending Gmail

1. From a Home screen, touch  **Apps** →  **Gmail**.
2. Touch  **Compose**.
3. Touch the **To** field to enter recipients. As you enter names or email addresses, matching contacts display. Touch a contact to add it to the field.
4. Touch the **Subject** field to enter a subject.
5. Touch **Compose email** to enter the text of your email.
6. While composing a message, the following options are displayed:
  - **+ CC/BCC:** Create Cc (copy) and Bcc (blind copy) fields in the message. After creating the fields, touch to enter recipients.
  -  **Attach:** Launch Gallery to select a photo to add to the message.
7. Touch  **Menu** for the following options:
  - **Save draft:** Touch **Save draft** to save a draft of this message.
  - **Attach video:** Touch a video from your Gallery.

- **Discard:** Touch Discard to delete the message.
- **Settings:** Configure settings. For more information, refer to “Gmail Account Settings” on page 48.
- **Send feedback:** Fill out a Google feedback form.
- **Help:** Learn about using Gmail.

8. Touch **SEND** to send this message



## Gmail Account Settings

1. From a Home screen, touch  **Apps** →  **Gmail**.
2. Touch  **Menu** → **Settings** to access your gmail settings.

## Email

Use Email to view and manage all your email accounts in one application.

### Setting up Email Accounts

1. From a Home screen, touch  **Apps** →  **Email**.
2. At the **Set up email** screen, enter an **Email address** and **Password**, then touch **Next**.

3. Your account's incoming server settings are different depending on the kind of email service for the account. If you are asked **What type of account?**, touch the type of account: **POP3 account**, **IMAP account**, or **Microsoft Exchange ActiveSync**.
4. If you are setting up a Microsoft Exchange ActiveSync account, tap **Manual setup** at the top of your screen. The Server settings screen displays.
5. Enter the required settings and touch **Next**. The **Account options** screen is displayed.
6. Enter the desired information in the different fields, then tap **Next**.

---

**Note:** For Microsoft Exchange ActiveSync accounts, the **Activate device administrator?** screen may appear. Read the information and touch **Activate** to continue.


---

7. Enter an account name for the email account just added, which is displayed on the email screen, and enter Your name, if required.
8. Touch **Done**.



The device communicates with the appropriate server to set up your account and synchronize your email. When complete, your email appears in the Inbox for the account.



---

**Note:** To configure email account settings at any time, use  **Menu** → **Settings**. Touch the account to display Account settings.

---



## Adding Additional Email Accounts

To add additional email accounts:

1. From a Home screen, touch  **Email**.
2. Touch  **Menu** → **Settings** → **Add account**.
3. Enter the **Email address**, **Password**, and so on.

## Managing Your Email Accounts








You can view email you receive for all accounts in the **Combined view** screen or you can view email accounts individually.

1. From a Home screen, touch  **Email**.
2. Touch the  drop-down menu at the top left of the screen to select:
  - **Combined view:** View all email in a combined inbox.

- **Priority sender inbox:** Use this setting to assign an email account for all outgoing emails.
- **<Account Name>:** View email for the account.




## Managing Your Email Conversations

In addition to managing your Email account, there are options for changing the status of one or more Email conversations in an account.

1. From a Home screen, touch  **Email**.
2. Touch the box to the left of one or more conversations and then choose one of the following options:
  - **Star**  : Use to flag email as important or that you want to locate later.
  - **Mark as Read**  / **Mark as Unread**  : Mark the conversations as read or unread. Once a conversation is marked as read, it has a gray background.
  - **Move to**  : Relocate the conversations to another folder in the current email account or in a folder within another email account.
  - **Delete**  : Delete the conversations.
3. Touch  **Menu** for these options:

- **Sort by:** Choose a method for listing your email conversations.
- **View mode:** Choose how to view your email conversations. Choices are: Standard view and Conversations view.
- **Delete all:** Delete all items for this email account.
- **Font size:** Select the font size for your email. Choose from, Use device font sizes, Tiny, Small, Normal, Large, or Huge.
- **Settings:** Display the settings for this email account.

## Composing and Sending Email

1. From a Home screen, touch  **Email**.
2. Touch an account, if you have more than one account set up, then touch  **Compose**.
3. Enter the recipient's email address in the **To** field.
  - If you are sending the email message to several recipients, separate the email addresses with a comma. You can add as many message recipients as you want.
  - Touch  to add a contact to the field.
  - Touch **+Cc/Bcc** to add additional carbon copy recipients.
    - Use the **Cc** field to carbon copy additional recipients.
    - Use the **Bcc** field to blind copy additional recipients.
  - Touch **+Me** to add yourself as a recipient.

4. Touch the **Subject** field to enter a subject.
5. Touch the body of the email to enter the text of your email.
6. While composing a message, the following options may be displayed:



**Scheduling options:** Tap the Schedule sending box and then set the Time and date for which the email will be sent.



**Priority:** Set the email priority. Options are: High, Normal, or Low.



**Attach:** Choose an attachment to add to the message from the listed apps, such as My Files, Images, Take picture, Video, Record video, Audio, SNote, Calendar, Contacts, and Location.



**Text mode:** Enter text.



**Drawing mode:** Draw in the message using drawing tools.



**Undo:** Erase the previous input.



**Redo:** Restore the previously erased input.



**Insert:** Choose an item to insert into the message from the listed apps, such as Images, S Note, Calendar, Contacts, and Location.



**Insert quick response:** Insert text that you frequently use in emails.



**Font size:** Choose a text font size of 9, 10, 12, 14, 17, 21, 24, 28, or 36 points.



**Bold:** Bold the following text. Touch again to turn off bold.



**Italics:** This action italicizes the subsequent entered text.



**Font color:** Set the color of the text font. The bar changes to the selected color.






**Background color:** Set the color of the background of the email.



**Pen settings:** Select a drawing pen and colour.





**Eraser:** Erase drawn content, set the eraser size.

7. Touch  **Save** to save the email to the Drafts folder,  **Send** to send the email, or  **Discard** to delete the email.

## Email Settings

Account settings lets you configure handling of email on your device.

1. From a Home screen, touch  **Email**.
2. Touch  **Menu** → **Settings** to modify your email settings.

## Google Talk



Talk is Google's instant messaging and audio and video chat service. You can use it to communicate, in real time, with other people who also use Google Talk on another Android tablet or phone or on a computer.

---

**Tip:** Talk requires that you have a Google account. To set up your Google account on your device use **Accounts** settings. For more information, refer to “Accounts” on page 133.

---

## Open Talk and Sign In

1. From a Home screen, touch  **Apps** →  **Talk**.  
If you are not signed in to a Google account, the Add a Google Account screen displays.
2. Touch **Existing**, if you already have a Google account, or **New** to create a Google account.  
For more information, refer to “*Setting Up Your Gmail Account*” on page 45.

---


**Note:** If you have already set up your Google account, you are automatically logged in. Just touch the account.

---

Once sign in is complete, the Talk main screen displays.


## Invite a Friend to Chat

You can invite anyone with a Google Account to become your friend in Google Talk, so you can chat with each other and view each other’s online status.

1. While viewing your Friends list, touch  **Add friend**.
2. Enter your friend’s Email address and touch **DONE**.  
Your friend’s address in Talk is a Gmail or other email address that is configured to connect to Google Talk.

If your friend accepts your invitation, they are added to your Friends list in Talk and you can share each others status in Talk and other applications.

## View and Accept an Invitation to Become a Friend






When a contact invites you to become a friend in Google Talk, you receive a  notification in the System Bar and the invitation displays in your Friends list.

1. Touch the invitation.
2. Touch **Accept**, if you want to accept the invitation and chat, **Decline**, if you do not want to chat with and share your Google Talk status with the sender right now, or **Block**, if you do not want to receive any more invitations from that person.

If you touch **Accept**, the friend is added to your Friends list in Talk and you can share your status in Talk and other applications.


## Options While Chatting

There are several options that are available while you are chatting.

1. Touch  to search your chats for a word,  to invite another friend to chat,  to invite this friend to video chat, or  to invite this friend to voice chat.
2. Touch  **Menu** to display the following options, which are available while chatting. For more information, refer to “*Additional Talk Options*” on page 53.
  - **End chat:** End this chat session.
  - **Go off the record/Stop chatting off the record:** Set whether you want to stop saving your chat to the chat history.
  - **Friend info:** Display information about the friend with which you are chatting. The following options are also displayed:
    - **Block:** Keeps this person from sending you messages and removes the person from your Friends list.
    - **Remove:** Remove the friend as if you never accepted their invitation. However, the friend is not blocked.
  - **Add to chat:** Choose another friend to invite to this conversation.
  - **Clear chat history:** Remove the history of this chat from your device.
  - **Settings:** Offers various settings for Google talk. For more information, refer to “*Google Talk Settings*” on page 54.




- **Help:** Displays additional help information.
- **Send feedback:** Fill out a Google feedback form.

---

**Note:** If you touch the **REMOVE** option, touch  **Add friend** → **Send chat invitation to**, to make the Friend visible again.

---




### **Additional Talk Options**

1. While viewing your Friends list, touch  to search your Talk messages. Use the on-screen keyboard to enter a search term. Touch  on the keyboard to search your Talk messages.
2. Touch  **Menu** to display the following options:
  - **Display options:** To set the way your friends list is sorted, touch **Availability**, **Name**, or **Recency**.
  - **End all chats:** End all chats in which you are engaged.
  - **Sign out:** Sign out of Google Talk and display the Talk main screen.
  - **Settings:** Offers various settings for Google talk. For more information, refer to “*Google Talk Settings*” on page 54.
  - **Help:** Displays additional help information.
  - **Send feedback:** Fill out a Google feedback form.

3. Touch a Friend's entry to display the Chat entries for that Friend.

## Google Talk Settings

Use Google Talk Settings to configure your Talk account. If you have more than one account, each maintains its own Talk settings.

1. From a Home screen, touch  **Apps** →  **Talk**.
2. Touch  **Menu** → **Settings**, then touch an account for options:

### GENERAL

- **Mobile indicator:** Check and your friends see an outline of an android next to your name in their Friends list when you are signed into Google Talk on a tablet or phone.
- **Away when screen off:** Check to change your Talk status to Away when your screen turns off. When unchecked, your status is not changed.
- **Invitation notifications:** Show notification when a friend invitation arrives.

### CHAT NOTIFICATIONS

- **IM notifications:** Set whether to open a dialog, display a notification in the System Bar, or neither, when you receive a text chat.
- **Notification ringtone:** Set a ringtone to sound, or silent, when you receive a text chat.
- **Vibrate:** Set how vibrate functions. Choices are: Always, Only when silent, or Never.

### VOICE & VIDEO CHAT

- **Video chat notifications:** Set whether to open a dialog or display a notification in the System Bar when you are invited to a video chat.
- **Video chat ringtone:** Set a ringtone to sound, or silent, when you receive an invitation to a video chat.
- **Vibrate:** Set the device to vibrate Always, Only when silent, or Never.
- **Default video effect:** Set the video image stabilization.

### ACCOUNT

- **Blocked friends:** Displays a list of friends you have blocked. Touch a blocked friend and then touch OK to unblock the friend.

- **Clear search history:** Erases your search history. No previous searches are shown until you search for new words.
- **Manage account:** Opens the Accounts and sync settings. For more information, refer to “Accounts” on page 133.

## ABOUT



- **Terms & privacy:** Displays the Google Talk terms of use and privacy policies.


## Google+

Share updates and see what is going on around you with Google+ for mobile.

- Share your thoughts and location.
- Instantly upload your photos and videos as you take them.
- Get updates from your circles in the stream.
- Check in to a place.
- Make plans on-the-go with group messaging.
- View posts from people around you.

To get started:




1. From a Home screen, touch  **Apps**  
→  **Google+.**  
The Google+ home screen displays.

2. Touch  **Menu** → **Help** and then touch a topic to learn more about using Google+.

## Messenger

With Google Messenger, you can bring groups of friends together into a simple group conversation, putting everyone on the same page. When you get a new conversation in Messenger, Google+ sends an update to your device.



To get started, touch the Messenger icon on the home screen of the Google+ app or use the Messenger icon on your Applications screen.

1. From a Home screen, touch  **Apps**  
→  **Messenger.**  
The Messenger screen displays.
2. Touch  **Menu** → **Help** for more information on getting started.

## ChatON


Provides a global mobile communication service where you can chat with more than 2 buddies via a group chat. Share things such as pictures, videos, animation messages (Scribbles), audio, Contacts, Calendar entries, and Location information.

For more information, visit: <https://web.samsungchaton.com>.

1. From a Home screen, touch  **Apps** →  **ChatON**.
2. At the ChatON display, tap **Sign in** to sign in to your Samsung account if you have not already done so. For more information, refer to “*Creating a Samsung Account*” on page 5.

– or –

Tap **Skip** if you have already signed in to your Samsung account.

3. Enter your real name and tap  **OK**.
4. Follow the on-screen instructions to add a buddy and begin your chat session.



## Section 6: Music


---

This section explains how to use the music features of your device including the Music app and the Music Player, and the Music Hub.

### Listening to Music




You can listen to music by using your device's built-in speakers, through a wired headset, or through a wireless Bluetooth stereo headset.

For more information, refer to “Bluetooth” on page 82.

Press the **Volume Key**  on the side of the device to activate on-screen volume control, then touch and drag on the scale to set volume. You can also press the Volume Key to adjust playback volume.



### Google Play Music

With Google Play Music, you can play music that you have added to your music file as well as any music you copied from your PC. While offline, you can listen to music you have copied from your PC.


1. From the Home screen, tap  → **Play Music** . All music on your device and external SD card is displayed, including Music folders that may contain multiple songs.
2. Tap a song to start playback.
3. From the main Play Music screen, you can tap any of the following tabs for a more detailed listing of songs: Playlists, Recent, Artists, Albums, Songs, and Genres.
4. Tap  **Menu** for the following options:
  - **Settings**: allows you to view Open source licenses and the music version for the Play Music application.
  - **Help**: allows you to view a help file on the Google Support website.

## Music Player

Music Player plays songs stored on your tablet or an installed memory card.



1. From a Home screen, touch  **Apps**  
→  **Music Player.**


The Music Player application searches your device's internal storage or on an installed memory card for music and playlists. This can take from a few seconds to several minutes, depending on the amount of new music added since you last opened the application. It then displays your music in several ways.

2. Touch a tab, such as **Songs**, **Playlists**, **Albums**, and so on, to change the way you view the contents of your library.
3. Touch the Music application icon  at the top-left of the Application bar to return to the previous Music screen.

## Searching for Music




To find music in your library:

1. From a Home screen, touch  **Apps**  
→  **Music Player.**

2. Touch  **Search** and use the keyboard to type the name of an artist, album, or song.


## Music Player Options and Settings

To use Music Player options and configure settings:

1. From a Home screen, touch  **Apps**  
→  **Music Player.**
2. Touch  **Menu** to display the following options:
  - **Delete:** Delete a song, an album, or every song or album.
  - **Share via:** Share your music. Select the songs you want to share, touch **Share**, touch an option, such as Bluetooth, and follow the on-screen instructions.
  - **Set as alarm tone:** Choose a song and touch **Set** to use the song as an alarm tone.
  - **Scan for nearby devices:** Search for DLNA -compliant devices used to send or receive streaming media.
  - **Settings:** The following settings display:  
**Advanced**
    - **Sound settings:** Choose **SoundAlive** and **Play speed** settings.
    - **Lyrics:** Display the lyrics of the song, if available.



- **Music auto off:** Set the option Off or set your music to turn off automatically by touching one of the time values.

#### Music menu


- **Music menu:** Enable or disable the music display options that appear on the main music screen. A check mark  next to an option means that it is enabled.
- **End:** This option returns you to the home screen.

## Managing Playlists


To create, manage, or delete a playlist:

- From a Home screen, touch  **Apps**  
→  **Music Player**.

### Creating a Playlist

- Touch  **Add to playlist** → **Create playlist** and use the keyboard to enter a name for the playlist.



### Renaming a Playlist

1. Touch the **Playlists** tab.
2. Touch a playlist, touch  **Menu** → **Rename playlist** and use the keyboard to enter a new name for the playlist.


### Adding Songs to Playlists

1. Touch  **Add to playlist** and touch a playlist.



– or –

Touch **Playlists**, touch a playlist, and then touch  **Add music** or  **Menu** → **Add music** in portrait mode.




All songs are displayed.

2. Touch  next to each song you want to add or next to **Add all** to add all songs to the playlist.
3. Touch **Done** to save the playlist.

### Removing Songs from Playlists

1. Touch  **Add to playlist** and touch a playlist.
2. Touch  to remove a song from the playlist.
3. Touch **Done** to save the playlist.


### Changing the Order of a Playlist

1. Touch the **Playlists** tab and touch a playlist.
2. Touch  **Change order** or  **Menu** → **Change order** in portrait mode.
3. Touch the grid  for an entry and drag the entry to a new position in the list.
4. Touch **Done** to change the order and save the playlist.

## Playing a Playlist



1. Touch the **Playlists** tab.
2. Touch **Favourites**, **Most played**, or **Recently added**, or touch a playlist title that you created.
3. Touch a song to start playing the playlist at that song.

## Deleting a Playlist


1. Touch the **Playlists** tab and touch a playlist.
2. Touch  **Delete** in the Application bar.
3. Touch the box next to a playlist title, touch **Remove**, and then touch **OK**.

## Playing Music

To play a song:

1. From a Home screen, touch  **Apps**  
→  **Music Player**.
2. Touch a song or touch an album or genre and then touch a song in the list of songs on the album.  
The song you touch starts to play. The tracks in the current list play in order until you reach the end of the list (unless you choose a repeat option). Otherwise, playback stops only if you stop it, even when you switch applications.

## Accessing the Music Player



If you navigate away from the Music Player application and music is playing, the Music notification icon  is displayed in the System Bar.


You can change songs or easily return to the Music Player:

1. Touch the System Bar and drag down to open the Quick Settings panel.
2. Touch the album image to display the Music Player. You can also pause and resume playback and skip to the next or previous song in the panel. For more information, refer to “Notifications” on page 17.

## Music Player Controls







When a song is playing, the Music Player screen displays and various controls are available.

1. From a Home screen, touch  **Apps**  
→  **Music Player**.
2. Touch a song or playlist to begin playback.  
The music player displays below (portrait mode) or to the right (landscape mode) of the music listing.
3. Touch the music player to enlarge it and touch the screen to display the sound and playlist controls.






4. During playback, use the sound and playlist controls:

- **Favourite:** Touch the star ★ to mark the current song as a favourite.

- **Volume:** Touch to toggle Silent and Sound mode, then touch and drag on the scale to set volume. You can also press the Volume Key on the side of the device to adjust playback volume.
- **SoundAlive:** Touch to view and set SoundAlive options.
- **Info:** Touch to view information about the current song.
- **List Mode:** Touch to switch to the list of songs.
- **Shuffle:** When enabled, songs play in random order. When disabled, songs play in the order they appear in List view.
- **Progress Bar:** Touch and drag the end of the progress bar to scan forward or backward through the current song.
- **Playback Controls:** These buttons control the playback of songs:
  - Touch  to advance to the next song. Touch and hold  to scan forward through the current song.
  - Touch  to go back to the previous song. Touch and hold  to scan backward through the current song.
  - Touch  to pause playback. Touch  to resume playback.
- **Repeat:** Touch to repeat the current song, repeat all songs, or disable repeat mode.

## Options While Playing a Song

There are various options and controls available while a song is playing:

1. From a Home screen, touch  **Apps**  
→  **Music Player**, touch a song or an album, and then a song.
2. Touch the music player to enlarge it.
3. Touch  **Menu** to display the following options:
  - **Add to playlist:** Add the song to a new playlist or an existing playlist.
  - **Via Bluetooth:** Play the current song by using a Bluetooth device.
  - **Share via:** Share your music. Touch an option, such as Bluetooth, select the songs you want to share, and touch **Share**.
  - **Set as alarm tone:** Use the current song as an alarm tone.
  - **Scan for nearby devices:** Discover and connect directly to nearby devices.
  - **Settings:** Displays Music Player settings. For more information, refer to “*Music Player Options and Settings*” on page 58.

- **End:** This option returns you to the home screen.



## Section 7: Photos and Video

---

This section explains how to use your device's built-in camera and camcorder as well as the Image Viewer and Gallery to view and manage photos and videos.

### Camera


Use your device's built-in camera and camcorder to take photos and record videos.

1. From a Home screen, touch  **Apps** →  **Camera**.
2. If a memory card is inserted, the first time you open the camera the Storage location pop-up displays. Touch **OK** to change the storage location to memory card or touch **Cancel** to use the device storage for storing pictures and videos.

---



**Note:** If memory card storage is used, photos are stored in the / storage/sdcard0/DCIM/Camera folder as jpg files. For more information, refer to “My Files” on page 100.

---




### Taking Photos

To take a photo:

1. From a Home screen, touch  **Apps** →  **Camera**.
2. Using the display as a viewfinder, compose your photo by aiming the lens at the subject.

Use the Up and Down volume keys or Pinch the screen to zoom in or out.

To configure settings, see “*Camera Settings*” on page 64.

3. To take the photo, touch the **Camera** button.
4. Touch  **Back** to leave the Camera and display the previous screen.

---

**Important!** Do not take photos of people without their permission.  
Do not take photos in places where cameras are not allowed.  
Do not take photos in places where you may interfere with another person’s privacy.

---

## Camera Settings

While taking photos, use the camera settings to configure the camera for best results. Camera settings are represented by icons on the left or top of the screen.

### Editing Camera Settings Shortcuts

The first five icons are actually shortcuts to camera settings. These five shortcuts can be customized to fit your preference.



**Self-portrait**,



**Shooting mode**,



**Timer**




**Effects**, and



**Exposure value** are default settings shortcuts.


To customize these shortcuts:

1. Touch  **Settings** → **Edit shortcuts**.  
– or –  
Touch and hold any of the shortcut icons to edit them.
2. Touch and hold a setting, then drag and drop it on one of the five settings shortcuts to the left. The replaced setting shortcut displays in the edit list.



## Configuring Camera Settings

To configure Camera settings:

- While in Camera mode, touch a settings shortcut or touch  **Settings** to configure the following camera settings:
  - **Edit shortcuts:** Customize your settings shortcuts. For more information, refer to “*Editing Camera Settings Shortcuts*” on page 64.
  - **Use the volume key as:** Press the volume key to zoom in or zoom out, or to capture the picture.
  - **GPS tag:** Touch to switch the GPS tag on or off.
  - **Self portrait:** Touch to switch to the front-facing camera lens and take a photo of yourself.

---

**Warning!** If the battery is low, the flash is not available. For more information, refer to “*Charging the Battery*” on page 2.

---

- **Shooting mode:** Choose an automatic shooting mode, from:
  - **Single shot:** Take a single photo.

- **Panorama:** Touch the Camera button to take a photo, then use the on-screen guideline to move the viewfinder and take up to 13 shots automatically.
- **Share shot:** Share photos with other users via Wi-Fi Direct. A Wi-Fi Direct connection is required.
- **Buddy photo share:** Take and share photos with friends via face detection.
- **Smile shot:** Touch the Camera button to automatically focus on the subject’s face and take the photo.
- **Cartoon:** Take a photo with cartoon effects.
- **Effects:** Apply an effect to photos.
- **Scene mode:** Choose a mode to match the kind of pictures you want to take.
- **Exposure value:** Use the slider to set the exposure value from -2.0 to +2.0.
- **Focus mode:** Set the focus mode to Auto focus or Macro.
- **Timer:** Set a delay time to wait between touching the Camera button and taking a photo.
- **Resolution:** Choose a size for the photo.
- **White balance:** Set the light source.

- **ISO:** This value determines how sensitive the light meter is on your digital camera. Use a lower ISO number to make your camera less sensitive to light, a higher ISO number to take photos with less light, or Auto to let the camera automatically adjust the ISO for each of your shots.
- **Metering:** Select a method for measuring light.
- **Outdoor visibility:** When taking outdoor shots in bright settings, enabling Outdoor visibility increases the brightness of your screen to make it easier to see what you are shooting.

---

**Note:** What you see on screen will not correspond to the luminance of the actual photograph taken.



---




- **Guidelines:** Enable or disable an on-screen grid to aid in photo composition.
- **Contextual filenames:** Enable or disable a system generated filename.
- **Taking photos using voice:** Enable or disable an voice command to take a photo.
- **Save as flipped:** Set self-portrait mode and set this option to **On** to take and save a mirror-image photo.
- **Image quality:** Choose a quality setting for photos.

- **Storage:** Set whether to store you photos on your device or on your memory card, if one is installed.
- **Reset:** Set all Camera settings to the defaults.

## Viewing Photos with the Image Viewer

After taking a photo, use the Image Viewer to view, share, delete, or edit photos.


1. Touch **Image Viewer** to view the photo.
2. Touch the screen to show or hide Image Viewer options.
3. Touch the screen with two fingers or double-tap on the screen to zoom all the way in or out. For more information, refer to “Pinch” on page 14.
4. Sweep across the screen to display the next or previous photo. The current photo is outlined in the thumbnails at the bottom of the screen. Touch a thumbnail to view the photo it represents.
5. To set the photo as a favourite, touch  **Favourites**.
6. Touch  **Share** to share the photo. Touch an option, such as Bluetooth, and follow the on-screen instructions. After using this option, the most recent Share option is displayed in the Application Bar.

- To delete the photo being displayed, touch  **Delete** and then touch **Delete** to delete the photo or **Cancel** to exit.
- Touch  **Slideshow** to display a slide show of the available pictures and videos.
- Touch  **Menu** to select **Set as** to assign the photo as a Contact photo or a Home screen, Lock screen, or Home and lock screens wallpaper.  
For more information, refer to “*Viewing Photos and Videos*” on page 73.

---





**Note:** Photos are stored as .jpg files in the device in the /storage/sdcard0/DCIM/Camera folder or in a storage card at /storage/extSdCard/DCIM/Camera. For more information, refer to “*My Files*” on page 100.

---


- Press  **Back** to return to the Camera to take more photos.

## Camcorder









Use your device's built-in Camcorder to record high-definition video in 1080p resolution.

- From a Home screen, touch  **Apps** →  **Camera**.
- Slide the  **Mode** button to the  **Camcorder** setting.

The Camcorder screen displays.



## Recording Videos

1. From a Home screen, touch  **Apps** →  **Camera**.
2. Slide the  **Mode** button to the  **Camcorder** setting.
3. Using the display as a viewfinder, compose your shot by aiming the lens at the subject.  
To configure settings, see “*Camcorder Settings*” on page 68.
4. To start recording, touch  **Record**.  
During recording, the **Record** button flashes.
5. To pause recording, touch  **Pause**.
6. To stop recording, touch  **Stop**.
7. Touch  **Back** to leave the Camcorder and display the previous screen.

---

**Important!** Do not take videos of people without their permission.  
Do not take videos in places where cameras are not allowed.  
Do not take videos in places where you may interfere with another person’s privacy.






---

## Camcorder Settings

While taking videos, use the camcorder settings to configure the camcorder for best results. Camcorder settings are represented by icons on the left side of the screen.

### Editing Camcorder Settings Shortcuts


As with the camera, the first five icons are actually shortcuts to camcorder settings. These five shortcuts can be customized to fit your preference.

 **Self-recording**,  **Recording mode**,  **Timer**,  **Effects**, and  **Exposure value** are default settings shortcuts.

To customize these shortcuts, see “*Editing Camera Settings Shortcuts*” on page 64.

### Configuring Camcorder Settings

To configure Camcorder settings:

- While in Camcorder mode, touch a settings shortcut or touch  **Settings** to configure the following Camcorder settings:
  - **Edit shortcuts:** Customize your settings shortcuts. For more information, refer to “*Editing Camera Settings Shortcuts*” on page 64.

- **Use the volume key as:** Press the volume key to zoom in or zoom out.
- **GPS tag:** Touch to switch the GPS tag on or off.
- **Self recording:** Touch to switch to the front-facing camera lens and record a video of yourself.
- **Recording mode:** Set a recording mode. Options are: Normal, Limit for MMS and Limit for email, which limits the size of the video to 50 megabytes.
- **Effects:** Apply an effect to videos.
- **Exposure value:** Use the slider to set the exposure value from -2.0 to +2.0.
- **Timer:** Set a delay to wait between touching Record and starting recording.
- **Resolution:** Set a size for the video.
- **White balance:** Set the light source.
- **Outdoor visibility:** When recording outdoors in bright settings, enabling Outdoor visibility increases the brightness of your screen to make it easier to see what you are recording.

---

**Note:** What you see on screen will not correspond to the luminance of the actual video taken.





---

- **Guidelines:** Enable or disable an on-screen grid to aid in video composition.
- **Contextual filename:** Enter the file with an applicable name.
- **Save as flipped:** Set self-recording mode and set this option to **On** to take and save a mirror-image video.
- **Video quality:** Choose a quality setting for videos.
- **Storage:** Set whether to store your videos on your device or on your memory card.
- **Reset:** Set all Camera settings to the defaults.

### **Viewing Videos with the Image Viewer**

After recording a video, use the Image Viewer to play, share, or delete your video.






1. Touch **Image Viewer** to view the video.
2. Touch the screen to show or hide Image Viewer options.
3. Sweep across the screen to display the next or previous video. The current video is outlined in the thumbnails at the bottom of the screen. Touch a thumbnail to view the video it represents.

4. To set the video as a favorite, touch  **Favorites**.
5. Touch  **Share** to share the video. Touch an option, such as Bluetooth, and follow the on-screen instructions. After using this option, the most recent Share option is displayed in the Application Bar.
6. Touch  **Slideshow** to display a slide show of the available pictures and videos.
7. To delete the video being displayed, touch  **Delete**.



---







**Note:** Videos are stored as .mp4 files in the device in the /storage/sdcard0/DCIM/Camera folder or in a storage card at /storage/extSdCard/DCIM/Camera. For more information, refer to “My Files” on page 100.

---

8. To play a video, touch  **Play**. Touch  **Pause** to pause the video and touch  **Resume** to resume playing the video.
9. Touch  **SoundAlive** to set the sound quality.
10. Touch and drag the  white dot on the progress bar to fast forward or rewind the video. Touch the left end of the progress bar to restart the video. Touch the right end of the progress bar to end the video playback.



– or –









Touch  **Rewind** to restart the video or  **Fast Forward** to end the video.

11. To change the screen size of the video, touch  **Full screen view** (the entire screen is used, which may cause some minor distortion),  **Original size view** or  **Full screen in ratio view** (the video is enlarged as much as possible without becoming distorted).
12. Touch  **Pop up play** to play a video as a small pop-up while viewing another screen. Touch and drag the pop-up video to the desired location on the screen. Double-tap the pop-up to return to full screen mode.
13. Touch the  **Bookmark** to mark this video.
14. Press  **Back** to return to the Camcorder.

## Video Player

Your device's 8.0-inch 1280x800 WXGA TFT (PLS) LCD screen provides playback of videos. Use Video Player to view and manage videos stored on your tablet.

1. From a Home screen, touch  **Apps** →  **Video Player**.
2. Touch the **Thumbnails**, **List**, or **Folders** tab.

3. Touch  **Search** and use the keyboard to enter a search term. The current folder is searched and results are displayed. Touch **X** to remove the search field.
4. While viewing the list, touch **Menu** for options:
  - **Go to Video Hub**: opens the Video Hub application.
  - **List by**: Display videos by Name (default), Date, Size, or Type.
  - **Share via**: Share the video. Touch an option, such as Bluetooth, and follow the on-screen instructions.
  - **Delete**: Touch videos to select them for deletion or touch **Select all** to delete all videos.
  - **Video editor**: Opens the video editor (not pre-installed on your device, must be downloaded and installed from Samsung Apps).
  - **Auto play next**: Touch to enable or disable automatic playing of videos in the order they appear.
  - **Scan for nearby devices**: scans for nearby DLNA-compliant devices that can receive or display videos.
5. Touch a video to play it. While playing a video, touch the screen to display or hide on-screen playback controls.
6. To change the screen size of the video, touch  **Full screen view** (the entire screen is used, which may cause some minor distortion),  **Original size view** or  **Full screen in ratio view** (the video is enlarged as much as possible without becoming distorted).
7. Touch  **SoundAlive** to set the sound quality.
8. Touch  **Pop up play** to play a video as a small pop-up while viewing another screen. Touch and drag the pop-up video to the desired location on the screen. Double-tap the pop-up to return to full screen mode.
9. While the video is playing, touch  **Bookmark** to mark your favorite areas of the video. A yellow mark displays on the progress bar.
10. During playback, press  **Menu** for options:
  - **Share via**: Share the video. Touch an option, such as Bluetooth, and follow the on-screen instructions.
  - **Chapter preview**: If chapter information is recorded in the video file, display the chapters. Touch a chapter to begin playing the video at that point.
  - **Edit**: Touch Trim or Video editor (download from Samsung Apps).

- **Tag buddy:** Assign a name to a person in a photo.
- **Add weather tag:** Choose from Sunny day, Cloudy day, Rainy day, Snowy day, or Clear night.
- **Via Bluetooth:** Turn Bluetooth on to use Bluetooth services.
- **Video auto off:** Set the automated stop for the playing video. Choose from **Off**, **After playing**, **After 15 mins**, **After 30 mins**, **After 1 hour**, **After 1 hour 30 mins**, and **After 2 hours**.
- **Scan for nearby devices:** scans for nearby DLNA-compliant devices that can receive or display the current video.
- **Settings:** Touch this option to view the following:
  - **Play speed:** Touch and drag the slider to decrease or increase play speed.
  - **Subtitles:** View subtitles for the video, if available.
  - **Auto play next:** automatically play the following videos in the play sequence.
  - **Capture:** Turn On or Off the Capture mode.
  - **Colour tone:** Set the colour tone to Normal, Warm, or Cold.
  - **Outdoor visibility:** Turn outdoor visibility On or Off.
- **Details:** Provides details about the video, such as Name, Size, Resolution, and so on.

For more information, refer to “*Playing Videos*” on page 75.

## Gallery





Use Gallery to view, capture, and manage photos and videos.

---

**Note:** Photos and videos are stored as .jpg and .mp4 files in the device in the /storage/sdcard0/DCIM/Camera folder or in a storage card at /storage/extSdCard/DCIM/Camera. For more information, refer to “*My Files*” on page 100.

---




### Selecting Photos and Videos to View




1. From a Home screen, touch  **Apps** →  **Gallery**. All albums display.
2. Choose items to display by making selections from the menus in the Application bar: **Albums**, **Time**, **Locations**, **Person**, **Group**, or **Favourites**.
3. To launch the Camera app, touch  **Camera**.
4. Touch the icon next to Camera to change the way your albums are displayed (**Grid**, **Timeline**, or **Spiral**).
5. Touch  **Menu** to display the following options:
  - **Slideshow:** View a slideshow of the available pictures and videos.
  - **Tag buddy:** Assign a name to a person in a photo.







- **New album:** Create a new album. Use the keyboard to enter a name for the album.
- **Hidden Items:** Touch this icon to show items that have been hidden.
- **View by:** View content from all sources or set a single source, such as in your device.
- **Select album:** Touch one or more albums or groups that you want to share, share, or delete.
- **Scan for nearby devices:** scans for nearby DLNA-compliant devices that can receive or display photos and videos.
- **Show/Hide nearby devices:** display nearby DLNA-compliant devices that can receive or display photos and videos, or hide the list.
- **Settings:** Set account to sync pictures and videos with, and choose whether to sync only via Wi-Fi.





### Viewing Groups of Photos and Videos

1. From a Home screen, touch  **Apps** →  **Gallery**.
2. Touch a category and then a group to view it. Thumbnails for each photo and video in the group display.
3. Touch  **Camera** to take a photo or video.

4. Touch  **Slideshow** to view a slideshow of the available pictures and videos.
5. Touch  **New album** to create a new album. Enter a name for the album then tap **OK**.
6. Touch  **Menu** for these options:
  - **Select item:** Touch one or more items that you want to share, delete, or use for a slideshow.

### Viewing Photos and Videos

1. From a Home screen, touch  **Apps** →  **Gallery**.
2. Touch a category and then a group to view it, and then touch a photo or video thumbnail.
3. Touch the screen to show or hide Gallery options.
4. Touch the screen with two fingers or double-tap on the screen to zoom all the way in or out. For more information, refer to “Pinch” on page 14.
5. Sweep across the screen to display the next or previous photo or video. (Videos are indicated by the  **Play** button.) The current photo or video is outlined in the thumbnails at the bottom of the screen. Touch a thumbnail to view the photo or video it represents.
6. Touch  to assign this photo or video as a Favourite.

7. Touch  **Share** to share the photo or video. Touch an option, such as Bluetooth, and follow the on-screen instructions.
8. Touch the  to choose from Start slideshow and Slideshow settings.
9. To delete the photo or video being displayed, touch  **Delete**.
10. Touch  **Menu** to display the following options for photos:
  - **Face tag:** Set whether to look for a face in this picture.
  - **Tag buddy:** Assign a name to a person in a photo.
  - **Add weather tag:** Choose from Sunny day, Cloudy day, Rainy day, Snowy day, or Clear night.
  - **Photo frame:** Add a frame to the selected photo. Press **Save** when completed or **Cancel**.
  - **Photo note:** Add a note to a photo.
  - **Copy to clipboard:** Copy the current photo to the clipboard.
  - **Rotate left:** Allows you to rotate the photo counterclockwise 90 degrees.
  - **Rotate right:** Allows you to rotate the photo clockwise 90 degrees.


- **Crop:** Allows you to crop the image. Touch and drag the crop box or the sides or corners of the crop box to create the crop area, then touch **Done**. Touch **X** to stop without cropping the photo.
- **Edit:** Use Photo Editor or Paper Artist to edit your photo.
- **Set as:** Assign the photo as a Contact photo or a Home screen, Lock screen, or Home and lock screens wallpaper.
- **Buddy photo share:** Detect the face in this picture and email that person.
- **Print:** Print the current photo to a Samsung printer.
- **Rename:** Enter an new file name.
- **Scan for nearby devices:** scans for nearby DLNA-compliant devices that can receive or display photos and videos.
- **Details:** Provides details about the photo, such as title, time taken, size, and so on.

There are three options for videos that are not playing:

- **Tag buddy:** Assign a name to a person in a photo.
- **Rename:** Enter an new file name.
- **Scan for nearby devices:** scans for nearby DLNA-compliant devices that can receive or display videos.




- **Details:** Provides details about the video such as Title, Time, Duration, and so on.

For menu options while a video is playing and other video options, see “*Video Player*” on page 70.

11. Touch  **Back** to return to the category screen.

## Setting a Picture As

You can use the photos you take as a contact’s photo or as wallpaper for the Home or Lock screen:

1. From a Home screen, touch  **Apps** →  **Gallery**.
2. Touch a category and then a group to view it, and then touch a photo to select it.
3. Touch  **Menu** → **Set as**.
4. Touch **Contact photo** and then touch a contact entry.  
– or –

Touch **Home screen**, **Lock screen**, or **Home and lock screen**.

A crop photo screen displays.

5. Touch and drag the crop box or the sides or corners of the crop box to create the crop area, then touch **Done** to save the cropped photo as the contact’s icon or wallpaper. Touch **Cancel** to stop without cropping the photo.

---

**Tip:** To remove a contact photo, see “*Updating Contacts*” on page 32.



---

---


**Tip:** To change wallpaper, see “*Wallpapers*” on page 24.

---



## Playing Videos


1. From a Home screen, touch  **Apps** →  **Gallery**.
2. Touch a category and then a group to view it, and then touch a video thumbnail to play the video.

---


**Note:** Videos are marked with a  **Play** button.

---

3. Touch  **Pause** to pause the video.
4. Touch  **Resume** to resume playing the video.

5. Touch and drag the  white dot on the progress bar to fast forward or rewind the video. Touch the left end of the progress bar to restart the video. Touch the right end of the progress bar to end the video playback.





– or –

Touch  **Rewind** to restart the video or

 **Fast Forward** to end the video.

## Sharing Photos and Videos

Share photos and videos with your friends.

1. From a Home screen, touch  **Apps** →  **Gallery**.
2. Touch a category and then a group to display thumbnails.
3. Touch  **Menu** → **Select item**.
4. Touch one or more photos and videos to highlight them for sharing.
5. Touch  **Share**.
6. Touch an option, such as Bluetooth, and follow the on-screen instructions.


## Section 8: Connections

---

Your device includes features to connect to the Internet and to other devices by using Wi-Fi, Bluetooth, or a USB cable.

### Internet






Your device is equipped with a full HTML Browser that allows you to access the Internet.

- From a Home screen, touch  **Internet**.

### Navigating the Internet

The following options are available for Internet navigation.

#### Command Keys

- Touch  **Back** or  to return to the previous page.
- Touch and hold  **Back** display browser History.
- Touch  **Forward** to go forward to a recent page.
- Touch  **Refresh** to reload the current page.

#### Touching and Dragging

- Touch and drag your finger on the screen to navigate pages and to reposition pages within the screen.

### Entering Text in a Field

- While browsing, touch a text field to display the virtual QWERTY keyboard to enter text.

### Zoom

- Tap the screen twice to zoom in or out.
- Use two fingers, such as your index finger and thumb, to zoom out by making an inward pinch motion on the screen. To zoom in, make an outward motion by sweeping your fingers out.



---

**Tip:** For convenient browsing, you can rotate the device to landscape mode.

---




### Selecting Items On a Page

While browsing, use gestures and menus to navigate:

- Touch an item to select it.
- Touch a hyperlink to follow the link.
- Touch and hold on a hyperlink or an image for options.


## Using Browser Windows

You can have multiple windows open at one time and easily switch between windows.

1. From a Home screen, touch  **Internet**.
2. To open a new window, touch  at the top of the screen.
3. To switch to another open window, touch its tab at the top of the screen.
4. To delete an open window, touch the tab at the top of the screen, and then touch .

## Entering a URL

Access a website quickly by entering the URL.

1. From a Home screen, touch  **Internet**.
2. Touch the **URL** field at the top of the screen, then enter the URL using the virtual QWERTY keyboard.  
As you enter characters, potential matches display.

---

**Note:** Touch X to clear the URL field, if necessary.



---


3. Touch a match to complete the URL.  
– or –

Continue entering characters and touch the **Go** key to load the page.

## Creating Bookmarks

While browsing, bookmark a site to quickly access it later.

1. From a Home screen, touch  **Internet**.
2. Browse to a website, touch  **Add bookmark** at right of the address field, enter the required information, and touch **OK**.

A gold star  displays on the Bookmarked page.

## Internet Menu

While viewing a webpage:

- Touch  **Menu** for options.



To configure web settings:

- Touch  **Menu** → **Settings**.

Follow the on-screen instructions.


## Internet Quick Controls

Use Quick Controls to maximize your viewing area while browsing the internet.


1. From a Home screen, touch  **Internet**.
2. While viewing a webpage, touch  **Menu** → **Settings** → **Labs**, and then touch **Quick controls** to enable the function.

The Application and URL bars are hidden.

3. Swipe slowly inward from the left or right edge of the screen to access quick controls.



4. Without lifting your finger, move to an option and then lift your finger to initiate the option.

5. To cancel, display the Quick controls and touch  **Settings** → **Labs** and touch **Quick controls** to uncheck it.

## Wi-Fi

Wi-Fi is a wireless networking technology that provides access to local area networks. Use your device's Wi-Fi feature to:

- Access the internet for browsing or to send and receive email.
- Access your corporate network.
- Use hotspots provided by hotels or airports while traveling.

Wi-Fi communication requires access to an existing Wireless Access Point (WAP). WAPs can be Open (unsecured) or Secured (requiring you to provide login credentials). Your device supports the 802.11 a/b/g/n Wi-Fi protocol.

### Configuring Wi-Fi Settings




For more information about configuring your device's Wi-Fi settings, see "Wi-Fi" on page 111.

### Finding Wi-Fi Networks

You can have your device automatically notify you of available networks. For more information, refer to "Advanced Settings" on page 112.




## Turning Wi-Fi On

By default, your device's Wi-Fi feature is turned off. Turning Wi-Fi on makes your device able to discover and connect to compatible in-range WAPs.




1. From a Home screen, touch  **Apps** →  **Settings** → **Wi-Fi**.
2. Tap the **ON/OFF** slider, located to the right of the **Wi-Fi** field, to turn **Wi-Fi ON** .

## Scanning and Connecting to a Wi-Fi Network

When you turn on Wi-Fi, your device searches for available Wi-Fi connections, then displays them on screen.

1. From a Home screen, touch  **Apps** →  **Settings** → **Wi-Fi**.
2. Touch the **OFF / ON** icon  to turn **Wi-Fi** on. Your device automatically scans for available Wireless Access Points.
3. When the scan is complete, touch a **Wi-Fi** network to connect. If the **Wi-Fi** network is open, your device automatically connects. If the **Wi-Fi** network is secured, enter the password at the prompt to connect.

## Adding a Wi-Fi Network Manually

4. From a Home screen, touch  **Apps** →  **Settings** → **Wi-Fi**.
5. Touch the **OFF / ON** icon  to turn **Wi-Fi** on.
6. Touch **Add Wi-Fi network**, then enter network information:
  - **Network SSID**: Enter the name of the Wi-Fi Wireless Access Point (WAP).
  - **Security**: Select the type of security used by the WAP.

---




**Note:** Depending on the Security protocol used by the WAP, additional network information may be required, such as a Password.

---

- **Password**: If the WAP is secured, enter the password or hex key.
7. Touch **Save** to save the settings.

## Wi-Fi Direct

Wi-Fi Direct allows device-to-device connections so you can transfer large amounts of data over a Wi-Fi connection.

1. From a Home screen, touch  **Apps** →  **Settings** → **Wi-Fi**.
2. Touch the **OFF / ON** icon  to turn **Wi-Fi** on.



3. At the top of the Wi-Fi screen, tap the **Wi-Fi Direct** button.  
Your device will begin to search for other devices enabled with Wi-Fi direct connections.
4. Enable Wi-Fi Direct (similar to Steps 1 - 3) on the device to which you want to connect.
5. Once the device you want to connect to is displayed, touch on it.  
An Invitation to connect displays on the device to which you want to connect.
6. On that device, touch **Accept**.

You have 30 seconds to touch **Accept** on the device to which you want to connect for the connection to be made.

Once connected, the other device will show as **Connected** in your list of Wi-Fi Direct devices and the



icon will display at the bottom of your screen.

### Sharing Information with Connected Device

To share videos, photos, or other information with the connected device, follow these steps:

1. View the information that you want to share. For example, if you want to share a photo, find the photo in your camera viewer or **My Files** folder, then touch the **Share**, **Share via**, or **Send via** option.
2. Touch the **Wi-Fi Direct** option.  
The Wi-Fi Direct settings screen displays, Wi-Fi Direct is turned on, and your device scans for other devices.
3. Touch a connected device name. For example, `Android_XXXX`.
4. The other device displays a pop-up that indicates it is receiving the file.  
The file is transferred and can be found in **My Files** in the `ShareViaWifi` folder.

---

**Note:** Depending on the other device model, the prompts and shared folder information may differ.

---

## Bluetooth

Bluetooth is a short-range wireless communications technology for exchanging information over a distance of about 30 feet.




You do not need to line up the devices to send information with Bluetooth. If the devices are in range, you can exchange information between them, even if they are in different rooms.

### Configuring Bluetooth Settings


Configure your device's Bluetooth settings. For more information, refer to “Bluetooth” on page 113.

### Turning Bluetooth On or Off

To turn Bluetooth on or off:

1. From a Home screen, touch  **Apps** →  **Settings**.
2. Under **Wireless and network**, on the Bluetooth tab, touch the **OFF / ON** icon  to turn Bluetooth on or off.

---

**Note:** When Bluetooth is on, the **Bluetooth** icon  displays in the Status Bar.

---




## Pairing with a Bluetooth Device

Search for a Bluetooth device and pair with it, to exchange information between your device and the target device.

---

**Tip:** After pairing, your device and the target device recognize each other and exchange information without having to enter a passcode or PIN.

---

1. From a Home screen, touch  **Apps** →  **Settings** → **Bluetooth**.
2. Touch the **OFF / ON** icon  to turn Bluetooth on.
3. Enable the target device's discoverable or visible mode.
4. Touch **Scan**. Touch **Stop** at any time to stop scanning.
5. From the list of found devices, touch the target device, then follow the prompts to complete the pairing:
  - If the target device requires a PIN, enter a PIN for the target device and touch **OK**. When prompted, enter the PIN on the target device.
  - If the device allows automatic or smart pairing, your device attempts to pair with the device automatically. Follow the prompts on your device and the target device to complete the pairing.

## Sharing Data with a Bluetooth Device

To send data to a Bluetooth device:

1. Select a file or item from an appropriate application.
2. Select an option for sharing data with the Bluetooth feature.

---

**Note:** The method for selecting an option may vary by data type.

---


3. Search for and pair with a Bluetooth device. For more information, refer to “*Pairing with a Bluetooth Device*” on page 82.

## Receiving Data from a Bluetooth Device

To receive data from a Bluetooth device:

1. Turn Bluetooth on. For more information, refer to “*Turning Bluetooth On or Off*” on page 82.

---

**Note:** To select the length of time that your device will be visible, select  **Menu** → **Visibility timeout**.

---

2. Pair with the Bluetooth device from which you want to receive data. For more information, refer to “*Pairing with a Bluetooth Device*” on page 82.

A Bluetooth authorization request pop-up displays when a Bluetooth device sends data to your device.

3. Select **Accept** to confirm that you are willing to receive data.

A File received message displays.

---

**Note:** Received data is saved to the Bluetooth folder. If you receive a contact, it is saved to your contacts automatically.

---

## Managing Downloads

Files, apps, and other items you download via Internet, Gmail, Email, or in other ways, are stored on your tablet's internal storage. You can use the Downloads app to view, reopen, or delete what you have downloaded.



To manage the demands on their networks or to help you avoid unexpected charges, some mobile networks place restrictions on the size of the files you can download. When you are connected to such networks, and you try to download an oversized-file, you are asked or required to delay downloading the file until the next time you are connected to a Wi-Fi network. At that time, the download resumes automatically. The Downloads app can also be used to view and manage these queued files.

Downloaded files are stored in the Download directory in your tablet's internal storage. You can view and copy files from this directory when connected to a computer with a USB cable.

### Uninstalling an App

Apps come pre-installed on your device and you can download additional apps from Google Play. If you decide to, you can uninstall apps you downloaded from Google Play and other sources.

There are several ways to uninstall an app:

1. From a Home screen, touch  **Apps** →  **Settings** → **Application manager**.
2. Touch the **Downloaded** tab.
3. Touch the app you want to uninstall.
4. Touch the **Uninstall** button.  
A pop-up displays the message **Application will be uninstalled**.
5. Touch **OK** to confirm you want to uninstall the app.

You can also use Google Play to uninstall apps you downloaded from there (see “Play Store” on page 103).

### Kies Via Wi-Fi

Samsung Kies is a software that enables you to update your device firmware, synchronize files, and transfer data to and from your device directly by connecting to the PC.

---

**Note:** Some features will be supported through the System Updates feature in the future. For more information, refer to “Software Update” on page 142.

---

To learn more about Samsung Kies and Samsung applications, browse featured applications and download Kies at: <http://www.samsung.com/us/support/downloads>.

---

**Note:** Samsung Kies works on both PC and Macintosh computers.

---



### Connecting With Samsung Kies via Wi-Fi

1. From your PC, download the Samsung Kies application if you don't already have it. You can find it at [samsung.com](http://samsung.com).

---

**Warning!** Close any running applications before connecting your device to a PC.

---

2. From your PC, launch the Samsung Kies application.
3. From your PC, connect to a Wi-Fi network.
4. From a Home screen, touch  **Apps**  
→  **Settings**.
5. Touch **More settings** → **Kies via Wi-Fi**.
6. From your device, connect to the same Wi-Fi network that your PC is connected to if you have not already done so. For more information, refer to “Connecting With Samsung Kies via Wi-Fi” on page 85.

## Synchronizing with Windows Media Player

Ensure that Windows Media Player is installed on your PC.

1. Attach your device to the computer with the USB cable. Your computer recognizes the connection and displays the AutoPlay screen.
2. Click the option to **Sync digital media files to this device** to synchronize music files.
3. Select and drag the music files you want to the sync list and begin synchronizing.
4. When finished, exit Windows Media Player and disconnect the USB cable.

## Connecting as a Mass Storage Device

You can connect your device to a PC as a removable disk and access the file directory. If you insert a memory card in the device, you can also access the files directory from the memory card by using the device as a memory card reader.

---

**Note:** The file directory of the memory card displays as folder **Card**, separate from the internal memory, which is folder **Tablet**.

---

1. Attach your device to the computer with the USB cable. Your computer recognizes the connection and displays the AutoPlay screen.
2. Click the option to **Open device to view files**. You should see a Tablet folder and, if a memory card is installed, a Card folder.
3. Copy files from the PC to the tablet and/or memory card.
4. When finished, close the PC folder and disconnect the USB cable.

## Section 9: Applications

---


This section contains a description of each application that is available on the Apps screen, its function, and how to navigate through that particular application. If the application is already described in another section of this user manual, then a cross reference to that particular section is provided. Various widgets are also described.

---

**Tip:** To open applications quickly, add the icons of frequently-used applications to one of the Home screens, if it is not there by default. For details, see “*App Shortcuts*” on page 22.

---

### Updating Applications

Once you have registered your device (see “*Software Update*” on page 142) and signed into your Google account (see “*Setting Up Your Gmail Account*” on page 45), you may see the  **Updates Available** notification in the Status Bar if there is a new version of one or more apps available or, when you open an application that is preloaded on your device, an **Update Available** message may be displayed.

To update the applications:

1. Touch the Time / Status Icons area to display the Status Details panel.

The Status Details display.

2. Touch **Updates available**.

For more information, refer to “*Updates to Downloaded Apps*” on page 103.

### GPS Applications

GPS applications allow you to achieve real-time, GPS-enabled, turn-by-turn navigation and to access local searches based on a variety of category parameters.

To receive better GPS signals, avoid using your device in the following conditions:

- inside a building or between buildings
- in a tunnel or underground passage
- in poor weather
- around high-voltage or electromagnetic fields
- in a vehicle with tinted windows

Global GPS turn-by-turn navigation, mapping, and Point of Interest content is available for three continents, including North America (U.S., Canada, and Mexico), Western Europe, and China, where wireless coverage is available.

---




**Important!** If you touch or cover the internal GPS antenna while using GPS services, it may impede the GPS signal resulting in the GPS services not working in an optimal manner. Refer to the following diagram to locate the approximate location of the internal GPS antenna.

---

## Alarm




Set alarms for reminders or for wake-up times.

### Adding and Configuring Alarms



1. From a Home screen, touch  **Apps** →  **Alarm**.
2. Touch  **Create alarm** to display the Create alarm screen.  
– or –  
Touch an existing alarm to display the Edit alarm screen.
3. Touch fields on the screen to configure the alarm.

- Some fields have preset values. Touch the field and touch the desired value.
  - Other fields have to be input. Touch the field and use the on-screen keyboard to input information.
  - Touching the check box next to some fields may make additional fields available.
4. Touch **Save** to save the alarm.  
The main Alarm screen displays showing the new or updated alarm.

### Activating Alarms

1. From a Home screen, touch  **Apps** →  **Alarm**.
2. Touch  **Turn alarm on** to activate the alarm. A gray alarm means the alarm is deactivated.
3. Touch an alarm to change any of its settings and then touch **Save** to save the updates.


### Editing and Deleting Alarms

1. From a Home screen, touch  **Apps** →  **Alarm**.
2. Touch and hold an alarm and then touch one of the following options:
  - **Edit**: Edit the alarm. For more information, refer to “Adding and Configuring Alarms” on page 88.



- **Delete:** Delete the alarm.

– or –

Touch  **Delete**, touch the existing alarms you want to delete or touch **Select all**, and then touch **Delete**.


## Turning Off an Alarm

When the alarm sounds, to turn off the alarm:

- Touch and drag  to the right.



## Setting the Snooze Feature

To activate the Snooze feature after an alarm sounds:








- Touch and slide  to the left. Snooze must first be set in the alarm settings.


## aNote HD

Use ANote HD to easily and effectively managing your life on the go. Use the tabs to choose the categories for notes, such as creating a shopping list and check things off on-the-go.

1. From a Home screen, touch  **Apps** →  **aNote HD**.
2. Use the tabs on the left of the screen to open the category you wish to use. Choose from the following options.
  - Quick Memo
  - Calendar
  - My Idea
  - My Diary
  - Travel Journal
  - Shopping
  - To-Do list
  - Anniversary
  - My Calendar
  - Work
  - Study
  - Scrap
  - Email/Print
  - Recipe
  - Thoughts

## Settings






- Touch  to access Settings:
  -  **Help & Support:** This help option provides Screen Tips, User Guide, BRID Website, and Copyright information. Follow on-screen instructions for more information.
  -  **General:** This option allows you to adjust the Image Quality.
    - **Image Quality:** Choose from Low Quality, Normal Quality and High Quality. Tap the  to make your selection.
    - **Save Images to Gallery when taking a picture:** Use the **OFF / ON** icon  to automatically save your images to your the Gallery.
    - **Background:** Choose from background options shown on the screen. Tap the background image to make your selection.
  -  **Passcode Lock:** Use this option to set a passcode for this application.
    - **Passcode Lock:** Use the **OFF / ON** icon  to turn the Passcode Lock option on or off.
    - **Change Passcode:** Use the Change Passcode option to reset your passcode. Enter a passcode at the pop-up screen.



- **Startup:** This passcode is used in locking individual folders, the entire application and when using this application. Use the **OFF / ON** icon  to enable this option.

---

**Tip:** Use the **OFF / ON** icon  to enable these options.




---




-  **To-do Settings:** Use this option to set the following options:
  - Badge Count:** Available options are: Overdue+Today, Overdue+Today+Tomorrow, or Overdue. Tap the  to make your selection.
  - Set Alarm for Due-date:** Tap the **OFF / ON** icon  to activate this option.
  - To-do:** Available options are: Standard Alarm 1, Standard Alarm 2, Bird, Alarm Clock, and Trumpet. Tap the  to make your selection.
  - Anniversary:** Available options are: Bell, Piano, Happy Birthday. Tap the  to make your selection.

-  **Backup/Restore via USB:** Use this option to Backup and Restore files.  
Tap the Create a New Backup option to create a current backup of your Note.  
Tap the Restore option to select the backup to restore.
-  **Web Sharing over Wi-Fi:** Use this option to Start the Backup or Restore options using Wi-Fi.

## Calculator



The calculator provides the basic arithmetic functions to solve simple arithmetic problems and scientific functions to solve more complex problems.





1. From a Home screen, touch  **Apps**  
→  **Calculator.**
2. Enter the first number using the numeric keys.
3. Enter the operation for your calculation by touching the + (add), - (subtract), × (multiply), or ÷ (divide) key.
4. Enter the next number.
5. To view the result, touch the = (equals) key.
6. Repeat Steps 3 through 5 as many times as required.
7. Touch  to clear the result.

8. For scientific functions such as **sin**, **ln**, **cos**, **log**, **tan**, rotate your device to landscape mode.
9. Touch and hold entries in the Calculator's display field to copy or cut the contents of the display.  
The  and  displays. Use the icons to select the content to Cut or Copy. Select  to review the Clipboard.

## Calendar




Your device includes a powerful calendar to help you organize your schedules more conveniently and effectively. Learn to create and manage events and tasks, and set alarms to remind yourself of important events and tasks.

1. From a Home screen, touch  **Apps**  
→  **Calendar.**
2. Touch the drop-down box at the top of the screen to choose a calendar view (the default view is Month). The following options are available:
  - **Year:** Display all twelve months of this year. Sweep across the years at the bottom of the screen to display a different year.

- **Month:** Display the current month. Touch a month and year at the bottom of the screen to display a different month.
  - **Week:** Display the current week. Touch a week at the bottom of the screen to display a different week.
  - **Day:** Display today's schedule by hour. Touch a day at the bottom of the screen to display a different day.
  - **List:** Display only event and task names and dates for a selected year. Touch a year at the bottom of the screen to display a different year. Touch a date to hide or show the event or task name.
  - **Task:** Display your list of tasks. Touch the sort field to change how your tasks are sorted. Tasks can be sorted by due date, priority, date, week, month, or group.
3. Swipe left or right across the screen to view other months, days or weeks. Swipe up or down the screen to view other events.
  4. To find an event or task, touch  **Search**. Use the on-screen keyboard to enter a search term. Possible events display as you type.  
Touch  to display the keyboard.  
Touch an event to send, edit, or delete the event.
  5. Touch  and then **Add event**, **Add task**, or **Add memo** to add a new event to your calendar. For more information, refer to “*Creating an Event or Task*” on page 92.
  6. Touch  **Menu** to select from the following options:
    - **Zoom in:** Use this to zoom in on the calendar event.
    - **Zoom out:** Use this to zoom out on the calendar event.
    - **Go to:** Use this option to go directly to a different date using the calendar function.
    - **Delete:** Use this option to delete an event.
    - **Sync:** Use this option to synchronize the calendar with other devices.
    - **Settings:** Use this setting to View settings and their options, Event notification and their options, Sync settings, and the associated email accounts attached to this calendar.
  7. Touch **Today** to return to the current date.
  8. Touch **Calendars** to configure which events to display. Touch **Add account** to add additional accounts from which calendar events can be synced.





## Creating an Event or Task

To create an event or task:

1. From a Home screen, touch  **Apps** →  **Calendar**.
2. Double-tap the date for which you want to enter an event or task.
  - or –
 Touch the date for which you want to enter an event or task and touch .
3. Touch the **Add event**, **Add task** or **add Memo** tab.
4. Enter the event or task information.
5. Touch **Save**.




## Add Additional Calendar Accounts

To add additional accounts:

1. From a Home screen, touch  **Apps** →  **Calendar** → **Calendars** → **Add account**.
  - or –
 From a Home screen, touch  **Apps** →  **Settings** → **Add account**.  
 The Add account screen displays.
2. Touch an account type and enter your account information.

## Calendar Settings



To set up Calendar preferences:

1. From a Home screen, touch  **Apps** →  **Calendar**.
2. Touch  **Menu** → **Settings**.
3. On the left side of the screen touch **View settings**, **Event notification**, **Sync settings**, or one of your accounts. Options display on the right side of the screen.
4. Touch fields on the screen to configure the Calendar.
  - Some fields have preset values. Touch the field and touch the desired value.
  - Other fields have to be input. Touch the field and use the on-screen keyboard to input information.
  - Touching the check box next to some fields may make additional fields available.

## Camera

Take photos and record video with your device's built in Camera.



For more information, refer to “*Camera*” on page 63.

- From a Home screen, touch  **Apps** →  **Camera**.

## ChatON



Use ChatON to send and receive instant messages from any device that has a mobile phone number.

For more information, refer to “*ChatON*” on page 55.

- From a Home screen, touch  **Apps** →  **ChatON**.

## Chrome

Use Chrome to browse the internet and bring your open tabs, bookmarks and omnibox data from your computer to your phone or tablet.



- From a Home screen, touch  **Apps** →  **Chrome**.

Follow on-screen instructions.

## Contacts





Store contact information for your friends, family and colleagues, to quickly access information or to send a message.

For more information, refer to “*Contacts*” on page 32.

- From a Home screen, touch  **Apps**  
→  **Contacts**.

## Downloads



Files, apps, and other items you download in Internet, Gmail, Email, or in other ways, are stored on your tablet’s internal storage. Use the Downloads app to view, reopen, or delete what you have downloaded.

1. From a Home screen, touch  **Apps**  
→  **Downloads**.
2. Touch an item to open it.
3. Touch headings for earlier downloads to view them.
4. Touch items you want to send, to check them, and then touch  **Share**. Touch an option to share the item. Options are: aNote HD, Add to Dropbox, Bluetooth, ChatON, Email, Flipboard, Gmail, Google+, Group Play, Messaging, Paper Artist, Picasa, S Note, Wi-Fi Direct, or YouTube (videos only).
5. Touch items you want to delete, to check them, and then touch  **Delete**.  
The items are deleted from your tablet.

6. Touch **Sort by size** or **Sort by date**, at the bottom of the Downloads pop-up, to switch back and forth. Touch **Clear list** to cancel the download and clear the download history.

## Dropbox



Dropbox is a free service that lets you bring all your photos, documents, and videos anywhere. Any file you save to your Dropbox will automatically save to all your computers, phones and even the Dropbox website.

From the Home screen, tap  →  **Dropbox**.

Follow the onscreen instructions to sign up for your Dropbox account.



## Email

Send and receive email using popular email services. For more information, refer to “*Email*” on page 48.

- From a Home screen, touch  **Apps** →  **Email**.

## Flipboard

This application creates a personalized digital magazine out of everything being shared with you. Access news stories, personal feeds and other related material. Flip through your Facebook newsfeed, tweets from your Twitter account, photos from friends and much more.

1. From the Home screen, tap  → **Flipboard** .
2. Tap **Get started**, select some on-screen categories and tap **Build Your Flipboard** to create a new profile.  
– or –  
Tap **Tap to Sign In** to log into your previously created profile.
3. Follow the on-screen instructions.




## Gallery



Use Gallery to view, capture, and manage photos and videos. For more information, refer to “*Gallery*” on page 72.

- From a Home screen, touch  **Apps** →  **Gallery**.

## Game Hub



Access social and premium games. Join Game Hub to enjoy free games with your friends.

1. From a Home screen, touch  **Apps**  
→  **Game Hub**.  
A Disclaimer screen displays.
2. Read the Disclaimer and touch **Confirm**.
3. Touch  Menu to display the following options:
  - **Uninstall**: Touch this option to uninstall a previously installed game.
  - **Legal notices**: Displays Game Hub legal information.
4. Touch a game and follow the on-screen instructions.

2. Use the keyboard to enter search criteria to display matching searches.  
– or –  
Touch  and speak the search criteria slowly and clearly. Google searches for the information and displays results.  
Suggestions display below the text entry area.
3. Touch a suggestion to search for that term.  
– or –  
Touch  on the keyboard to start the search.  
A browser window displays the search results.



## Gmail


Send and receive email with Gmail, Google's web-based email. For more information, refer to "Gmail" on page 45.

- From a Home screen, touch  **Apps** →  **Gmail**.





## Google Search

Search the internet using the Google search engine.

1. From any Home screen, touch  **Apps** →  **Google**.  
– or –

From the main Home screen, swipe your tablet to the left, then touch   **Google**.



To use Voice Search directly:

1. From a Home screen, touch  **Apps**  
→  **Voice Search**.
2. Touch  and speak the search criteria slowly and clearly. Google searches for the information and displays results or displays **Retry**. Touch the  to retry speaking the search word(s).



## Google Settings



Google Settings provides shortcuts to your settings for Apps with Google+ Sign-in, Google+, Play games, Location, Maps & Latitude, Search, and Ads. All of these options are already accessible in other locations on the device, except Apps with Google+ Sign-In. This setting lets you manage the apps you've used to sign in and share information with your Google+ account.

- From any Home screen, touch  **Apps** →  **Google Settings**.

## Google+

Share updates and see what is going on around you with Google+ for mobile.

For more information, refer to “Google+” on page 55.



- From a Home screen, touch  **Apps** →  **Google+**.

## Group Play




Group Play is an easy way to share files in real time with others who are on the same Wi-Fi network. Group Play can be used when you want to share documents, images, music, and so on.

You can use Group Play for meetings, sales presentations, conferences, and classes. All you need is a Wi-Fi network that works with Group Play, and most do.

### Using Group Play from an Application

While using various applications, such as  **Gallery**, when you touch  **Share** to share a file, you see Group Play as an option.

To share a file using Group Play:

1. From a Home screen, touch  **Apps** →  **Gallery**.
2. Navigate to the file you want to share and touch  **Share via** → **Group Play**.

For more information, refer to “Gallery” on page 72.

3. Use the keyboard to enter a PIN code and touch **Done**. This process makes sure only desired recipients can view your shared image.

The Group Play screen displays and the device waits for other connected recipients to accept the connection and enter the PIN on their screens.

You can now interact and draw with the on-screen image, and users will instantaneously see the same gestures and also be able to interact.



---

**Note:** The newly altered image (with markups and comments) cannot be saved, but you can take a screen shot of the current image and save it to your Clipboard. For more information, refer to “*S Pen Screen Capture*” on page 17.

---

## Using Group Play Directly

You can also access Group Play from the Applications screen.

1. From a Home screen, touch  **Apps**  
→  **Group Play**.

The Group Play screen displays.



2. If **Not connected** is displayed on the left side of the screen, touch **Wi-Fi settings** to connect to a Wi-Fi network.

Once your device is connected to a Wi-Fi network, the network name is displayed.

3. Touch **Start** to share a picture, document, or music.
4. Touch **Join** to join a Group Play session in progress. Use the keyboard to enter the required PIN code and touch **Done**.

## Help



Use this app to learn more about your camera, change important settings, use key applications, and link to product videos.

1. From a Home screen, touch  **Apps** →  **Help**.
2. Touch a topic on the left side of the screen to view information on the right side of the screen.

## Internet


Your device includes a full HTML Browser, to access the internet.

For more information, refer to “*Internet*” on page 77.

- From a Home screen, touch  **Apps** →  **Internet**.

## Learning Hub

Samsung Learning Hub provides free access to 6,000 textbooks and video lectures from 30 different content providers, for all ages.

- From a Home screen, touch  Apps →







## Local

Google Local is an application that uses Google Maps and your location to help you find destinations, such as restaurants, bars, hotels, attractions, ATMs, and gas stations. You can also add your own locations.

---

**Note:** You must enable location services to use Local. Some features require Standalone or Google location services. For more information, refer to “*Location Services*” on page 123.



1. From a Home screen, touch  Apps →  Local.
2. Touch  to choose or enter your location.
3. Touch one of the business categories to search for a particular business.
4. Touch a business in the list to see more details about it.
5. Touch your location at the bottom of the Local pop-up to write or view reviews, check in here, and so on.
6. For more information touch  Menu → Help.

## Maps

Use Google Maps to find your current location, get directions, and other location-based information.

---

**Note:** You must enable location services to use Maps. Some features require Standalone or Google location services. For more information, refer to “*Location Services*” on page 123.

- From a Home screen, touch  Apps →  Maps.

### Navigating the Map

#### Zooming

- Double-tap on the screen to zoom in.
- Use two fingers, such as your index finger and thumb, to zoom out by making an inward pinch motion on the screen. To zoom in, make an outward motion by sweeping your fingers out.



---

**Tip:** For convenient browsing, you can rotate the device to landscape mode.

#### Scrolling




- Touch and drag on the screen to reposition the map in the display.

## Touch

- Touch an icon on the map to display information about the location.  
For example, your location is indicated by a flashing icon.

## Maps Menu



While viewing a map:

1. Touch  **Menu** for options.
2. Touch  **Menu** → **Settings** to configure Maps settings.
3. For more information touch  **Menu** → **Help**.

## Messenger

With Google Messenger, you can bring groups of friends together into a simple group conversation.



For more information, refer to “*Messenger*” on page 55.

- From a Home screen, touch  **Apps**  
→  **Messenger**.

## Music Player



Play music and other audio files that you copy from your computer.

For more information, refer to “*Music Player*” on page 58.

- From a Home screen, touch  **Apps**  
→  **Music Player**.

## My Files

Find, view, and manage folders and files, such as music files, photo files, video files, and so on, stored on your tablet. If the file is associated with an application on your device, you can launch the file in the application.


1. From a Home screen, touch  **Apps**  
→  **My Files**.
2. Touch a folder and scroll down or up until you locate a file.


---

**Note:** You may have to touch one or more subfolders before you encounter files.

---

3. Touch a file to launch it in the associated application, if the file is associated with an application.
4. While browsing files, use these controls:

 **Up:** Display a higher directory.

 **Search:** Use the keyboard to enter a search term. The current folder is searched and results are displayed. Touch **X** to remove the search field.



**Display mode:** Enable thumbnails for each file.



– or –  
Enable list mode.



**Home:** Display the root directory.



**Create folder:** Create a new folder in the current folder.



**Mark files:** Touch the box to the left of each file or next to the folder to select all files in the folder. Then touch copy, cut, delete, or send via in the Application bar.

5. To view a photo file:

- Touch the file.

6. To view a video file:

- Touch the file.

The Video Player is launched and plays the video.

For more information, refer to “*Video Player*” on page 70.

## Navigation



Use Google Navigation to find a destination and to get walking or driving directions.

Navigation works best when Wi-Fi is enabled. For more information, refer to “*Turning Wi-Fi On*” on page 80.

---




**Note:** You must enable location services to use Navigation. Some features require Standalone or Google location services. For more information, refer to “*Location Services*” on page 123.

---

- From a Home screen, touch  **Apps**  
→  **Navigation.**




## Navigation Menu

While viewing a map:

1. Touch  **Menu** for options.
2. Touch  **Menu** → **Settings** to configure Navigation settings:
3. For more information touch  **Menu** → **Help.**



## Paper Artist

Add cartoon and many other effects to existing photos or photos you take within Paper Artist.

1. From a Home screen, touch  **Apps**  
→  **Paper Artist**.
2. Touch  **Menu** → **Help** to get started.

## Play Books

Use the Play Books app to download and read eBooks from the Internet-based Google Play Books service. Google eBooks is a new way to discover, buy, and enjoy books online and offline.

- From a Home screen, touch  **Apps**  
→  **Play Books**.

The Google Play Books main screen displays.




---

**Note:** You may be asked to create or sign on to your Google account. For more information, refer to “*Setting Up Your Gmail Account*” on page 45.

---



## Play Books Menu

From the Play Books main screen:

1. Touch  **Menu** for options.
2. Touch  **Menu** → **Settings** configure Play Books settings.
3. For more information touch  **Menu** → **Help**.




## Play Magazines

Google Play Magazines helps you subscribe to your favorite magazines so you can have them available to read on your tablet at your leisure.

- From a Home screen, touch  **Apps**  
→  **Play Magazines**.

## Play Movies



The Play Movies app is a new application for select Android devices. Any movie you rent from the Google Play Store can be downloaded for offline viewing through this application. In addition, the Play Movies app can be used to stream your Google Play movie rentals as well as play any of your personal videos stored on your tablet.

1. From a Home screen, touch  **Apps**  
→  **Play Movies**
2. For more information touch  **Menu** → **Help**.

## Play Music



Play music and other audio files that you copy from your computer.

For more information, refer to “*Google Play Music*” on page 57.

- From a Home screen, touch  **Apps**  
→  **Play Music.**

## Play Store

Google Play Store provides access to downloadable applications and games to install on your device. It also allows you to provide feedback and comments about an application, or flag an application that might be incompatible with your device.


1. From a Home screen, touch  **Apps**  
→  **Play Store.**

If you are not already logged in with your Google account, the Add a Google Account screen displays.

- Touch **Existing**, if you already have a Google account, or **New** to create a Google account.

For more information, refer to “*Setting Up Your Gmail Account*” on page 45.



2. The first time you open Play Store, read the Google Play Terms of Service, the Google Music Terms of Service, the Google Books Terms of Service, and the YouTube Rentals Terms of Service, then touch **Accept** to continue.

3. To get help for using Google Play, touch  **Menu** → **Help.**

## Updates to Downloaded Apps

You can check for new versions of applications by visiting the Google Play Store. Items that have a new version available will say **Update**.


You can also select apps that you would like to be updated automatically. To do this:

1. From a Home screen, touch  **Apps**  
→  **Play Store.**

2. Touch  **Installed Apps.**

3. Touch the **Installed** tab to list the Play Store apps installed on your device.




Update is displayed if there is an update available for the app.

4. To enable automatic updating, touch an app and then touch touch  **Menu** → **Auto-update** to place a checkmark in the selection box.
5. Touch **Open** to open the app on your device.
6. Touch **Update** to immediately update the app on your device.

## Polaris Office



Polaris Office Mobile for Android is a Microsoft Office compatible office suite. This application provides a central place for managing your documents online or offline.

The application can also open Adobe PDF (Portable Document Format) files.

1. From a Home screen, touch  **Apps**  
→  **Polaris Office**.
2. Enter your Email information, if desired, and touch **Register** to complete the process.  
– or –  
Touch **Skip** to ignore this registration.  
The main Polaris Office screen displays.
3. To get help for using Polaris Office, touch  **Menu**  
→ **Help** → **User Guide**.

## Readers Hub

Samsung Readers Hub is a one stop shop for books, magazines and newspapers from around the world.

1. From a Home screen, touch  **Apps** →  
 **Readers Hub**.



---

**Important!** Data download charges may apply. Costs may apply for paid Samsung Readers Hub material. Check with your Service provider for more details.

---



## S Note

Use S Note to create notes with productivity tools that turn handwriting into typed text and correct drawn shapes, lines, and formulas to make them perfect.

1. From a Home screen, touch  **Apps** →  **S Note**.
2. Read the Learn about application pop-up then touch **OK** to open the application.



## S Voice

The S Voice app enables you to perform various tasks simply by speaking.

1. From a Home screen, touch  **Apps** →  **S Voice**.  
The Samsung Disclaimer for S Voice displays.
2. Touch **Confirm**.  
The Terms of Service displays.
3. Touch **Terms of service** and **Privacy policy** to read those documents and then touch **Agree**.






The About S Voice pop-up displays.

4. Touch **Next** to view a tutorial or touch **Skip** to display the S Voice main screen.
5. Touch  in the lower, right corner of the S Voice screen to display phrases you can use to open various apps.
6. Touch  **Menu** → **Settings** to view and manage your S Voice settings. Touch fields on the screen to configure the settings.
  - Some fields have preset values. Touch the field and touch the desired value.
  - Other fields have to be input. Touch the field and use the on-screen keyboard to input information.
  - Touching the check box next to some fields may make additional fields available.
  - Touch **Help** for more information.

## Samsung Apps

Connect to Samsung Apps and make your smart device even smarter. Simply and easily download an abundance of applications to your tablet such as games, news, reference, social networking, navigation, and more.

1. Sign on to your Samsung account if you have not already done so.
2. From a Home screen, touch  **Apps** →  **Samsung Apps**.
3. Tap an application that you would like, then tap **Get**.
4. Tap **Accept and download**.  
The application is downloaded to your device. You can find the app icon in your app menu.
5. Press  **Menu** → **Help and notices** for additional information.



## Samsung Link

This application wirelessly synchronizes your Samsung device with your TV, streams content, and even keeps tabs on who calls or sends text messages with real-time, on-screen monitoring. Samsung Link makes staying connected easy. Samsung Link allows users to share their in-device media content with other external devices using DLNA certified™ (Digital Living Network Alliance) Devices. These external devices must also be DLNA-compliant. Wi-Fi capability can be provided to TVs via a digital multimedia streamer.

---

**Important!** You must first connect both of your communicating devices to the same Wi-Fi and be using an active/registered Samsung account prior to using this application. For more information, refer to “*Wi-Fi*” on page 111. For more information, refer to “*Creating a Samsung Account*” on page 5.




---

1. From a Home screen, touch  **Apps** → **Samsung Link** .
2. Tap **Sign in** to sign into your Samsung Account if you have not already done so.
3. If prompted, read the on-screen message about network charges and tap **OK** to continue and return to the main Samsung Link screen.
4. Tap **Start** and follow the on-screen prompts.
5. The screen contains two separate streaming media options:
  - **Registered storage:** allows you to receive and playback media stored externally (server, laptop, etc.) directly on your device by allowing you to add a Web storage service for streaming content.

- **Registered devices:** allows you to stream/share selected multimedia content from your device to DLNA compliant device connected to the same Wireless Access Point.

## Configuring Samsung Link Settings

Samsung Link must first be configured prior to its initial use. You must setup parameters such as connected Wi-Fi, Items to share, source server address, and external device acceptance rights.

1. From a Home screen, touch  **Apps** → **Samsung Link** .
2. Press  and configure the following settings as desired:
  - **Refresh:** allows you to refresh the screen.
  - **Register your storage:** allows you to add a Web storage location. Without a storage service/location added, you will not be able to use Samsung Link.
  - **Nearby devices:** view available devices .
  - **My Account:** view and update your account information.
  - **Settings:**

- **Registered storage:** allows you to add a Web storage location. Without a storage service/location added, you will not be able to use Samsung Link.
- **Registered devices:** displays the name of all devices you have registered for use with Samsung Link. Tap the name of this device to change the device name.
- **Setting up web services:** allows you to set up connections to Facebook, Twitter, YouTube, Picasa and Flickr.
- **Auto Upload:** allows you to setup automatic upload of images from your device to those storage locations specified within the Web storage list.
- **Video quality settings:** allows you to optimize video quality for streamed video content. Touch the selection box to place a checkmark in the box.
- **Lock Samsung Link:** allows you to restrict access to Samsung Link by requiring a user enter the currently active and associated Samsung account password. Touch the selection box to place a checkmark in the box.
- **Language:** select the display language for Samsung Link.
- **About this service:** displays version and license information about Samsung Link.

- **Customer support:** allows you access to Help information.




- **FAQ:** Opens Samsung Link's FAQ (Frequently Asked Questions) web page.


## Sharing Media via Samsung Link to a Target Device

---

**Important!** Make sure all communicating devices are connected to the same Wi-Fi.

---

1. Launch Samsung Link on the target device (such as an Internet TV, Samsung Tablet, etc.).
1. From a Home screen, touch  **Apps** → **Samsung Link** .
2. Tap your device name from the **Devices** list.
3. Tap an available category tab (Photos, Music, Videos, Files) and select a file.
  - Touch and hold to select multiple files.
  - A file with  in the upper-left indicates it is stored externally on a memory card or in a web storage location. Selecting this media causes your device to access the file from its current location.

4. Tap an available on-screen file, image, or video to place a green check mark in the selection box.
5. Tap  to begin streaming the selected files.
6. On a target device (for example, an Internet TV) select the on-screen **Allow** button to continue.

---



**Note:** At this stage your device is requesting access to share media with the external source.

---

## Settings

Configure your device to your preferences.

For more information, refer to “Settings” on page 111.

- From a Home screen, touch  **Apps**  
→  **Settings**.



## Smart Remote

Allows you to locate and watch programming on your tv and then control your entertainment system with gestures from the device.

For more information, go to: <http://www.peel.com>.

Discover and control TV programming right from your device. Lose your remotes, once and for all. Quit scrolling those tiresome grid guides. See what you want, right at your own fingertips: your shows, your controls, your friends.



Peel suggests Top Pick TV shows for you based on what you watch and like. Instead of a long, boring channel grid, Peel presents an easy-to-use mosaic of your favorite shows, filtered by type and genre in the order you like.

1. From a Home screen, touch  **Apps**  
→  **Smart Remote**.  
The Samsung Disclaimer displays.
2. Touch **Agree**.
3. Touch Set Up Smart Remote Now: **Choose Your Country or Region**.
4. Follow the on-screen instructions.

## Talk

Use Google Talk to chat with other Google Talk users.

For more information, refer to “Google Talk” on page 51.

- From a Home screen, touch  **Apps** →  **Talk**.



## Video Hub

Samsung Video Hub provides a platform for downloading and viewing of movies, television shows and other entertainment content.

---

**Note:** Video Hub service requires a Samsung account and depends on service availability.



---

1. From the Home screen, tap  → **Video Hub** .
2. Follow the online instructions to rent or buy media.

## Video Player



View and manage videos stored on your tablet.


For more information, refer to “*Video Player*” on page 70.

- From a Home screen, touch  **Apps**  
→  **Video Player**.

## Voice Search




To use Voice Search:

1. From a Home screen, touch  **Apps**  
→  **Voice Search**.

2. Touch  and speak the search criteria slowly and clearly. Google searches for the information and displays results or displays **Retry**.

## World Clock

View the date and time in any time zone.

1. From a Home screen, touch  **Apps**  
→  **World Clock**.  
A map of the world displays with the locations you have added flagged.
2. Touch  **Add** to add a location to display.  
A list of world locations displays in landscape mode.
3. Scroll through the list and touch the city you want to add.

---






**Tip:** Touch the first letter of the location’s name, to the right of the list, to find it more quickly.

---


– or –

In portrait or landscape mode, touch and turn the globe to find a location you want to add and touch it.

A pop-up displays the name, the current time and date there, and the GMT offset.







4. To add the location, touch  **Add** on the pop-up.
5. To change the order of the locations, touch  **Reorder**. Touch the grid  on an entry and drag the entry to a new position in the list. Touch **Done** to change the order.
6. Touch  **Remove** to delete entries. Touch the box next to the locations you want to delete so that a  check mark displays, then touch **Delete**.
7. Touch and hold an entry to remove it or to set the **DST settings**, which enable or disable Daylight Savings Time adjustments.

Follow the on-screen instructions.

5. For more information touch  **Menu** → **Help**.

## YouTube

View and upload YouTube videos, right from your device.


1. From a Home screen, touch  **Apps** →  **YouTube**.
2. Touch  **Search YouTube** and use the keyboard to enter a keyword or phrase. Touch  on the keyboard to initiate the search.
3. From the YouTube main screen, touch  **Menu** for options.
4. Touch  **Menu** → **Settings**.

## Section 10: Settings

---

This section explains Settings for customizing your device.


### Accessing Settings

- From a Home screen, touch  **Apps** →



**Settings**.

– or –

From any screen, pull down the Quick Settings bar, then touch  **Settings**. For more information, refer to “Quick Settings” on page 17.

The Settings screen displays.

### The Settings Screen

The Settings screen has tabs on the left side of the screen. Information related to the tabs displays on the right side of the screen. There are five groups of settings: Wireless and networks, Device, Personal, Accounts and System.

### Wi-Fi

Your device supports Wi-Fi a/b/g/n. Use Wi-Fi settings to manage your device's Wi-Fi connections.

For more information about using your device's Wi-Fi features, see “Wi-Fi” on page 79.


### Turning Wi-Fi On or Off

When you turn Wi-Fi service on, your device automatically searches for available, in-range Wireless Access Points (WAPs).

- From any screen, pull down the Quick Settings bar, then touch **Wi-Fi** from the Quick Settings menu.

For more information, refer to “Quick Settings” on page 17.

– or –

From a Home screen, touch  **Apps** →






**Settings**. On the Wi-Fi tab, touch the **OFF / ON** icon



to turn Wi-Fi on or off.




### Scan for Wi-Fi Networks

To make sure you have an accurate list of Wi-Fi networks.

- From a Home screen, touch  **Apps** →  **Settings** →  **Wi-Fi**, and then touch **Scan**.

## Add Wi-Fi Network

To open a dialog where you can add a Wi-Fi network by entering its Network SSID (the name it broadcasts), security type, and other properties:

1. From a Home screen, touch  **Apps** →  **Settings** →  **Wi-Fi**, and then touch **Add Wi-Fi network**.
2. Use the keyboard to enter **Network SSID**.
3. Touch the **Security** field and then touch a security type.

---





**Note:** Depending on the Security protocol used by the WAP, additional network information may be required, such as a Password.

---


4. If necessary, touch **Password** and enter the password or hex key.
5. Touch **Save**.

## Advanced Settings

Set up and manage wireless access points.

1. From a Home screen, touch  **Apps** →  **Settings** →  **Wi-Fi**.
2. Touch  **Menu** → **Advanced**.

The following options display:

- **Network notification:** Have your device alert you to new Wireless Access Points (WAPs). Touch **Network notification** to turn notifications On or Off. When enabled, a check mark  appears in the check box.
- **Keep Wi-Fi on during sleep:** Specify when to disconnect from Wi-Fi. Option are: Always, Only when plugged in, or Never.
- **Check for Internet service:** Checks if Wi-Fi internet service is available when connected to an AP (Access Point).
- **MAC address:** View your device's MAC address, required when connecting to some secured networks (not configurable).
- **IP address:** View your device's IP address.

## Wi-Fi Direct Settings





You can configure your device to connect directly with other Wi-Fi capable devices. This is an easy way to transfer data between devices. These devices must be enabled for Wi-Fi Direct communication. This connection is direct and not via a hot spot or WAP.

---

**Note:** Activating this feature will disconnect your current Wi-Fi network connection.

---



1. From a Home screen, touch  **Apps** →  **Settings** →  **Wi-Fi**.
2. Touch the **OFF / ON** icon  to turn Wi-Fi on.
3. Touch **Wi-Fi Direct** to display Available devices.  
Your device begins to search for other devices enabled with Wi-Fi direct connections.
4. When scanning is complete, touch a device name to begin the connection process to another Wi-Fi Direct compatible device.

---

**Note:** The target device must also have Wi-Fi Direct service active and running before it is detected by your device.

---

The direct connection establishes, the status field displays “Connected”, and your connected device is displayed in the Wi-Fi Direct devices listing.

5. Touch **End connection** → **OK** to end the Wi-Fi Direct connection.

For more information, refer to “*Wi-Fi Direct*” on page 80.

## Bluetooth


Use Bluetooth settings to manage Bluetooth connections, set your device’s name, and control your device’s visibility.



### Turning Bluetooth On or Off

To turn your device’s Bluetooth service On or Off:

- From any screen, pull down the Quick Settings bar, then touch **Bluetooth** from the Quick Settings menu.  
For more information, refer to “*Quick Settings*” on page 17.

– or –





From a Home screen, touch  **Apps**

→  **Settings**. On the Bluetooth tab, touch the **OFF / ON** icon  to turn Bluetooth on or off.

For more information about using Bluetooth to exchange information with other Bluetooth devices, see “*Bluetooth*” on page 82.

## Additional Bluetooth Settings




When Bluetooth is on, additional settings are available.

1. From a Home screen, touch  **Apps** →  **Settings** →  **Bluetooth**.
2. Touch **Scan** to scan for nearby discoverable devices. After searching, touch a device to pair with it. For more information, refer to “*Pairing with a Bluetooth Device*” on page 82.
3. Touch  **Menu** and select a Bluetooth setting to configure:
  - **Rename device:** Your device’s default name displays on screen. Touch to change the device name. Available when Bluetooth is turned On.
  - **Visibility timeout:** Use this setting to control when to automatically turn off the Discoverable option: 2 minutes, 5 minutes, 1 hour, or Never timeout.
  - **Received files:** Show the list of files received by using Bluetooth.

## Data Usage

Monitor and manage your device’s data usage capabilities.


Features include activation/deactivation of network data usage, set mobile data usage for a set period of time, and view application data usage.

1. From a Home screen, touch  **Apps** →  **Settings** →  **Data usage**.
2. Tap the **Data usage cycle** button and select either the current cycle or define your own by selecting **Change cycle**.

---



**Note:** Data is measured by your device. Your service provider may account for data usage differently.

---

3. Touch the  **Menu** and the following options display:
  - **Auto-sync data:** allows your accounts to automatically sync
  - **Mobile hotspots:** displays available mobile hotspots.

## More Settings

This tab displays additional wireless and network information.

- From a Home screen, touch  **Apps** →  **Settings** → **More settings**.

Options display for Flight mode, VPN, Nearby devices, AllShare Cast, and Kies via Wi-Fi.

## Flight Mode



Flight mode allows you to use many of your tablet's features, such as Camera, Games, and more, when you are in an airplane or in any other area where accessing data is prohibited.


---

**Important!** When your tablet is in Flight Mode, it cannot access online information or applications.

---

- Press and hold the **Power** button then touch **Flight mode**.  
– or –

From a Home screen, touch  **Apps** →  **Settings** → **More settings** → **Flight mode**, touch the check box, and then touch **OK** to turn on flight mode.

A check mark  appears in the check box when Flight mode is On.

A list of the available access points displays. The active access point displays a green, filled circle to the right of the name.

## VPN

The VPN settings menu allows you to set up and manage Virtual Private Networks (VPNs).



---

**Important!** Before you can use a VPN you must establish and configure one.

---

## Adding a Basic VPN

Before you add a VPN you must determine which VPN protocol to use: PPTP (Point-to-Point Tunneling Protocol), L2TP/IPSec PSK (Pre-shared key based L2TP/IPSec), L2TP/IPSec RSA, IPSec Xauth PSK, IPSec Xauth RSA, IPSec Hybrid RSA.

1. Before using VPN, you must first set up a screen unlock PIN or password. For more information, refer to “Lock Screen” on page 124.
2. From the Home screen, touch  **Apps** →  **Settings** → **More settings** → **VPN**.
3. Tap **Add VPN network**.
4. Enter a name for the VPN network in the **Name** field.
5. Select a VPN type from the **Type** drop-down menu. The options are:

- PPTP (Point-to-Point Tunneling Protocol)
  - L2TP/IPSec PSK (Layer 2 Tunneling Protocol / Internet Protocol Security Pre-Shared Key)
  - L2TP/IPSec RSA
  - IPSec Xauth PSK
  - IPSec Xauth RSA
  - IPSec Hybrid RSA
6. Enter the Server address and any other required fields (dependent upon the **Type** selected).
  7. Tap the **PPP encryption (MPPE)** check box to use the MPPE protocol for encryption.
  8. Tap the **Show advanced options** check box to display additional VPN options.
  9. Tap **Save** to save your VPN settings.

## Nearby Devices




This option allows you to share your media files with nearby DLNA (Digital Living Network Alliance) enabled devices.

---

**Warning!** If file sharing is enabled, other devices can access your data. Use the Wi-Fi network and this option with care.



---

To configure this option:

1. From a Home screen, touch  **Apps** →  **Settings** → **More settings** → **Nearby devices**.
2. Touch **File sharing** to turn File sharing on.  
A check mark  appears in the check box when File sharing is On.
3. In the Advanced section, set the following options:
  - **Shared contents:** Select the content to share. Choices are: Videos, Photos, and Music.
  - **Device name:** Enter the name for your device. The default is the model number: SGH-I467M.
  - **Allowed devices list:** Indicate the devices accessible to your device.
  - **Not-allowed devices list:** Indicate the devices not accessible to your device.
  - **Download to:** Set whether to download data to Device or SD card.
  - **Upload from other devices:** If a nearby device attempts to upload data, this setting indicates the response. Options are: Always accept, Always ask, and Always reject.

## Kies via Wi-Fi



Samsung Kies is a software that enables you to update your device firmware, synchronize files, and transfer data to and from your device directly by connecting to the PC. Kies via Wi-Fi allows you to access Samsung Kies using a Wi-Fi network.

1. From a Home screen, touch  **Apps** →  **Settings** → **More settings** → **Kies via Wi-Fi**.
2. Select the source of the Wi-Fi connection for Kies air.

For more information, refer to “Kies Via Wi-Fi” on page 84.

## Home screen mode







Home screen mode allows you to set your display to the conventional layout of **Basic mode** or provide an easier user experience for the first-time tablet users using **Easy mode**.

1. From the Home screen, touch  **Apps** →  **Settings** → **Home screen mode**.
2. Tap the pull-down dropbox and select one of the following options:
  - **Basic mode**: provides conventional layout for the apps and widgets on your home screens.
  - **Easy mode**: provides easier user experience for first-time tablet users on the home screens.

3. Tap **Apply**.

## Blocking Mode

When enabled, notifications for selected features are disabled.

1. From a Home screen, touch  **Apps** →  **Settings** → **Blocking mode**.
2. Touch the **OFF / ON** icon , to turn Blocking mode **ON**.
3. Touch **Disable notifications** to enable this feature.  
A check mark  appears in the check box when Disable notifications is On.
4. Touch **Disable alarm** to enable this feature.  
A check mark  appears in the check box when Disable alarm is On.
5. The **Set time** option allows you to set **Blocking mode** for a specific time range or **Always**.
6. Touch the **Always** field to disable it or configure the **From** and **To** time fields. A check mark  appears in the check box when Disable alarm and timer is On.

## Sound



### Volume

Set the volume level for all types of sounds.

---

**Note:** You can only set volume when Silent Mode is disabled.

---

1. From a Home screen, touch  **Apps** →  **Settings** → **Sound** → **Volume**.
2. Touch and drag the sliders to set the volume for:
  - **Music, video, games and other media:** Sounds made by music apps, video apps, and more.
  - **Notifications:** Sounds for alerts to other events.
  - **System:** Application sounds and other sounds made by your device.

---

**Tip:** You can also set System volume from the Home screen by pressing the Volume Key.

---

3. Touch **OK** to save your settings.



### Vibration intensity

1. From a Home screen, touch  **Apps** →  **Settings** → **Sound** → **Vibration intensity**.

2. Touch and drag the sliders to set the Vibration intensity:
  - **Notification:** Vibration intensity for alerts to other events.
  - **Haptic feedback:** Vibration intensity for the Haptic feedback.
3. Touch **OK** to save your settings.



### Default Notifications

Select a default ringtone for message, alarm, and other notifications.

1. From a Home screen, touch  **Apps** →  **Settings** → **Sound** → **Default notifications**.
2. Touch a ringtone to hear a sample and select it.
3. Touch **OK** to save the setting.

### System

You can activate or deactivate both touch and screen lock sounds.

1. From a Home screen, touch  **Apps** →  **Settings** → **Sound**.
2. Touch **Touch sounds** or **Screen lock sound** (both default to On).




When enabled, a check mark  appears in the check box.


3. Touch **Haptic feedback** to enable a vibration when softkeys are pressed.

When enabled, a check mark  appears in the check box.

## Display

In this menu, you can change various settings for the display.

1. From a Home screen, touch  **Apps** →  **Settings** → **Display**:
  - **Wallpaper**: allows you to set the Wallpaper for your Home screen, Lock screen, or both.
  - **Notification panel**: allows you to set the brightness of your notification panel and also select the quick setting buttons that you want to display at the top of the notification panel. For more information, refer to “*Quick Settings*” on page 17.
  - **Multi window**: tap this option to enable/disable the automatic Multi window feature.
  - **Page buddy**: allows context related pages to be created on the Home screen. You can select S Pen page, Earphones page, Docking page, and Roaming page. Tap Page buddy help for more information. Touch and slide the Page buddy slider to the right to turn it on .



- **Screen mode**: allows you to select from several different color modes.
- **Reading mode**: optimizes the screen for reading on selected applications. Touch and slide the Reading mode slider to the right to turn it on .
- **Brightness**: configures the LCD Brightness levels. To adjust the brightness, tap Automatic brightness to remove the checkmark, then drag the slider to the desired brightness and tap OK.
- **Screen timeout**: adjusts the delay time before the screen automatically turns off. Selections are: 15 seconds, 30 seconds, 1 minute, 2 minutes, 5 minutes, 10 minutes, and 30 minutes.
- **Smart stay**: when activated, your screen stays on as long as you are looking at it.
- **Font style**: allows you to set the font style that your tablet will use. You can also tap Get fonts online to choose from a wider selection.
- **Font size**: allows you to select which size of font is displayed.
- **Increase legibility**: enhances the clarity of text.

- **Touch key light duration:** allows you to set the time that the touch keys located on the bottom of your tablet are lit.
- **Display battery percentage:** allows you to see the battery charge percentage next to the battery charge icon at the top of the display.

## Storage

From this menu you can view the device memory or mount, unmount, or format an SD card.

### Device Memory



- From a Home screen, touch  **Apps** →  **Settings** → **Storage**.

The Device memory displays as Total space; Applications; Pictures, videos; Audio; Downloads; Miscellaneous files; and Available.



### SD Card

When a memory card has been installed in your device, the SD card memory displays as Total space and Available space.

### Mounting an SD Card

1. Install an SD card. For more information, refer to “*Installing a Memory Card*” on page 6.
2. From a Home screen, touch  **Apps** →  **Settings** → **Storage**.
3. Touch **Mount SD card**.

### Unmounting an SD Card

1. From a Home screen, touch  **Apps** →  **Settings** → **Storage**.
2. Touch **Unmount SD card**.
3. At the prompt, select **OK** to safely unmount the memory card.
4. Remove the SD card from the slot. For more information, refer to “*Removing a Memory Card*” on page 6.

---



**Note:** Unmounting an SD card may stop some applications from functioning. These applications may not be available until you mount the SD card again.

---






## Formatting an SD Card

When formatting an SD card you will want to backup your music and photo files that are stored on the card because formatting the SD card deletes all the stored data.

1. From a Home screen, touch  **Apps** →  **Settings** → **Storage**.
2. Touch **Format SD card** and then touch **Format SD card** again on the warning screen.
3. Touch **Erase everything**.



## Power Saving Mode

When enabled, your device automatically analyzes the screen and adjusts the brightness to conserve battery power.

1. From a Home screen, touch  **Apps** →  **Settings** → **Power saving mode**.
2. On the Power saving tab, touch the **OFF / ON** icon  to turn Power saving on or off.
3. Turn Power saving on and touch the Power saving mode settings (**CPU power saving**, **Screen power saving**, **Turn off haptic feedback**) to enable or disable them.
4. Touch **Learn about Power saving mode** to display more information about saving power mode.

## Battery

See how much battery power is used for device activities.

1. From a Home screen, touch  **Apps** →  **Settings** → **Battery**.  
The battery level displays in percentage. The amount of time the battery has been used since the last charge also displays. Battery usage displays in percentage per application.
2. Touch the various applications to view how they are affecting battery use.

---

**Note:** Other applications may be running that affect battery use.

---

## Application Manager

You can download and install applications from Google Play or create applications using the Android SDK and install them on your device. Use Application manager settings to manage applications.



---

**Warning!** Because this device can be configured with system software not provided by or supported by Google or any other company, you operate this device at your own risk.

---



## Memory Usage


See how memory is being used by Downloaded or Running applications.

1. From a Home screen, touch  **Apps** →  **Settings** → **Application manager**.
2. Touch **Downloaded**, **Running** or **All** to display memory usage for that category of applications.  
The graph at the bottom of the Downloaded tab shows used and free device memory. The graph at the bottom of the Running tab shows used and free RAM.

## Downloaded



Displays apps you have downloaded onto your device.

1. From a Home screen, touch  **Apps** →  **Settings** → **Application manager**.
2. Touch **Downloaded** to view a list of all the downloaded applications on your device.

3. To switch the order of the lists displayed in the Downloaded tabs, touch  **Menu** → **Sort by size** or **Sort by name**.
4. Touch an application to view and update information about the application, including memory usage, default settings, and permissions.



The following options are displayed:

- **Force stop:** Stops an app that is misbehaving. Restart your device if stopping an app, process, or service causes your device to stop working correctly.
- **Uninstall:** Deletes the application from the tablet.  
For more information, refer to “*Uninstalling an App*” on page 84.
- **Clear data:** Clears application data from memory.
- **Clear cache:** If the app stores data in a temporary area of the device’s memory, and the amount of information stored is displayed, touch this button to clearing the temporary storage.
- **Clear defaults:** If you have configured an app to launch certain file types by default, clear that setting.
- **Permissions:** Lists the kinds of information about your device and data to which the app has access.

5. Touch  **Menu** →  **Reset app preferences** to reset preferences set for disabled apps, disabled app notifications, default apps and background data restrictions for apps.

## Running Services

View and control services running on your device.

1. From a Home screen, touch  **Apps** →  **Settings** → **Application manager**.
2. Touch the **Running** tab.  
All the applications that are currently running on the device display.
3. Touch **Show cached processes** to display all the cached processes that are running. Touch **Show services in use** to switch back.
4. Touch one of the applications to view application information.

The following options display:

- **Stop**: Stops the application from running on the device. This is usually done prior to uninstalling the application.

---

**Warning!** Not all services can be stopped. Stopping services may have undesirable consequences on the application or Android System.

---

- **Report**: Report failure and other application information.
- 




**Note:** Options vary by application.

---



## Location Services


In order to guard your privacy, by default, your device only acquires your location when you allow it. To use Location-Based Services, you must first enable location services on your device.

### Use GPS Satellites

1. From a Home screen, touch  **Apps** →  **Settings** → **Location services**.
2. Touch **Use GPS satellites** to enable the GPS satellite. When enabled, a check mark  appears in the check box.

### Location and Google Search



1. From a Home screen, touch  **Apps** →  **Settings** → **Location services**.

2. Touch **Location and Google search** to use your location data for improved Google Search results and other Google services. When enabled, a check mark  appears in the check box.

## Lock Screen

### Screen Lock

Choose settings for unlocking your screen. For more information about using the lock and unlock features, see “*Locking and Unlocking the Touch Screen*” on page 7.

1. From a Home screen, touch  **Apps** →  **Settings** → **Lock screen**.
2. Touch **Screen lock** for these settings:
  - **Swipe**: Swipe the screen to unlock it.
  - **Face unlock**: Look at your tablet to unlock it. Follow the on-screen instructions to set up Face unlock.
  - **Face and voice**: Look at your tablet and speak a phrase to unlock it. Follow the on-screen instructions to set up Face and voice unlock.
  - **Pattern**: A screen unlock pattern is a touch gesture you create and use to unlock your device. Follow the prompts to create or change your screen unlock pattern.

- **PIN**: Select a PIN to use for unlocking the screen.
- **Password**: Create a password for unlocking the screen.
- **None**: No pattern, PIN, or password is required.





---





**Note:** Additional options are available only if you set **Screen lock** to display a lock screen (any setting other than **None**).

---

### Lock Screen Options


You can customize the Lock screen with the lock screen options.

1. From a Home screen, touch  **Settings** → **Lock screen**.
2. Touch **Lock screen options** and set the following options:
  - **Shortcuts**: Touch the **OFF / ON** icon  to turn this option on or off. Touch **Shortcuts** to add up to four application shortcuts to the lock screen.
  - **Information ticker**: Touch the **OFF / ON** icon  to turn this option on or off. Set news or stock information ticker on the lock screen. This option requires a Wi-Fi connection.
  - **Clock**: Activate or deactivate the Lock screen clock. When enabled, a check mark  appears in the check box.

- **Dual Clock:** Touch the **OFF / ON** icon  to turn this option on or off, which causes dual clock to be displayed on the lock screen when roaming.
- **Weather:** Touch the **OFF / ON** icon  to turn this option on or off, which causes weather information to be displayed on the lock screen. This option requires a Wi-Fi connection.
- **Ripple effect:** Shows a ripple effect on the lock screen. When enabled, a check mark  appears in the check box.
- **Ink effect:** Shows the ink effect on the lock screen.
- **Help text:** Display help text on the lock screen. When enabled, a check mark  appears in the check box.
- **Wake up in lock screen:** Unlock the screen using wake-up command when swipe or motion lock is enabled.
- **Set wake-up command:** Set the wake-up command if **Wake up in lock screen** is enabled.

### Popup Note on Lock Screen

Use this option to display a Popup Note on the lock screen.

1. From a Home screen, touch  **Settings** → **Lock screen**.
2. Touch **Popup Note on lock screen**.

When enabled, a check mark  appears in the check box.

### Using a Visible Pattern

When the **Make pattern visible** option is enabled, the device displays the on-screen lock grid that is used for unlocking.

---

**Note:** This option only appears when a screen lock option is active.

---

### Lock Automatically

This option allows you to define the time delay before the device automatically locks when the screen turns off.

---

**Note:** This option only appears when a screen lock option is active.

---

### Lock Instantly with Power Key

When enabled, the screen is automatically locked when the Power/Lock key is pressed.

---

**Note:** This option only appears when a screen lock option is active.

---

## Vibrate on Screen Tap

When enabled, you will feel vibration as feedback when entering an unlock pattern, PIN or password.



---

**Note:** This option only appears when a screen lock option is active.

---

## Owner Information



Use this option to enable or disable whether to show owner information on the lock screen.

1. From a Home screen, touch  **Apps** →  **Settings** → **Lock screen**.
2. Touch **Owner information** and then touch **Show owner info on lock screen** to enable or disable the option.
3. Touch the text field and use the keyboard to enter the text to display on the lock screen.

## Security

### Encryption

To require a numeric PIN or password to decrypt your tablet each time you power it on or encrypt the data on your SD card each time it is connected:



1. From a Home screen, touch  **Apps** →  **Settings** → **Security**.
  2. Touch **Encrypt device**. For more information, read the displayed help screen.
  3. Touch **Encrypt external SD card** to enable the encryption of SD card data, which requires entry of a password each time the microSD card is connected.
- 

**Tip:** Make sure your battery is charged more than 80 percent or the charger is connected. Encryption takes an hour or more.

---

### Make passwords visible



When enabled, password characters display briefly as you touch them while entering passwords.

1. From a Home screen, touch  **Apps** →  **Settings** → **Security**.
2. Touch **Make passwords visible** to enable or disable brief displays of password characters.

When enabled, a check mark  appears in the check box.




## Device Administrators

To add or remove device administrators:

1. From a Home screen, touch  **Apps** →  **Settings** → **Security**.
2. Touch **Device administrators**.

## Unknown Sources

To enable or disable installation of non-Google Play applications:

1. From a Home screen, touch  **Apps** →  **Settings** → **Security**.
2. Touch **Unknown sources**.  
An informational pop-up displays.
3. Read the message and touch **OK** to allow installation of non-Google Play applications.  
When enabled, a check mark  appears in the check box.



---

**Warning!** Enabling this option causes your tablet and personal data to be more vulnerable to attack by applications from unknown sources.

---

## Trusted Credentials

If a certificate authority (CA) certificate gets compromised or for some other reason you do not trust it, you can disable or remove it.

1. From a Home screen, touch  **Apps** →  **Settings** → **Security**.
2. Touch **Trusted credentials**.


The trusted credentials screen has two tabs:

- **System:** Displays CA certificates that are permanently installed in the ROM of your device.
  - **User:** Displays any CA certificates that you installed, for example, in the process of installing a client certificate.
3. Touch a CA certificate to examine its details.  
A scrolling screen displays the details.
  4. Scroll to the bottom of the details screen and touch **Disable** to disable a System certificate or **Remove** to remove a User certificate.

---

**Caution!** When you disable a system CA certificate, the **Disable** button changes to **Enable**, so you can enable the certificate again, if necessary. When you remove a user-installed CA certificate, it is permanently deleted and must be re-installed, if needed.

---

5. Touch **OK** to return to the certificate list.  
When enabled, a check mark  appears in the check box.



## **Install from Device Storage**

Install encrypted certificates from an installed memory card.

---

**Note:** You must have installed a memory card containing encrypted certificates to use this feature.

---

1. From a Home screen, touch  **Apps** →  **Settings** → **Security**.
2. Touch **Install from device storage**, then choose a certificate and follow the prompts to install.



## **Clear Credentials**

Clear stored credentials.

---

**Note:** This setting only appears if you have installed encrypted certificates.



---

1. From a Home screen, touch  **Apps** →  **Settings** → **Security**.
2. Touch **Clear credentials** to remove all certificates.

## **Language and Input**



### **Language**

Set the language used by your device.

1. From a Home screen, touch  **Apps** →  **Settings** → **Language and input** → **Language**.
2. Touch a language / locale from the list.

### **Keyboards and Input Methods**


Set the keyboard used by your device.

1. From a Home screen, touch  **Apps** →  **Settings** → **Language and input**.
2. Touch **Default** and select an input method (Samsung keyboard).  
– or –




Tap **Set up input methods** to configure the available input methods.

## Google voice typing Settings

- Touch  next to Google voice typing to display the following options:
  - **Choose input languages:** tap on a language that you want to input. Select Automatic to use the local language or select a language from the list.
  - **Block offensive words:** tap to create a checkmark and enable the blocking of recognized offensive words from the results of your voice-input Google typing.
  - **Download offline speech recognition:** Enables voice input while offline. Touch the All tab to download speech recognition for other languages.

## Samsung Keyboard Settings

To configure the Samsung keyboard:


- Touch  next to Samsung keyboard to display the following options:

- **Input languages:** Used to set a default text entry language. Touch this field, scroll through the options, and touch the desired input language. When activated, a check appears in the box.
- **Predictive text:** Enable or disable XT9 predictive text. When enabled the system suggests words matching your text entries, and, optionally, completes common words automatically.  
When XT9 is enabled, touch the **Predictive text** field to set the following options:
  - **Personalized data:** Enter personalized data to improve prediction results.
  - **Learn from Gmail:** Log in to let your device learn your Gmail Style.
  - **Learn from Facebook:** Log in to let your device learn your Facebook Style.
  - **Learn from Twitter:** Log in to let your device learn your Twitter Style.
  - **Clear remote data:** Delete your anonymous data stored on the personalization server.
  - **Clear personalised data:** Remove all personalized data entered.

- **Continuous input:** Enable or disable the Continuous input feature. When enabled, you can enter text by sliding your finger across the keyboard.
- **Cursor control:** Move cursor by sliding finger across keyboard.
- **Pen detection** displays the handwriting pad whenever the pen is detected.
- **Handwriting:** Touch to display the following options:
  - **Recognition type:** sets the stroke recognition for the content.
  - **Recognition time:** Set the recognition time to 100, 300, 500, 1000, or 2000 milliseconds.
  - **Pen thickness:** Set the pen thickness to 1, 3, 5, 7, or 9 pixels.
  - **Pen colour:** Choose a pen colour.
  - **Gesture guide:** Displays examples of the various gestures that can be used to edit handwriting.
  - **Tutorial:** Help for using Handwriting recognition.
  - **About:** Displays information about the handwriting software.
- **Advanced** displays the following advanced options:
  - **Auto capitalisation** automatically capitalizes the first letter of the first word in each sentence (standard English style).
  - **Auto spacing:** automatically inserts spaces between words.
  - **Auto-punctuate** automatically inserts a full stop in a sentence by tapping the space bar twice when using the on-screen QWERTY keyboard.
  - **Character preview** provides an automatic preview of the current character selection within the text string. This is helpful when multiple characters are available within one key.
  - **Key-tap vibration** enables vibration feedback when you tap an on-screen key.
  - **Key-tap sound** enables auditory feedback when you tap an on-screen key.
- **Tutorial:** Displays help for using the Samsung keyboard and XT9 predictive text.
- **Reset settings:** Reset keyboard settings except XT9 my words and auto-substitution.



## Speech Settings


To set the speech settings for Voice search:

1. From a Home screen, touch  **Settings** → **Language and input**.
2. Touch **Voice search** to configure:
  - **Language:** Choose a language for your voice input.

- **Speech output:** Always provides audible readout of text, or only when using Hands-free functions.
- **Block offensive words:** Enable or disable blocking of recognized offensive words from the results of your voice-input Google searches.
- **Download offline speech recognition:** Enable voice input while offline. Touch the **All** tab to download speech recognition for other languages.
- **Bluetooth headset:** Records audio through a Bluetooth headset when connected.



Voice output provides audible readout of text, for example, the contents of email messages.

1. From a Home screen, touch  **Settings** → **Language and input**.
2. Touch **Text-to-speech output** and select the preferred TTS engine.
3. Touch  next to the preferred TTS engine and configure.
4. Configure the following:
  - **Speech rate:** Set the speed at which the text is spoken.

- **Listen to an example:** Play a sample of speech synthesis (available if voice data is installed).
- **Driving mode:** New notifications are read aloud when enabled. Touch the **OFF / ON** icon  to enable, then touch **Driving mode** to display the Driving mode settings: New emails, Alarm, Schedule, and Unlock screen.



## Mouse/trackpad

This option sets your Pointer speed for your mouse or trackpad when you are using a keyboard dock accessory.

1. From a Home screen, touch  **Apps** →  **Settings** → **Language and input**.
2. Touch **Pointer speed** then drag the slider to the right to go faster or to the left to go slower.
3. Touch **OK** to save your setting.

## Cloud

Back up your personal data using your Samsung Account or use a Dropbox account to sync your device content.

1. From a Home screen, touch  **Apps** →  **Settings** → **Cloud**.
2. Under **Personal data management:**

If you have not signed in to your Samsung Account, touch **Add account**.

If you have signed in to your Samsung Account:

- Touch your Samsung Account to manage your sync settings or remove your Samsung Account.
  - Touch **Sync settings** to sync your calendar, contacts, Internet, and S Note settings with your Samsung Account.
  - Touch **Device backup** to manage your back up and restore options.
3. Under **Contents sync (with Dropbox)**:
- Touch **Set account** to set up your Dropbox account and sync device content.



## Back Up and Reset

You can also back up your data to the Google server and reset your device to its factory defaults.

### Backup and Restore

#### Back Up My Data



Enable or disable backup of your information to the Google server.

1. From a Home screen, touch  **Apps** →  **Settings** → **Backup and reset**.

2. Touch **Back up my data** to enable or disable back up of application data, Wi-Fi passwords, and other settings to the Google server.



#### Backup Account

If you have enabled the **Back up my data** option, then the **Backup account** option is available.

1. From a Home screen, touch  **Apps** →  **Settings** → **Back up and reset**.
2. Touch **Backup account** and touch your Google Gmail account or touch **Add account** to set your Google Gmail account to be backed up to the Google server.

#### Automatic Restore



When enabled, backed-up settings are restored when you reinstall an application.

1. From a Home screen, touch  **Apps** →  **Settings** → **Back up and reset**.
2. Touch **Automatic restore** to enable or disable automatic restoration of settings from the Google server.

## Personal Data

### Factory Data Reset

Use Factory data reset to return your device to its factory defaults. This setting erases all data from the device, including Google or other email account settings, system and application data and settings, and downloaded applications, as well as your music, photos, videos, and other files. If you reset the tablet in this way, the next time you turn on your tablet you are prompted to reenter the same kind of information as when you first started Android.

1. From a Home screen, touch  **Apps** →  **Settings** → **Backup and reset**.
2. Touch **Factory data reset**.  
The Factory data reset screen displays reset information.
3. Touch **Reset device**, then follow the prompts to perform the reset.

---

**Note:** If you have set up your Samsung account, it has to be deleted before performing this function. For more information, refer to “*Adding an Account*” on page 133.

---



## Accounts

Set up and manage accounts, including your Google accounts, Samsung accounts, and email accounts.

Your device provides the ability to synchronize information from a variety of accounts, including Email, Facebook, Google, and your Samsung account. Depending on the account, you can choose to synchronize your calendar, contacts, and other types of content.

With synchronization, you can ensure that the information on your device is updated with any information that changes in your accounts.

### Adding an Account



1. From a Home screen, touch  **Apps** →  **Settings** and then navigate to the **Accounts** area.
2. Tap **Add account** and select one of the account types.
3. Use the keyboard and follow the prompts to enter your credentials and set up the account.
4. A green button will appear next to the account type once you have created an account. Your accounts will also be displayed in the **Accounts** section of the main Settings menu.

## Removing an Account

---



**Important!** Removing an account also deletes all of its messages, contacts, and other data from the device.

---

1. From a Home screen, touch  **Apps** →  **Settings** and then navigate to the **Accounts** area.
2. Tap the account name.
3. From the Accounts area of the screen, tap the account name.
4. Tap **Remove account**, then tap **Remove account** at the prompt to remove the account and delete all its messages, contacts, and other data.

## Synchronizing a Accounts

By default, all managed accounts are synchronized. You can also manually sync all current accounts.



1. From a Home screen, touch  **Apps** →  **Settings** and then navigate to the **Accounts** area.
2. Tap the account type.
3. Tap **Sync all** to synchronize all your accounts of the same type.

– or –

Tap an account name. Tap selection boxes next to the available account components to add or remove checkmarks that indicate the component will be synchronized (for example, a Gmail account can sync Calendar, Contacts, Gmail, Google Photos, and more). Tap **Sync now** to synchronize the account.

## Motion

It is possible to control certain aspects of your tablet by simply tilting it. You can tilt your tablet to reduce or enlarge the screen. You can move an icon from one Home page to another by panning your device to the left or right while holding the icon.



1. From a Home screen, touch  **Settings** → **Motion**.
2. The following options are available:
  - Touch the **OFF / ON** icon  to activate each option.
  - **Palm swipe to capture:** Once enabled, you can capture any on-screen information swiping across the screen. In a single motion, press the side of your hand on the screen and swipe from left to right. The image is then copied to the clipboard.

- **Palm touch to mute/pause:** Once enabled, you can pause any on-screen video or mute any current sound by simply covering the screen with your hand. Once you remove your hand from the screen, the device goes back to normal by either continuing to play the current video or unmuting the current sound.
- **Learn about hand motions:** Choose this option to display on-screen instructions for the **Palm swipe to capture** and **Palm touch to mute/pause**.

## S Pen

### Pen Attach/Detach Sound

To set the sound that is made when the pen is attached or detached from your tablet:

1. From a Home screen, touch  **Apps** →  **Settings** → **S Pen**.
2. Touch **Pen attach/detach sound**.
3. Touch **Off**, **Sound1**, **Sound2**, or **Sound3**.  
If a sound is chosen, a sound example plays.
4. Touch **OK**.



### Open Popup Note


When the S Pen is detached, a Popup note displays.

When enabled, a check mark  appears in the check box.

### Battery Saving

To extend battery life when the pen is attached:



1. From a Home screen, touch  **Apps** →  **Settings** → **S Pen**.
2. Touch **Battery saving**.


When enabled, a check mark  appears in the check box and, when the pen is attached, your tablet does not try to detect it.

### Air View

Hold the pen nib near the screen to see more information.




To enable the air view pointer when using the S Pen:

1. From a Home screen, touch  **Apps** →  **Settings** → **S Pen**.
2. Touch the **OFF / ON** icon  next to **Air view** to activate the option.

3. When enabled, touch **Air view** to enable the Pointer, Information preview, Icon labels (by pen nib), and List scrolling options. When enabled, a check mark  appears in the check box next to the option.




## Sound and Haptic Feedback

To enable or disable sound and vibration when using the S Pen:

1. From a Home screen, touch  **Apps** →  **Settings** → **S Pen**.
2. Touch **Sound and haptic feedback**.  
When enabled, a check mark  appears in the check box.



## Quick Command Settings

To create pen gestures to open selected applications or perform tasks:

1. From a Home screen, touch  **Apps** →  **Settings** → **S Pen**.
2. Touch **Quick Command settings**.  
The Quick Command settings screens displays existing gestures.
3. Touch  **Add a command** to set up a new gesture.

## S Pen Help




To view S Pen help information:

1. From a Home screen, touch  **Apps** →  **Settings** → **S Pen**.
2. Touch **S Pen help**.
3. Touch **Air view**, **Gesture**, or **Quick Command** to view the help information.

## Accessory

This menu allows you to select the Dock sound, Audio output mode, and Audio output options when using a car or desk dock.



## Dock

1. From a Home screen, touch  **Apps** →  **Settings** → **Accessory**.
2. **Dock sound:** The tablet will play sounds when inserting and removing the device from the dock when enabled.  
When enabled, a check mark  appears in the check box.
3. **Audio output mode:** Use external dock speakers when the phone is docked.





## HDMI

To set the HDMI (High-Definition Multimedia Interface) audio setting:

1. From a Home screen, touch  **Apps** →  **Settings** → **Accessory**.
2. Touch **Audio output**.
3. Touch **Stereo** or **Surround** to set the audio output setting.

## Date and Time

By default, your device receives date and time information from the wireless network. When you are outside network coverage, you may want to set date and time information manually using the Date & time settings.

1. From a Home screen, touch  **Apps** →  **Settings** → **Date and time**.
2. Tap **Automatic date and time** to allow the network to set the date and time.
3. Tap **Automatic time zone** to allow the network to set the time zone.

---

**Important!** Deactivate **Automatic date and time** to manually set the rest of the options.

---

4. Tap **Set date** and tap the up and down arrows to set the **Month, Day, and Year** then tap **Set**.
5. Tap **Set time** and tap the up and down arrows to set the **Hour, Minute, and PM/AM**, then tap **Set**.
6. Tap **Select time zone**, then tap a time zone.
7. Optional: Tap **Use 24-hour format**. If this is not selected the tablet automatically uses a 12-hour format.
8. Tap **Select date format** and tap the date format type.

## Accessibility



Accessibility services are special features to make using the device easier for those with certain physical disabilities. Use the Accessibility settings to activate these services.

---

**Note:** You can download accessibility applications from Google Play and manage their use here.

---

## System Accessibility

1. From a Home screen, touch  **Apps** →  **Settings** → **Accessibility**.
2. Configure the following settings:

- **Auto-rotate screen:** When this option is checked, the screen orientation changes when you rotate the device. When this option is not checked, the screen orientation locks in the current orientation (landscape or portrait) and the orientation does not change when you rotate the device.

---

**Tip:** Swipe down from the top of the screen to display the Quick Settings panel. Touch **Screen rotation** to enable or disable the auto-rotate feature. For more information, refer to “Quick Settings” on page 17.

---

- **Screen timeout:** Select the screen delay time the screen delays shutting off after inactivity for the selected period of time.
- **Lock automatically** to lock the screen automatically after a selected amount of time.

---

**Note:** The Lock automatically function is only available if your device is already using the screen lock feature.

---

- **Speak passwords:** Speaks passwords to enter them.
- **Accessibility shortcut:** Add a shortcut to Accessibility settings that displays when you press and hold the Power key.



## Services Accessibility

Enable or disable accessibility services.

---

**Note:** You must activate **Accessibility** before enabling services.


---

1. From a Home screen, touch  **Apps** →  **Settings** → **Accessibility**.
2. Touch **TalkBack** to activate TalkBack.

---



**Note:** TalkBack, when installed and enabled, speaks feedback to help blind and low-vision users.

---




3. Touch the **OFF / ON** icon  to turn TalkBack on.
4. Touch **Settings** to configure TalkBack.

## Vision Accessibility



To set the font size:

1. From a Home screen, touch  **Apps** →  **Settings** → **Accessibility**.
2. Touch **Font size**.
3. Touch a font size. Options are: Tiny, Small, Normal, Large, and Huge.

To set negative screen colours:

1. From a Home screen, touch  **Apps** →  **Settings** → **Accessibility**.
2. Touch **Negative colours**.  
When enabled, a check mark  appears in the check box.



To set voice output settings:


1. From a Home screen, touch  **Apps** →  **Settings** → **Accessibility**.
2. Touch **Text-to-speech output** and select the preferred TTS engine. For more information, refer to “*Speech Settings*” on page 130.

To install accessibility scripts:




1. From a Home screen, touch  **Apps** →  **Settings** → **Accessibility**.
2. Touch **Enhance web accessibility**.
3. Touch **Allow** to allow applications to install scripts from Google that make their Web content more accessible.

## Hearing Accessibility

1. From a Home screen, touch  **Apps** →  **Settings** → **Accessibility**.



2. Tap the **Sound balance** field and use the slider to set the Left and Right balance when using a stereo device.  
Touch **OK** to save or **Cancel** to discard.
3. Touch **Mono audio**. When Mono audio is enabled, you can listen through one earphone to mono audio sound.  
When enabled, a check mark  appears in the check box.

To turn off all sounds including receiver voice:

1. From a Home screen, touch  **Apps** →  **Settings** → **Accessibility**.
2. Touch **Turn off all sounds**.  
When enabled, a check mark  appears in the check box.




## Mobility Accessibility

This option allows you to set the Tap and hold delay time.

1. From a Home screen, touch  **Apps** →  **Settings** → **Accessibility**.
2. Touch **Tap and hold delay**, and then touch a delay time.  
Options are: Short, Medium, and Long.

## Developer Options

Set options for application development.

1. From a Home screen, touch  **Apps** →  **Settings** → **Developer options**.
2. Touch the **OFF / ON** icon  at the top of the screen to activate developer options.

---

**Caution!** These settings are intended for development use only. They can cause errors to occur on your device and with the applications on your device.

---

The following options are available:



- **Desktop backup password:** Protect the desktop with a backup password ID.
- **Stay awake:** The display screen does not go into sleep mode while charging.
- **Protect SD card:** Requires apps to ask your permission before accessing data on your SD card.
- **USB debugging:** When enabled, allows debugging when the device is attached to a PC by a USB cable.

- **Allow mock locations:** Used by developers when developing location-based applications.
- **Select debug app:** Allows developers to select a specific application to debug.
- **Wait for debugger:** Specified apps must have debugger attached before executing.
- **Show touches:** Displays touch interactions on the screen.
- **Show pointer location:** Highlights the data that was touched on the screen.
- **Show layout boundaries:** Displays clip bounds, margins, and so on.
- **Show GPU view updates:** Flashes views inside windows when drawn with GPU.
- **Show screen updates:** Areas of the screen flash when they update.
- **Window animation scale:** Configure the scale for animation (ranges from off to 10x).
- **Transition animation scale:** Configure the scale for transitioning when using animation (ranges from off to 10x).
- **Animator duration scale:** Configure the scale for duration when using animation (ranges from off to 10x).

- **Disable hardware overlays:** Assigns the work of rendering to the GPU.
- **Force GPU rendering:** Allows the use of 2D hardware accelerations in applications.
- **Strict mode:** Makes the screen flash when applications perform long operations on the main thread.
- **Show CPU usage:** Screen highlights the current CPU usage.
- **Profile GPU rendering:** Uses a 2D acceleration in applications.
- **Enable traces:** Enables/disables on-screen tracing based on an available parameter.
- **Do not keep activities:** Destroys every activity as soon as the application is closed.
- **Limit background processes:** Sets the number of processes that can run in the background.
- **Show all ANRs:** Displays a prompt when applications running in the background are not responding.

## About Device

View information about your device, including status, legal information, hardware and software versions, and battery use.

1. From a Home screen, touch  **Apps** →  **Settings** → **About device**.
2. Touch items to view details:
  - **Software update:** Connect to the network and download new software. For more information, refer to “*Software Update*” on page 142.
  - **Status:** View Battery status, Battery level, Network, Signal strength, Mobile network type, Service state, Roaming, Mobile network state, My phone number, IMEI (International Mobile Equipment Identity), IMEI SV, IP address, Wi-Fi MAC address, Bluetooth address, Serial number, Up time, and Device status.
  - **Legal information:** Display **Open source licenses**, **Google legal**, **Samsung legal** and **License settings** information.

---

**Tip:** To find your device's DivX<sup>®</sup> registration code and information about registering your device to play DivX protected video, touch **License settings** → **DivX<sup>®</sup> VOD**.

---

- **Model number:** Display your device's model number.
- **Android version:** Display the firmware version of your device.


- **Baseband version:** displays the baseband version loaded on this handset.
- **Kernel version:** Display the kernel version of your device.
- **Build number:** Display your device's build number.

## Software Update

The Software Update feature enables you to use your device to connect to the network and download any new software directly to your device. The device automatically updates with the latest available software when you access this option.

### Software Update Options

The Software Update feature enables you to use your phone to connect to the network and upload any new phone software directly to your phone. The phone automatically updates with the latest available software when you access this option.

1. From a Home screen, touch  **Apps** →  **Settings**  
→ **About device** → **Software update**.
2. Touch **Update** to check for updates.
3. At the **Software update** prompt, tap **OK**.

The tablet automatically updates the software.

– or –

when **The latest updates have already been installed** is displayed, tap **OK**.

4. When updating software, once the update file is downloaded, you can delay the update on the start screen by postponing it for a certain period of time. If you want to resume the update before the selected time, tap **Continue update**.



## Section 11: Health and Safety

---

### Getting the Most Out of Your Reception

#### *Keeping Tabs on Signal Strength*

The quality of each call you make or receive depends on the signal strength in your area. Your phone informs you of the current signal strength by displaying a number of bars next to the signal strength icon. The more bars displayed, the stronger the signal. If you're inside a building, being near a window may give you better reception.

#### *Understanding How Your Phone Operates*

Your phone is basically a radio transmitter and receiver. When it's turned on, it receives and transmits radio frequency (RF) signals. When you use your phone, the system handling your call controls the power level. This power can range from 0.006 watts to 0.2 watts in digital mode.

#### *Maintaining Your Phone's Peak Performance*

There are several simple guidelines for operating your phone properly and maintaining safe, satisfactory service.

- Speak directly into the mouthpiece.

- Avoid exposing your phone and accessories to rain or liquid spills. If your phone does get wet, immediately turn the power off and remove the battery. If it's inoperable, return it to a dealer store or call Customer Support for service.

---

**Note:** For the best care of your phone, only authorized personnel should service your phone and accessories. Faulty service may void the warranty.

---

### Maintaining Safe Use of and Access to Your Phone

Failure to follow the instructions outlined may lead to serious personal injury and possible property damage.

#### *Using Your Phone While Driving*

Talking on your phone while driving (or operating the phone without a hands-free device) is prohibited in some jurisdictions. Laws vary as to specific restrictions. Remember that safety always comes first.



### **When using your phone in the car:**

- Get to know your phone and its features, such as speed dial and re-dial.
- When available, use a hands-free device.
- Position your phone within easy reach.
- Let the person you are speaking to know you are driving. If necessary, suspend the call in heavy traffic or hazardous weather conditions.
- Do not take notes or look up phone numbers while driving.
- Dial sensibly and assess the traffic. If possible, place calls when stationary or before pulling into traffic.
- Do not engage in stressful or emotional conversations that may divert your attention from the road.
- Dial 911 to report serious emergencies. It's free from your wireless phone.
- Use your phone to help others in emergencies.
- Call roadside assistance or a special non-emergency wireless number when necessary.

---

**Note:** Always turn off the phone in health care facilities and request permission before using the phone near medical equipment.

---

### ***Turning Off Your Phone Before Flying***

Turn off your phone before boarding any aircraft. To prevent possible interference with aircraft systems, Transport Canada regulations require you to have permission from a crew member to use your phone while the plane is on the ground. To prevent any risk of interference, regulations prohibit using your phone while the plane is in the air.

### ***Turning Off Your Phone in Dangerous Areas***

To avoid interfering with blasting operations, turn off your phone when in a blasting area or in other areas with signs indicating that two-way radios should be turned off. Construction crews often use remote-control RF devices to set off explosives.

**Turn off your phone when you are in an area with a potentially explosive atmosphere. Although it is rare, your phone or its accessories could generate sparks. Sparks**

**could cause an explosion or a fire resulting in bodily injury or even death. These areas are often, but not always, clearly marked.**

**These areas include:**

- Fueling areas such as gas stations.
- Below deck on boats.
- Fuel or chemical transfer or storage facilities.
- Areas where the air contains chemicals or particles such as grain, dust, or metal powders.
- Any other area where you would normally be advised to turn off your vehicle's engine.

---

**Note:** Never transport or store flammable gas, liquid, or explosives in the compartment of your vehicle that contains your phone or its accessories.

---

### ***Restricting Children's Access to your Phone***

Your phone is not a toy. Children should not be allowed to play with it because they could hurt themselves and others, damage the phone, dial 911 by mistake, or make calls that increase your phone bill.

### ***Warning Regarding Display***

The display on your handset is made of glass or acrylic and could break if your handset is dropped or if it receives significant impact. Do not use if screen is broken or cracked as this could cause injury to you.

### ***Caring for the Battery***

#### ***Protecting Your Battery***

The guidelines listed below help you get the most out of your battery's performance.

- Use only Samsung approved batteries and desktop chargers.  
These chargers are designed to maximize battery life. Using other batteries or chargers voids your warranty and may cause damage.
- In order to avoid damage, charge the battery only in temperatures that range from 32° F to 113° F (0° C to 45° C).
- Don't use the battery charger in direct sunlight or in high humidity areas, such as the bathroom.
- Never dispose of the battery by incineration.
- Keep the metal contacts on top of the battery clean.
- Don't attempt to disassemble or short-circuit the battery.
- The battery may need recharging if it has not been used for a long period of time.

- It's best to replace the battery when it no longer provides acceptable performance. When used correctly, the battery can be recharged hundreds of times before it needs replacing.
- Don't store the battery in high temperature areas for long periods of time. It's best to follow these storage rules:
  - Less than one month:  
-4° F to 140° F (-20° C to 60° C)
  - More than one month:  
-4° F to 113° F (-20° C to 45° C)

### **Disposal of Lithium Ion (Li-Ion) Batteries**

For safe disposal options of your Li-Ion batteries, contact your nearest service center.

**Special Note:** Be sure to dispose of your battery properly. In some areas, the disposal of batteries in household or business trash may be prohibited.

---

**Note:** For safety, do not handle a damaged or leaking Li-Ion battery.

---

## **Acknowledging Special Precautions and Industry Canada Notice**

### **Cautions**

Any changes or modifications to your phone not expressly approved in this document could void your warranty for this equipment, and void your authority to operate this equipment. Only use approved batteries, antennas, and chargers. The use of any unauthorized accessories may be dangerous and void the phone warranty if said accessories cause damage or a defect to the phone.

Although your phone is quite sturdy, it is a complex piece of equipment and can be broken. Avoid dropping, hitting, bending, or sitting on it.

### **Information to User**

This equipment has been tested and found to comply with the limits of a Class B digital device. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular

installation; if this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient/relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

---

**Warning!** At very high volumes, prolonged listening to a headset can damage your hearing.

---

## **Specific Absorption Rates (SAR) for Wireless Phones**

The SAR is a value that corresponds to the relative amount of RF energy absorbed in the head of a user of a wireless handset.

The SAR value of a phone is the result of an extensive testing, measuring and calculation process. It does not represent how much RF the phone emits. All phone models are tested at their

highest value in strict laboratory settings. But when in operation, the SAR of a phone can be substantially less than the level reported to Industry Canada. This is because of a variety of factors including its proximity to a base station antenna, phone design and other factors. What is important to remember is that each phone meets strict federal guidelines. Variations in SARs do not represent a variation in safety.

All phones must meet the federal standard, which incorporates a substantial margin of safety. As stated above, variations in SAR values between different model phones do not mean variations in safety. SAR values at or below the federal standard of 1.6 W/kg are considered safe for use by the public.

The highest reported SAR value for the N5110 is:

Body: 1.08 W/Kg

This phone has been tested and meets RF exposure guidelines when used with an accessory that contains no metal and that positions the mobile device 0 cm from the body.

## Owner's Record

The model number, regulatory number, and serial number are located on a nameplate inside the battery compartment.

Record the serial number in the space provided below. This will be helpful if you need to contact us about your phone in the future.

Model: SGH-I467M

Serial No.:

# Index

---

## A

### Accessibility 137

- Hearing 139
- Mobility 139
- Services 138
- System 137
- Vision 138

### Accounts

- setting up 31

### Adobe PDF 104

### Alarm

- Turning Off 89

### Android keyboard

- configuring 40

### aNote HD 89

### App Shortcuts 22

### Application Bar 13

### Application Manager settings

- downloaded apps 122
- running services 123

### Applications 29

- downloading new 103

150

### Applications settings

- USB debugging 140

### Audio

- Output Mode 136

## B

### Back button 13

### Battery

- charging 2
- indicator 2
- installing and removing 2

### Battery Care 146

### Bluetooth

- pairing with a device 82
- settings 113
- turning on or off 82

## C

### Calendar 104

### Camcorder

- recording video 68
- settings 68

### Camera

- settings 64

- taking photos 63

### ChatON 55

### Contacts

- creating 32
- display options 33
- exporting and importing 35
- groups 35
- joining 34
- linking 34
- namecards 34
- separating joined 34
- setting a photo as contact icon 75
- starred contacts 37
- updating 32

## D

### Data Usage 114

### Developer Options

- allow mock locations 140

### DivX®

- registration code 141

### Downloads

- managing 84

**Dropbox** 95

## E

**Email**

- Combined view 49
- composing and sending 50

## F

**Firmware Update** 84

**Flight Mode** 115

**Flipboard** 95

## G

**Gallery** 72

- sharing photos and video 76
- viewing photos and video 73

**Gmail**

- account settings 48
- composing and sending 47
- refreshing your account 46
- setting up your account 45

**Google**

- Gmail 45
- Local 99
- Maps 99
- Navigation 101

Play Store 103

YouTube 110

**Google Messenger** 55

**Google Play** 103

**Google Search** 96

**Google Settings** 97

**Google Voice Typing** 43

**Google+** 55

**GPS Applications** 87

**Groups**

- creating 35

## H

**Handwriting** 42

**Health and Safety** 144

- Children 146
- Dangerous Areas 145
- Driving 144
- Flying 145

**Home screen** 11

- adding widgets 22
- folders 23
- primary shortcuts 22
- wallpaper 24

**Hotspots** 114

## I

**Icons**

- Status Bar 21

**Industry Canada** 147

**Infrared Blaster** 10

**Internet** 77

- Quick Controls 79

## K

**Kies** 84

- via Wi-Fi 117

## L

**Language and input settings**

- select language 128

**Local** 99

**Location Services Settings** 123

## M

**Maps** 99

**Memory Card**

- formatting 30
- installing 6
- removing 6

**Messages**

- email 48

- Gmail 45
- types 45
- Messenger** 55
- Mobile networks** 115
- Multi Window**
  - Activate/Deactivate 25
  - Customizing 27
  - Increase App Window Size 29
  - Maximize App 29
  - Panel Relocation 26
  - Rearrange Apps 27
  - Removing Apps 27
  - Restoring Apps 27
  - Running Multiple Apps 27
  - Switch Arrangement 28
  - Tab Repositioning 25
  - Using 25
- Music**
  - creating a playlist 59
  - Music Player 58
- Music Hub** 58
- Music Player** 58

**N**

- Namecards**

- sending 34
- Navigation** 13
  - command keys 22
  - Primary Shortcuts 22
  - screen 14
- Nearby Devices**
  - settings 116
  - status 20
- Notification Panel** 17
- Notifications** 17

**O**

- Owner's Record** 149

**P**

- Pairing with Bluetooth** 82
- Photo ID**
  - setting 75
- Photos**
  - Gallery 72
  - sharing 76
  - taking 63
- Play Books** 102
- Play Music** 57
- Play Store** 103
- Playlists**

- creating 59
- Polaris® Office** 104
- Portable Wi-Fi Hotspot** 115
- Powering On and Off** 4
- Predictive Text** 129
- Privacy settings**
  - factory data reset 133

**Q**

- Quick Controls** 79

**R**

- Readers Hub** 104
- Remote**
  - Smart 108
- Reset**
  - factory data 133

**S**

- Samsung Apps** 105
- Samsung Keyboard**
  - entering text 39
  - Settings 41
- Samsung Kies** 84
- Samsung Link** 105
  - Sharing Media 107



**Samsung Link Settings** 106  
**SAR** 148  
**Screen Capture** 98  
**Securing your device**  
locking and unlocking 7  
**Security**  
locking and unlocking 7  
**Security settings**  
device administration 127  
passwords 126  
trusted credentials 127  
**Settings** 111  
developer options 140  
Location Services 123  
**Shortcuts** 22  
**Signal strength** 144  
**Smart Remote** 108  
Set up 108  
**Snooze** 89  
**Software Update** 142  
**Sound settings**  
notifications 118  
volume 118  
**Specific Absorption Rates** 148

**Status Bar** 21

## T

**Text**

input methods 39

**Touch Screen** 7

Lock/Unlock 7

**Turning Your Device On and Off** 4

## U

**Updating Applications** 87

**USB connections**

as a mass storage device 86

**USB settings**

as a mass storage device 86

Windows Media Player 85

## V

**Video Hub** 109

**Videos**

Gallery 72

recording 68

sharing 76

**Voice Search** 96, 109

**Volume Key** 10

## W

**Widgets** 22

**Wi-Fi**

adding a connection manually 80

Direct settings 112

scanning and connecting 80

settings 111

turning on 80

turning on or off 111

**WiFi (see Wi-Fi)** 79

**Wi-Fi Direct** 20, 80

**Windows Media Player**

synchronizing with 85

**Wireless Networking**

Bluetooth 82

Wi-Fi 79

**World Clock** 109

## X

**XT9 Predictive Text** 129

## Y

**YouTube** 110