

Polaird Tablet

In the box

- Polaird Tablet
- User Manual
- USB Cable
- AC Adapter

Location of controls

Basic operation

Charging the battery:

Connect the tablet to wall outlet using the included AC adapter.

The tablet may also be charged by connecting it to a computer using the USB cable, however, it will take much longer to fully charge.

Turning on the tablet

Press and hold the **Power** button until the startup screen appears.

Turning off the tablet

For quick power-off, you can select the "Power" button on the Polaird Settings widget to turn off the tablet.

Press the **Power** button, and the **Power off dialog** appears.

Unlock (enter) the tablet

Slide the "Lock icon" to the right.

Lock (standby) the tablet

To lock or unlock the tablet, briefly press the **Power** button (Lock the device to conserve the battery).

Battery Type:

- Turn off Wi-Fi when it's not in use.
- Lock the tablet (the display is off) to shorten charging time.
- To optimize battery time and performance, adjust the Brightness and Screen timeout options in the Settings app.

Home screen

On the Home screen, you can place app shortcuts and widgets.

Home screen (left) Polaird Media widget

Home screen (center) Polaird Home widget

Home screen (right) Polaird Settings widget

Access apps & widgets screen

Press **Home** to access the Apps & widgets screens.

Placing apps & widgets on the Home screen

Press & hold an app or widget to place it on one of the Home screens.

Removing shortcuts or widgets

Press and hold the app or widget and slide it as shown below.

You can always bring the widgets back from the Widgets screen.

Connecting to Wi-Fi & downloading apps

Status Bar

The Status Bar is available on all screens and apps of the tablet.

Setting up Wi-Fi

To browse web sites, use e-mail and download apps, you must first connect the tablet to the internet.

- Swipe the Home screen to the left to access the Polaird Settings widget.
- Select "Wi-Fi Setup".
- Select a network.
- If required, enter the correct password and select "Connect".
- When the tablet is connected to a network, the Wi-Fi icon will appear on the Status Bar and "Connected" will appear under the selected network.

To conserve battery life, turn off Wi-Fi when not connected to a network.

Downloading and installing apps

After downloading the selected app store, it is possible to download and install apps directly to the tablet - these apps will appear on the Apps screen.

- Open "Settings".
- Select "Display".
- Select "Accelerometer Coordinate System".
- The default setting is "Default Coordinate System". This setting should work for most games.
- In case your game is not functioning properly, select "Special coordinate system to support some other games".

Note: Apps compatibility / games: There are many apps available on the various app stores, but unfortunately not all will be compatible with the tablet. This is because some of the apps are designed for mobile phones and require functions or specifications that are not supported by the tablet. We recommend always searching for the free or "Lite" version of an app and testing it before purchasing the paid app.

Note: Polaird and the manufacturer of this tablet are not affiliated with, connected to, or sponsored by Amazon or the Amazon app store.

Camera and video chat

Front facing camera

To access a large library of free apps and games, you need to download an app store. We have provided links to several app stores that can be easily accessed by selecting the "Download App Stores" option on the Settings widget.

- After successfully connecting the tablet to Wi-Fi, select "Download App Stores" on the Polaird Settings widget.
- Select an app store, and follow the instructions to download and install it on the tablet.
- Click here.
- Select the downloaded app store (apk file) from the Pop-up window.
- Select "Install" to install the app.
- The app store appears on the Apps screen.

Download and installing apps

After downloading the selected app store, it is possible to download and install apps directly to the tablet - these apps will appear on the Apps screen.

Games

Sometimes, while playing games, the g sensor on the tablet may not function correctly. This results in games not being controllable. To correct this problem, follow the steps below:

- Open "Settings".
- Select "Display".
- Select "Accelerometer Coordinate System".
- The default setting is "Default Coordinate System". This setting should work for most games.
- In case your game is not functioning properly, select "Special coordinate system to support some other games".

Note: Polaird and the manufacturer of this tablet are not affiliated with, connected to, or sponsored by Amazon or the Amazon app store.

Camera and video chat

Front facing camera

To access a large library of free apps and games, you need to download an app store. We have provided links to several app stores that can be easily accessed by selecting the "Download App Stores" option on the Settings widget.

- After successfully connecting the tablet to Wi-Fi, select "Download App Stores" on the Polaird Settings widget.
- Select an app store, and follow the instructions to download and install it on the tablet.
- Click here.
- Select the downloaded app store (apk file) from the Pop-up window.
- Select "Install" to install the app.
- The app store appears on the Apps screen.

Download and installing apps

After downloading the selected app store, it is possible to download and install apps directly to the tablet - these apps will appear on the Apps screen.

Games

Sometimes, while playing games, the g sensor on the tablet may not function correctly. This results in games not being controllable. To correct this problem, follow the steps below:

- Open "Settings".
- Select "Display".
- Select "Accelerometer Coordinate System".
- The default setting is "Default Coordinate System". This setting should work for most games.
- In case your game is not functioning properly, select "Special coordinate system to support some other games".

Note: Polaird and the manufacturer of this tablet are not affiliated with, connected to, or sponsored by Amazon or the Amazon app store.

Web browsing

Select "Browser" on the Home or Apps screen. You must connect to Wi-Fi before accessing the web.

Select for Browser options:

- Recent history view
- Recent history view

Mobile browser mode

Desktop (Full view) browser mode

Setting up e-mail

Select "Email" on the Home or Apps screen and follow the instructions to set up your email account on the tablet. You must connect to Wi-Fi before accessing or setting up email accounts.

Email Setup screen

INBOX screen

Photo gallery

Select "Gallery" on the Home or Apps screen to access pictures and videos stored on the tablet or Micro SD card.

Viewing pictures: Press to enlarge or shrink, and swipe to go to previous or next pictures.

Watching videos: While playing a video, tap the display to access the video controller, tap the display again to hide the controller.

Share pictures to Email, Facebook or Twitter: To utilize this feature you must have a Facebook or Twitter account and be logged in. For Email, an account must be set up for this option to appear.

Share: Share the selected picture through Email, Facebook or Twitter.

Delete: Deletes the selected picture.

Menu: Slideshow, edit and more.

Transferring and managing files

Conserving Internal Memory!

It is strongly recommended to purchase and install a Micro SD card before transferring or downloading media files.

Inserting Micro SD card

The tablet supports Micro SD cards up to 32GB (not included).

To install a Micro SD card into the tablet:

- Insert the card face up into the card slot until it clicks and locks into place.
- Once the card is mounted, the card icon appears on the Status Bar.
- To access the Micro SD card, select "File Manager" from the Apps screen.

Tip: Transfer and store media files such as music, pictures and videos on to a Micro SD card and avoid placing these types of files in the internal memory of the tablet - this will conserve the internal memory, and allow you to download more apps.

Unmount & remove the Micro SD card:

- Open "Settings".
- Select "Storage".
- Select "Unmount Micro SD card".
- If it now says to remove the card from the tablet, to remove the card, gently push it until it pops out.

A card can only be inserted one way; do not use force when inserting the card.

Make sure to unmount the card before taking it out of the tablet.

Connecting the tablet to a PC or Mac:

- Connect the included USB cable to the "USB" port of the tablet and USB port of the computer.
- The "USB connected" screen appears, select "Turn on USB storage", then select "OK".
- Press to proceed.

Minimum system requirements:
 Windows: 2000, XP, Vista, 7
 Mac OS: 10.5 or later (with USB connected)

"Removable Disk" is inserted when a Micro SD card is inserted.

Browsing files

File Manager:

To view, open, copy or delete files on the internal memory of the tablet or inserted Micro SD card, select "File Manager" on the Apps screen.

Go back to the previous folder | Go to pictures | Go to internal memory | Go to moves | Go to MicroSD card | Settings | Folder actions

Press to open | Press & hold for Options

Copy, move or delete a file or folder:

- Press and hold a file or folder until the options window appears, then select an option from the options window.
- Select a file or folder.
- If you select "Copy" or "Move", press and hold on a folder and select "Paste into folder" to copy the file there.

Use the tablet to store and play music, pictures and video files.

Music: Access music files stored on the tablet.

Music screen | Music playback screen | Music playback options

Settings

Settings app: Select and customize the options in "Settings" to conserve battery performance, manage applications, manage Wi-Fi, change display options, set passwords and more.

Online help

Select "Online Help" on the Apps screen to access:

- FAQs
- Firmware updates
- Technical support
- Product registration

Software updates

Your tablet is capable of receiving OTA over the air updates. The tablet is set to automatically check for updates, and will notify you when there is an update available.

Manually check for updates: To manually check for updates, follow the instructions below: (You must connect to Wi-Fi before checking for updates)

- On the Apps screen, select "Settings".
- Under the "System" tab, select "Software updates".
- Select "Update" to manually check for OTA updates.

You may also go to <http://www.polaird.com> to check for updates.

Software update

Resetting

In the event that the tablet freezes or does not function properly, by connecting the problem by pressing the RESET button located on the back panel (shown below).

Use a paper clip or the tip of a stylus to press the RESET button. Data stored on the tablet will not be affected by using the RESET button.

Reset

Restore

If the problem persists it may be necessary to restore the tablet to the factory default settings.

- Select "Settings" from the Apps screen.
- Select "Backup & reset".
- Select "Factory data reset" (this will erase data stored on the device so make sure to back up your data prior to using the option).

Backup & reset

Specifications

- Operating System: Android 4.0 (Ice Cream Sandwich)
- Processor: ARM Cortex-A8
- Processor Speed: 1GHz
- RAM: 512MB DDR3
- Graphic Accelerator: OpenGL ES 2.0 (3D game support)
- Memory: Internal Memory: 4GB
- External Memory: Micro SD card slot
- Display: 7" capacitive multi-touch screen
- Display Resolution: 800x480 (16:9, 4 way auto rotation)
- Camera: 0.3MP Front camera
- Network: Wi-Fi (802.11 b/g/n)

* Actual internal memory may vary depending on the operating system of the device and the pre-installed apps.

Legal information

FCC Part 15: This equipment has been tested and found to comply with the requirements for a Class B digital device under Part 15 of the Federal Communications Commission (FCC) rules. These requirements are intended to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-orient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Do not attempt to repair or modify this equipment. Warning: Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.

Shielded USB cables must be used with this unit to ensure compliance with the Class B FCC limits.

PI R/P Holdings, LLC, its licensors and affiliates, fully support all electronic waste initiatives. As responsible stewards of the environment, and to avoid violating established laws, you should properly dispose of this product in accordance with all applicable regulations, directives or other governments in the area where you reside. Please check with local authorities or the retailer where you purchased this product to determine a location where you can responsibly dispose of the product.

TO OBTAIN WARRANTY SERVICE:

- Provide proof of the date of purchase within the package (Dated bill of sale).
- Include a return shipping address (not P.O. Boxes), a telephone contact number, and the defective unit within the package.
- Describe the defect or reason you are returning the product.

Your product will be repaired or replaced, at our option, for the same or similar model of equal or lesser equipment by the service center that determines this product is defective. Products received damaged as a result of shipping, will require you to file a claim with the carrier.

The shipping address of the authorized service center is:

PI-RAT, Inc.
 Attention: Customer Service (2nd Floor)
 14-C 53rd Street
 Brooklyn, NY 11222

Limited Warranty

This product is supplied and distributed new by PI-RAT, Inc. ("PI-RAT") to the original consumer purchaser is warranted by PI-RAT against defects in material and workmanship for a period of one year from your date of purchase. This warranty does not cover the product in the unlikely event that this product is defective, or does not perform properly, you may within one year from your original date of purchase return it to the authorized service center for repair or exchange.

Customer Support:
 ☎ 1-877-768-8481 (Toll Free)
 ☐ polaird@pi-rat.com or pi-rat@pi-rat.com
 Monday - Friday 8AM - 10PM (EST)

