


## WIRELESS THERMOMETER



### GET STARTED

**Step 1:** Insert 2 *new* AA batteries (not included) into the station. Observe the correct polarity.

**Step 2:** Insert 2 *new* AA batteries (not included) into the TX141-BV2 sensor. Observe the correct polarity. The red LED will flash when transmitting.

**Step 3:** After 15 minutes place the sensor outside in a shaded location.

**Note:** If the outdoor temperature is not displayed after 3 minutes, hold the **MIN/MAX/+** button for 3 seconds to search for the sensor. Press the TX button on the sensor to send a signal.

## SET TIME

1. Hold the **SET/°F/°C** button to enter time set mode.
2. To adjust values press the **MIN/MAX/+** button.
3. Press the **SET/°F/°C** button to confirm adjustments and move to the next item.

### Time setting order:

1. 12/24 Hour Time Format
2. Hour
3. Minutes



Press the **SET/°F/°C** button to exit, or wait 20 seconds without pressing buttons to return to the normal time display.

## FAHRENHEIT/CELSIUS

Press the **SET/°F/°C** button to select Fahrenheit or Celsius temperature.

## VIEW/RESET MIN/MAX TEMPERATURES

The station automatically resets min/max temperatures daily at midnight (12:00 AM).

- Press the **MIN/MAX/+** button once, to view minimum temperatures
- Hold the **MIN/MAX/+** button to reset minimum temperatures
- Press the **MIN/MAX/+** button twice, to view maximum temperatures
- Hold the **MIN/MAX/+** button to reset maximum temperatures



## TEMPERATURE TREND INDICATORS

- The **ARROWS** indicate a rising, falling or steady temperature trend (2°F/1°C) over the past three hours.
- The temperature trend indicators update every 30 minutes or less.



## POSITION OUTDOOR SENSOR

- Mount the outdoor sensor on a north-facing wall or in any well shaded area. Under an eave or deck rail is preferred.
- The maximum transmitting range to the wireless thermometer is over 300 feet (91 meters) in open air, not including walls.

## SEARCH FOR OUTDOOR SENSOR

- Hold the **MIN/MAX/+** button for 3 seconds to search for the outdoor sensor.



## LOW BATTERY ICON

Low battery icon indicates low battery for sensor or station.

- If the icon is displayed in Outdoor Temperature section, replace batteries in the outdoor sensor.
- If the icon is displayed in Indoor Temperature section, replace batteries in the station.



## SPECIFICATIONS

<b>Indoor:</b>	
Temperature Range:	+32°F to +122°F (0°C to 50°C)
Interval:	About every 30 seconds
<b>Outdoor:</b>	
Temperature Range:	-40°F to 140°F (-40°C to 60°C)
Alkaline Batteries:	-20°F to 140°F (-28.8°C to 60°C)
Lithium Batteries:	-40°F to 140°F (-40°C to 60°C)
<b>NOTE:</b>	Temperatures below - 20°F (-28.8°C) require Lithium batteries in the outdoor sensor.
Distance:	Over 300 ft. (91 meters) RF 433MHz (open air)
Interval:	About every 50 seconds
<b>Power:</b>	
Wireless Thermometer	2-AA, IEC, LR6 batteries (not included)
TX141-BV2 Sensor:	2-AA, IEC, LR6 batteries (not included)
<b>Battery Life:</b>	
Wireless Thermometer	Battery life is over 24 months when using reputable battery brands for both Alkaline and Lithium batteries
TX141-BV2 Sensor:	Battery life is over 24 months when using reputable battery brands for both Alkaline and Lithium batteries
<b>Dimensions:</b>	
Wireless Thermometer:	3"L x 1.36"W x 4.17"H (76 x 34 x 106 mm)
TX141-BV2 Sensor:	1.57" x 0.79" x 5.12" (40 x 20 x 130mm)

## CARE AND MAINTENANCE

- **Do not mix old and new batteries**
- **Do not mix Alkaline, Standard, Lithium or Rechargeable Batteries**
- Always purchase the correct size and grade of battery most suitable for the intended use.
- Replace all batteries of a set at the same time.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the batteries are installed correctly with regard to polarity (+and -).
- Remove batteries from equipment with is not to be used for an extended period of time.
- Remove used batteries promptly.

## WARRANTY AND SUPPORT INFORMATION

La Crosse Technology, Ltd. provides a 1-year limited time warranty (from date of purchase) on this product relating to manufacturing defects in materials & workmanship.

View full warranty details online at:

[www.lacrossetechnology.com/warranty\\_info.pdf](http://www.lacrossetechnology.com/warranty_info.pdf)



**For warranty work, technical support or other information contact:**

La Crosse Technology, Ltd  
2830 South 26<sup>th</sup> St  
La Crosse, WI 54601

**Contact Support:**

1-608-782-1610

**Online Product Support:**

[www.lacrossetechnology.com/support](http://www.lacrossetechnology.com/support)

**Product Registration:**

[www.lacrossetechnology.com/support/register](http://www.lacrossetechnology.com/support/register)

**Protected under U.S. Patents:**

5,978,738 | 6,076,044 | RE43903

## FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device must not be co-located or operating in conjunction with any other antenna or transmitter.

**Operation is subject to the following two conditions:**

**(1) this device may not cause harmful interference, and**

**(2) this device must accept any interference received, including interference that may cause undesired operation.**

**Caution!**

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.

All rights reserved. This manual may not be reproduced in any form, even in part, or duplicated or processed using electronic, mechanical or chemical process without the written permission of the publisher.

This booklet may contain errors or misprints. The information it contains is regularly checked and corrections are included in subsequent editions. We disclaim any responsibility for any technical error or printing error, or their consequences. All trademarks and patents are recognized.