

7 DAY WIRELESS FORECASTER

WEATHERFX

FOR MOUNTAIN SPORTS




Quick Start Guide

Bushnell®

MODEL# 950070C
 Lit #: 98-1266/08-08

LCD Display



Front Panel Buttons



- 1 Set region to view mountain areas
- 2 View current conditions for the selected mountain
- 3 Save and scroll through top 5 favorites
- 4 View Hi and Lo temperatures for next six days

Front Panel Button Operation

1. Set Region

To set the Mountain Region:

- Press “Set Region” and use +/- buttons to view regions.
- Press “Set Region” again to save.
- Use +/- to scroll through Mountain Areas within that region.

For a complete list of all mountains and their respective regions, please visit www.bushnell.com/weatherfx/ski.html

2. Mountain Data

Press (1-4 times) to view information for the selected mountain, including:

- **Base Depth** – depth of the mountain’s base snow in inches
- **Lifts** – the # of lifts at the mountain
- **Trails** – total # of ski trails on the mountain
- **% Open** – percent of the trails are currently open for use

Mountain data will “turn off” when all lifts for that mountain are closed for the winter season. At that point, the skier graphic will change to a hiker allowing your device to be used for summer activities. The snow and the mountain data will reappear when the lifts open again for the following ski season.

3. Favorite (Mountains)

The “Favorite” button allows you to save up to 5 favorite mountain areas.

- Press and hold the button until the “Favorite” icon appears next to the mountain name.  Favorites Indicator
- Press the “Favorite” button repeatedly to view each stored favorite.
- To remove a favorite, press and hold the Favorite button until the icon disappears.

4. Hi/Lo

Press the “Hi/Lo” button to view the forecasted low temperatures for the next six days at the bottom of the display. Press again to return to viewing highs.

Top Button Operation



5. Windchill

Press the “Windchill” button on top of the SkiFX to view the current temperature with windchill factor.

6. Zone

To set the time zone, press “Zone” button on top of unit. Press down repeatedly until your local time zone appears on display. The screen will save the new setting and return to the default display after 5 seconds.

7. C/F

Press to select Celsius or Fahrenheit units for all displayed temperatures.

Troubleshooting Guide

Q: What does **NO COVERAGE. TRY ANOTHER LOCATION.** mean?

A: This message will appear when your device has been unable to receive a signal for an extended period of time. Check the coverage map by visiting www.bushnell.com/weatherfx/ski.html to ensure that your location is within the coverage area. **Note:** Full signal strength will help improve and sustain battery life.

Note: Coverage is not guaranteed. Coverage areas are approximate areas within a specified zone and may include locations with limited or no coverage particularly near boundaries or in remote areas. Although service is available in most U.S. metropolitan cities, service is not guaranteed in all areas. When service is not available your device will not operate.

Parts Guide-Rear Panel



Attaching the Easel Stand



Battery Compartment w/Door Removed

Note: The SkiFX unit is not waterproof, and should only be used indoors or in a dry location.

FCC COMPLIANCE INFORMATION

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protections against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with these instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

Note: If harmful interference to radio or television reception should occur, determined by turning the product off and on, the user is encouraged to correct interference by trying one or more of the following measures:

- Relocate the receiving antenna.
- Increase the separation between equipment and receiver.
- Connect product to an outlet on a circuit different from receiver.
- Consult an experienced radio/TV technician for help.



Q: What does **Low Battery** mean?

A: The low battery indicator will flash on the display when the batteries are low and need to be replaced. **Note:** Low power may cause erratic behavior and inaccurate information.

Q: I turned on my SkiFX and the screen is totally blank.

A: Your device will be blank until it receives its first update from our network. If this continues for more than six hours, try moving your SkiFX to another location where you can receive a stronger signal, as shown on the signal strength indicator.

Q: I don't see any bars next to the signal strength indicator.

A: Your SkiFX is located in an area with poor reception. Try moving your unit closer to a window or upstairs. If your SkiFX still doesn't show any signal bars, go to www.bushnell.com/weatherfx/ski.html to verify that your location is within signal coverage. **Note:** Full signal strength will help improve and sustain battery life.

Q: The time on the clock display is off by one or more hours.

A: Press the Zone button on top of the device until your proper time zone appears. Your SkiFX should maintain accurate time from the network without further adjustments.

Q: Will this device work outside the United States?

A: At the present time, network coverage is only supported within the United States

*For additional troubleshooting tips and FAQ, please visit
www.bushnell.com/weatherfx/ski.html*

ONE-YEAR LIMITED WARRANTY

Your Bushnell SkiFX is warranted to be free of defects in materials and workmanship for one year after the date of purchase. In the event of a defect under this warranty, we will, at our option, repair or replace the product, provided that you return the product with return postage prepaid. This warranty does not cover damages caused by misuse, improper handling, installation, or maintenance provided by someone other than a Bushnell Authorized Service Department.

Any return made under this warranty must be accompanied by the items listed below:

- 1) A check/money order in the amount of \$10.00 to cover the cost of return postage and handling
- 2) Name and address for product return
- 3) An explanation of the defect
- 4) Proof of Date Purchased
- 5) Product should be well packed in a sturdy outside shipping carton, to prevent damage in transit, with return postage prepaid to the address listed below:

IN U.S.A. Send To:

Bushnell Outdoor Products

Attn.: Repairs

8500 Marshall Drive

Lenexa, Kansas 66214

©2008 Bushnell Outdoor Products



For further questions or additional information please contact:

Bushnell Outdoor Products
9200 Cody, Overland Park, Kansas 66214
(800) 423-3537 • www.bushnell.com