


SHARP

R-654M

&

R-754M

QUICK START GUIDE



- 1 DIGITAL DISPLAY
- 2 TIME keys
- 3 EXPRESS COOK keys
- 4 EXPRESS DEFROST keys
- 5 MEAL IN ONE keys
- 6 AUTO COOK key
- 7 MICROWAVE POWER LEVEL key
GRILL key
DUAL GRILL key
- 8 LESS/MORE keys
WEIGHT keys
- 9 DELAY START/CLOCK SET key
WEIGHT CONVERSION key
KITCHEN TIMER key
- 10 START/AUTO MINUTE key
STOP/CLEAR key


Read **SAFETY WARNINGS** in the Operation Manual before operating

TINS-A259URRO

1


INSTALLATION

1. Remove all packaging and accessories from the oven, including the feature sticker fixed to the outside of the door and the wrapping shown in the diagram. **DO NOT REMOVE THE WAVEGUIDE COVER**, this can be found on the right hand side wall inside your microwave. Please see page 4 in the operation manual.




2. Ensure there is at least 21cm (R-654M) or 19.5cm (R-754M) of free space above the oven.

3. Ensure the turntable parts are assembled as shown in the diagrams opposite.



Other Accessories

The racks can be used for "Grilling" or "Dual Grilling" of food.



MICROWAVING

To reheat 425g of canned soup on 70P for 6 minutes.

1. Pour the soup into a dish, cover with cling film, pierce 5 times and place in the centre of the turntable. Close the oven door.
2. Enter the cooking time by pressing the **1 MIN** key 6 times.
3. Choose the power by pressing the **MICROWAVE POWER LEVEL** key twice and then press the **START/AUTO MINUTE** key once to start cooking.
4. The display will count down through cooking time. Stir the soup halfway through the cooking time.
5. After heating, leave to stand for 2 minutes.




x2



x1

1min.

x6



STIR TURN KG/LB GRILL MICRO COOK

4

GETTING STARTED

Plug in the oven.

The oven display will flash as shown:




STIR TURN KG/LB GRILL MICRO COOK

Press the **STOP/CLEAR** key:



The display will now show:



STIR TURN KG/LB GRILL MICRO COOK

The oven is now ready for use.

To set the clock, press the **DELAY START/CLOCK SET** key and follow the instructions in Step 3 below.

NOTE:

When using the oven for the first time:

Heat the oven using **GRILL** mode without food for 20 minutes. See note on page 9 of the Operation Manual.

If you require any advice or assistance regarding your Sharp product, please visit our Website or call our Help Line.

Website:

<http://www.sharp.co.uk/support>

Help Line:

08705 274277 (U.K.)

(01) 676 0648 (Ireland)

(office hours)

SETTING THE CLOCK

Your oven is fitted with a 12 and 24 hour clock.

To set the time of day, ensure the door is closed and follow the guidelines given below:

EXAMPLE: To set the 24 hour clock to 23:35 :

1. Press the **DELAY START/CLOCK SET** key twice.



x2

2. Enter the hour by pressing the **10 MIN** key twice and the **1 MIN** key three times.



x2



x3

3. Press the **DELAY START/CLOCK SET** key again and enter the minutes by pressing the **10 MIN** key three times and the **1 MIN** key five times.



x1



x3




x5

4. Press the **DELAY START/CLOCK SET** key once more to start the clock.



x1

Check the display.



STIR TURN KG/LB GRILL MICRO COOK

3