FURURIO OPERATOR'S MANUAL

GPS RECEIVER

MODEL GP-320B



PRINTED IN JAPAN

▲ SAFETY INSTRUCTIONS

Confirm that the power supply voltage is compatible with the voltage rating of the equipment.

Connection to the wrong power supply can cause fire or damage the equipment.

NOTICE

No one navigation device should ever be solely relied upon for the navigation of a vessel.

Always confirm position against all available aids to navigation, for safety of vessel and crew.


TABLE OF CONTENTS

SYSTEM OVERVIEW EQUIPMENT LISTS	
1. MOUNTING	1
2. WIRING	2
3. DEFAULT SETTINGS	6
4. TROUBLESHOOTING, BATTERY	7
SPECIFICATIONS	SP-1
PACKING LIST	
OUTLINE DRAWING	
Declaration of Conformity	


SYSTEM OVERVIEW

The GP-320B is a GPS receiver with WAAS (Wide Area Augmentation System) capability. WAAS, available in North America, is a provider in the worldwide SBAS (Satellite Based Augmentation System) navigation system. An SBAS provider furnishes GPS signal corrections to SBAS users, for even better position accuracy, typically better than three meters. Two more SBAS providers are also currently under development, MSAS (Multi-Functional Satellite Augmentation System) for Japan and EGNOS (Euro Geostationary Navigation Overlay Service) for Europe. All providers will be compatible with one another, thus providing "seamless" position fixes to SBAS users.

SBAS is currently in the developmental phase and SBAS providers are expected to have initial operations capability from the times shown below. During the developmental phase the reliability and availability of the SBAS signal cannot be guaranteed.



Note: Unless otherwise noted, this manual uses "WAAS" when referring to any SBAS provider.



EQUIPMENT LISTS

Standard supply

Name	Туре	Code No.	Qty	Remarks
GPS Receiver	GP-320B	_	1	With 10 m cable

Optional equipment

Name	Name Type		Qty	Remarks
Cable Assembly	Assembly MJ-A7SPF/SRMD-100		1	7P-7P, straight, 10 m
Mast Mounting Kit	ast Mounting Kit CP20-01111		1	
Right Angle Antenna Base	NO.13-QA330	000-803-239	1	
L-angle Antenna Base	NO.13-QA310	000-803-240	1	
Handrail-mount Antenna Base	NO.13-RC5160	000-806-114	1	


(This page intentionally left blank.)

1. MOUNTING

Mounting considerations

Follow the guidelines below to choose a suitable mounting location for the antenna unit.

- The antenna may be mounted three ways: screwed into a pipe (local supply), fixed to a post with the optional mast mounting kit, or screwed into an optional mounting base. For fixing by the post or pipe, it is recommended to use stays to prevent damage to the GPS receiver.
- Select a location out of the radar beam. The radar beam will obstruct or prevent reception of the GPS signal.
- The location should be well away from a VHF antenna. A GPS receiver is interfered by a harmonic wave of a VHF antenna.
- The location should be well away from an Inmarsat antenna. Inmarsat transmission will obstruct or prevent reception of the GPS signal.
- There should be no interfering object within the line-of-sight to the satellites. Objects within line-of-sight to a satellite, for example, a mast, may block reception or prolong acquisition time.
- Mount the antenna unit as high as possible to keep it free of interfering objects and water spray, which can obstruct reception of the GPS signal if the water freezes.
- Observe the following minimum separation distances from other antenna units.



Mounting procedure

Install the antenna unit by referring to the installation diagram on page D-1.


2. WIRING

This unit outputs position and speed to external equipment. NavNet equipment, Multi Display RD-30 and Echo Sounder LS-6100 can be connected directly. For connection to other equipment, use a junction box (local supply) which has seven terminals.

The antenna cable is 10 meters long. If the distance between the antenna unit and the display monitor is more than 10 meters, use the optional cable assy. (10 m). Up to four extension cables can be connected serially.


Connecting to FURUNO NavNet equipment

Connect the antenna cable to the DATA1 port on NavNet equipment.




Waterproofing connectors

If you use the cable assy.(s), waterproof their connectors by wrapping them with vulcanizing tape and then vinyl tape. Bind tape ends with suitable cable-ties.




Connecting to Multi Display RD-30

WAAS is not operative in this installation.




Connecting to Echo Sounder LS-6100



Connecting to other equipment

Remove the connector from the antenna cable and attach crimp-on lugs or similar terminals to the cable's cores. Connect the cores to the junction box as below.



Note 1: When connecting FURUNO DGPS beacon receiver GR-80 to this unit, set it as follows:

Byte Format, 8-6; First Bit, LSB; Parity Bit, None; Stop Bit, 1; Bit Rate, 8.

- **Note 2:** The signal ground and frame ground are separated, however the power line is not isolated. Therefore, do not connect the signal ground to the frame ground when other equipment is connected to a positive ground battery.
- Note 3: WAAS function is inoperative when wiring as shown above.

Output/Input data sentences

Priority		Input Data Output Data		Output Data	Settable Output Cycle	Default Output
High			GPDTM	Geometric datum	Yes	Yes
↑ 	XXGGA	GPS position status (time of fix, latitude, longitude, receive status, satellite used)	GPGGA	GPS fix data	Yes	Yes
	XXZDA	UTC date (time in minutes and seconds, day, month, year, time)	GPZDA	UTC time and date	Yes	Yes
	XXGLL	Position (latitude, longitude)	GPGLL	Geographic position, latitude and longitude	Yes	Yes
			GPVTG	Course over ground and ground speed	Yes	Yes
↓ Low	XXRMC	Navigation data (UTC time and latitude, longitude, ground speed, true course, year, month, day)	GPRMC	Recommended minimum specific GPS/TRANSIT data	Yes	Yes

Note 1: Data output from high to low priority.

Note 2: GPDTM data is attached in front of GPGGA, GPGLL and GPRMC when those sentences are output.

Note 3: "XX" means talker ID.

3. DEFAULT SETTINGS

	Setting	Default setting	Backup
	Initial Latitude/Longitude	North=34°44.0000, East=135°21.0000	Yes
G	Date, Time	2001/1/1, 00:00:13	Yes
Ρ	Antenna Height	0 m	Yes
S	Almanac Data		Yes
	Ephemeris Data		Yes
	Local Zone Time	+0	Yes
R	PDOP	6	Yes
E C	Geometric Datum	WGS84	Yes
E	Mask Elevation	5°	Yes
	Disable Satellite	None	No
V	Smoothing Coefficient	2 (Standard)	No
Ě	Dynamic Coefficient	2 (Standard)	No
R	Data Output (Cycle)	DTM, GGA, ZDA, GLL, VTG, RMC (1 s)	Yes
	DGPS Setting Parameter	1 (LSB first)	Yes
W	GEO Satellite, Provider ID Auto: from 120, in sequential order		No
А	WAAS Availability	OFF	No
A S	Type 0 Message	0: Correct data not output for 60 s	Yes

4. TROUBLESHOOTING, BATTERY

Troubleshooting

If the message "No position data" appears on the display of NavNet equipment, there may be a problem with the GPS receiver. Turn off the power and then check the following points:

- 1) Check for objects around the antenna which may interfere with reception.
- 2) Check that the antenna cable is firmly fastened.
- 3) If extension cable(s) are used, check for water leakage at junction point(s).
- 4) Check the antenna cable for damage.
- 5) Check the antenna for damage.
- If the problem seems to be with the antenna cable or antenna, contact your dealer.

Battery

The antenna unit contains a lithium battery which preserves data when the power is turned off, and its life is approximately 20 years (operating rate 70%) for large vessels and 10 years (operating rate 20%) for small vessels. The equipment can be used when the voltage of the battery is low, however data is not backed up and the unit starts up in the "cold start" condition.

SPECIFICATIONS OF THE GPS RECEIVER GP-320B

1. GENERAL

1.1	Receiving Channels	
	GPS	12 channels parallel, 12 satellites tracking
	WAAS	1 channel
1.2	Rx Frequency	1575.42 MHz
1.3	Rx Code	C/A code, WAAS
1.4	Position Fixing System	All in view, 8-state Kalman filter
1.5	Position Accuracy	
	GPS	10 m (95% of the time, HDOP 4)
	DGPS	5 m (95% of the time, external data required)
	WAAS	3 m (95% of the time)
1.6	Tracking Velocity	999 kt
1.7	Position-fixing Time	Warm start: 12 s approx., Cold start: 90 s approx.
1.8	Position Update Interval	1 s

2. I/O INTERFACE

2.1	Data format	IEC 61162-1 (NMEA 0183 Ver 2.30)
2.2	Output data	DTM, GGA, ZDA, VTG, GLL, RMC
2.3	Input data	DGPS: RTCM SC-104
		Control command

3. POWER SUPPLY

12-24 VDC: 105-55 mA

4. ENVIRONMENTAL CONDITION

- 4.1 Ambient Temperature -25°C to +70°C
- 4.2 Relative Humidity 95% at 40°C
- 4.3 Water proofing IEC 60529: IPX6
- 4.4 Vibration IEC 60945

5. COATING COLOR

N9.5


PACKING LIST

20**AW-X-9**852 -0 1/1

GP-320B (E)

NAME		OUTLINE DESCRIPTION/C		0' TY
ユニシト	UNIT			
GPS受信機 GPS RECEIVER		φ 89 ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓	GP-320B(E)	1
			004–367–500	_

(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)



FURURO

FURUNO ELECTRIC CO., LTD.

9-52 Ashihara-Cho, Nishinomiya City, 662-8580, Hyogo, Japan Tel: +81 798-65-2111 Fax: +81 798-65-4200

			Pub NO. DOC-461
Decl	aration of	Conformity	E 0560
We FUF		IC CO., LTD.	
		(Manufacturer)	
9-52 Ashihara-Cho, N	ishinomiya City	y, 662-8580, Hyogo, Japar	ı
		(Address)	
declare under our sole	e responsibility	that the product	
	GPS rec	ceiver Model GP-320B	
	(Model	name, serial number)	
1999/5/EC of the Euro equipment and teleco	pean Parliame mmunications cal regulations EC 60945 Thirc	,	March 1999 on radio TE Directive) and
, ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	ـ ـ ـ ـ ـ ـ ـ	ue of the standard(s) or other n	ormative document(s))
For assessment, see		. ,	
	on Nº 02214062	2/AA/00 of 10 April 2002 is	sued by Telefication,
		25 February 2002 and Sat ared by Furuno Labotech I	
		On behalf of Furund	o Electric Co., Ltd.
		HA TOM	alle.
Nishinomiya City, Jap	an	Hiroaki Komatsu Manager,	7
June 17, 2002		International Rules	and Regulations
(Place and date of issue)		(name and signature c authorized person)	or equivalent marking of

© FURUNO ELECTRIC CO., LTD.

9-52 Ashihara-cho, Nishinomiya, Japan

 Telephone :
 0798-65-2111

 Telefax :
 0798-65-4200

All rights reserved. Printed in Japan

PUB.No. OME-44220

(YOSH) GP-320B

Your Local Agent/Dealer

FIRST EDITION : APR. 2002

B : JUL. 03,2002



* O M E 4 4 2 2 0 B 0 0 *