



1.9 GHZ PCS, 800 MHZ CDMA (ALL DIGITAL)

VI5225



Something to talk about!

VI5225



Indicator
Flashes for
incoming calls
or messages

External
Caller-ID
Display



Ear Piece

Navigation Key
Scrolls through
menus and displays
the next or previous
message, entry
or item

Left Soft Key

Volume Up/Down

Programmable Hotkey

Downloads

TALK Key

Messaging

Right Soft Key



Web

END/PWR Key
Powers the phone on
or off, ends a call
or returns you to
the main menu

Microphone

- 2 Sprint PCS VisionSM
- 2 Web
- 2 Messaging
- 3 Sound Settings
- 3 Display Settings
- 4 Other Settings
- 5 The Planner
- 5 Call History
- 5 Phone Book
- 6 Call Options
- 6 Using the Battery
- 6 Making a Call

TABLE OF CONTENTS



CONNECTIVITY FEATURES

DOWNLOADING SPRINT PCS VISIONSM CONTENT

The new PCS phone by LG Model VI-5225 can store up to 1 megabyte of content from Sprint PCS VisionSM.

Downloading New Content from Sprint PCS Vision (Games, Ringers, Screen Savers, etc.)

1. From the **Downloads (6)** menu, select the desired content classification (**Games, Ringers, Screen Savers, Applications** or **Other**) and press **OK**.
2. Highlight **Get New** from the classification menu and press **OK** to initiate a Web session displaying Sprint PCS Vision content for the chosen classification.
3. Select the desired content and follow Sprint PCS Vision prompts to complete the purchase and download (extra fees may apply on some services).

Accessing Downloaded Content

1. From the **Downloads (6)** menu, select the content classification followed by pressing **OK** to access downloaded content.

Shortcut: Press the Downloads Folder icon on the Navigation Key while in standby mode to quickly access downloaded content.

ACCESSING THE WEB

The new PCS phone by LG Model VI-5225 features Sprint PCS Vision enabled by the Openwave 6.2.2.5 Browser to access the Web and Sprint PCS Vision content.

1. Select **Web (5)** from the main menu.
2. Press **End** to exit or end your browsing session.

Shortcut: Press the Web icon on the Navigation Key while in standby mode to quickly access the Web.

MESSAGING

Sending an SMS Message

The ability to send SMS text messages is subject to network service availability.




1. From the **Messaging (3)** menu, select **Send Message (1)**.
2. Select **Enter Addr 1**.
3. Highlight **Number, Email** or **Contact** and press **OK**. Enter the number or e-mail address using your keypad or select a name from your contact list.
4. Nine additional addresses may be entered for a total of ten recipients per message.
5. Select **Enter Msg**.
6. Enter the message using the keypad and press **OK**.
7. Press **Left Soft Key** for **Send**.

Shortcut: Press the Messaging icon on the Navigation Key while in standby mode to quickly access the Messaging menu.

Sending an E-mail

Sprint PCS Vision service required.

1. From the **Messaging (3)** menu, select **E-mail (5)**.
2. Scroll to **Compose** and press **Left Soft Key** to select.
3. Follow Sprint PCS Vision prompts.



CUSTOMIZABLE FEATURES

CHANGING THE SOUND SETTINGS

Selecting a Ringer

1. From the **Settings (7)** menu, select **Sounds (1)**.
2. Select **Ringers (1)**.
3. Select either **Voice Calls (1)** or **Messages (2)**.
4. For **Voice Calls**, select **Caller ID (1)**, **No Caller ID (2)** or **Roaming (3)**. For **Messages**, select either **Voicemail (1)** or **Page/Text (2)**.
5. Choose from the list of available default ringers and press **OK**.
6. You may switch to the list of downloaded ringers by pressing **Right Soft Key** for **Options**.

Selecting Key Tones

1. From the **Sounds (1)** menu, select **Key Tones (2)**.
2. Choose either **Short Tones** or **Long Tones** and press **OK**.

Adjusting Ringer, Earpiece and Key Beep Volume Settings

1. From the **Settings (7)** menu, select **Sounds (1)**.
2. Select **Volume (3)**.
3. Select **Ringer (1)**, **Earpiece (2)**, **Key Beep (3)**, **Power On/Off (4)** or **Application (5)**.
4. Use the Navigation Key to choose a volume level and press **OK**.

Ringer Volume Shortcut: Press the volume keys on the side of the handset to adjust the ringer volume while in standby mode.

Earpiece Volume Shortcut: Press the volume keys on the side of the handset to adjust the earpiece volume during a conversation.

Silent Mode Shortcut: While in standby mode, press and hold the lower volume key on the side of the handset to mute all sounds.

CHANGING THE DISPLAY SETTINGS

Changing the Backlight Settings

1. From the **Settings (7)** menu, select **Display (2)**.
2. Select **Backlight (2)**.
3. For **Phone**, highlight **8 seconds**, **15 seconds**, **30 seconds** or **On flip open** and press **OK**.
4. For **Web/Pictures**, highlight **15 seconds** or **On flip open** and press **OK**.

Changing the Greeting


1. From the **Settings (7)** menu, select **Display (2)**.
2. Select **Greeting (1)**.
3. Enter the desired greeting and press **OK**.

Changing the Wallpaper Image

1. From the **Settings (7)** menu, select **Display (2)**.
2. Select **Wallpaper (3)**.
3. Select from the list of four default images and press **Left Soft Key** to **Save**.
4. You may switch to the list of downloaded images by pressing **Right Soft Key** for **Options**.

Changing the Menu Style

1. From the **Settings (7)** menu, select **Display (2)**.
2. Select **Menu Style (5)**.
3. Select either **Icon** or **List** and press **OK**.




Changing the Clock Display

1. From the **Settings (7)** menu, select **Display (2)**.
2. Select **Clock (7)**.
3. Select **Normal (1)**, **Analog (2)**, **Digital (3)** or **Dual (4)**. The Dual function displays the local time and date and the time & date for the any of the more than 50 cities across the globe, selectable in the World Clock found in the **Tools (4)** menu.
4. Press **Left Soft Key** to **Save**.

OTHER NOTABLE SETTINGS

Setting Your Roaming Preference

1. From the **Settings (7)** menu, select **Roaming (4)**.
2. Select **Set Mode (1)**.
3. Highlight **Sprint Only** or **Automatic** and press **OK**.



Setting Your Location Preference


GPS/Location based services are not currently available but may be in the future. When this service becomes available, below is the overview of the feature.

Turning location On will allow the network to detect your position, enabling use of certain network applications. Turning location Off will conceal your location from everyone except emergency services. Even when location is turned On, no service may use your location without your expressed permission.

1. From the **Settings (7)** menu, select **Location (5)**.
2. Highlight either **On (1)** or **Off (2)** and press **OK**.

Setting your Security Preferences

Your lock code is commonly the last four digits of the mobile phone number.



Changing Your Lock Code

1. From the **Settings (7)** menu, select **Security (7)**.
2. Enter the current lock code.
3. Select **Change Lock (2)**.
4. Enter a new 4-digit lock code.
5. Re-enter the new lock code.

Locking the Handset

Helps protect the phone from unauthorized use. Once the phone is locked, the phone is restricted from making calls until the lock code is entered. However, the phone will still receive incoming calls and make emergency calls while in the locked mode. You may store up to ten additional telephone numbers within the Security menu for use when the phone is locked.

1. From the **Security (7)** menu, select either **Lock** or **On Power Up** and press **OK**. The **On Power Up** function will lock the handset when the phone is power cycled.

Using Airplane Mode

Enabling Airplane Mode will prevent any outgoing and incoming calls, as well as any online access. When Airplane Mode is enabled, "Phone Off" is displayed on the screen.

1. From the **Settings (7)** menu, select **Airplane Mode (8)**.
2. Highlight either **On** or **Off** and press **OK**.

Programming the Short Cut Key

1. From the **Settings (7)** menu, select **Setup (9)**.
2. Select **Shortcut (1)**.
3. Select your most frequently used function from the list provided and press **OK**.

Shortcut: Pressing the left arrow key of the navigation button while in standby mode will now quickly access this function.



PERSONAL INFORMATION TOOLS



THE PLANNER

The Planner menu allows you to view the calendar, schedule an event, program your handset's alarm clock, and view and compose memos on the notepad.

Scheduling an Event


1. From the **Planner (8)** menu, select **Schedule (1)**.
2. Highlight the event date using your Navigation Key and press **Left Soft Key** for **Add**.
3. You may set the appropriate start and end times, title, alarm & ringer and a reoccurrence (if any) by scrolling to the corresponding field and entering the desired information and pressing **OK**.
4. Press **Left Soft Key** to **Save** to confirm your selection.

Scheduling an Alarm

1. From the **Planner (8)** menu, select **Alarm Clock (2)**.
2. Select from **Alarm 1 (1)**, **Alarm 2 (2)**, **Alarm 3 (3)** or **Quick Alarm (4)** and press **OK**.
3. You may set the set the appropriate time, ringer and a reoccurrence (if any) by scrolling to the corresponding field and entering the desired information.
4. Press **Left Soft Key** to **Save** to confirm your selection.

Composing a Notepad Memo

1. From the **Planner (8)** menu, select **Notepad (3)**.
2. Press **Left Soft Key** for **Add**.
3. Enter your memo using the keypad and press **OK**.




CALL HISTORY

Call History logs your most recent 20 incoming, outgoing and missed calls. Only the most recent duplicate call is logged in the Outgoing Calls.

Making a Call From Call History

1. From the **Call History (1)** menu, select **Outgoing Calls (1)**, **Incoming Calls (2)** or **Missed Calls (3)** and press **OK**.
2. Place a call by selecting the desired entry and press **TALK** to connect.




PHONE BOOK


The internal phone book is capable of storing up to 200 entries with up to 5 numbers per entry.

Adding a New Phone Book Entry

1. From the **Phone Book (2)** menu, select **Add New Entry (2)**.
2. Enter the telephone number for the entry and press **OK**.
3. Select a label (**Home, Home 2, Office, Office 2, Mobile, Mobile 2, Pager, Fax, Fax 2** or **None**) and press **OK**.
4. Enter a name for the entry and press **OK**.
5. To exit to the Phone Book press **Left Soft Key** for **Done**.
6. To set a speed dial, highlight **Speed Dial** and press **OK**.
7. Select or enter a slot number and press **OK**.

Note: You may also create additional entries, or save numbers to existing entries through the Call History menu and by entering the number from standby screen and selecting Save. Follow the on-screen prompts.





UNIQUE CALL OPTIONS

The Actions menu may be accessed during a call by pressing **Right Soft Key** for **Options**.

Monitor

1. Scroll to **Monitor On** and press **OK** to amplify the phone's audio for hands-free listening. While the Monitor function is enabled, the microphone will be muted.

Warning! Due to higher volume levels, do not place the phone near your ear while the Monitor function is enabled.

Write Memo

1. Scroll to **Write Memo** and press **OK** to write a memo during a call. From the Notepad, you may select an existing memo or press **Left Soft Key** for **Add** to create a new memo.

USING THE BATTERY

The VI-5225 comes with a standard 950 mAh Li-Ion battery.

Installing the Battery

1. Place the battery in the opening at a 45-degree angle with the metal contacts facing inward at the bottom.
2. Gently press inward on the top of the battery until the latch snaps into place.

Removing the Battery

1. Make sure the power is off to avoid losing any stored numbers or messages.
2. Push the battery release latch up.
3. Remove the battery from the phone at a 45-degree angle.



MAKING A CALL

1. To turn the phone on, press the **END** button for two seconds.
2. Enter the phone number with the area code if necessary.
3. Use the **BACK** key to erase incorrect numbers. Press and hold the **BACK** key to erase all typed numbers.
4. When the phone number is properly entered, press **TALK**.
5. Press **END** to disconnect the call or close the flip.

1 Call History

- 1 Outgoing Calls**
- 2 Incoming Calls**
- 3 Missed Calls**
- 4 Erase Calls**

- 1 Outgoing Calls
- 2 Incoming Calls
- 3 Missed Calls
- 4 All Calls

2 Phone Book

- 1 Find Name**
- 2 Add New Entry**
- 3 Speed Dials**
- 4 Groups**
- 5 Services**

- 1 Customer Solutions
- 2 Directory Assistance
- 3 Account Info.
- 4 Sprint Operator
- 5 Voice Command

6 My Number

3 Messaging

- 1 Send Message**
- 2 Inbox**
- 3 Outbox**
- 4 Draft**
- 5 E-mail**
- 6 Voice Mail**

- 1 Clear

4 Tools

- 1 EZ Tips**
- 2 Calculator**
- 3 World Clock**
- 1 Set DST

5 Web

6 Downloads

- 1 Games**
- 1 Get New

2 Ringers

- 3 Screen Savers**
- 4 Applications**
- 5 Other**

7 Settings

1 Sounds

- 1 Ringers
- 2 Key Tones
- 3 Volume
- 4 Alerts

2 Display

- 1 Greeting
- 2 Backlight
- 3 Wallpaper
- 4 Contrast
- 5 Menu Style
- 6 Theme Color
- 7 Clock
- 8 Text Input Font

3 PCS Vision

- 1 Enable PCS Vision**
- 2 Net Guard**
- 3 Update Vision Profile**

4 Roaming

- 1 Set Mode
- 2 Call Guard

5 Location

- 1 On
- 2 Off

6 Messaging

- 1 Display Pop-Up
- 2 Message Alerts
- 3 Auto Delete
- 4 Signature
- 5 Canned Messages

7 Security

8 Airplane Mode

- 1 On
- 2 Off

9 Setup

- 1 Shortcut
- 2 Call Answer
- 3 Auto Answer
- 4 Language
- 5 Phone Info

8 Planner

1 Schedule

- 1 Add
- 2 Options

2 Alarm Clock

- 1 Alarm 1
- 2 Alarm 2
- 3 Alarm 3
- 4 Quick Alarm

3 Notepad

- 1 Add



LG Infocomm USA, Inc.
 10225 Willow Creek Road
 San Diego, CA 92131-1639
 www.LGmobilephones.com
 Customer Service: 800-793-8896
 Accessories: 800-851-6734



Copyright © 2004 LG. All rights reserved. Other products and services are trademarks of their respective owners. Phone features and specifications are subject to change without prior notice. Services and features may vary depending on network service provider, service plan, network conditions, and personal usage. The use of non-LG approved accessories will void the warranty and may result in damage to the phone, the phone to explode, or other dangerous conditions. Battery talk and standby times are estimates only. Use of certain features and other conditions including, but not limited to, battery age and condition, charging habits, temperatures to which the battery is exposed, and use in digital mode will cause actual standby and talk time to vary. The amount of talk time used will impact the standby time. In the same way, the amount of time that the phone is in standby mode will impact the talk time.