

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to prevent the risk of fire, electric shock, burns, or other injuries or damages:

- Read all instructions.
- To protect against risk of electrical shock do not put the cord or the blender's power base in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from the outlet when not in use, before putting on or taking off parts, and before cleaning.
- Avoid contacting moving parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or is dropped or damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair or electrical or mechanical adjustment.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock or injury.
- Do not use outdoors or in a damp area.
- Do not let the cord hang over edge of a table or counter.
- Blades are sharp. Handle carefully.
- Always operate the blender with the cup in place.
- Do not blend hot liquids.
- Cup must be properly tightened and in place before operating the appliance.
- Do not use appliance for other than intended use.
- Do not attempt to defeat the interlock mechanism.

Before using your new product, please read these instructions to prevent any damage.

ADDITIONAL SAFEGUARDS

- This appliance is for HOUSEHOLD USE ONLY.
- DO NOT OPERATE THE APPLIANCE IF THE LINE CORD SHOWS ANY DAMAGE OR IF THE APPLIANCE WORKS INTERMITTENTLY OR STOPS WORKING ENTIRELY.

EXTENSION CORDS

A short power cord is provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord. Extension cords may be used if care is exercised in their use. If an extension cord is absolutely necessary:

- An extension cord rated a minimum of 13 ampere, 16 American wire gauge cord should be used. Cords rated for less amperage may overheat.
- An extension cord with the power cord must be arranged so that it will not drape over the countertop or tabletop where they can be pulled on by children or tripped over accidentally.

POLARIZED PLUG

This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

SAVE THESE INSTRUCTIONS

PACKAGE CONTENTS

- Blender
- Quick Setup Guide



FEATURES

- Powerful 200 Watt motor
- Stainless steel base
- Multiple cup sizes
- Blends solids and liquids
- Includes comfort lip rings for comfortable drinking
- Resealable lids allow for easy food storage
- Includes shaker lids for straining

BEFORE USING YOUR BLENDER

- Remove all packaging materials, labels and stickers from your blender.
- Make sure that all parts are enclosed and that your blender is not damaged. Clean the blender and all accessories.

Note: All the accessories except the power base are dishwasher safe.

Warning: Do not immerse the power base in water or any other liquids. This may result in electrical shock or damage to your blender.



USING YOUR BLENDER

Warning: Before starting any operation, always make sure the power cord is unplugged.

- 1 Place the power base on a flat surface. Make sure that the power cord is disconnected from power.
- 2 Peel or core any fruits or vegetables and cut them into small chunks. Do not overfill the cups to avoid spillage.

CUP	MAXIMUM CAPACITY
Tall cup	13.5 oz. (liquids only)
Small cup	1.6 oz. (solid food only)

- 3 Fill the cup you want with prepared food.

Hints:

- For best results, cut solid food into approximately 0.5-inch to 1-inch cubes.
- Cut cheese into pieces no larger than 0.5 inch.

- 4 Assemble your blender according to the food type you would like to process.


CUP AND BASE	SUITABLE FOR
Tall cup with blending base	Blending liquids
Small cup with grinding base	Grinding/chopping solid foods

Note: You cannot blend solid foods in the tall cup.



Warnings:

- The blades are sharp. Always handle blade assemblies with care.
- Do not touch the blades. This may cause injuries.



- Do not fill cups with hot liquids or run the appliance empty.
- Warning:** Always make sure that the blending base or grinding base is securely screwed on and tightened onto the cup before turning on your blender.
- 5 Connect the power plug to a wall outlet.
 - 6 Position the cup with base on the drive shaft.
 - 7 To turn on your blender, align the tabs on the cup with the blending base or grinding base and twist clockwise until it locks in place.



- 8 To turn off your blender, turn the cup counter-clockwise until the blender stops. Disconnect the plug from the wall outlet before removing the cup from the power base.

Hints:

- Operate your blender for only as long as needed to reach the right consistency.
- Never use the blender for more than three minutes at a time. After use, let your blender cool for at least three minutes before you start using it again.

- 9 Turn the cup around, so that the base faces upwards. Unscrew the base of the cup.

USING YOUR LIDS

- To make sure that the contents stay fresh, screw a supplied resealable lid on the cup.



Hint: Store any unused portions in the refrigerator.

- To remove pulp or larger food particles from your drink, screw one of the shaker lids onto the cup.



- Cover cups with the lip rings to enjoy the freshly made drink directly out of the cup.



SPECIFICATIONS

- 120V, 60Hz, 200W

ONE-YEAR LIMITED WARRANTY

Visit www.insigniaproducts.com for details.

CONTACT INSIGNIA:

For customer service, call 877-467-4289 (U.S.) or 01-800-926-3000 (Mexico)

www.insigniaproducts.com

INSIGNIA is a trademark of Best Buy and its affiliated companies. Registered in some countries.
 Distributed by Best Buy Purchasing, LLC
 7601 Penn Ave South, Richfield, MN 55423 U.S.A.
 ©2014 Best Buy. All rights reserved.
 Made in China