



**CORDLESS  
3 GEAR  
HAMMER DRILL**

**3G12V, 3G144V, 3G18V, 3G18VM, 3G24V, 3G24VM  
INSTRUCTION MANUAL**

**GMC<sup>®</sup>**

**GLOBAL MACHINERY COMPANY**

# Contents

Warranty	2
Introduction	3
Environmental protection	3
Description of symbols	3
Specifications	4
General safety rules	5
Additional safety instructions for drills	6
Additional safety instructions for charger	7
Additional safety instructions for battery pack	8
Unpacking	8
Know your product	9
Adjustable side handle	10
Inserting and removing bits	10
Fitting and removing the battery pack	10
Battery charging	11
To obtain the best life for the battery	11
Battery indicator	11
LED Work area light	12
Trigger switch	12
Forward/Reverse control	12
Variable speed	12
Drilling positions	12
Torque adjustment/hammer selection collar	13
3 Speed gearbox	13
Screw driver bit storage	13
Chuck replacement	13
Drilling metals	14
Drilling plastics and plastic coated chipboard	14
Drilling masonry	14
Drilling wood	14
All drilling operations	14
Care	15
Maintenance	15
Power cord maintenance	15

## Warranty Power Tools

Whilst every effort is made to ensure your complete satisfaction with this tool, occasionally, due to the mass manufacturing techniques, a tool may not live up to our required level of performance and you may need the assistance of our service department.

This product is warranted for a 2-year period for home domestic use from the date of the original purchase. If found to be defective in materials or workmanship, the tool or the offending faulty component will be repaired or replaced free of charge with another of the same item. A small freight charge may apply. Proof of purchase is essential. We reserve the right to reject any claim where the purchase cannot be verified.

This warranty does not include damage or defects to the tool caused by or resulting from abuse, accidents, alterations or commercial or business use. It also does not cover any bonus items or included accessories. Only the power tool is covered under this warranty.

With continuing product development, changes may have occurred which render the product received slightly different to that shown in this instruction manual.

Please ensure that you store your receipt in a safe place.

Conditions apply to the above warranty. For full details of the warranty terms and conditions please refer to our website – [www.gmcompany.com](http://www.gmcompany.com)

For prompt service we suggest you log your service request online - [www.gmcservice.com.au](http://www.gmcservice.com.au), should you not have access to the internet, please contact our service department on 1300 880 001 (Australia) or 0800 445 721 (New Zealand).

## Introduction

Your new GMC power tool will more than satisfy your expectations. It has been manufactured under stringent GMC Quality Standards to meet superior performance criteria.

You will find your new tool easy and safe to operate, and, with proper care, it will give you many years of dependable service.

**CAUTION.** Carefully read through this entire Instruction Manual before using your new GMC Power Tool. Take special care to heed the Cautions and Warnings.

Your GMC power tool has many features that will make your job faster and easier. Safety, performance, and dependability have been given top priority in the development of this tool, making it easy to maintain and operate.

## Environmental protection



Recycle unwanted materials instead of disposing of them as waste. All tools, hoses and packaging should be sorted, taken to the local recycling centre and disposed of in an environmentally safe way.

## Description of symbols

The rating plate on your tool may show symbols. These represent important information about the product or instructions on its use.



Wear hearing protection.

Wear eye protection.

Wear breathing protection.



Double insulated for additional protection.



N380

Conforms to relevant standards for electromagnetic compatibility.

## Specifications

	<b>3G12V</b>	<b>3G144V</b>	<b>3G18V/3G18VM</b>	<b>3G24V/3G24VM</b>
<b>Charger</b>	230 – 240 Vac, 50Hz 45W 14Vdc, 2A	230 – 240 Vac, 50Hz 50W 17Vdc, 2A	230 – 240 Vac, 50Hz 65W 21Vdc, 2.1A	230 – 240 Vac, 50Hz 85W 28Vdc, 2.3A
<b>Charging time</b>	1 Hour	1 Hour	1 Hour	1 Hour
<b>Batteries</b>	2 x 1.5Ah	2 x 1.5Ah	2 x 1.7Ah	2 x 1.7Ah
<b>Nominal battery voltage</b>	12V	14.4V	18V	24V
<b>Gear</b>	Three speed	Three speed	Three speed	Three speed
<b>Switch</b>	Variable speed	Variable speed	Variable speed	Variable speed
<b>Torque settings</b>	20 positions	20 positions	20 positions	20 positions
<b>Drill chuck capacity</b>	10mm Keyless	10mm Keyless	13mm Keyless	13mm Keyless
<b>Weight</b>	2.4kg	2.5kg	2.9kg	3.2kg
<b>Maximum torque</b>	17.65 Nm	20.6 Nm	36.3 Nm	45.15 Nm
<b>Maximum drill no-load speed</b>				
<b>Low</b>	0–330min <sup>-1</sup>	0–385min <sup>-1</sup>	0–385min <sup>-1</sup>	0–400min <sup>-1</sup>
<b>Medium</b>	0–570min <sup>-1</sup>	0–670min <sup>-1</sup>	0–670min <sup>-1</sup>	0–700min <sup>-1</sup>
<b>High</b>	0–1300min <sup>-1</sup>	0–1500min <sup>-1</sup>	0–1500min <sup>-1</sup>	0–1600min <sup>-1</sup>
<b>Hammer impact frequency</b>				
<b>Low</b>	0–4950 BPM	0–5775 BPM	0–5775 BPM	0–6000 BPM
<b>Medium</b>	0–8550 BPM	0–10050 BPM	0–10050 BPM	0–10500 BPM
<b>High</b>	0–19500 BPM	0–22500 BPM	0–22500 BPM	0–24000 BPM
<b>Maximum drilling capacity</b>				
<b>Steel</b>	10mm	10mm	13mm	13mm
<b>Wood</b>	25mm	28mm	38mm	38mm
<b>Concrete</b>	10mm	10mm	13mm	13mm

## General safety rules

**WARNING.** Read all instructions. Failure to follow all instructions listed below may result in electric shock, fire and/or serious injury. The term “power tool” in all of the warnings listed below refers to your mains operated (corded) power tool or battery operated (cordless) power tool.

### Save these instructions

#### 1. Work area

- a. **Keep work area clean and well lit.** Cluttered and dark areas invite accidents.
- b. **Do not operate power tools in explosive atmospheres,** such as in the presence of flammable liquids, gases or dust. Power tools create sparks which may ignite the dust or fumes.
- c. **Keep children and bystanders away while operating a power tool.** Distractions can cause you to lose control.

#### 2. Electrical safety

- a. **Power tool plugs must match the outlet. Never modify the plug in any way.** Do not use any adapter plugs with earthed (grounded) power tools. Unmodified plugs and matching outlets will reduce risk of electric shock.
- b. **Avoid body contact with earthed or grounded surfaces such as pipes, radiators, ranges and refrigerators.** There is an increased risk of electric shock if your body is earthed or grounded.
- c. **Do not expose power tools to rain or wet conditions.** Water entering a power tool will increase the risk of electric shock.
- d. **Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool.** Keep cord away from heat, oil, sharp edges or moving parts. Damaged or entangled cords increase the risk of electric shock.
- e. **When operating a power tool outdoors, use an extension cord suitable for outdoor use.** Use of a cord suitable for outdoor use reduces the risk of electric shock.

#### 3. Personal safety

- a. **Stay alert, watch what you are doing and use common sense when operating a power tool.** Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication. A moment of inattention while operating power tools may result in serious personal injury.
  - b. **Use safety equipment. Always wear eye protection.** Safety equipment such as dust mask, non-skid safety shoes, hard hat, or hearing protection used for appropriate conditions will reduce personal injuries.
  - c. **Avoid accidental starting.** Ensure the switch is in the off position before plugging in. Carrying power tools with your finger on the switch or plugging in power tools that have the switch on invites accidents.
  - d. **Remove any adjusting key or wrench before turning the power tool on.** A wrench or a key left attached to a rotating part of the power tool may result in personal injury.
  - e. **Do not overreach.** Keep proper footing and balance at all times. This enables better control of the power tool in unexpected situations.
  - f. **Dress properly. Do not wear loose clothing or jewellery.** Keep your hair, clothing and gloves away from moving parts. Loose clothes, jewellery or long hair can be caught in moving parts.
  - g. **If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used.** Use of these devices can reduce dust related hazards.
- #### 4. Power tool use and care
- a. **Do not force the power tool.** Use the correct power tool for your application. The correct power tool will do the job better and safer at the rate for which it was designed.
  - b. **Do not use the power tool if the switch does not turn it on and off.** Any power tool that cannot be controlled with the switch is dangerous and must be repaired.

- c. **Disconnect the plug from the power source before making any adjustments, changing accessories, or storing power tools.** Such preventive safety measures reduce the risk of starting the power tool accidentally.
- d. **Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool.** Power tools are dangerous in the hands of untrained users.
- e. **Maintain power tools. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tools operation.** If damaged, have the power tool repaired before use. Many accidents are caused by poorly maintained power tools.
- f. **Keep cutting tools sharp and clean.** Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.
- g. **Use the power tool, accessories and tool bits etc., in accordance with these instructions and in the manner intended for the particular type of power tool, taking into account the working conditions and the work to be performed.** Use of the power tool for operations different from those intended could result in a hazardous situation.

## 5. Battery tool use and care

- a. **Ensure the switch is in the off position before inserting battery pack.** Inserting the battery pack into power tools that have the switch on invites accidents.
- b. **Recharge only with the charger specified by the manufacturer.** A charger that is suitable for one type of battery pack may create a risk of fire when used with another battery pack.
- c. **Use power tools only with specifically designated battery packs.** Use of any other battery packs may create a risk of injury and fire.
- d. **When battery pack is not in use, keep it away from other metal objects like paper clips, coins, keys, nails, screws, or other small metal objects that can**

**make a connection from one terminal to another.**

Shorting the battery terminals together may cause burns or a fire.

- e. **Under abusive conditions, liquid may be ejected from the battery; avoid contact.** If contact accidentally occurs, flush with water. If liquid contacts eyes, additionally seek medical help. Liquid ejected from the battery may cause irritation or burns.

## 6. Service

- a. **Have your power tool serviced by a qualified repair person using only identical replacement parts.** This will ensure that the safety of the power tool is maintained.

## Additional safety instructions for drills

### **Wear ear protectors with impact drills.**

Exposure to noise can cause hearing loss.

### **Use auxiliary handles supplied with the tool.**

Loss of control can cause personal injury.

- If possible, always use clamps or a vice to hold your work.
- Always switch off before you put the drill down.
- Ensure that the lighting is adequate.
- Do not put pressure on the drill, such that it slows the motor down. Allow the drill bit to cut without pressure. You will get better results and you will be taking better care of your tool.
- Keep the area free of tripping hazards.
- Do not let anyone under 18 years operate this tool.
- Only use accessory bits in good condition.
- Before drilling, check that there is sufficient clearance for the drill bit under the workpiece.
- Do not touch the bit after operation. It will be very hot.
- Keep your hands away from under the workpiece.
- Never use your hands to remove sawdust, chips or waste close by the bit.
- Rags, cloths, cord, string and the like should never be left around the work area.

- Support the work properly.
- If you are interrupted when operating the drill, complete the process and switch off before looking up.
- Periodically check that all nuts, bolts and other fixings are properly tightened.
- When using the drill, use safety equipment including safety glasses or shield, ear defenders, and protective clothing including safety gloves. Wear a dust mask if the drilling operation creates dust.

If in doubt, do not plug in the tool. Using a power source with a voltage less than the nameplate rating is harmful to the motor.

The tool must be used only for its prescribed purpose. Any use other than those mentioned in this Manual will be considered a case of misuse. The user and not the manufacturer shall be liable for any damage or injury resulting from such cases of misuse.

To use this tool properly, you must observe the safety regulations, the assembly instructions and the operating instructions to be found in this Manual. All persons who use and service the machine have to be acquainted with this Manual and must be informed about its potential hazards.

Children and frail people must not use this tool. Children should be supervised at all times if they are in the area in which the tool is being used. It is also imperative that you observe the accident prevention regulations in force in your area. The same applies for general rules of occupational health and safety.

The manufacturer shall not be liable for any changes made to the tool nor for any damage resulting from such changes.

Even when the tool is used as prescribed it is not possible to eliminate all residual risk factors. The following hazards may arise in connection with the tool's construction and design:

- Damage to the lungs if an effective dust mask is not worn.
- Damage to hearing if effective ear defenders are not worn

## Additional safety instructions for the charger

- Before using the charger, read all the instructions and cautionary markings on the charger and battery pack as well as the instructions on using the battery pack.
- Only charge your batteries indoors as the charger is designed for indoor use only.
- **DANGER.** If the battery pack is cracked or damaged in any other way, do not insert it in the charger. There is a danger of electric shock or electrocution.
- **WARNING.** Do not allow any liquid to come into contact with the charger. There is a danger of electric shock.
- To allow the battery pack to cool down after charging, do not place it in a hot environment such as a metal shed or open trailer left in the sun.
- The charger is not intended for any use other than charging the exact type of rechargeable battery pack as supplied with the charger. Any other use may result in the risk of fire, electric shock or electrocution.
- The charger and battery packs supplied with it are specifically designed to work together. Do not attempt to charge the battery pack with any other charger than the one supplied.
- Do not place any object on top of the charger as it could cause overheating. Do not place the charger near any heat source.
- Do not pull on the lead of the charger to disconnect it from the power source.
- Make sure that the charger cable is positioned where it will not be stepped on, tripped over or otherwise subjected to damage or stress.
- Do not use an extension cord unless it is absolutely necessary. The use of an improper extension cord could cause the risk of fire, electric shock or electrocution.
- Do not use the charger if it has been subjected to a heavy knock, dropped or otherwise damaged in any way. Take the charger to an authorised service centre for a check or repair.



- Do not disassemble the charger. Take it to an authorised service centre when service or repair is required. Incorrect re-assembly may result in the risk of fire, electric shock or electrocution.
- To reduce the risk of an electric shock, unplug the charger from the power supply before attempting to clean it. Removing the battery alone does not reduce the risk.
- Never attempt to connect two chargers together.
- Do not store or use the tool and battery pack in locations where the temperature may reach or exceed 104°F (40°C) such as alongside sheds or metal structures in the summer.
- The charger is designed for use from a standard household electrical supply (230–240 volts). Do not attempt to connect the charger to a supply with a different supply.
- If you wish to charge a second battery pack, unplug the charger from the mains supply and leave it for at least 15 minutes. After this time you can charge a second battery pack.
- The battery pack utilizes nickel-cadmium cells. Cadmium is considered to be a toxic material. Use an environmentally safe disposal unit at a municipal waste disposal centre to dispose of a damaged or worn out battery.

## Unpacking

Due to modern mass production techniques, it is unlikely that your GMC Power Tool is faulty or that a part is missing. If you find anything wrong, do not operate the tool until the parts have been replaced or the fault has been rectified. Failure to do so could result in serious personal injury.

## Additional safety instructions for the battery pack

- The battery pack for this tool has been shipped in a low charge condition. You should charge the battery pack fully before use.
- To ensure the longest battery life and best battery performance, always charge the battery when the air temperature is between 18–24°C. Do not charge the battery pack when the temperature is below 0°C, or above 40°C. This is important. Failure to observe this safety rule could cause serious damage to the battery pack.
- Do not incinerate the battery pack even if it is seriously damaged or can no longer hold a charge. The battery pack can explode in a fire.
- Never attempt to open the battery pack for any reason. If the plastic housing of the battery pack breaks open or cracks, immediately discontinue its use and do not recharge it.



## Know your product

This drill can be used for drilling in wood, metal, masonry and screwdriving. Use the tool and accessories only for intended applications. All other applications are expressly ruled out.

1. Single sleeve keyless chuck
2. Torque adjustment/  
hammer selection collar
3. Trigger with variable  
speed control
4. Forward/reverse control  
(not shown)
5. Adjustable side handle
6. Battery pack release buttons
7. Rechargeable battery pack
8. Charger
9. 3 Speed gear selector
10. Screw Driver bit storage
11. Spirit level
12. Battery indicator button
13. LED Light switch
14. LED lights (x5)



## Adjustable side handle

The drill is supplied with a 360° adjustable side handle (5). Always fit and use the side handle when using the drill, this increases safety when operating the drill.

To adjust the side handle, rotate the side handle in an anti clockwise direction approximately 2 full turns. Once the side handle is loose rotate the collar left or right to the desired position. You do not need to fully remove the handle.

If you want to remove the side handle, slide the collar completely forward over the chuck.

To tighten the collar on the housing, rotate the handle in a clockwise direction firmly.

Ensure the collar is fully located on the aluminium housing.

## Inserting and removing bits

The drill is fitted with auto spindle lock which means if you try and rotate the chuck by hand the spindle of the drill will automatically lock. This means you only need to grasp the chuck and rotate the chuck housing to remove or fit accessories.

This drill has a keyless chuck, hence a chuck key is not needed to secure a bit in the drill. Always set the forward/reverse control (4) to the locked 'OFF' position when installing and removing bits. It is also recommended to remove the battery pack to avoid unintentional starting.

1. Open the chuck jaws by firmly holding the chuck housing and rotating the housing in an anti clockwise direction. Open the jaws sufficiently so as to fit the desired accessory.
2. Ensure the accessory is fully inserted.
3. To firmly clamp the accessory in the chuck, grasp the chuck housing and rotate the chuck housing in a clockwise direction. Ensure the bit is retained firmly or damage to the chuck jaws can result.
4. To remove the accessory, open the chuck jaws by firmly holding the chuck housing and rotating the housing in an anti clockwise direction. Open the jaws sufficiently so as to remove the specific accessory.



## Fitting and removing the battery pack

To remove the battery pack from the drill firmly press the battery release buttons (6) at either side of the battery pack, and slide the battery backward out of the tool.

To install the battery pack, align rails, on the tool with the tabs on the battery pack and slide the battery pack on to the drill. Ensure the battery pack is sitting straight on the foot and correctly entering the runners. The battery should slide fully on to the drill foot until the battery pack "clicks" into position.



## Battery charging



Make sure power circuit voltage is the same as that shown on the charger specification plate. Connect charger to power source. The yellow light (a), should light up. This indicates the charger is ready to begin charging.

Position battery pack on charger; align rails (d), on battery charger with (e) on battery pack. Slide battery forward onto charger until it clicks into position.

The red light (b), should begin to glow continuously, indicating that the battery pack is receiving a “Fast Charge”.

**Note.** If the red light does not glow continuously, but the yellow light is flashing and the green light (c), begins to glow, remove battery and re-insert when battery temperature is between 0°C and 40°C.

After approximately one hour, the “Fast Charge” indicator red light (b) should go out indicating that the battery pack is fully charged and that the charger is now in a “Maintenance Charge” mode, this is confirmed by the green light (c) coming on. The battery pack can be left on “Maintenance Charge” until you are ready to use it.

To remove the battery pack from the charger depress the battery pack release buttons (6).

Depending on room temperature, line voltage, and existing charge level, initial battery charging may take longer than one hour.

Disconnect charger from power source when not in use.

## To obtain the best life for the battery

Never allow the drill to come to a complete stand still before recharging. The battery should be placed on charge whenever the battery is noticeably running down or the drill no longer performs a task it previously performed.

Avoid conducting short charges. Make sure that the battery is fully charged every time by allowing the charger to complete its full charging cycle.

Avoid allowing loose items like screws or nails etc to be stored with battery packs as these or similar items can short battery packs and cause a fire or explosion.

Always unplug the charger when not in use and store in a dry secure place.

Avoid charging or storing your battery in temperatures below 0°C and above 40°C.

## Battery indicator

Press the battery indicator button (12), this will display the level of charge remaining in the battery. The LED's lighting up indicate the charge remaining in the battery, the higher the number of LED's the more charge remaining in the battery. When the battery indicator is showing only one LED the battery should be removed and put on the charger.



## LED Work area light

The drill has five LED lights (14) to illuminate the work area and improve vision when drilling in areas with insufficient light.

To turn the LED lights on depress the LED light switch (13).  
To turn the LED lights off depress the LED light switch (13).

## Trigger Switch

**To start the drill, depress the trigger switch.**

Use the forward/reverse control (4) to select the direction of rotation, then squeeze the trigger switch (3). This trigger switch is an electronic variable speed control which enables the user to vary the speed continuously. The speed varies according to how far the trigger switch is depressed, the further it is depressed the faster the chuck will rotate and the lighter it is depressed, the slower it will rotate. The switch is equipped with a brake, the chuck will stop as soon as the trigger switch is fully released.


**To stop the drill, release the trigger switch.**

## Forward/Reverse control

The forward/reverse control (4) allows you to change the direction of the tool while the variable speed trigger is not depressed.

To select forward rotation depress the control (4) toward the left side of the tool. To select reverse depress the control (4) to the right side of the tool.

Drilling uses the forward mode.



The reverse mode is intended for the removal of screws.

The centre position of the control button locks the tool in the off position.

## Variable speed

The variable speed feature is particularly useful when driving screws.

It also enables you to select the best speed for a particular application. The farther you squeeze the trigger, the faster the tool will operate.

Use lower speeds for starting holes without a centre punch, drilling metals or plastic, driving screws and drilling ceramics, or in any application requiring high torque. Higher speeds are better drilling in wood, wood compositions and for using abrasive and polishing accessories. For maximum tool life, use variable speed only for starting holes or fasteners.

**Note.** It is best to use the variable speed feature for a short time only. Do not continuously operate the drill in variable speed mode this may damage the switch.

## Drilling Positions



This symbol indicates the DRILL POSITION. Use this mode for high speed drilling (Wood, Aluminium, and Steel) and the clutch will be locked.



This symbol indicates the HAMMER POSITION. Use this mode to select hammer action. For best results in hammer mode, use set the gear selector (9) to Position 3 (high speed).

## Torque adjustment/hammer selection collar

By rotating the torque adjustment/hammer selection collar (2) behind the chuck, it is possible to adjust the torque to each of twenty settings, or select hammer action or the drill setting.

The range of twenty torque settings allows better control when using the drill as a screwdriver as it prevents over-tightening of the screws.

The numbers circling the collar are used to indicate the level of torque. The higher number on the collar, the higher torque and the larger the fastener which can be driven. To select any of the numbers, rotate the collar (2) until the desired number aligns with the arrow head indicator on the housing.

## 3 Speed gearbox

The 3 Speed Gearbox allows you to select a gear with the optimum speed and torque to suit the application.

To select the first gear (low speed, high torque setting), turn the tool off and wait until it stops. Push the gear selector (9) back, away from the chuck, so the number 1 is displayed.

To select the second gear (medium speed, medium torque setting), turn the tool off and wait till it stops. Slide the gear selector forward towards the chuck, so the number 2 is displayed.

To select the third gear (high speed, low torque setting), turn the tool off and wait until it stops. Slide the gear selector (9) to the middle position, so the number 3 is displayed.

**Note.** Do not change gears when the tool is running.



## Screw driver bit storage

A convenient storage area (10) with retaining clip, for screwdriver bits is provided on the left side of the tool.


## Chuck replacement

### Chuck removal

#### Always wear eye protection.


Turn the torque adjustment collar (2) to the "drill" position and first gear, on the gear shift (9). Tighten the chuck around the shorter end of a hex key (not supplied) of 5mm or greater size. Using a wooden mallet or similar object, strike the longer end in the clockwise direction. This will loosen the screw inside the chuck.

1. Open chuck jaws fully.
2. Insert a 5mm hex key into front of chuck between jaws to engage screw head. Remove screw by turning clockwise.
3. Place the hex key in chuck and tighten. Using a wooden mallet or similar object, strike key sharply in the anti-clockwise direction. This will loosen the chuck so that it can be unscrewed by hand.



### Chuck installation

1. Screw the chuck on by hand as far as it will go and insert screw (LH thread).
2. Tighten the chuck around the shorter end of hex key (not supplied) strike the longer end in the clockwise direction with a wooden mallet.



3. Remove the hex key and open the jaws fully. Tighten the screw in the centre of the chuck firmly, with the hex key in an anti-clockwise direction.

## Drilling metals

- For maximum performance, use high speed steel bits for metal or steel drilling.
- Ensure that the torque adjustment / hammer selection collar (2) is in normal drilling mode.
- Begin drilling at a very low speed to prevent the bit from slipping off the starting point.
- Always clamp sheet metal.
- Support thin metal with a block of wood to avoid distorting it.
- Use a punch to mark the centre of the hole.
- Use a suitable lubricant for the material you are working on.

### Use:

Oil  
Turpentine or paraffin  
Do not lubricate

### for:

Steel  
Aluminium  
Brass, copper or cast iron

## Drilling plastics and plastic coated chipboard

- Use high speed drill bits
- See drilling wood below

## Drilling masonry

- For maximum performance use carbide-tipped masonry impact bits when drilling holes in brick, tile, concrete etc.
- Turn the mode selector to hammer mode, then rotate the torque collar to the drill position.
- Apply light pressure and medium speed for best results in brick.
- Apply additional pressure and high speed for hard materials such as concrete.
- When drilling holes in tile, practice on a scrap piece to determine the best speed and pressure.

## Drilling wood

- For maximum performance, use high speed steel bits for wood drilling.
- Ensure that the mode selector is in normal drilling mode.
- Begin drilling at a very low speed to prevent the bit from slipping off the starting point. Increase the speed as the drill bites into the material.
- When drilling through holes, place a block of wood behind the work piece to prevent ragged or splintered edges on the back side of the hole.
- **WARNING.** Never attempt to lock the trigger switch in the on position, do not lock the trigger on jobs where your hammer drill may need to be stopped suddenly.

## All drilling operations

- Mark off the centre of the hole using a centre punch or nail.

## Care

- Don't force the drill, let it work at its own pace
- Keep the drill bit sharp.
- Reduce pressure, as the drill is about to break through the item being drilled.

## Maintenance

- Store the tools, instruction manual and where necessary the accessories in the original packaging. In this way you will always have all the information and parts ready to hand.
- Do not throw used batteries into fire or water. There is a danger of explosion! Please hand in non-working or used batteries, or tools with built-in batteries, to the environmentally-safe disposal unit at a municipal waste-disposal centre, or to your dealer.

## Power cord maintenance

If the supply cord needs replacing, the task must be carried out by the manufacturer, the manufacturer's agent, or an authorised service centre in order to avoid a safety hazard.



---

# GMC customer assist

---

Attach Your  
Receipt Here

If your product needs repairing, replacing, technical service or you simply need help or advice, please contact us on our Customer Assist Line 1300 880 001 (Australia) or 0800 445 721 (New Zealand).

For prompt service we suggest you log your service request online at [www.gmcservice.com.au](http://www.gmcservice.com.au). Should you not have access to the Internet, please contact our service department on 1300 880 001 (Australia) or 0800 445 721 (New Zealand). 7am – 7pm, 7 days a week (AEST).

---

**Please note that if repair or replacement is required, you must provide a valid original purchase receipt.**

---

You will need the following details at hand to log your service request;

**Personal details:** First & Last name, address, pick up address, contact phone numbers, email address

**Product details:** Product number, date of purchase, retailer bought from, State & postcode, receipt number, reason for the request, copy of official purchase receipt

Attach your purchase receipt and save with this Manual for future reference.

Please refer to our website [www.gmcompany.com](http://www.gmcompany.com) for full GMC warranty Terms and Conditions.

**GMC**<sup>®</sup>  
**GLOBAL MACHINERY COMPANY**