


STAR WARS™

CLONE TROOPER LAPTOP



For Ages 5 & Up



Product does not have INTERNET
or data storage capabilities.



Dear Parent(s)/Guardian(s),

Thank you for choosing the **CLONE TROOPER LAPTOP**.

Designed with fun in mind,

the **CLONE TROOPER LAPTOP** is packed with
stimulating games and activities that will

make an invaluable contribution to your child's development.

The activities used to help further your child's skills cover words, math,
memory, logic, typing, music and games.

The **CLONE TROOPER LAPTOP** provides a dependable and
realistic introduction to computers,
encourages creativity and independent learning.

Learning has never been so much fun!

Table of Contents

Chapter 1	1
About the CLONE TROOPER LAPTOP	
Chapter 2	3
Getting Started	
Chapter 3	5
Game Rules and Selection	
Chapter 4	6
Useful Features and Controls	
Chapter 5	8
Activities	
Word	8
Word Facility	8
Order Scramble	8
Letter Assemble	8
Word Loop	8
Spelling Execution	8
Word Force	8
Battle Arena	9

Math	9
The Force Of Numbers	9
Jawa Subtract	9
Operation Sign	9
Balance Code	9
Rescue Time	9
Rapid Response	10
TIE Attack	10
Memory	10
Republic Assault	10
Creature I.D.	10
Tune Range	10
Trooper Training	10
Logic	11
Speeder Bike	11
Heated Battle	11
The Next System	11
Coruscant Landing	11
Droid Repair	11
Game	12
Defend the City	12
Droid Battle	12
At War	12
Ultimate Duel	12

Music	12
Target Locked	12
Dancing Jam	13
Max Rebo Play	13

Chapter 6	14
------------------------	----

Troubleshooting

Chapter 1

About the CLONE TROOPER LAPTOP

Features

30 Activities!

- Word
- Math
- Memory
- Logic
- Game
- Music

Multimedia

- Volume Control

Display

- LCD screen
- Automatic shut-down

Interface

- QWERTY keyboard
- Number keys
- Direct button to Game Category selection
- Cursor pad


Audio

- Voices of Obi-Wan, Captain Rex and Yoda


The **CLONE TROOPER LAPTOP** is supplied with the following parts:
(Please contact your retailer should any parts be missing.)

1 - Unit

2 - Instruction manual



Unit






Chapter 2

Getting Started

The **CLONE TROOPER LAPTOP** operates on 3 “AA” size batteries or a 6V AC/DC adaptor (not included).

Battery Installation

1. Make sure the unit is turned off.
2. Open the battery cover at the back of the unit using a coin or a straight blade screwdriver.
3. Insert 3 “AA” size batteries.
(Note the correct polarity: +, -).
4. Replace the cover.



AC/DC Adaptor Connection

Please turn off the unit before plugging in the AC/DC adaptor to prevent damage to the unit. Plug the adaptor into the adaptor jack (center positive type) located on the left hand side of the unit. Plug the adaptor into a wall outlet.


Caution

- Do not mix different types of batteries or old and new batteries together.
- Only use batteries of the same or equivalent type as recommended.
- Remove all batteries when replacing.
- Remove batteries from the unit if the unit is not going to be used for long periods of time.
- Do not dispose of batteries in fire.
- Do not recharge non-rechargeable batteries.
- Rechargeable batteries are to be removed from the toy before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Remove exhausted batteries from the toy.
- Do not short-circuit the supply terminals.
- It may contain small parts due to abuse and/ or damage to the unit.
- Not suitable for children under 3 years of age.

Caution

- The unit must not be connected to a power supply greater than 6V.
- Only use the recommended adaptor.
- The adaptor is not a toy.
- Do not short-circuit the supply terminals.
- Toys liable to be cleaned with liquid are to be disconnected from the power source before cleaning.
- Due to AC/DC adaptor connection, this product is not suitable for children under 3 years to use without adult supervision.
- Any safety isolating adaptor to be used with the toy should be regularly examined for potential hazard, such as damage to the cable or cord, plug, or enclosure of other parts. In the event of such damage, the toy must not be used until the damage has been properly removed.

Starting the **CLONE TROOPER LAPTOP**

Open the unit by pushing on the mouthpiece of the Clone Trooper helmet situated on the laptop cover. Alternatively, if the unit is already open, turn on the **CLONE TROOPER LAPTOP** using the  button located on the upper right hand corner of the keyboard.




Closing the **CLONE TROOPER LAPTOP**

At the end of a session, remember to turn off the power by pressing the ON/OFF button located at the top right of the keyboard and close the lid. Ensure the lid is securely shut to lock it.



Auto-off

If there is no input on the unit after five minutes, the unit plays a closing prompt and automatically turns itself off to conserve power. To begin play, press the  button to turn the unit back on.

Storage & Care

To ensure that the product enjoys a long life, please follow these simple rules:



- Regularly examine the unit for damage to the enclosure and other parts. In the event of such damage, the unit must not be used until the damage has been repaired.
- Always disconnect the power supply before cleaning. Keep the unit clean by wiping the exterior of the unit with a dry cloth.
- Avoid getting the unit wet.
- The unit should not be dismantled.
- Always store the unit away from direct sunlight, and high temperatures.
- Avoid leaving the unit in a car where it is exposed to direct sunlight. The unit should not be subjected to extreme force or shock.

Chapter 3

Game Rules and Selection

Game Selection

There are 6 categories in the **CLONE TROOPER LAPTOP** : Word, Math, Memory, Logic, Game and Music.

The main category selection menu will scroll to the next category every 7 seconds. Use the ◀ ▶ keys to scroll to the next category and press  to select. All the games under a category are listed in a game title selection menu. The player can use the ▲ ▼ keys to scroll through the activity names and press  to play.

Alternatively during game play, the player can press the  button to go back to the game categories. Every 15 seconds if the player is idle, Captain Rex will say “Use the arrow keys and press  to select a category” .

Attempts

In most activities the player will have three attempts per question. *Star Wars* characters will reveal the correct answer after three incorrect attempts.

If there is no input after 30 seconds, the instruction prompts will be repeated.

Levels

Some of the activities have different levels. At the end of each round (consisting of ten questions) a summary score screen will be shown so the player can see how well they have done. If the player has 80 or more points they will go up a level. A score between 50 to 79 will mean repeating the same level. A score of 49 or less will mean going down a level. When the player has successfully finished all levels or ten questions in games with no levels, a “PLAY AGAIN” screen will appear. Select “YES” to play the game again. To play another game, select “NO” to exit to “Game Title Selection”.

Time Limit

For most games, the player has one minute to answer each question.

Chapter 4

Useful Features and Controls


Keyboard

The **CLONE TROOPER LAPTOP** features a fully functional computer keyboard.

Game Category Button

Pressing the  button will bring the player to a list of categories.

Arrow Keys

Use the arrow keys  to make a selection or to navigate in the games.

Cursor Pad

The **CLONE TROOPER LAPTOP** comes with a directional cursor pad below the keyboard. The pad can be pushed up, down, left or right to move the highlight on screen for selection and navigation of the games. To submit an answer, press one of the submit buttons near the directional cursor pad.


Volume Control


Use the volume controls located at the top right of the keyboard. The choices are high, middle and low.

Contrast Control


Use the contrast controls located at the top left of the keyboard. The choices are high, middle and low.

Demo


Press the  key to see a demonstration of some of the exciting features and activities in the **CLONE TROOPER LAPTOP**.



Help

Press the  key for extra hints to a question. Using this function will reduce the total score for the current question. Not all games have this function.

Repeat

Press the  key to repeat a question or an instruction.

ESC

Press the  key to exit the game and return to the previous menu.


Music

Press the  key to turn the background music on/off during game play.

Backlight Key

Press the  key to turn the LCD backlight on and off. The LCD backlight is on by default.


Answer Key

Press the  key to reveal the correct answer to a question. The player needs to think carefully before pressing this key as no points will be awarded for that question.


Delete

Press the  key to remove previously entered letter(s) or number(s).

Enter

Press the  key to submit an answer.

Shift

Hold down the  key to access secondary functions.

Chapter 5

Activities

Word

Word Facility

Learn the spelling and the pronunciation of the vocabulary words from five different topics: Animals, Transport, Objects, Jobs and Places, Body and Actions along with some amazing animation.

Order Scramble

Rearrange the letters to spell the word correctly.

Letter Assemble

Delete the extra letter from the word to spell it correctly.

Word Loop


Spell the word by only driving through the letters in the vocabulary word.

Spelling Execution

An animated vocabulary word is displayed and the player is asked to spell out the word.

Word Force

Guess the word with the given hints. Two hints will be shown per question, one at a time.



Battle Arena


The clone armies are under attack! Type as fast as possible to evade the incoming bullets. The Clone Trooper will read out the selected word for the player to type.



Math

The Force Of Numbers

Complete the addition equation.



Jawa Subtract

Complete the subtraction equation.



Operation Sign

Complete the equation by selecting the correct sign.



Balance Code

Find the equation with the smallest or the largest value.



Rescue Time

Select the correct time shown on the clock.



Rapid Response

Answer as many question as you can in the given time.



TIE Attack

Reorganize the numbers within the given order.



Memory

Republic Assault

Remember the number sequence on the passing Republic Attack Gunships.



Creature I.D.

Remember which creature is shown and identify it from a selection of two similar creatures.



Tune Range

Remember the sequence of the tones played and repeat it.



Trooper Training

Watch carefully and remember which Clone Trooper has the blaster.



Logic


Speeder Bike

Drive through the checkpoints without repeating your steps or hitting any other speeder bikes.



Heated Battle

Type in the answer to complete the sequence.



The Next System

Select the object, letter or number that fits into the missing space.



Coruscant Landing

Color coordinate the landing Jedi starfighters to the same color docks located on the bottom of the screen.



Droid Repair

Spot the odd character out.



Game

Defend the City

Repair the damages created by the droids.




Droid Battle

Help Anakin get across the battle field by jumping from STAP to STAP.



At War

Eliminate as many droids as you can. When it reaches the middle of the screen, on top of the arrow, press  to attack.



Ultimate Duel

Be put to the test by answering as many games as possible in three minutes.





Music

Target Locked

Select a musical melody and add beats to the song! Type in the letter shown when it reaches the targeted area in the middle of the screen.





Dancing Jam

Choose a song and select dance moves for Sy Snootles to dance to. Use the arrow keys and press  to select the dance moves. Press  to see Sy Snootles dance. Press [C] to cancel all moves.



Max Rebo Play

Have fun composing melodies with the on-screen piano. Use the keyboard to compose a melody. Press  to listen,  to pause and [C] to cancel all previously entered tunes.



Chapter 6

Troubleshooting

Developing learning products is a responsibility that we at Oregon Scientific take very seriously. We make every effort to ensure the accuracy and appropriateness of the information which forms the value of our products. However, errors can sometimes occur. It is important for you to know that we stand behind our products and we encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. Our service representative will be happy to help you. Before contacting an authorized service representative at 1-800-853-8883, carry out the following simple checks. It may save you the time of an unnecessary service call.

No display

Are the batteries installed properly?
Do the batteries need replacing?

Black-out screen or abnormal display

Disconnect the power supply by removing batteries for at least 10 seconds before connecting the power supply again. In an environment prone to static discharge, the unit may malfunction. To reset, remove batteries or disconnect the adaptor for at least 10 seconds before connecting the power supply again. Conforms to safety requirements of ASTM F963, EN71 Parts 1,2 and 3 and EN62115. In an effort to continually improve our products, the actual screen display on the product may differ slightly from the diagrams shown.

Oregon Scientific, Inc.
19861 SW 95th Avenue
Tualatin, OR 97062, USA
Hotline: 1-800-853-8883

Warning:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

- There may be small parts that can cause damage to the unit.
- Not suitable for children under 3 years.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy. If not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.
- This Class B digital apparatus complies with Canadian ICES-003.



DISPOSAL

Do not dispose of this product as unsorted municipal waste.

Such waste should be collected separately for special treatment.

STAR WARS™



 **Oregon**
SCIENTIFIC

Electronic Learning Products