

Stretch your mind with
other software titles for your Smart Cycle®!

Each sold separately and subject to availability.



© 2010 Viacom International Inc. All Rights Reserved. Nickelodeon, SpongeBob SquarePants and all related titles, logos and characters are trademarks of Viacom International Inc. Created by Stephen Hillenburg.



DC SUPER FRIENDS and all related characters and elements are trademarks of and © DC Comics.



WB SHIELD: TM & © Warner Bros. Entertainment Inc.

(s10)

Disney • Pixar elements © 2010 Disney • Pixar

Shrek Forever After™ & © 2010 DreamWorks Animation L.L.C.


Fisher-Price, Inc., a subsidiary of Mattel, Inc., East Aurora, NY 14052 U.S.A. ©2010 Mattel, Inc. All Rights Reserved. ® and ™ designate U.S. trademarks of Mattel, Inc., unless otherwise indicated.

www.fisher-price.com

Fisher-Price®

SMART CYCLE®
RACER

PHYSICAL LEARNING ARCADE SYSTEM



NOTICE ABOUT EPILEPSY AND SEIZURES

PLEASE READ THIS NOTICE BEFORE YOU OR YOUR CHILD USE ANY VIDEO GAME.


A very small portion of the population have a condition which may cause a momentary loss of consciousness when viewing certain kinds of flashing lights or patterns that are commonly present in our daily environment. This condition may cause seizures while watching some kinds of television pictures or playing certain video games. Players who have not had any previous seizures may nonetheless have an undetected epileptic condition.

If you or anyone in your family has experienced symptoms linked to an epileptic condition (e.g. a seizure or loss of awareness), consult your physician before playing video games. We recommend that parents observe their children while they play video games. If you or your child experience any of the following symptoms such as dizziness, altered vision, eye or muscle twitching, involuntary movements, loss of awareness, disorientation or convulsions, DISCONTINUE USE IMMEDIATELY and consult your physician.


Additionally, please follow these precautions whenever playing a video game:

- Do not sit or stand too close to the television screen. Play as far back from the screen as possible.
- Do not play if you are tired or need sleep.
- Always play in a well lit room.
- Be sure to take a 10-15 minute break every hour while playing.

CYCLE CONTROLS



GETTING STARTED



- Please keep these instructions for future reference, as they contain important information.
- Insert the game cartridge into the socket on top of the cycle. Push to be sure it's fully inserted.
- Turn your TV or VCR power **ON**.
- Slide the power switch on the cycle to **ON I**.
- To find the picture on your TV screen, set your TV's or VCR's mode selector to INPUT or VIDEO IN.

Note: You can use this Smart Cycle® software with any Smart Cycle® model.



GARAGE



- Use the joystick to choose the type of car you'd like to drive.
- Press either handlebar button to make your selection.
- Repeat this process to choose the color, look and sound of your car.



BACK TO THE ROAD



Find the objects!

- Pedal the cycle to move down the road.
The faster you pedal the faster you go!
- Use the handlebar to steer.
- Collect all the objects shown in the upper left of the screen. Simply drive into them. Don't bump into the other objects.



Taking Snap Shots

- Press the right handlebar button  to take snap shots in any activity.



MATH SMASH DERBY



Off Ramps

- Keep traveling down the road and go all the way around the road or head onto an off-ramp for other fun games and activities. Simply bear to the side of the road as you see one approaching.


Hint: If you miss your ramp, you can pedal in reverse to back up.



Time


Score

Ram into other cars to collect points.

- Use the joystick to drive your car.
- Crash into other cars to collect points.
- Collect enough points before time runs out to move to the next round.
- Look out for added obstacles in every level!
- When you're finished with this activity, press the exit button  to return to the road. Pedal to the next activity.



FOUR ON THE FLOOR




Test your engine's speed!

- Use the joystick and handlebar buttons to choose the engine you'd like to test out.




Tach

Target Number

- Pedal to "rev" the engine. As you pedal faster or slower, the needle on the tach moves up and down.
- Try to match the target number. For example, "rev" the engine to 80!
- Be careful so that you don't "rev" the engine to the red zone or you'll overheat.
- When you're finished with this activity, press the exit button  to return to the road. Pedal to the next activity.




FREEWAY FRENZY



Gas Gauge

Gas Can




- Cross the finish line and your time is displayed on screen.
- Move to the next level where there are more obstacles and more traffic to drive through.
- When you're finished with this activity, press the exit button  to return to the road. Pedal to the next activity.

Drive down the road without crashing or running out of gas.

- Use the joystick to drive your car down the road.
- Check your gas gauge and collect gas cans on the road before you run out of gas!
- Don't run into other cars or objects, or they'll slow you down.
- Drive over ramps or turbo arrows for extra fun.




DISASTER ALLEY



Number of Moves

Help fix the mixed up road!

- Use your joystick to select a road piece on the bottom of the screen. Press a red handlebar button to pick it up.
- Then, use your joystick to move the road piece. Press a red handlebar button to put it down.



Dynamite

- Complete the road so traffic can resume. Move to the next level where the road is tougher to rebuild.

Hint: Select the dynamite to start over at any time.

- When you're finished with this activity, press the exit button  to return to the road. Pedal to the next activity.



NUMBER JUMP




Cars

How many vehicles can you jump?


- Move the joystick to choose the number of cars to jump. Then, press a handlebar button to make your selection.



- Pedal as fast as you can. The faster you pedal, the farther you jump.
- If you don't pedal fast enough, you'll crash.
- When you're finished with this activity, press the exit button  to return to the road. Pedal to the next activity.



THE BIG RACE



Pedal as fast as you can to the finish line!

- Use the joystick to choose 1 Player or 2 Player game. Press either handlebar button to select the game.



1 Player


- Pedal down the road as fast as you can to the finish line. Try to speed past the other cars. Get to the finish line first and you win!




BONUS ACTIVITY



2 Player

- Each player takes a turn. Pedal down the road as fast as you can to the finish line. Look at your time.
- Now it's time for Player 2 to beat your time.
- The player with the fastest time *wins*.
- When you're finished with this activity, press the exit button  to return to the road. Pedal to the next activity.



- To visit here, you need to visit all of the activities around the road first.
- Watch the cars parade through victory lane.
- When you're finished with this activity, press the exit button  to return to the road. Pedal to the next activity.




TRAVEL JOURNAL





See previous
snap shot

See next
snap shot

- Press the travel journal button . Then use the joystick and handlebar buttons to review and select a snap shot.





Stamp Tool Erase

- Next, use the joystick and handlebar buttons to select the stamp tool to decorate your picture.
- Choose a stamp with the joystick and handlebar buttons and place it on the snap shot. 
- Select the erase button  to clear the screen and decorate another picture.



THE MAP



- You can travel down the road and head onto an off-ramp to access activities or simply press the map button  to visit any of the activities around the course.

CONSUMER INFORMATION

CONSUMER ASSISTANCE
 1-800-432-5437 (US & Canada)
 1300 135 312 (Australia)
service.fisher-price.com

Fisher-Price, Inc., 636 Girard Avenue, East Aurora, NY 14052.
 Hearing-impaired consumers: 1-800-382-7470.

Outside the United States:

Canada: Mattel Canada Inc., 6155 Freemont Blvd.,
 Mississauga, Ontario L5R 3W2; www.service.mattel.com.

Great Britain: Mattel UK Ltd, Vanwall Business Park,
 Maidenhead SL6 4UB. Helpline: 01628 500303.
www.service.mattel.com/uk

Mattel Europa, B.V., Gondel 1, 1186 MJ Amstelveen, Nederland.

Australia: Mattel Australia Pty. Ltd., 658 Church Street,
 Locked Bag #870, Richmond, Victoria 3121 Australia.

New Zealand: 16-18 William Pickering Drive,
 Albany 1331, Auckland.

- Wipe with a clean cloth dampened with a mild soap and water solution. Do not immerse.
- This product has no consumer serviceable parts. Do not take this product apart.



Protect the environment by not disposing of this product with household waste (2002/96/EC). Check your local authority for recycling advice and facilities (Europe only).