

FLX – VoIP

Registering with Panasonic

KX-TDE100, KX-TDE200, KX-TDE600, KX-NCP500, KX-NCP1000

Date: April 6th, 2012

This technical note gives a detailed description on how to register a Revolabs FLX conference phone with a Panasonic IP PBX. In the management interface of the Panasonic IP PBX a SIP extension and user has to be created. Once that user is created, the FLX can be set up to register with the Panasonic IP PBX.

To perform the tasks described in this document, the user needs to have administrative rights on the Panasonic PBX. While the steps in this document are not difficult, we recommend that a trained administrator should perform them.

Configuring the Panasonic PBX for FLX Registration

If you do not have SIP enabled yet on your system, you need to add a virtual SIP card (SIPEXT32 Virtual Card) to the PBX if you do not have one yet. This is done on the System Management – Configuration page.



Click on Activation Key, and add the license for the SIP stations.

| ninund Anno Anno Anno Anno Anno Anno Anno An | OK(0) Cancel(C) Apply(A) IPCMPR-ID:1300-0202-F038-499E IPCMPR-ID:1300-0202-F038-499E | Ti IP-GW channel | he number of activated IP-GW : 3 s can only be set to 32 or less. | /0 | | | |
|--|--|------------------------------------|--|-------|--|--|--|
| | | The nun | nber of activated IP Softphone : 0 | /0 | | | |
| | Activated Eacture | The number of activated feature by | | | | | |
| | Activated Feature | VolP-DSP Card | SD Card | Total | | | |
| | IP Trunk (ch) | 0 | 0 | 0 | | | |
| | IP Proprietary Telephone (ch) | 0 | 0 | 0 | | | |
| | IP Proprietary Telephone / IP Softphone (ch) | 0 | 0 | 0 | | | |
| | SIP Extension (ch) | 0 | 16 | 16 | | | |
| | Enhanced Features | 0 | 0 | 0 | | | |
| | CA Basic (user) | 10 | 0 | 10 | | | |
| | CA Pro (user) | 0 | 0 | 0 | | | |
| | CA Supervisor (user) | 0 | 0 | 0 | | | |
| | CA Operator Console (user) | 0 | 0 | 0 | | | |
| | CA Network Feature (user) | 0 | 0 | 0 | | | |
| | CA Thin Client Server | 0 | 0 | 0 | | | |
| | CA Multiplexer (application) | 0 | 0 | 0 | | | |
| | Reserved | 0 | 0 0 | | | | |

Make sure that you restart the virtual IP cards after this step to activate the licenses. Please consult your Panasonic manuals for the exact procedure.

Back on the Slot page, open the properties page of the SIPEXT32 card.

| X 1.1.5 | K 1.1 Slot Port Property - Virtual SIP Extension Port | | | | | | | | | | |
|---------|---|-----------------|---------------------|------------------|----------|------------|-----------------------|-----------|---------------------------------------|----------------------------------|------|
| | | | | | | | | | | | |
| | ON | (0) | Cancel(C) | Apply(A) | | | | | | | |
| | amm | and(<u>U</u>) | Copy to(<u>I</u>) |] | | | | | | | |
| | . , | io. Siot | Port | Extension Number | Password | Connection | Current IP Address | Bearer | Packet Sampling Time (G.711/G.722) | Packet Sampling Time (G.729A) | Rese |
| 1 | 5 1 | 6 | 1 | 469 | | Faut | 0.0.0.0 | Automatic | 20 ms | 20 ms | OFF |
| | 1 | 6 | 2 | 470 | | Faul | 0.0.0 | Automatic | 20 ms | 20 ms | OFF |
| | 1 | 6 | 3 | 471 | | Fout | 0.0.0.0 | Automatic | 20 ms | 20 ms | OFF |
| | 4 | 6 | 4 | 472 | | Fault | 0.0.0.0 | Automatic | 20 ms | 20 ms | OFF |
| | 5 | 6 | 5 | 473 | | Fault | 0000 | Automatic | 20 ms | 20 ms | OFF |
| | e | 6 | 6 | 474 | | Fault | 0.0.0.0 | Automatic | 20 mš | 20 mš | OFF |
| | 7 | 6 | 7 | 475 | | Faut | 0000 | Automatic | 20 ms | 20 ms | OFF |
| | 1 | 6 | 8 | 476 | | Faut | 0.0.0.0 | Automatic | 20 ms | 20 ms | OFF |
| | 5 | 6 | 9 | 477 | | Fault | 0.000 | Automatic | 20 ms | 20 ms | OFF |
| | . 1 | 0 6 | 10 | 478 | | Faut | 0.0.0.0 | Automatic | 20 ms | 20 ms | OFF |
| | | 1 6 | 11 | 479 | | Fault | 0.0.0.0 | Automatic | 20 ms | 20 ms | OFF |
| | 1 | 2 6 | 12 | 480 | | Faut | 0.0.0.0 | Automatic | 20 ms | 20 ms | OFF |
| | 1 | 3 6 | 13 | 481 | | Fault | 0.0.0.0 | Automatic | 20 ms | 20 ms | OFF |
| | 1 | 4 6 | 14 | 402 | | Faut | 0.0.0.0 | Automatic | 20 ms | 20 ms | OFF |
| | 1 | 5 6 | 15 | 483 | | Faut | 0.0.0.0 | Automatic | 20 ms | 20 ms | OFF |
| | 1 | 6 6 | 16 | 484 | | Fout | 0.0.0.0 | Automatic | 20 ms | 20 ms | OFF |
| | 1 | 7 6 | 17 | 486 | | Fault | 0.0.0.0 | Automatic | 20 ms | 20 mš | OFF |
| | 1 | 8 6 | 18 | 487 | | Faut | 0.0.0.0 | Automatic | 20 ms | 20 ms | OFF |
| | 1 | 9 6 | 19 | 400 | | Faut | 0.0.0.0 | Automatic | 20 ma | 20 ms | OFF |
| | 2 | 0 6 | 20 | 459 | | Fault | 0.000 | Automatic | 20 ms | 20 ms | OFF |
| 2 | 3 | 1 6 | 21 | 490 | | Faut | 0.0.0.0 | Automatic | 20 ms | 20 mš | OFF |
| | 2 | 2 6 | 22 | 491 | | Fault | 0.0.0.0 | Automatic | 20 ms | 20 ms | OFF |
| | 3 | 3 6 | 23 | 492 | | Faut | 0.0.0.0 | Automatic | 20 ma | 20 ms | OFF |
| | 2 | 4 6 | 24 | 493 | | Faul | 0.0.0.0 | Automatic | 20 ma | 20 ms | OFF |
| | 2 | 5 0 | 25 | 494 | | Feut | 0.0.0.0 | Automatic | 20 me | 20 ms | OFF |
| | 3 | 6 8 | 28 | 495 | | Paul | 0.000 | Automatic | 20 ms | 20 ms | Chh |
| | 3 | 7 6 | 27 | 490 | | Faut | 0.0.0.0 | Automatic | 20 ms | 20 ms | OFF |
| | 1 | 5 0 | 28 | 497 | | Faul | 0.0.0.0 | Automatic | 20 ms | 20 ms | OFF |
| | 2 | 9 6 | 29 | 498 | | Fault | 0.0.0 | Automatic | 20 ms | 20 ms | OFF |
| | | 0 0 | 30 | 565 | | Faul | 0.0.0.0 | Automatic | 20 ms | 20 ms | OFF |
| 2 | 1 3 | 1 6 | 31 | 566 | | Faut | 0.0.0.0 | Automatic | 20 ms | 20 ms | OFF |
| | - 2 | 2 0 | 22 | 201 | | Faul | 3.0.0.0 | Automatic | 20 ms | ev ris | OFF |
| | | | | | | | | | | | |

In "Connection", take the port you want to use out of service ("OUS"). You can now assign a password to the extension you want to use, in our case we assign password "469" to extension 469.

| System Menu | X 115 | 61.7 | Port Prope | rty - Vitua | i SIP Extension Port | | | | | | |
|-----------------|-------|-------|------------|-------------|----------------------|----------|------------|----------------------|-----------|---------------------------------------|----|
| t Configuration | | | | | | | | | | | _ |
| No. 1 Set | | OK(2) | | Cancel() | A399y(<u>A</u>) | | | | | | |
| ag 3 option | | No. | Set | Pert | Edension Number | Password | Connection | Current P Address | 5 carer | Packet Sampling Time (0.711/0.722) | |
| | 9 | 1 | 6 | 1 | 469 | 405 | OUS | 0.000 | Automatic | 20 | 1 |
| | | 2 | 6 | 2 | 470 | | Faut | 0000 | Automatic | 20 ma | 1 |
| | | 2 | | 3 | 471 | | Faut | 0000 | Automatic | 20 ma | 1 |
| | | 4 | 6 | 4 | 472 | | Fault | 0000 | Automatic | 20 ma | 1 |
| | | 5 | 6 | 5 | 473 | | Fault | 0.0.0 | Automatic | 20 mi | 1 |
| | | 6 | 6 | 6 | 474 | | Fault | 0.000 | Automatic | 20 ma | 12 |
| | | 7 | 6 | 7 | 475 | | Fault | 0000 | Automatic | 20 mi | 1 |
| | | | 6 | 8 | 476 | | Fault | 0000 | Automatic | 20 mil | 12 |
| | | 9 | 4 | 9 | 427 | | Fault | 0000 | Automatic | 20 ma | 12 |
| | | 10 | 6 | 10 | 478 | | Fault | 0000 | Automatic | 20 ma | |
| | 1.000 | e-0.1 | | | | | | | | | |

Click on "Apply" to apply the settings, then select "INS" for the Connection to put it back into service.

Please note that the Panasonic PBX does not support NAT traversal, therefore the FLX VoIP wireless conference phone needs to be on the same network as the PBX, or using a VPN connection into the network.

Registering the FLX with the Panasonic PBX

You can use either the FLX handset or the FLX web UI to register the FLX with the Panasonic PBX. We are showing how to do it with the web interface.

- 1. IP address of the FLX.
 - a. If you are using DHCP in your environment, the FLX automatically receives an IP address. From the FLX handset, choose Menu and "System Info" (the symbol with the "i") and select "About System". The IP address (static or via DHCP) of your FLX is shown.
 - b. If you are using static IP, on the FLX handset chose "Setup" (the wrench symbol), "Advanced Setup", enter the administrator password (default password is "7386""), enter "Network Settings". Change "DHCP ON" to "DHCP OFF". Then enter "IP Settings". In this menu you can enter the IP address, Subnet Mask, and other relevant information. Once you have entered all information, select "Return", and in the Network Settings menu select "Load Settings. This will restart your phone with the new network settings.
- 2. In a web browser of your choice, enter the IP address of the FLX phone. This will open the web interface for FLX. Enter the password ("7386"), and select "Administrator" in the right top of the screen.
- 3. On the left side, select "SIP Registration". The following screen will show:

| CRevolabs FLX VoIP Phone - Windo | ws Internet Explorer | | |
|--|---|--|-----------------------------|
| G V F http://10.134.123.2 | 10/ | 👻 😽 🗙 🚼 Google | • م |
| <u>File Edit View Favorites Too</u> | ols <u>H</u> elp | | 🗙 🍓 Convert 🔻 🔂 Select |
| 🚖 Favorites 🛛 😭 🏉 Suggested S | ites 🔻 🔊 Web Slice Gallery 👻 | | |
| 🖉 Revolabs FLX VoIP Phone | | 🗄 🕶 🗟 👻 🚍 🖶 💌 | Page • Safety • Tools • 🕢 • |
| Contraction of the second seco | SIP Registration Registrar: Use Proxy for Registration: Outbound Proxy: ID: Display Name: Username: Password: Registration Timeout (sec): Auto Re-registration Retry Interval (sec): Save Restart Phone | 10.1.1.1 No Proxy • 469 469 469 •••• 55 300 •••el Definition of the second se | Home User Administrator |

4. Enter the registration info for the Panasonic PBX:

Registrar – the IP address of your Panasonic PBX, in our example **10.1.1.1**

ID – User ID for the End User, most likely the extension number, in our example 469

Display Name - this can be any friendly name for the user

Username - enter the same User ID as above

Password – the End User's password, in our example **469**.

5. Press "Save". You will see the following screen.



6. On the left side select "Restart", and click on the "Restart" button. Your FLX phone will restart. You can close the Web browser.

If registration is successful, the handset will show the user ID at the top of the home screen.

If there is a registration failure, the handset will show that the phone is not registered. Please verify that the user ID and password are the same as the ones specified when configuring the Panasonic PBX. Also, in the Panasonic Management UI verify that the device was correctly set up and associated with the user.