

morphy richards®



12 cup filter coffee maker



Please read and keep these instructions

Getting the best from your new coffee maker...

Safety first

Caution must be used when handling hot water, coffee or steam.

Run water through your machine before first use

It is important to run water through your coffee maker in order to rinse the machine. You can also run water through to warm your coffee machine.

Descale as appropriate for the hardness of the water in your area

It is important to descale as the performance of your coffee maker may be impaired by limescale and other impurities in the water supply.




For replacement parts, help with using your Morphy Richards product, problems and lots more, contact us by phone or through our website.

CM47076 Rev 1



UK Helpline: 0844 871 0946
Replacement Parts: 0844 873 0712
Ireland Helpline: 1800 409 119

www.morphyrichards.com



Important safety instructions

The use of any electrical appliance requires the following common sense safety rules.

Primarily there is danger of injury or death and secondly the danger of damage to the appliance. These are indicated in the text by the following two conventions:

WARNING: Danger to the person!

IMPORTANT: Damage to the appliance!

In addition, we offer the following safety advice.

Location

- Remove all the packaging and retain for future reference.
- Ensure the coffee maker is used on a firm, flat surface.
- Do not use the coffee maker outdoors or in a bathroom.
- Do not place the coffee maker on a highly polished wooden surface, as damage may occur to the surface.
- Do not place the coffee maker on or near hot surfaces, such as a hot plate or radiant rings or near a naked flame.
- **WARNING:** Do not place the coffee maker onto a metal tray or metal surface whilst in use.

Mains lead

- Do not let the mains lead hang over the edge of the worktop where a child could reach it.
- Do not let the lead run across an open space e.g. between a low socket and a table.
- Do not let the lead run across a cooker or other hot area which might damage the cable.

- The mains lead should reach from the socket to the base unit without straining the connections.
- If the supply cord is damaged, it must be replaced by the manufacturer, it's service agent or similarly qualified person in order to avoid a hazard.

Personal safety


- Ensure the lid of the glass jug is securely in place before pouring.
- Take care to pour hot coffee slowly and carefully without tipping the glass jug too fast.
- Do not fill above the capacity mark of the water level gauge marked on the jug.
- Do not use the glass jug in a microwave.
- Do not touch metal parts until the unit has cooled.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.

Children

- Children do not understand the dangers associated with operating electrical appliances. Never allow children to use this appliance.
- Children should be supervised to ensure that they do not play with the appliance.

Product safety

- Never use warm or hot water to fill the water tank.
- Do not overfill the water tank.
- Ensure the lid of the glass jug is securely in place before pouring.



- Take care to pour hot coffee slowly and carefully without tipping the glass jug too fast.
- Do not place the glass jug on the hot plate unless the lid is in position.
- Do not fill above the capacity mark of the water level gauge.
- Make sure the mains lead does not touch the hot parts of the machine.
- Do not wind the mains lead around the hot appliance or store the appliance until it has fully cooled down.
- Do not use the coffee maker for anything other than it's intended purpose.

ELECTRICAL REQUIREMENTS

Check that the voltage on the rating plate of your appliance corresponds with your house electricity supply which must be A.C. (Alternating Current).

If the socket outlets in your home are not suitable for the plug supplied with this appliance, the plug should be removed and the appropriate one fitted.

WARNING : The plug removed from the mains lead, if severed, must be destroyed, as a plug with a bared flexible cord is hazardous if engaged into a live socket outlet.

Should the fuse in the 13 amp plug require changing, a 13 amp BS1362 fuse must be fitted.

WARNING: This appliance must be earthed.

Treating scalds


- Run cold water over the affected area immediately. Do not stop to remove clothing, get medical help quickly.

Other safety considerations

- Disconnect the coffee maker from the mains supply when filling, cleaning or not in use.
- When unplugging, turn any control to 'off', then remove the plug from the wall outlet.
- Keep the outside of the coffee maker area clean and dry at all times.
- Do not touch hot surfaces. Always use handles or knobs.
- Do not immerse the coffee maker itself in water and always ensure the electrical connections are kept dry.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Ring the helpline number for advice on examination and repair.
- The use of attachments or tools not recommended or sold by Morphy Richards may cause fire, electric shock or injury.

FEATURES

- 1 Hinged reservoir lid
- 2 Illuminated water level indicator
- 3 Glass jug with water level indicator
- 4 Jug lid
- 5 Hot plate
- 6 Digital control panel with LED display
- 7 Non drip valve
- 8 Filter locating tab
- 9 Removable permanent mesh filter
- 10 Removable filter holder



OPERATING THE APPLIANCE

Before use


Take your coffee maker out of the box and remove the packaging.

Wash the detachable parts of the machine in warm soapy water.

The first time you use your coffee maker, operate the coffee maker with water only.

General use




- 1 Lift up the hinged reservoir lid **1**.
- 2 Fill the water reservoir with the required amount of water using the water level indicator **2** as a guide **A**. Both the jug **3** and the water level indicator are marked in cups. Do not exceed the maximum level on the water gauge.
- 3 Spoon the required amount of ground filter coffee into the mesh filter **9**, spreading it evenly. We suggest one rounded dessert spoon for every cup, but individual tastes will vary. Ensure the filter is sitting properly in the filter holder and do not fill above the mesh line.
- 4 Close the reservoir lid.
- 5 Slide the jug into the coffee maker ensuring it sits correctly on the hot plate **5**. The jug lid must be in place during the brewing process, otherwise the non-drip valve **7** will not open, causing the filter to flood.
- 6 Plug the filter coffee maker in at the wall socket and switch ON. The LCD display **6** will illuminate to show the coffee maker is working.
- 7 Press the on/off button to start the brewing process. The red power light will glow and the coffee will start to brew.
- 8 Hot water will start to flow through the coffee grounds and into the glass jug as coffee.
- 9 When the coffee has been made, serve as required. The anti-drip valve will prevent any remaining coffee dripping onto the hot plate. Ensure that the jug is replaced on the hot plate after serving. While the coffee maker is switched ON, the hot plate will keep the coffee warm.
- 10 Switch off the coffee maker when the jug is empty or the coffee is no longer required.
- 11 Allow the unit to cool.
- 12 Remove the permanent filter and empty the used coffee grounds. Wash the filter immediately and dry thoroughly.




Refilling

- Switch off the coffee maker and allow 3 minutes to cool before refilling with cold water.

BUTTONS KEY

-  ON/OFF
-  Auto timer
-  Warmer

CONTROL PANEL



Switching on

- When the machine is switched on, the display will illuminate.
- To set the time, press the HOUR button. It is a 24 hour clock with AM or PM denoted.
- Then press the MINUTE button.

To brew at a pre-set time

- Press the PROGRAM button.

Note: If no buttons are pressed, the display will revert to the time display within 10 seconds.

- Press the HOUR button.
- Then press the MINUTE button to set the desired start time.
- Press the AUTO button (green light glows).

Note: Press the AUTO button again to cancel pre-set brewing.

To brew manually

- Press the ON/OFF button (red light glows).


Note: Press the ON/OFF button again to cancel brewing.


Adjustable warming plate temperature

- This coffee maker gives you the option of adjusting the Stay Warm Setting to slightly reduce the temperature of the coffee after it has brewed.
- When brewing the coffee, a steady orange light will appear on the 'warmer' button. In order to reduce the Stay Warm setting, push the 'warmer' button once, and the steady orange light will then blink.
- This setting should be used when the carafe is half full or less, to ensure the coffee quality is maintained.
- The Stay Warm setting will continue to operate as long as the unit is ON and will shut off automatically after two hours.
- When you begin to brew a new pot of coffee, the steady orange light will reappear, indicating the Coffeemaker will maintain the temperature of the higher Stay Warm Setting.

Coffee quality indicator

- To help you to decide if your coffee is likely to be of a good quality during keep warm mode, bars on the outside of the clock face indicate how long ago the coffee was brewed.





Locating the filter

- 1 To remove the filter holder, lift by using the two handles either side. To clean, see 'Cleaning and Maintenance' section on page 7.
 - 2 To refit, place the removable filter holder into the top of your coffee maker. Ensure that the cut out on the filter holder lines up with the slot at the back of the product.
 - 3 Then place the permanent mesh filter inside the filter holder.
- Note: Ensure the filter holder is correctly located, otherwise the non-drip valve will not open, causing the filter to flood.

CLEANING AND MAINTENANCE

Descaling

- If you live in a hard water area, we recommend that your coffee maker is descaled at regular intervals, e.g. every 2-3 months. In areas of moderately hard water, you should descale every 6 months.
 - If the water filters through more slowly than usual, it is a sign that descaling is necessary.
 - We recommend you use a proprietary liquid descaler which is especially made for coffee makers and plastic kettles. Follow the instructions on the bottle or sachet, and then operate the coffee maker with just water 3 times before making coffee.
 - Do not use a kettle descaler unless the packet specifically states it is suitable for coffee makers.
- Note: The permanent mesh filter should not be used during descaling.

Helpline

If you have any difficulty with your appliance, do not hesitate to call. We are more likely to be able to help than the store from where you bought it.

Please have the following information ready to enable our staff to deal with your enquiry quickly:

- Name of the product.
- Model number as shown on the underside of the appliance.
- Serial number as shown on underside of the appliance.


UK Helpline 0844 871 0946


Replacement Parts 0844 873 0712

Ireland Helpline 1800 409 119

Cleaning care

- Unplug the coffee maker and allow to cool.
- Do not immerse the coffee maker in liquid.





YOUR TWO YEAR GUARANTEE

It is important to retain the retailer's receipt as proof of purchase. Staple your receipt to this back cover for future reference.

Please quote the following information if the product develops a fault. These numbers can be found on the base of the product.

Model no.

Serial no.

All Morphy Richards products are individually tested before leaving the factory. In the unlikely event of any appliance proving to be faulty within 28 days of purchase, it should be returned to the place of purchase for it to be replaced.

If the fault develops after 28 days and within 24 months of original purchase, you should contact the Helpline number quoting Model number and Serial number on the product, or write to Morphy Richards at the address shown.

You may be asked to return a copy of proof of purchase.

Subject to the exclusions set out below (see Exclusions), the faulty appliance will then be repaired or replaced and dispatched usually within 7 working days of receipt.

If, for any reason, this item is replaced during the 2 year guarantee period, the guarantee on the new item will be calculated from the original purchase date. Therefore, it is vital to retain your original till receipt or invoice to indicate the date of initial purchase.

To qualify for the 2 year guarantee, the appliance must have been used according to the manufacturer's instructions. For example, coffee makers should have been regularly descaled.

Morphy Richards products are intended for household use only.

Morphy Richards has a policy of continuous improvement in product quality and design. The company, therefore reserves the right to change the specification of it's models at any time.

EXCLUSIONS

Morphy Richards shall not be liable to replace or repair the goods under the terms of the guarantee where:

- 1 The fault has been caused or is attributable to accidental use, misuse, negligent use or used contrary to the manufacturer's recommendations or where the fault has been caused by power surges or damage caused in transit.
 - 2 The appliance has been used on a voltage supply other than that stamped on the products.
 - 3 Repairs have been attempted by persons other than our service staff (or authorised dealer).
 - 4 The appliance has been used for hire purposes or non domestic use.
 - 5 The appliance is second hand.
 - 6 Morphy Richards are not liable to carry out any type of servicing work, under the guarantee.
 - 7 Plastic filters for all Morphy Richards kettles and coffee makers are not covered by the guarantee.
- This guarantee does not confer any rights other than those expressly set out above and does not cover any claims for consequential loss or damage. This guarantee is offered as an additional benefit and does not affect your statutory rights as a consumer.
 - This guarantee is valid in the UK and Ireland only.



For electrical products sold within the European Community. At the end of the electrical products useful life, it should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice in your country.

morphy richards®

**The After Sales Division
Morphy Richards Ltd**
Mexborough, South Yorkshire,
England, S64 8AJ

Helplines (office hours)
UK 0844 871 0946
Spare Parts 0844 873 0712
Republic of Ireland 1800 409 119

CM47076 Rev 1 04/08

For details of other products in the Morphy Richards range, please see our website . . .

www.morphyrichards.com

8

