TP-LINK®

Ouick Installation Guide

Wireless Pan/Tilt Surveillance Camera

MODEL NO. TL-SC4171G

Package Contents








Camera

Mounting Bracket

Power Adapter







Ethernet Cable

Resource CD

OIG

System Requirement

The following operating systems are supported:

- Windows 2000 Windows Vista
- · Windows 2003
- Windows XP

(*The pictures are for reference only.)

• Windows 7 • Mac

The following browsers are supported:

- Internet Explorer 6 or higher

(*Windows and Internet Explore Browser are recommended.)

Warning Before Installation

• Do not keep the Camera exposed to direct sunlight.



• Do not place the Camera in high humidity environments such as in a kitchen.




· Do not place the Camera where there are high temperatures such as near an oven.



· Do not place the Camera near devices that emit radio waves, such as mobile phones.




2 Physical Description



	Item	Description
•	Power LED	• Solid: The electrical power is on. • Off: There is no electrical power.
	Ethernet LED	 Solid: The Ethernet port is linked, but there is no activity. Blinking: There is traffic between the Ethernet port and the network. Off: There is no network connection.
	Reset Button	Step 1: Re-power on the camera and wait for at least 45s until it restarts up normally. Step 2: Press the button for more than 10s, then it will be restored to factory defaults after automatic rebooting.

3 Camera Mounting







Type A screws



Type B screws

NOTE: In the bracket, there are several mounting holes arranged in a circle. The direction of the camera's installation can be anywhere within a 360 degree scope, adjusted as required.

It is strongly recommended that you connect the Ethernet cable and power adapter cord to the camera first

Ceiling Mount


1 Fix the camera to the bracket with two type A screws.

> to the ceiling using two type B screws and two hollow ceiling anchors.





Fix the bracket to the wall using two type B screws and two hollow wall anchors.

Wall Mount




Fix the camera to the bracket with two type A screws.





4 Hardware Connection




- Connect the Camera to the LAN network (Router or Switch) via Ethernet cable.
- 2 Connect the power adapter cord to the DC In jack.
- 3 Plug the power adapter into the power outlet.

*For wireless connection, please refer to User Guide on the Resource CD.




Before proceeding, confirm that your PC is connected to your router and can access the Internet.

Make sure that your router's DHCP feature is enabled. If not, please refer to your router's instruction to enable it.



Software Installation


Insert the provided Resource CD into your CD-ROM drive.



The Setup Wizard will automatically pop up, then click "Intelligent IP Installer". 1



The Intelligent IP Installer window will appear. Click "Next".



Select the optional program as needed. The default setting is highly recommended. Click "Next".




Click "Finish" to complete the setup.

6 PC Configuration

The configuration is similar in Windows XP/Vista/7. Here we take Internet Explorer 6.0 in Windows XP for example.

Open IE browser. Click "Tools", then select "Internet Options..."




Click "Security" -> "Internet" -> "Custom Level...". Find the item "Download signed ActiveX controls" and check "Prompt". Click "OK". 2





Click "Security" -> "Local Intranet" -> "Custom Level...". Find the item "Download signed ActiveX controls" and check "Prompt". Click "OK". 2





- 1. If the CD does not automatically run with the installation window appearing, find the CD drive in the "My Computer" space and run it directly there.
- 2. The item "Download signed ActiveX controls" is "Prompt" by default, you can change it after the whole configuration.

Access the Camera Using IP installer

Click the icon of **Intelligent IP Installer** on the computer's Desktop. 3




Click "Search", the main page will show up listing all active TP-LINK camera devices. You can find the MAC Intelligent IP address of the Camera on its lable. Select the relevent camera from the list and click "Link to IE".



Enter User name and Password to log in to the IP Camera. (Default is admin / admin)



When accessing the IP Camera for the first time, a yellow information bar will appear below the address bar. Click the information bar, and select "Install ActiveX Control...".



Click "Install"



5 Live video displays in the centre of your web browser.



Note:

For advanced settings, please refer to the User Manual and Application Guide on Resource CD.

For detailed Troubleshooting and Technical Support contact, please log on to our Technical Support Website.

http://www.tp-link.com/en/support

Technical Support

Australia / New Zealand

NZ 0800 87 5465 E-mail: support.au@tp-link.com (AU)

support.nz@tp-link.com (NZ) Service time: 24hrs, 7 days a week

NZ 0800 87 5465 E-mail: support.tr@tp-link.com Service time: 9:00 AM to 6:00 PM, 7days a week

Turkey
Tel: 444 19 25 (Turkish Service)

E-mail: support.usa@tp-link.com Service time: 24hrs, 7days a week

E-mail: support.my@tp-link.com Service time: 24hrs, 7days a week

(if calls from mobile phone)

Tel: 1300 88 875465 (1300 88TPLINK)

Tel: AU 1300 87 5465

USA/ Canada Toll Free: +1 866 225 8139

- For more troubleshooting help, go to www.tp-link.com/en/support/faq
- To download the latest Firmware, Driver, Utility and User Guide, go to

http://www.tp-link.com/en/support/download/
For all other technical support, please contact us by using the following details:

Global Tel: +86 755 26504400

E-mail: support@tp-link.com Service time: 24hrs, 7 days a week

Singapore
Tel: +65 62840493
E-mail: support.sg@tp-link.com
Service time: 24hrs, 7 days a week

Tel: +44 (0) 845 147 0017 E-mail: support.uk@tp-link.com Service time: 24hrs, 7days a week

Ukraine Tel: 0-800-505-508

E-mail: support.ua@tp-link.com Service time: Monday to Friday 14:00 PM to 22:00 PM

Toll Free: 0800-770-4337 (Portuguese Service) E-mail: suporte.br@tp-link.com Service time: Monday to Saturday 08:00 AM to 08:00 PM

Tel: +39 02 66987799 E-mail: support.it@tp-link.com Service time: Monday to Friday, 9:00 AM to 6:00 PM

Indonesia

Tel: (+62) 021 6259 135 E-mail: support.id@tp-link.com Service time: Monday to Friday 9:00 -12:00 ; 13:00 -18:00 (Except public

Germany / Austria

Tel:+49 1805 875465 (German Service) +49 1805 TPLINK F-#3 1000 TPLINK
E-mail: support.de@tp-link.com
Fee: 0.14 EUR/min from the German
fixed phone network and up to 0.42
EUR/min from mobile phone. Service Time: Monday to Friday, 9:00 AM to 6:00 PM, GMT+1 or GMT+2 (Daylight Saving Time in Germany)
* Except bank holidays in Hesse

(IF Calls Hoff Thouse priorie) E-mail: support.pl@tp-link.com Service time: Monday to Friday 9:00 AM to 5:00 PM. GMT+1 or GMT+2 (Daylight Saving Time) Switzerland Tel: +41 (0)848 800998 (German Service)

Tel: +48 (0) 801 080 618 / +48 22 7217563

E-mail: support.ch@tp-link.com Fee: 4-8 Rp/min, depending on rate of different time Service time: Monday to Friday 9:00 AM to 6:00 PM. GMT+ 1 or GMT+ 2 (Daylight Saving

Tel: +33 (0) 820 800 860 (French service) Email: support.fr @tp-link.com Fee: 0.118 EUR/min from France Service time: Monday to Friday 9:00 AM to 6:00 PM (Except French Bank holidays) **Russian Federation**

Tel: 8 (499) 754-55-60 / 8 (800) 250-55-60 tel: 8 (499) 754-55-60 / 8 (800) 250-55-60 (toll-free call from any RF region)
E-mail: support.ru@tp-link.com
Service time: From 10:00 to 18:00 (Moscow time)
*Except weekends and holidays in
Russian Federation

TP-LINK TECHNOLOGIES CO., LTD.

www.tp-link.com