


Quick start guide for model DS3101

Battery installation

1. Align the two holes of the battery plug with the socket pins in the handset battery compartment, matching the red and black wires of the color-coded label.
2. Place the battery with the label **THIS SIDE UP** facing up and the wires in the lower right corner inside the battery compartment.
3. Align the cover flat against the battery compartment cover, then slide it towards the unit until it clicks into place.





Battery charging

The battery may have enough charge for short calls. For optimal performance, please charge the handset for 16 hours. You can keep the battery charged by returning the handset to the charger after each use. When the battery power is fully depleted, a full recharge takes about 16 hours.

For further information on battery, please see the **Battery** section of the user's manual.

The battery needs charging when:

- A new battery is installed in the handset.
- The handset beeps.
- The battery indicator  on the handset display is flashing.



Place the handset in the charger. The **CHARGE** light is on when the handset is properly positioned in the charger.

NOTE: Use only the power adapter and battery (or equivalent) supplied with your VTech telephone.




Adding your new handset

The **DS3101** handset will show **NOT REGISTERED** on the screen when newly purchased. This **DS3101** handset needs to be registered to the telephone base before use. You can register up to five handsets to the telephone base.

To register a handset to your telephone base:

Before registering an additional handset, make sure that the handset is installed and charged.

1. Place the unregistered handset in the telephone base or charger. If **PRESS FIND HNDST 4 SEC ON BASE** does not appear on the handset screen after a few seconds, remove the handset and place it in the telephone base or charger again.
2. On the telephone base, **press and hold FIND HANDSET** for about four seconds (until the **IN USE** light on the telephone base turns on) and then release the button. The handset will show **PLEASE WAIT...** and it will take about 10 seconds to complete the registration. The handset will show **HANDSET X REGISTERED** and will beep if registration is successful.



When the registration is complete, the newly registered handset will be assigned the next available handset registration number. For instance, if you already have **HANDSET 1** and **HANDSET 2**, the next registered handset will be **HANDSET 3**.

NOTES:

- If the registration is not successful, the display will show **NOT REGISTERED**. To reset the handset, remove the handset from the telephone base or charger and place it back in. Try the registration process again.
- You cannot register a handset if any telephone connected to the same telephone line is in use.
- If you experience difficulty registering a handset, see the **Troubleshooting** section on page 9 of the user's manual.

Replacing a handset

When you are replacing rather than adding a handset, for your handsets to be numbered sequentially, you need to delete all the handset registrations on the telephone base and then register all handsets again.

To de-register all handsets

1. **Press and hold FIND HANDSET** on the telephone base for about 10 seconds (until the **IN USE** light on the telephone base turns on and starts to flash), then release the **FIND HANDSET** button.
2. **Press and release FIND HANDSET** again. You must **press FIND HANDSET** while the **IN USE** light is still flashing. The **IN USE** light will flash for approximately seven seconds.
3. All handsets registered to the same telephone base will show **CONNECTING...** and it will take about 10 seconds to complete the de-registration process. All handsets will show **NOT REGISTERED** if deregistration is successful.



After deleting the registrations of all handsets, you will need to individually register each handset with the telephone base. For complete feature instructions, please refer to your user's manual.

NOTES:

- If the de-registration process is not successful, you may need to reset the system and try again. To reset: pick up the registered handset and press the **TALK/FLASH** button, then press the **OFF/CLEAR** button and place the handset back into the telephone base. You may also reset by unplugging the power from the telephone base, then plugging it back in.
- You cannot de-register the handset(s) if any telephone connected to the same telephone line is in use.

IMPORTANT!

If your product is not working properly:

- Refer to the **Troubleshooting** section of the user's manual.
- Visit our website at www.vtechphones.com. In Canada, go to www.vtechcanada.com
- Call our customer service at 1 (800) 595-9511. In Canada, call 1 (800) 267-7377.