


# Bravetti

PLATINUM PRO

## Accessories for Food Processor with Blender Model EP90XX



1. Blender Jar
2. Blender Jar Cover
3. Chopping Blade
4. Chopping Blade Protective Cover


### Using the Blender

**CAUTION:** Make sure that the unit is unplugged from the power source and the operating button is "OFF" before inserting or removing attachments and before cleaning.

1. Remove the processor bowl and lid.
2. Remove the safety cover. This can only be done once the processor lid has been removed.
3. Place the blender into its location on the processor body with the handle to the left. Turn counter clockwise until the blender clicks into place and the arrows are aligned.

**Warning:** Use extreme caution - blades are sharp. Handle carefully.


4. Place food in blender.
5. Place the blender lid and the measuring cap on the blender.
6. Replace the processor bowl and processor lid. Ensure that the lid tab has clicked into place. The blender will not operate if the processor lid is not clicked in place.
7. Plug in the processor.
8. Always operate the blender with the lid in place.



TO REMOVE THE BLENDER, YOU MUST FIRST UNLOCK AND REMOVE THE PROCESSOR LID (A). THEN UNLOCK AND REMOVE THE BLENDER (B) BY TWISTING CLOCKWISE.



**WARNING:** ALWAYS REMOVE THE BLENDER AND FIT THE SAFETY COVER (2) INTO THE PROCESSOR BODY (1) WHEN USING THE PROCESSOR.



**IMPORTANT:** Remove protective blade cover(s) before use. Protective blade covers to only be used for storage.

**CAUTION:** Never operate the blender with more than 42 oz. (1250 ml) of liquid or when empty.

- Recommended speed levels for blending are between 5 - Max.
- Do not overload past the MAX level on the blender.
- You can crush 10 oz. of ice cubes in 15-20 seconds in the blender.
- **To prevent spilling, do not operate the blender with more than 42 oz. (1250 ml) of liquid.**
- **Avoid contact with moving parts at all times.**
- Do not blend boiling liquid.
- To reduce the risk of severe injury to people or damage to the blender, keep hands, hair, clothing as well as spatulas and other utensils out of container while blending.





# **Bravetti**

PLATINUM PRO

## **Accessories for Food Processor with Blender Model EP90XX**

### **FITTING & USING THE CHOPPING BLADE**

In general, all attachments which are fitted within the processor bowl must be firmly attached to the spindle. Always adjust the attachments until you are sure that they are correctly fitted.



#### **Chopping Blade**

1. Fit the processor bowl and spindle as detailed previously.
2. Remove the chopping blade protective cover (4) from the metal chopping blade.
3. Fit the blade over the spindle and press firmly into place.

#### **WARNING:**

**USE EXTREME CAUTION - BLADES ARE SHARP. ALWAYS HANDLE THE CHOPPING BLADE BY ITS CENTRAL PLASTIC HUB.**

4. Place the food into the bowl.
5. Fit the lid and click into place as detailed in the "Setting Up" Section of the Instruction Book for the Food Processor/Blender (page 4).
6. Insert power cord into electrical wall outlet.
  - Keep hands and utensils away from cutting blades while chopping food to reduce the risk of injury to persons or damage to the food chopper. A scraper may be used, but must be used only when food processor is not running.
  - Do not leave the appliance unsupervised when it is operating, i.e. when it is "ON".
7. Never feed by hand. Always use the food pusher to push food into the food processor bowl through the feeder tube.
8. **WARNING:** When the processing is completed, unplug, then remove the spindle and blade from the bowl before removing the processed food.
9. **AFTER CLEANING, ALWAYS REPLACE THE PROTECTIVE COVER (4) ON THE METAL CHOPPING BLADE (3).**

#### **WARNING:**

**USE EXTREME CAUTION - BLADES ARE SHARP. ALWAYS HANDLE THE CHOPPING BLADE BY ITS CENTRAL PLASTIC HUB. ALWAYS REMOVE CHOPPING BLADE PROTECTIVE COVER BEFORE USING.**

# Bravetti

PLATINUM PRO

## ONE (1) YEAR LIMITED WARRANTY

**EURO-PRO OPERATING LLC** warrants this product to be free from defects in material and workmanship for a period of one (1) year from the date of purchase when utilized for normal household use.

If your appliance fails to operate properly while in use under normal household conditions within the warranty period, return the complete appliance and accessories, freight prepaid. For customer service support, call 1 (800) 798-7398 or visit our web site [www.euro-pro.com](http://www.euro-pro.com).

If the appliance is found to be defective in material or workmanship, **EURO-PRO Operating LLC** will repair or replace it free of charge. Proof of purchase date and \$ 9.50 to cover the cost of return shipping and handling must be included.\*

The liability of **EURO-PRO Operating LLC** is limited solely to the cost of the repair or replacement of the unit at our option. This warranty does not cover normal wear of parts and does not apply to any unit that has been tampered with or used for commercial purposes. This limited warranty does not cover damage caused by misuse, abuse, negligent handling or damage due to faulty packaging or mishandling in transit.

This warranty is extended to the original purchaser of the unit and excludes all other legal and/or conventional warranties. The responsibility of **EURO-PRO Operating LLC** if any, is limited to the specific obligations expressly assumed by it under the terms of the limited warranty. **In no event is EURO-PRO Operating LLC** liable for incidental or consequential damages of any nature whatsoever. Some states do not permit the exclusion or limitation of incidental or consequential damages, so the above may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

**\*Important: Carefully pack item to avoid damage in shipping. Be sure to include proof of purchase date and to attach tag to item before packing with your name, complete address and phone number with a note giving purchase information, model number and what you believe is the problem with item. We recommend you insure the package (as damage in shipping is not covered by your warranty). Mark the outside of your package "ATTENTION CUSTOMER SERVICE".**



---

## OWNERSHIP REGISTRATION CARD FOR CANADIAN CONSUMERS ONLY

Please complete and return within ten (10) days of purchase. The registration will enable us to contact you in the event a product defect is discovered. By returning this card you acknowledge to have read and understood the instructions for use, and warnings set forth in the accompanying instructions.

RETURN TO: **EURO-PRO** Operating LLC, 4400 Bois Franc, St. Laurent, QC H4S 1A7

PURCHASER: .....

ADDRESS: .....

DATE OF PURCHASE: ..... MODEL: ..... SERIAL NO: .....

NAME AND ADDRESS OF STORE: .....