



40-Channel 2.4 GHz Caller ID with Call Waiting Cordless Telephone User's Guide

INTRODUCTION

Your Caller ID phone stores and displays specific information, provided by your local telephone company, to subscribers of Caller ID or similar caller identification services. You must subscribe to one of these services in order to use this unit.

Your Caller ID phone enables you to:


- Identify callers before you answer the phone.
- View the time and date of each incoming call.
- Record up to 40 Caller ID messages sequentially.
- Know who called while you were away.

To get the most from your new phone, we suggest that you take a few minutes right now to read through this user's guide.

IMPORTANT: In order to use this unit, you must subscribe to either the standard Name/Number Caller ID Service or Caller ID with Call Waiting Service. To know who is calling while you are on the phone, you must subscribe to Caller ID with Call Waiting Service.

IMPORTANT: Because cordless phones operate on electricity, you should have at least one phone in your home that isn't cordless, in case the power in your home goes out.

CAUTION: When using telephone equipment, there are basic safety instructions that should always be followed. Refer to the **IMPORTANT SAFETY INSTRUCTIONS** provided with this product and save them for future reference.




WARNING: TO PREVENT FIRE OR ELECTRICAL SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

CAUTION: RISK OF ELECTRICAL SHOCK. DO NOT OPEN. CAUTION TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER OR GRAB. NO USER SERVICEABLE PARTS INSIDE. REFER TO QUALIFIED SERVICE PERSONNEL. THE EXPLANATION OF THE SYMBOLS IS AS FOLLOWS: THIS PRODUCT IS A HAZARDOUS WASTE. PLEASE DO NOT DISPOSE OF IT AS UNUSUAL WASTE. PLEASE ACCORDING TO THE INSTRUCTIONS ACCOMPANYING THE PRODUCT.

BEFORE YOU BEGIN

PARTS CHECKLIST

Make sure your package includes the items shown here.



MODULAR JACK REQUIREMENTS

You need an RJ11 type modular phone jack, which is the most common type of phone jack and might look like the one pictured here. If you don't have a modular jack, call your local phone company to find out how to get one installed.

INSTALLATION NOTE: Some cordless telephones operate at frequencies that may cause interference to nearby TVs microwave ovens, and VCRs. To minimize or prevent such interference, the base of the cordless telephone should not be placed near or on top of a TV, microwave ovens, or VCR. If such interference continues, move the cordless telephone farther away from these appliances.

Certain other communications devices may also use the 2.4 GHz frequency for communication, and, if properly set, these devices may interfere with each other and/or your new telephone. If you are concerned with interference, please refer to the owner's manual for these devices on how to properly set channels to avoid interference. Typical devices that may use the 2.4 GHz frequency for communication include wireless audio/video senders, wireless computer networks, multi-handset cordless telephone systems, and some long-range cordless telephone systems.

HEARING AID COMPATIBILITY

This telephone system meets FCC standards for Hearing Aid Compatibility.

FCC NUMBER IS LOCATED ON THE CABINET BOTTOM
REN NUMBER IS LOCATED ON THE CABINET BOTTOM

ATLINKS USA, Inc.
10330 North Meridian Street
Indianapolis, IN 46290
© 2001 ATLINKS USA, Inc.
Trademark(s) © Registered
Marca(s) © Registrada(s)

Model 27930/31A
15727280 (Rev. 3 DOM E)
© 2001 ATLINKS USA, Inc.
01-34
Printed in China

DIGITAL SECURITY SYSTEM


Your cordless phone uses a digital security system to provide protection against false ringing, unauthorized access, and charges to your phone line.

When you place the handset in the base, the unit verifies its security code. After a power outage or battery replacement, you should place the handset in the base for about 20 seconds to reset the code.

INSTALLATION

DESKTOP INSTALLATION

NOTE: For desktop charging only, the handset is able to charge facing up or down.




1. Remove the battery compartment door on the handset, insert the battery pack, plug the cord into the jack (inside the compartment), and replace the compartment door.
2. Set the RINGER switch (on the handset) to ON and place the handset in the cradle on the base.
3. Plug the telephone line cord into the TEL LINE jack on the back of the base and into a modular jack.
4. Plug the power supply into the power jack on the back of the base and the other end into an electrical outlet. The "charge" indicator comes, verifying the battery is charging.

Allow the phone to charge for 12 hours prior to first use. If you don't properly charge the phone, battery performance will be compromised.

CAUTION: Use only the ATLINKS USA, Inc. 5-2501 power supply that came with this unit. Using other power supplies may damage the unit.

NOTE: The phone is shipped in Tone Dialing Mode from the manufacturer.

WALL MOUNT INSTALLATION



Because it is necessary to charge the handset for 12 hours prior to connecting the phone for use the first time, it is better to leave the unit on a flat surface during initial charge before attempting to hang it on the wall.

1. Remove the battery compartment door on the handset, insert the battery pack, plug the cord into the jack (inside the compartment), and replace the compartment door.
2. Set the RINGER switch (on the handset) to ON and place the handset in the cradle on the base.
3. Plug the power supply into the power jack on the back of the base and the other end into an electrical outlet. The "charge" indicator comes, verifying the battery is charging.

Allow the phone to charge for 12 hours prior to first use. If you don't properly charge the phone, battery performance will be compromised.

4. Remove the handset from the cradle and set aside. Turn the base over and align the four slots on the bottom of the base with the four hook-tabs on the mounting bracket.
5. Insert the hook-tabs into the slots and push upwards until the mounting bracket snaps securely into place.
6. Plug the telephone line cord into the TEL LINE jack on the back of the base and the other end into a modular jack.
7. Slip the mounting holes on the bracket over the wall plate posts and firmly slide the unit down into place (wall plate not included).
8. Place the handset in the cradle.

NOTE: If desired, gather the extra telephone line and power supply cord together, fasten with a wire tie, and store inside the wall mounting bracket.

NOTE: The phone is shipped in Tone Dialing Mode from the manufacturer.

CAUTION: Use only the ATLINKS USA, Inc. 5-2501 power supply that came with this unit. Using other power supplies may damage the unit.

SET UP

There are five programmable menus available: Language, Area Code, Ringer Tone, Set Tone/Pulse, and Default Setting.

LANGUAGE SETTING SELECTION

1. Press the flash/program button until "1ENGLISH 2FRA 3ESP" shows in the display. "1ENGLISH" is the default setting.
2. Use the CID review (up or down arrow) button or the handset number pad to enter your selection.
3. Press flash/program to store selection. You will hear a confirmation tone.

AREA CODE SELECTION

1. Press the flash/program button until "SET AREA CODE - - -" shows in the display. "- - -" is the default setting.
2. Use the handset number pad to enter your three digit area code.
3. Press flash/program to store selection. You will hear a confirmation tone.

RINGER TONE SELECTION

1. Press the flash/program button until "SET RINGER TONE123" shows in the display. "1" is the default setting.
2. Use the CID review (up or down arrow) button or the handset number pad to scroll to 1, 2, or 3.
3. Press flash/program to store selection. You will hear a confirmation tone.


TONE/PULSE DIALING SELECTION

1. Press the flash/program button until "SET TONE/PULSE 1TONE 2PULSE" shows in the display. "1TONE" is the default setting.
2. Use the CID review (up or down arrow) button or the handset number pad to scroll to 1TONE or 2PULSE.
3. Press flash/program to store selection. You will hear a confirmation tone.

DEFAULT SETTING SELECTION

1. Press the flash/program button until DEFAULT SETTING? 1YES 2NO shows in the display. "2NO" is the default setting.
2. Use the CID Review (up or down arrow) button or the handset number pad to scroll to 1YES or 2NO.
3. Press flash/program to store selection. You will hear a confirmation tone.

CORDLESS PHONE BASICS



RECEIVING A CALL

1. Check the display to see who is calling.
2. Press the TALK button.

MAKING A CALL

To make a call, press the TALK button before you dial and press it again to hang up.

REDIAL

While the phone is on, press the redial/delete button to redial the last number you dialed (up to 32 digits). If you get a busy signal, and want to keep dialing the number, just press redial/delete again (you don't have to turn the phone off and back on).

FLASH

Use the flash/program button to activate custom calling services such as call waiting or call transfer, which are available through your local phone company.

TIP: Don't use the TALK button to activate custom calling services such as call waiting, or you'll hang up the phone.

IN USE INDICATOR

The phone is ON when the indicator on the handset antenna is lit and the page/ in use indicator on the base is lit. The antenna indicator and the in use indicator on the base flashes when you receive a call.

CHANNEL BUTTON

While talking, you might need to manually change the channel in order to get rid of static. Press and release the chan button to advance to the next clear channel.

TEMPORARY TONE

This feature enables pulse (rotary) service phone users to access touch-tone services offered by banks, credit card companies, etc., by pressing the TONE button to temporarily make the phone touch-tone compatible. To get information about your bank account, for example, you would:

1. Call the bank's information line.
2. Press the TONE button (*) after your call is answered.
3. Follow the voice instructions to complete your transaction.
4. Hang up when finished. The phone returns to Pulse (rotary) service.

HOLD

Press the hold button to put a call on hold. HOLD shows in the display, and the handset antenna indicator flashes. To release a line on hold, press the hold button again or pick up an extension phone.

CANCEL

Press the cancel button to cancel any command you initiated. Press cancel to hang up after finishing a call.

FINDING THE HANDSET

This feature helps to locate a misplaced handset.

Press the PAGE button on the base. The handset beeps continuously for about 2 minutes or until you press the TALK button on the handset..

NOTE: The ringer does not have to be on for this feature to work.

RINGER SWITCH


The RINGER switch must be ON for the handset to ring during incoming calls.

VOLUME

The VOLUME button controls the volume of the handset's earpiece.


VOICE MESSAGING

Provided your phone company offers voice messaging service and you subscribe to it, the in use/vmwi indicator on the base flashes when the phone is not in use to indicate there is a message waiting. It stops flashing after the message has been reviewed.



CALLER ID FEATURES

This unit receives and displays information transmitted by your local phone company. This information can include the phone number, date, and time; or the name, phone number, date, and time. The unit can store up to 40 calls for later review.



CALLER ID WITH CALL WAITING

Provided you subscribe to Caller ID with Call Waiting service from your phone company, you are able to see who is calling when you hear the call waiting beep. The caller identification information appears in the display after you hear the tone.

- Press the flash button to put the current person on hold so that you can answer the incoming call.

IMPORTANT: In order to use the Caller ID functions with this unit, you must subscribe to either the standard Name/Number Caller ID Service or Caller ID with Call Waiting Service. To know who is calling while you are on the phone, you must subscribe to Caller ID with Call Waiting Service.

RECEIVING AND STORING CALLS

When you receive a call, the information is transmitted by the phone company to your Caller ID telephone between the first and second ring.

When the memory is full, a new call automatically replaces the oldest call in memory. NEW appears in the display for calls received that have not been reviewed.

NOTE: Check with your local phone company regarding name service availability.

REVIEWING RECORDS

As calls are received and stored, the display is updated to let you know how many calls have been received.

- Press the CID review down button to scroll through the call records from the most recent to the oldest.
- Press the CID review up button to scroll through the call records from the oldest to the newest.

TRANSFERRING CID RECORDS TO MEMORY

You may transfer a Caller ID record to your phone's memory.

NOTE: It is important that you format CID records correctly before storing in memory. It is not possible to re-format CID records stored in memory.

1. Use the CID review (up or down arrow) button to scroll to the desired record.
2. Press the mem button.
3. Press the desired memory location. Example, press the number 1 key to store the record in memory location 1. You will hear a confirmation tone.

DELETING RECORDS

Use the redial/delete button to erase the record currently shown in the display or all records.

DELETING THE CURRENT RECORD

1. Make sure the phone is OFF (not in talk mode).
2. Use the CID review (up or down arrow) buttons to display the desired Caller ID record.
3. Press redial/delete. The display shows DELETE CALL ID?
4. Press redial/delete again to erase the record and the next Caller ID record shows in the display. You will hear a confirmation tone.

DELETING ALL RECORDS

1. Make sure the phone is OFF (not in talk mode).
2. Use the CID review (up or down arrow) buttons to display any Caller ID record.
3. Press and hold redial/delete button until DELETE ALL? shows in the display.
4. Press redial/delete again to erase all records. You will hear a confirmation tone. The display shows NO CALLS.

