



M37530T-PTCB

Converter Board for 32-pin 0.8mm pitch LQFP for 7534, 7540, 7542, 7544 and 7546 Groups

User's Manual

Keep safety first in your circuit designs!

• Renesas Technology Corporation and Renesas Solutions Corporation put the maximum effort into making semiconductor products better and more reliable, but there is always the possibility that trouble may occur with them. Trouble with semiconductors may lead to personal injury, fire or property damage. Remember to give due consideration to safety when making your circuit designs, with appropriate measures such as (i) placement of substitutive, auxiliary circuits, (ii) use of nonflammable material or (iii) prevention against any malfunction or mishap.

Notes regarding these materials

- These materials are intended as a reference to assist our customers in the selection of the Renesas Technology product best suited to the customer's application; they do not convey any license under any intellectual property rights, or any other rights, belonging to Renesas Technology Corporation, Renesas Solutions Corporation or a third party.
- Renesas Technology Corporation and Renesas Solutions Corporation assume no responsibility for any damage, or infringement of
 any third-party's rights, originating in the use of any product data, diagrams, charts, programs, algorithms, or circuit application
 examples contained in these materials.
- All information contained in these materials, including product data, diagrams, charts, programs and algorithms represents information on products at the time of publication of these materials, and are subject to change by Renesas Technology Corporation and Renesas Solutions Corporation without notice due to product improvements or other reasons. It is therefore recommended that customers contact Renesas Technology Corporation, Renesas Solutions Corporation or an authorized Renesas Technology product distributor for the latest product information before purchasing a product listed herein. The information described here may contain technical inaccuracies or typographical errors. Renesas Technology Corporation and Renesas Solutions Corporation assume no responsibility for any damage, liability, or other loss rising from these inaccuracies or errors. Please also pay attention to information published by Renesas Technology Corporation and Renesas Solutions Corporation by various means, including the Renesas home page (http://www.renesas.com).
- When using any or all of the information contained in these materials, including product data, diagrams, charts, programs, and algorithms, please be sure to evaluate all information as a total system before making a final decision on the applicability of the information and products. Renesas Technology Corporation and Renesas Solutions Corporation assume no responsibility for any damage, liability or other loss resulting from the information contained herein.
- Renesas Technology semiconductors are not designed or manufactured for use in a device or system that is used under circumstances in which human life is potentially at stake. Please contact Renesas Technology Corporation, Renesas Solutions Corporation or an authorized Renesas Technology product distributor when considering the use of a product contained herein for any specific purposes, such as apparatus or systems for transportation, vehicular, medical, aerospace, nuclear, or undersea repeater use.
- The prior written approval of Renesas Technology Corporation and Renesas Solutions Corporation is necessary to reprint or reproduce in whole or in part these materials.
- If these products or technologies are subject to the Japanese export control restrictions, they must be exported under a license from the Japanese government and cannot be imported into a country other than the approved destination. Any diversion or reexport contrary to the export control laws and regulations of Japan and/or the country of destination is prohibited.
- Please contact Renesas Technology Corporation or Renesas Solutions Corporation for further details on these materials or the products contained therein.

Precautions to be taken when using this product

- This product is a development supporting unit for use in your program development and evaluation stages. In mass-producing your program you have finished developing, be sure to make a judgment on your own risk that it can be put to practical use by performing integration test, evaluation, or some experiment else.
- In no event shall Renesas Solutions Corporation be liable for any consequence arising from the use of this product.
- Renesas Solutions Corporation strives to renovate or provide a workaround for product malfunction at some charge or without charge.
 However, this does not necessarily mean that Renesas Solutions Corporation guarantees the renovation or the provision under any circumstances.
- This product has been developed by assuming its use for program development and evaluation in laboratories. Therefore, it does not
 fall under the application of Electrical Appliance and Material Safety Law and protection against electromagnetic interference when
 used in Japan.



If the requirements shown in the "CAUTION" sentences are ignored, the equipment may cause personal injury or damage to the products.

Renesas Tools Homepage http://www.renesas.com/en/tools

1. Outline

The M37530T-PTCB, by combining with the M37530T-PTC converter board, is a converter board for connecting the 42DIP package to the package for 32-pin 0.8mm pitch LQFP (PLQP0032GB-A).

2. Package Components (See Figure 1)

(1)	M37530T-PTCB converter board	р	c.
(2)	TQSOCKET032SAF	р	c.
(3)	TQPACK032SA	р	c.






Figure 1 Package components of the M37530T-PTCB

3. Specifications

Table 1 Specifications

Applicable package	PLQP0032GB-A (Previous code: 32P6U-A) (32-pin 0.8mm pitch LQFP)	
Insertion/removal iterations of connector	50 times guaranteed	

4. Usage

The M37530T-PTCB can only be used for debugging. The M37530T-PTCB can be used for debugging and on-board evaluation in common by mounting the NQPACK032SA (not included) on the user system.

(1) For debugging 1

Mount the TQPACK032SA on the foot pattern of the user system and attach the TQSOCKET032SAF on it. And connect the M37530T-PTCB to the TQSOCKET032SAF.

(2) For debugging 2 (Using NQPACK)

Mount the NQPACK032SA (not included) on the foot pattern of the user system and attach the YQPACK032SA (not included) on it. Next, mount two of the YQSOCKET032SAF (not included) on M37530T-PTCB. Then connect the M37530T-PTCB to the YQPACK032SA

(3) For on-board evaluation

Mount an MCU with QzROM and HQPACK032SA (not included) in that order on the NQPACK032SA (not included) of the user system.

Before using the M37530T-PTCB, be sure to read "7. Precautions" on page 4.




Figure 2 Usage of the M37530T-PTCB

5. External Dimensions




Figure 3 External dimensions of the M37530T-PTCB

6. Sample Foot Pattern

Figure 4 shows the sample foot pattern




Figure 4 Sample Foot Pattern

7. Precautions

A CAUTION

Caution to Be Taken for This Product:



- When connecting the YQPACK032SA, be sure to use the included YQ-GUIDE-SI.
- Do NOT use the screws included with the YQPACK032SA for connecting the YQPACK032SA.

IMPORTANT

Notes on This Product:

- We cannot accept any request for repair.
- For purchasing the TQPACK32SA, TQSOCKET032SAF, YQSOCKET032SAF, NQPACK032SA, YQPACK032SA, HQPACK032SA, contact the following:

Tokyo Eletech Corporation

ullet For inquiries about the product or the contents of this manual, contact your local distributor.

Renesas Tools Homepage http://www.renesas.com/en/tools

8. Correspondence of Connectors

Table 2 Correspondence of the connectors

J1 connector	CN1 connector	J1 connector	CN1 connector
Pin No.	Pin No.	Pin No.	Pin No.
J1-1	NC	J1-21	NC
J1-2	28	J1-22	12
J1-3	29	J1-23	13
J1-4	30	J1-24	14
J1-5	31	J1-25	15
J1-6	32	J1-26	16
J1-7	1	J1-27	NC
J1-8	2	J1-28	NC
J1-9	3	J1-29	17
J1-10	4	J1-30	18
J1-11	NC	J1-31	19
J1-12	NC	J1-32	20
J1-13	5	J1-33	21
J1-14	6	J1-34	22
J1-15	7	J1-35	23
J1-16	8	J1-36	24
J1-17	9	J1-37	25
J1-18	10	J1-38	26
J1-19	11	J1-39	27
J1-20	NC	J1-40	NC

("NC": No connection)