

# COBY DVDR-1100

## IMPORTANT PLEASE READ!

### COMMON TROUBLESHOOTING ISSUES

#### ISSUE #1 NO PICTURE

Make sure your TV is turned to the correct Video line (AV Input/Video Input 1,2,3.etc). Consult the TV manufacture if you need help setting the TV to the correct Video line. Once your TV is turned to the correct Video line, you should see the "COBY" logo.

#### ISSUE #2 ROLLING, COLORLESS SCREEN

Make sure the Yellow Video wire is connected to the Video connection on the DVD player and on the TV.

#### ISSUE #3 HAD A COLOR PICTURE, NOW RECEIVING A BLACK AND WHITE OR A ROLLING SCREEN

The DVD has been set to the incorrect broadcast system.

This DVD Recorder has to be reset back to the default setting. See below procedure on how to "Reset the DVD Recorder back to the default setting".

#### ISSUE #4 NO SOUND OR BACK GROUND SOUND WITH NO VOICES

Make sure the Red and White wire is connected into your TV "AUDIO IN".

Make sure the Red and White wire is connected into the DVD Recorder 5.1 AUDIO OUT MIXED L & R.

Make sure the DVD Recorder **Analog Audio Output** is set to 2-CH. (see user manual, page 25).

#### ISSUE #5 WHY CAN'T I RECORD FROM MY VCR OR THE RECEIVER BOX

STEP1- Connect the DVD Recorder to the TV using a Yellow, Red and White cable. The Yellow, Red and White cable will connect to the DVD Recorder Audio and Video OUTPUT going into your TV Video line.

Make sure your TV is turned to the correct Video line (AV Input/Video Input 1,2,3.ect).

Once your TV is set to the correct Video line, you should see the "COBY" logo.

STEP2- Connect the VCR or the Receiver Box into the DVD Recorder using a Yellow, Red and White cable. The Yellow, Red and White cable will connect into the DVD Recorder Audio and Video INPUT.

STEP3- Set the DVD Recorder to appropriate Audio and Video INPUT line. Pressing the AV button on your DVD Recorder remote control does this function. By pressing the AV button on the DVD Recorder remote control you will see the image from the VCR of the Receiver Box on your TV screen. Once the image appears on your TV screen, insert your DVD+R or DVD+RW disk and press the record button on the DVD Recorder remote control.

**\*\*\*\*\* WHEN USING A RECEIVER BOX, YOU CANNOT SET THE DVD RECORDER TO RECORD FROM A SPECIFIC CHANNEL. THE ONLY WAY TO ACCOMPLISH THIS IS TO LEAVE THE RECEIVER BOX TURNED ON AND SET IT TO THAT SPECIFIC CHANNEL.**

#### ISSUE #6 PICTURE FADES DARK TO LIGHT

You cannot connect the DVD Recorder through your VCR, TV/VCR combo, Cable or Satellite.

If you cannot connect directly to the TV via a Yellow Video input, then you will need to purchase an RF Modulator and a four-foot Coaxial wire at your local electronics store.

#### ISSUE #7 HAD PICTURE, NOW RECEIVING A BLACK OR BLUE SCREEN

The DVD player may be set to Progressive Scan Mode. You will need to change the Video mode from Progressive Scan to Composite. Make sure you DO NOT have a disk in the DVD tray. On the remote control press the PS button 2-3 times until the "COBY" logo appears.

#### **\*\*\*\*\* RESET THE DVD RECORDER BACK TO THE DEFAULT SETTING\*\*\*\*\***

Make sure you do not have a disk in the tray. Using the DVD player remote control:

- 1) Press the "Setup" button.
- 2) On the "Right" arrow, press it once.
- 3) On the "Down" arrow, press it three times.
- 4) On the "Right" arrow, press it once.
- 5) Press the "Select" button twice.

6) Press the Setup button to exit.

\*The default setting will take affect as soon as you press the setup button (step 6).

**If you are still having difficulty setting up your new DVD player, please contact Customer Service or Technical Support, Monday-Friday 8:00 AM – 11:00 PM EST, Saturday and Sunday 9:00 AM – 11:00 PM EST. You can also reach us online at [customerservice@cobyusa.com](mailto:customerservice@cobyusa.com) or [techsupport@cobyusa.com](mailto:techsupport@cobyusa.com)**

**1-800-681-2629 OR 718-416-3197**