

iHome™

Model iP99
The Home System
For Your iPhone® or iPod®




Table of Contents

Caution Information	1
Quick Start	2
Controls and Indicators / iP99 display	3
Using the iP99	4-5
Replacing iP99 Backup Batteries	5
Using the Remote Control	6
Install/Replace Remote Control Battery	
Troubleshooting	7-8
Solucionando problemas	9-10
A Consumer Guide to product Safety	13
Safety Instructions	
Warranty Information	14

Maintenance

Maintenance

- Place the unit on a level surface away from sources of direct sunlight or excessive heat.
- Protect your furniture when placing your unit on a natural wood and lacquered finish. A cloth or other protective material should be placed between it and the furniture.
- Clean your unit with a soft cloth moistened only with mild soap and water. Stronger cleaning agents, such as Benzine, thinner or similar materials can damage the surface of the unit.



CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user of the presence of uninsulated “dangerous voltage” within the product’s enclosure that may be of sufficient magnitude to constitute a risk electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user of the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

The symbols above are located on the bottom of the unit.

WARNING: DANGER OF EXPLOSION IF BATTERY IS INCORRECTLY REPLACED.
REPLACE ONLY WITH THE SAME OR EQUIVALENT TYPE.


AVERTISSEMENT: DANGER D’EXPLOSION LORSQUE LA BATTERIE N’EST PAS
REPLACÉE CORRECTEMENT.
REPLACER UNIQUEMENT AVEC DES BATTERIES IDENTIQUES OU D’UN TYPE ÉQUIVALENT.

CAUTION: To prevent electric shock, match wide blade of plug to wide slot. Fully insert.

CAUTION: To reduce the risk of fire, do not place any heating or cooking product beneath this unit


iP99 quick start

1:power




Attach AC adaptor cable to jack on back of the iP99 and plug the other end into a working wall socket.

2:antenna



Snap AM antenna into provided stand, then plug antenna cable into socket on back of iP99. Move antenna 12" away.

3:inserts



Select the dock insert for your iPhone or iPod® model from the table below and place insert in dock. Never dock an iPhone/iPod without an insert in place.

NOTE: If you do not have an insert for your iPhone/iPod, please visit an Apple store, www.ihomeaudio.com, or call iHome toll free at 800-288-2792 to purchase one.


Use this insert	iPhone Insert 12	3rd Gen nano Insert 13	iPod Touch Insert 14
For this iPod	iPhone	3rd Gen nano	iPod Touch

4:time




- Move the DST switch on back of unit to +1 or -1 (adds or subtracts an hour)
- Press & hold the Time Zone button on back until the display flashes
- Turn the Set Wheel to select your time zone
- Press the Time Zone button again.

5:iPod/ iPhone



Insert an iPhone or iPod® into the dock with proper insert (iPhone/iPod must not be in a skin or case). The iPhone/iPod will charge while docked. Press the Play/Pause Button on the iP99 to play your iPhone/iPod.


6:radio




Press the Radio button as needed to select AM/FM band. Turn the Set Wheel to tune in a station. See page 5 for programming presets.

Controls and Indicators


Top Panel



Rear Panel



iP99 display



Connect iP99 to Power Source

Plug the AC adaptor cable into the 13 AC Adaptor Jack and the other end into a standard 120 VAC wall socket. Adaptor must be plugged in to operate. **The iP99 does not operate on batteries.**

Setting the Clock

- Press and hold the 16 Time Zone Button until the display flashes.
- Turn the Set Wheel to select your time zone.
- Press the Time Zone Button again. The clock will display the current time in your time zone.
- To adjust the time for Daylight Saving Time, slide the 17 DST switch to +1 to advance the time 1 hour. Slide to -1 to turn the clock back 1 hour.

To Set Clock Manually

- Slide the DST switch to adjust for Daylight Saving Time (+1 for daylight saving time, -1 for standard time).
- Press and hold the 15 Clock Adjust Button located on back of the unit. The clock display will flash.
- Turn the 9 Set Wheel until the current time is displayed (a PM indicator appears when time is set to PM; there is no AM indicator).
- Press the Clock Adjust Button to accept the time. The year display will flash.
- Turn the Set Wheel to adjust the year and press the Clock Adjust Button. The date display will flash.
- Turn the Set Wheel to adjust the date and press the Clock Adjust Button. Two beeps will indicate clock setting is complete.

Using the Alarms

The iP99 has two independent alarms. Each can be set to wake you to iPod (iPhone), iPod (iPhone) playlist, radio or buzzer at separate times.

Setting the Alarms

- Press and hold the 12 Alarm 1 or 11 Alarm 2 Button until the alarm time flashes.
- Turn the Set Wheel to set the desired alarm time.
- Press the Alarm Button again and turn the Set Wheel to select having the alarm come on all week (7 days), only weekdays (5 days) or just weekends (2 days).
- Press the Alarm Button again and then turn the Set Wheel to select a wake source: Buzzer, iPod (iPhone), iPod (iPhone) playlist* (PLYLST) or Radio (last selected station).

* **PLYLST.** To wake to an iPhone/iPod playlist, you must create a playlist in iTunes called **'iHome'** and import it to your iPhone/iPod. When PLYLST is set as your wake to source, the iP99 will wake to random songs in your iHome playlist.

Note: If wake to source is set to iPod (iPhone) or playlist and iPhone/iPod or playlist is not present, the iP99 defaults to buzzer alarm.

Arming and Disarming Alarm (Turn Alarm Function ON and OFF)

- Press an Alarm Button to preview current alarm time(s). Press again to arm or disarm alarm function. When armed, the related alarm icon appears in the display.

Resetting the Alarm to Come on the Next Day

- When the alarm is sounding, press the 3 Alarm Reset/Power Button to stop the alarm and reset it to come on the following day.

Snooze

- Press the 1 Snooze/Dimmer Button after the alarm sounds. The alarm will be silenced and come on again after the selected snooze time. Snooze can be pressed several times during the 2 hour alarm cycle.
- To adjust the snooze time, during normal mode press and hold the 1 Snooze/Dimmer Button until the display flashes. Use the Set Wheel to adjust snooze time from 1 to 29 minutes.

Sure Alarm

The iP99 has a sure alarm feature so the buzzer alarm will still sound in the event of power failure, if backup batteries are installed.

iPhone/iPod

Playing and charging your iPhone or iPod

- Place proper insert for your iPhone/iPod (see insert table under Quick Start) in 7 Dock, then gently dock iPhone/iPod. When docked, your iPhone/iPod will charge until fully charged. **Unit will not overcharge** iPhone/iPod.
- Press the 10 Play/Pause Button to play iPhone/iPod, and again to pause. If your iPhone or iPod Touch is in video mode, you may see the "locked" slider on the iPhone/iPod display. If so, you will need to unlock your iPhone/iPod.
- Turn 4 Volume Wheel to adjust iP99 volume up or down
- Press the EQ Button to select Treble, Bass, SRS WOW sound or Balance. Turn the Set Wheel to adjust settings. EQ settings for iPhone/iPod and radio mode are independent.
- Press 3 Alarm Reset/Power Button to turn iP99 and iPhone/iPod off.

Note: If you dock an iPhone/iPod with a drained battery, it may take up to 6 minutes of charging before the iPhone/iPod will respond.

Radio

Setting up Antennas

a) Snap AM loop antenna into provided stand, then plug AM antenna cable into 20 AM Loop Antenna socket on back of unit. Move antenna away from unit and AC adaptor for best reception.

b) Extend 19 FM Antenna (on back of unit) fully for best reception. Do not strip, alter or attach to other antennas.

Tuning and Playing the Radio

a) Press the 5 Radio Button to select radio play mode. Press as needed to select FM or AM radio band.

b) Turn the Set Wheel to tune radio to a desired station.

c) To program the current station as a preset, press and hold 6 Preset Button 1-2 until P1 flashes on display; press again for P2 and allow to time-out (beep confirmation). Repeat steps a,b,and c for other preset buttons to preset up to 12 stations (6 AM, 6 FM). To listen to a preset station at any time, simply press the desired preset button once or twice.

d) Turn the 4 Volume Wheel to adjust iP99 volume up or down.

e) Press the 8 EQ Button to select Treble, Bass, SRS WOW sound effect or Balance. Turn the Set Wheel to adjust settings. EQ settings for iPhone/iPod and radio mode are independent.

f) Press 3 Alarm Reset/Power Button to turn iP99 off.

Using the Line-in Jack

a) You can play nondocking iPod models or other audio devices through the iP99 18 Line-in Jack, connect one end of a patch cord (available at ihomeaudio.com) in the device's line out or headphones jack, the other in the iP99 line-in jack. Make sure there is no iPhone/iPod docked in the iP99 when using the line-in jack.

b) To listen to your audio device, press the 5 Radio Button until "line-in" is displayed, indicating line-in mode. Adjust the output volume on your line-in device.

Using Sleep Mode

Sleep mode lets you sleep to your iPhone/iPod or the radio, gradually lowering the volume until the unit shuts off at the selected time.

a) Press the 2 Sleep Button to select an amount of time before the iP99 shuts off: 120, 90, 60, 30 or 15 minutes.

b) Turn the Volume Wheel to set the sleep volume (this volume setting is separate from your standard volume setting).

Using the Dimmer

a) Press the 1 Snooze/Dimmer Button during normal operation to adjust brightness of LCD display. There are 8 levels of brightness including OFF.

Replacing iP99 Backup Batteries


Install/Replace Backup Battery

The iP99 uses a backup battery system to provide continuous alarm operation and clock settings in the event of a power failure. If the Battery Low Icon located on the right of the display is on, it is time to replace the backup batteries. Please make sure the AC adaptor is connected, otherwise all settings may be lost during battery replacement.

Open the battery compartment cover located on the bottom of the unit. Insert 2 "AA" batteries as indicated. We recommend the use of alkaline batteries for longer life.


Batteries information:

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon -zinc) or rechargeable (nickel-cadmium) batteries.



Using The Remote Control

The Remote Control controls basic functions on the iP99 and certain iPhone/iPod functions when the iPhone/iPod is docked in the iP99. For best results, use the remote control within 12 feet of the unit.




- 1 Power On/Off Alarm Reset Button: Turns iP99 ON or OFF or resets alarm when alarm is sounding
- 2 Fwd/Rev Button: Skip to previous or next track, or HOLD to scan current playing track. Also controls set wheel functions (changing settings, tuning radio, etc.)
- 3 Menu Button: Press to access iPhone/iPod Menu functions
- 4 Preset Button: Cycles through AM or FM radio presets
- 5 Radio Button: Selects Radio (AM and FM radio bands) and line-in functions
- 6 EQ Button: Set Treble, Bass, SRS WOW sound effect and Balance settings for best sound
- 7 Snooze/Dimmer Button: Snooze mode when alarm sounds, otherwise dims display
- 8 Random Button: Press for random play
- 9 Repeat Button: Press for repeat play (press again to repeat all)
- 10 Sleep Button: Press to select an amount of time before the iP99 shuts off: 120, 90, 60, 30 or 15 minutes
- 11 Volume – Button: Lowers volume level
- 12 Volume + Button: Raises volume level
- 13 Enter Button: Press to select iPhone/iPod menu function
- 14 Up/Down Button: Press Up or Down to scroll iPhone/iPod menu
- 15 Play/Pause Button: Plays track. In play mode, press to pause
- 16 Mute Button: Toggles sound ON or OFF

Installing/Replacing the Remote Control Battery

The remote control battery is already installed at the factory. When the remote control stops operating or its range seems reduced, it is time to replace the battery with a new one.

1. The battery door is located on the back end of the remote.
2. Slide the battery door open and remove old battery.
3. Insert a CR2025 battery, checking that the + and – sides of the battery match the drawing inside the battery compartment.
4. Replace the battery door.

Note: Make sure you dispose of all batteries properly (see your local regulations).



Troubleshooting

Symptom	Possible Problem	Solution
iP99 does not turn on	AC adaptor isn't plugged into a working wall socket or not plugged into the power supply jack on back of the unit	Plug the AC adaptor into a working wall socket and plug the connector into the supply jack on the unit
iP99 doesn't respond	iP99 requires a reset	If unit is plugged in and doesn't respond, try resetting the unit by following these steps: a) remove iPhone/iPod from dock b) unplug unit from power source c) remove back up batteries d) wait 1 hour, then resume use
	iPhone/iPod is not docked properly	Remove your iPhone/iPod from the dock and check for obstruction on the connectors in the dock and on your iPhone/iPod. Then reseal it in the dock.
Battery Low icon always on	Batteries are weak	Replace with new batteries
	Batteries were not installed properly	Check to make sure the polarity (+ and – ends) matches the diagram in the battery compartment
iPhone/iPod does not respond to the unit/ iPhone/iPod is playing but no sound comes out	iPhone/iPod is not docked properly	Remove your iPhone/iPod from the dock and check for obstruction on the connectors in the dock and on your iPhone/iPod. Then reseal it in the dock.
	Your iPhone/iPod software is too old	Upgrade software on your iPhone/iPod. For details visit http://www.apple.com or use iTunes on your computer
	iPhone/iPod is locked up/plays but no sound comes out	Check the volume setting. Make sure your iPhone/iPod is working properly before docking into the unit. Please refer to your iPhone/iPod manual for details. See above for software upgrade information. You may need to reset your iPhone/iPod. Refer to your iPhone or iPod user guide for details on how to perform a reset.
	Using 1 st or 2 nd generation iPod, iPod Shuffle or other devices.	iP99 cannot control those iPod models or other devices.
Remote Control didn't work	Battery weak	Replace current battery with new battery
	Remote Control is out of range of the iP99 remote sensor	Move within 30 feet of the unit.
iP99/iPhone/iPod performance is erratic	The iP99 is reacting to external interference	Move unit away from potential sources of external interference such as computers, modems, wireless devices (routers) or fluorescent light.
No sound from iP99	Volume is set too low on iP99	Make sure volume is turned up
iPhone/iPod didn't charge up	iPhone/iPod is not docked properly	Remove your iPhone/iPod from the dock and check for obstruction on the connectors in the dock and on your iPhone/iPod. Then reinsert it in the dock.
	iPhone/iPod is locked up/ frozen	Please make sure your iPhone/iPod is working properly before docking into the unit. Please refer to your iPhone/iPod manual for details.
	iPhone/iPod battery has problem	

Troubleshooting

Symptom	Possible Problem	Solution
No AM band radio sound but others OK	AM loop antenna is not connected to the unit	Plug the AM loop antenna connector to the jack on the back of the unit
AM band radio is very noisy	AM loop antenna isn't located properly	Move the AM loop antenna away from the main unit and AC adaptor and rotate it for best reception
Unit makes odd beeping noise in radio mode	GSM noise: iPhone is sending signals to cell towers	Undock your iPhone or put iPhone in Airplane mode. Note that Airplane temporarily disables the phone features on the iPhone.
Sound is distorted	Volume level is set too high	Decrease the volume
	Sound source is distorted	If the iPhone/iPod original sound source (MP3) is old or of poor quality, distortion and noise are easily noticed with high-power speakers. Try a different audio source such as a music CD. If you are using an external sound source like older generation of iPod or iPod Shuffle, try reducing the output volume on the device itself. Also try turning bass boost OFF.
	EQ settings are too high	Lower EQ settings and/ or turn off SRS WOW
Unit/adaptor gets warm after extended play at high volume	This is normal	Turn unit off for awhile or lower volume
Can't hear headphones/speakers attached to line out jack	Line out jack is not meant for headphones. Speakers need a power source	The signal from the line out jack needs amplification. Use powered speakers/monitors or other amplified audio device.
Snooze time is too long/short	Custom snooze time not set	Press and hold Snooze button then turn set wheel to adjust
Can't wake to playlist	Playlist is misnamed or empty	Sync iPhone/iPod to iTunes and manually label playlist iHome . Make sure to add songs to your playlist. For help in creating a playlist, please see the Help tab in iTunes or visit www.apple.com
Alarm not working	AM/PM time/alarm time not set correctly	When setting clock or alarm time, take note of the PM indicator; there is NO AM indicator
	Alarm time or source selected for alarm 2 , not alarm 1 or vice versa	Make sure to set the alarm time and source for the alarm icon 1 or 2 that is shown on the clock display
	7-5-2 days setting is not correct	7 days is the every day alarm, 5 days is Mon-Fri, and 2 days is Sat-Sun. See page 4 for setting alarms.
	Calendar is not set correctly, which can affect 7/5/2 day alarm operation	See page 4 for setting Clock/Calendar Section.

Solucionando problemas

Síntoma	Causa	Solución
La unidad no enciende	El adaptador de corriente AC no está conectado a un tomacorriente que funcione o no está conectado en la parte posterior de la unidad	Conecte el adaptador de corriente a un tomacorriente que funcione y a la parte posterior de la unidad
La unidad no responde	La unidad debe ser reprogramada	Si la unidad está conectada y no responde, pruebe reprogramarla siguiendo estos pasos: a) Quite el iPhone/iPod de la base b) Desconecte la unidad del tomacorriente c) Quite las baterías auxiliares d) Espere 1 hora y vuelva a probar
El iPhone/iPod no encastra correctamente	No ha colocado el encastre del iPhone/iPod, o está utilizando el encastre incorrecto.	Verifique que el encastre sea el apropiado para su iPhone/iPod
	El iPhone/iPod no encastra correctamente	Quite el iPhone/iPod del encastre y retire la posible obstrucción del encastre o de su iPhone/iPod. Vuelva a colocar el iPhone/iPod dentro del encastre.
El ícono de batería baja está destellando	Las baterías están gastadas	Reemplace las baterías
	Las baterías no están instaladas correctamente	Verifique que la polaridad de las baterías (- y +) se encuentren de acuerdo al diagrama del compartimiento de baterías.
El iPhone/iPod no se comunica con la unidad	El iPhone/iPod no está instalado correctamente	Quite el iPhone/iPod del encastre y verifique posibles obstrucciones del encastre o de su iPhone/iPod. Vuelva a colocar el iPhone/iPod dentro del encastre.
	Su software es obsoleto	Renueve su software. Para mayor información, diríjase a http://www.apple.com o iTunes
	El iPhone/iPod no responde	Verifique que su iPhone/iPod funcione correctamente antes de conectarlo a la unidad. Refiérase al manual de su iPhone/iPod para más detalles.
	Usted tiene un iPhone/iPod de primera o segunda generación, un Shuffle u otro tipo de aparato	El iP99 no puede controlar estos otros aparatos
El control remoto no funciona	Las baterías están gastadas	Reemplace las baterías por nuevas
	No está apuntando el control remoto hacia el iP99	Apunte el control remoto hacia el iP99 y manténgase a una distancia máxima de 10 pies de la unidad.
El funcionamiento del iP99/iPhone/iPod es errático.	El iP99 está reaccionando a interferencias externas.	Aleje la unidad de Fuentes potenciales de interferencia externa como computadoras, modems, ruteadores inalámbricos, luz fluorescente, etc.
No sale sonido de su iP99	El volumen del iP99 se encuentra muy bajo	Asegúrese de subir el volumen
El iPhone/iPod no carga	El iPhone/iPod no está instalado correctamente	Quite el iPhone/iPod del encastre y retire la posible obstrucción del encastre o de su iPhone/iPod. Vuelva a colocar el iPhone/iPod dentro del encastre.
	El iPhone/iPod está trabado/no responde	Por favor asegúrese de que su iPhone/iPod funcione correctamente antes de colocarlo en el encastre. Refiérase al manual de su iPhone/iPod para mayor información.
	La batería del iPhone/iPod podría tener algún inconveniente	

Solucionando problemas

Síntoma	Causa	Solución
La banda de AM no suena pero las demás sí	La antena no está ubicada correctamente	Aleje la antena de la unidad y gírela para mejorar la recepción
El sonido sale distorsionado	El volumen se encuentra muy alto	Baje el volumen
	El sonido sale distorsionado de la unidad	Si el sonido original de su iPhone/iPod era de pobre calidad, las distorsiones y ruidos se harán más notables con los parlantes de alta potencia. Pruebe utilizar otra fuente de audio como un CD. Si está utilizando un iPod de primeras generaciones o un Shuffle, intente bajar el volumen de su aparato. También intente apagar el amplificador de bajos
	La programación de EQ está demasiado alta. Por ejemplo, si los agudos están en volumen muy alto, el efecto 3D podría no sonar bien.	Baje los niveles del EQ.
La unidad recalienta luego de largos períodos de uso a alto volumen	Esto es normal	Apague la unidad o baje el volumen
No puede escuchar los auriculares/parlantes que están conectados a la ficha de salida "line out"	La línea de salida no está diseñada para auriculares. Los parlantes necesitan una fuente de alimentación	La señal de salida requiere amplificación. Utilice parlantes u otra clase de aparato amplificado.
El tiempo de apagado con "Snooze" (Dormilón), es muy largo/corto.	La duración del programa "Snooze" no ha sido programada.	Mantenga oprimido el botón "Snooze" luego gire la rueda para programar la duración de tiempo deseada.
La unidad no reproduce la lista de canciones al despertar.	La lista está vacía o se encuentra mal denominada.	Sincronice su iPhone/iPod a iTunes y manualmente ingrese el nombre de la lista bajo "iHome". Asegúrese de agregar las canciones a su lista.
La alarma no funciona	El indicador de AM/PM no ha sido programado correctamente.	Ajuste la alarma según desee que suene en hora AM o después del mediodía PM.
	El ícono indicador en el visor es incorrecto.	Verifique que el horario de la alarma y el del ícono correspondiente 1 o 2 en el visor del reloj se encuentren sincronizados.
	La programación 7-5-2 no es correcta.	Utilice 7 para uso de alarma diario por 7 días, 5 para Lunes a Viernes y 2 para Sábado y Domingo. Diríjase a la página 4 para su programación.
	El calendario no se encuentra programado correctamente para 7-5-2 días.	Refiérase a la página 4 para ver la sección de programación del Reloj/ calendario.

IMPORTANT SAFETY INSTRUCTIONS

When used in the directed manner, this unit has been designed and manufactured to ensure your personal safety. However, improper use can result in potential electrical shock or fire hazards. Please read all safety and operating instructions carefully before installation and use, and keep these instructions handy for future reference. Take special note of all warnings listed in these instructions and on the unit.

1. **Water and Moisture** – The unit should not be used near water. For example: near a bathtub, washbowl, kitchen sink, laundry tub, swimming pool or in a wet basement.
2. **Ventilation** – The unit should be situated so that its location or position does not interfere with its proper ventilation. For example, it should not be situated on a bed, sofa, rug or similar surface that may block ventilation openings. Also, it should not be placed in a built-in installation, such as a bookcase or cabinet, that may impede the flow of air through the ventilation openings.
3. **Heat** – The unit should be situated away from heat sources such as radiators, heat registers, stoves or other appliances (including amplifiers) that produce heat.
4. **Power Sources** – The unit should be connected to a power AC adaptor of the type described in the operating instructions or as marked on the appliance.
5. **Power-Cord Protection** – Power AC adaptor cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them. It is always best to have a clear area from where the cord exits the unit to where it is plugged into an AC outlet.
6. **Cleaning** – The unit should be cleaned only as recommended. See the Maintenance section of this manual for cleaning instructions.
7. **Objects and Liquid Entry** – Care should be taken so that objects do not fall and liquids are not spilled into any openings or vents located on the product.
8. **Attachments** – Do not use attachments not recommended by the product manufacturer.
9. **Lightning and Power Surge Protection** – Unplug the unit from the wall outlet and disconnect the antenna or cable system during a lightning storm or when it is left unattended and unused for long periods of time. This will prevent damage to the product due to lightning and power-line surges.
10. **Overloading** – Do not overload wall outlets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.
11. **Damage Requiring Service** – The unit should be serviced by qualified service personnel when:
 - A. the power supply cord or plug has been damaged.
 - B. objects have fallen into or liquid has been spilled into the enclosure.
 - C. the unit has been exposed to rain.
 - D. the unit has been dropped or the enclosure damaged.
 - E. the unit exhibits a marked change in performance or does not operate normally.
12. **Antenna** – Do not connect an external antenna to the unit (other than that provided).
13. **Periods of Nonuse** – If the unit is to be left unused for an extended period of time, such as a month or longer, the power cord should be unplugged from the unit to prevent damage or corrosion.
14. **Servicing** – The user should not attempt to service the unit beyond those methods described in the user's operating instructions. Service methods not covered in the operating instructions should be referred to qualified service personnel.
15. **Replacement Parts** – When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards.
16. **Safety Check** – Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.

Questions? Visit www.ihomeaudio.com
For any other questions: 1-800-288-2792 Toll Free

Limited 90-Day Warranty Information

iHome Products, a division of SDI Technologies Inc. (hereafter referred to as SDI Technologies), warrants this product to be free from defects in workmanship and materials, under normal use and conditions, for a period of 90 days from the date of original purchase.

Should this product fail to function in a satisfactory manner, it is best to first return it to the store where it was originally purchased. Should this fail to resolve the matter and service still be required by reason of any defect or malfunction during the warranty period, SDI Technologies will repair or, at its discretion, replace this product without charge (except for a \$15.00 charge for handling, packing, return UPS/postage, and insurance). This decision is subject to verification of the defect or malfunction upon delivery of this product to the Factory Service Center listed below. The product must include proof of purchase, including date of purchase. The fee for service without proof of purchase is \$30.00.

Before returning this product for service, please first replace the batteries (if applicable) with fresh ones, as exhausted or defective batteries are the most common cause of problems encountered.

If service is still required:

1. Remove the batteries (if applicable) and pack the unit in a well padded, heavy corrugated box.
2. Enclose a photocopy of your sales receipt, credit card statement, or other proof of the date of purchase, if within the warranty period.
3. Enclose a check or money order payable to the order of SDI Technologies, for the sum of \$15.00 (\$30.00 without proof of purchase).
4. Send the unit prepaid and insured, to the Factory Service Center listed below.

Consumer Repair Department
SDI Technologies Inc.
1330 Goodyear Drive
El Paso, TX 79936-6420

Disclaimer of Warranty

NOTE: This warranty is valid only if the product is used for the purpose for which it was designed. It does not cover (i) products which have been damaged by negligence or willful actions, misuse or accident, or which have been modified or repaired by unauthorized persons; (ii) cracked or broken cabinets, or units damaged by excessive heat; (iii) damage to digital media players, CD's or tape cassettes (if applicable); (iv) the cost of shipping this product to the Factory Service Center and its return to the owner.

This warranty is valid only in the United States of America and does not extend to owners of the product other than to the original purchaser. In no event will SDI Technologies or any of its affiliates, contractors, resellers, their officers, directors, shareholders, members or agents be liable to you or any third party for any consequential or incidental damages, any lost profits, actual, exemplary or punitive damages. (Some states do not allow limitations on implied warranties or exclusion of consequential damages, so these restrictions may not apply to you.) This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Your acknowledgment and agreement to fully and completely abide by the above mentioned disclaimer of warranty is contractually binding to you upon your transfer of currency (money order, cashier's check, or credit card) for purchase of your SDI Technologies product.

**Questions? Visit www.ihomeaudio.com
or call 1-800-288-2792 Toll Free**



and are registered trademarks of SRS Labs, Inc.
TruBass and WOW technologies are incorporated under license from SRS Labs, Inc.