Historic, Archive Document

Do not assume content reflects current scientific knowledge, policies, or practices.



n83Et

ET-27



November 1934

FIELD SUPPORT FOR ROUND-FORM DISTANCE THERMOMETERS

By J. E. Dudley, Jr., Division of Truck Crop and Garden Insects,
Bureau of Entomology and Plant Quarantine,
U. S. Department of Agriculture

When several round-form distance thermometers with very stiff cables are used in the field, this support is especially useful in holding them in place and in allowing them to be moved quickly (fig. 1).

The support is made principally of galvanized pipe, 1 inch outside diameter. The upright is 30 inches long and is screwed into a T. In the lower end of the T is screwed a similar pipe 16 inches long, on the lower end of which is a pointed steel rod 1 foot long welded in the pipe by a blacksmith. At the open end of the T is a 4-inch piece of pipe with a cap on the end, used for forcing the support into the ground with the foot.

A board frame, round or square, large enough to cover the bolt holes in the thermograph, is fastened to a 4 by 4 inch block. Into the lower end of this block is bored a hole large enough to take the upper end of the support pipe and at least 6 inches deep. It is an advantage to bore a hole into the 4 by 4 inch block and into the pipe so that a nail may be inserted to keep the thermograph from turning on the support.

PIELD SUPPORT FOR ROUND-FORM DISTLANDS THERMOMETERS

By J. E. Dudley, Jr., Division of Truck Crop and Carden Insacts.

Bureau of Entemology and Flant Susrantine.

U. S. Department of Agriculture

When several round-form distance thereometers with very stirl oubles are used in the field, this support is especially useful in helding them in place and in allowing them to be moved quickly (Fig. 1).

The support is made principally of galvanized pipe, I inch cultiful disauter. The upright is 30 inches long and is acrowed into a T. In the lower and of that I is seressed a similar pipe 16 inches long, on the lower and of shich is a pointed steel and I foot long welded in the pipe by a blacksmith. At the open and of the T is a 4-inch piece of pipe with a cap on the and, used for foreing the support into the pround with the stoot.

A board frame, round or square, large enough to toper the boil notes in the their training to fact the state of the training to the state that the sample of this block is tored a hole large enough to take the upper and of the support pipe and of large to the support pipe and of large to the support pipe and of large and large that the pipe so that a calt may be inserted to heep the thereograph from the support




FIG. 1. - FIELD SUPPORT FOR ROUND-FORM THERMOGRAPH.