



DUDLEY KNOX LIBRARY
NAVAL POSTGRADUATE SCHOOL
MONTEREY, CALIFORNIA 93743

NAVAL POSTGRADUATE SCHOOL

Monterey, California



THESIS

FASTS: A RADAR SIMULATION MODEL
FOR THE DEVELOPMENT AND ANALYSIS
OF AIRCRAFT ANTI-SHIP TACTICS

by

Frank O. Barrett III

September 1985

Thesis Advisor:

R. N. Forrest

Approved for public release;
distribution is unlimited

T222817

REPORT DOCUMENTATION PAGE

READ INSTRUCTIONS
BEFORE COMPLETING FORM

1. REPORT NUMBER		2. GOVT ACCESSION NO.	3. RECIPIENT'S CATALOG NUMBER
4. TITLE (and Subtitle) FASTS: A Radar Simulation Model for the Development and Analysis of Aircraft Anti-Ship Tactics		5. TYPE OF REPORT & PERIOD COVERED Master's Thesis September, 1985	
7. AUTHOR(s) Frank O. Barrett III		8. CONTRACT OR GRANT NUMBER(s)	
9. PERFORMING ORGANIZATION NAME AND ADDRESS Naval Postgraduate School Monterey, California 93943-5100		10. PROGRAM ELEMENT, PROJECT, TASK AREA & WORK UNIT NUMBERS	
11. CONTROLLING OFFICE NAME AND ADDRESS Naval Postgraduate School Monterey, California 93943-5100		12. REPORT DATE September, 1985	13. NUMBER OF PAGES 137
14. MONITORING AGENCY NAME & ADDRESS (if different from Controlling Office)		15. SECURITY CLASS. (of this report)	
		15a. DECLASSIFICATION/DOWNGRADING SCHEDULE	
16. DISTRIBUTION STATEMENT (of this Report) Approved for public release; distribution is unlimited			
17. DISTRIBUTION STATEMENT (of the abstract entered in Block 20, if different from Report)			
18. SUPPLEMENTARY NOTES			
19. KEY WORDS (Continue on reverse side if necessary and identify by block number) Radar; Simulation; War-at-Sea; IREPS			
20. ABSTRACT (Continue on reverse side if necessary and identify by block number) This thesis describes an interactive computer program that was developed by the author. The program which is called FASTS simulates a many-on-many war-at-sea scenario involving ship based early warning radars, strike aircraft and supporting radar jammers. It provides the tactics designer a testbed for evaluating strike tactics against a defensive radar network and for estimating the impact of environmental conditions on radar detection.			

Approved for public release; distribution is unlimited

FASTS: A Radar Simulation Model for the
Development and Analysis of Aircraft Anti-Ship Tactics

by

Frank O. Barrett III
Commander, United States Navy
B.S., United States Naval Academy, 1969

Submitted in partial fulfillment of the
requirements for the degree of

MASTER OF SCIENCE IN OPERATIONS RESEARCH

from the

NAVAL POSTGRADUATE SCHOOL
September 1985

ABSTRACT

This thesis describes an interactive computer program that was developed by the author. The program which is called FASTS simulates a many-on-many war-at-sea scenario involving ship based early warning radars, strike aircraft and supporting radar jammers. It provides the tactics designer a testbed for evaluating strike tactics against a defensive radar network and for estimating the impact of environmental conditions on radar detection.

TABLE OF CONTENTS

I.	INTRODUCTION -----	8
A.	RECENT DEVELOPMENTS -----	9
B.	THESIS RESEARCH OBJECTIVE -----	9
II.	BACKGROUND -----	11
A.	THE RADAR MODEL -----	11
B.	THE RADAR JAMMING MODEL -----	14
C.	RADAR ENVIRONMENTAL PROPAGATION LOSSES -----	15
1.	The Optical Region -----	16
2.	Diffraction Effect -----	16
3.	Refraction and Anomolous Propagation -----	17
D.	DETECTION MODEL -----	21
E.	OPERATOR FACTOR -----	23
III.	THE PROBLEM SOLUTION -----	26
A.	PROGRAM OVERVIEW -----	26
B.	INITIALIZATION SUBROUTINE (INIT) -----	27
C.	AIRCRAFT MODULE (UPDAC) -----	30
D.	RADAR MODULE (UPDRD) -----	32
1.	Path Losses -----	37
2.	Noise Power -----	39
3.	Signal Power -----	40
4.	Probability of Detection -----	42
E.	PROGRAM OUTPUT -----	42
1.	Data -----	43

2. X-Y Plot -----	43
3. Probability of Detection for a Scan Plot --	48
4. First Detection Statistics -----	49
IV. FASTS VERIFICATION -----	53
A. LOSS COMPUTATION TEST -----	53
B. RADAR HORIZON TEST -----	54
C. JAMMER SELF-SCREENING TEST -----	55
D. STANDOFF JAMMER TESTS -----	55
1. Azimuth Test -----	55
2. Range Test -----	56
V. SAMPLE IMPLEMENTATION -----	60
A. SCENARIO -----	60
B. DATA FILE CONSTRUCTION -----	61
C. PROGRAM EXECUTION -----	61
D. EVALUATION OF RESULTS -----	66
E. FOLLOW-ON SIMULATIONS -----	71
VI. RESULTS AND CONCLUSIONS -----	72
APPENDIX A. FASTS PROGRAM SOURCE CODE -----	74
APPENDIX B. FASTS DATA INPUT GUIDE -----	124
LIST OF REFERENCES -----	135
INITIAL DISTRIBUTION LIST -----	136

LIST OF FIGURES

1.	The Optical and Diffraction Regions -----	15
2.	Horizon Extension Due to Defraction -----	17
3.	Radar Energy Propagation in a Surface-based Duct ---	19
4.	Required Signal-to-Noise Ratio for Detection with Noncoherent Integration of Pulses -----	20
5.	Path Loss for a 5000 MHz Transmitter at 90 Feet and a Receiver at 500 Feet for a Standard Atmosphere -----	22
6.	Probability of Detection versus Excess Signal- to-Noise Ratio for Probability of False Alarm 10^{-6} and an Integration Factor of 10 -----	24
7.	FASTS Main Routine -----	28
8.	Subroutine UPDAC -----	33
9.	Subroutine UPDRD -----	35
10.	Subroutine IREP -----	38
11.	Radar Azimuth Antenna Patterns, Four Degree Beamwidth -----	41
12.	Subroutine OUTPUT -----	44
13.	FASTS Data Output -----	47
14.	FASTS X-Y Plot Output -----	48
15.	FASTS Probability of Detection per Scan Plot Output -----	49
16.	Subroutine Output-Stats -----	51
17.	FASTS Statistics Output -----	52
18.	Radar Horizon Test -----	54
19.	Standoff Jammer Test -----	57
20.	Sample Data File Listing -----	62

21.	X-Y Plot for Radar 1, 100 nm Scale -----	67
22.	X-Y Plot for Radar 2; 100 nm Scale -----	67
23.	X-Y Plot for Radar 1; 50 nm Scale -----	68
24.	X-Y Plot for Radar 2; 50 nm Scale -----	68
25.	Probability of Detection per Scan Plot for Radar 1 -----	69
26.	Probability of Detection per Scan Plot for Radar 2 -----	69
27.	First Detection Statistics for Simulated Missile ---	70

I. INTRODUCTION

Recent advances in ship anti-air defensive systems have brought about significant changes to the War-at-Sea (WAS) battle environment. Improved surface-to-air missiles are able to kill incoming raid aircraft at longer ranges and at lower altitudes. In addition, close-in weapon systems designed to rapidly engage and destroy penetrating raids and missiles are widely deployed and have demonstrated a measure of success, and supporting radar systems have grown in both power and countermeasures sophistication.

Efforts to improve aircraft strike capabilities while reducing attrition have been directed toward reducing the time the attacker is exposed to the hostile environment. These efforts have led to the incorporation of low altitude flight profiles and standoff jamming into strike tactics for the purpose of delaying or preventing initial detection and degrading the enemy's fire control solution.

The development and evaluation of effective coordinated strike tactics that incorporate low altitude flight profiles and standoff jamming for the multi-threat radar scenario has proven a challenging problem for planners. The constantly varying aircraft, jammer, and radar geometrical relationships and the complex effects of the atmosphere on radar propagation

are not easily analyzed and understandably often have given way to broad assumptions of capability which have led to standard, invariant and often sub-optimum tactics.

A. RECENT DEVELOPMENTS

The introduction of the Integrated Refractive Effects Prediction System (IREPS) into the fleet provided a major tool for the tactical exploitation of the effects of atmospheric conditions on radar propagation. By providing a shipboard capability to predict radar coverage and propagation anomalies; IREPS highlights altitudes of radar energy ducting and demonstrates that in many cases the use of low altitude attack profiles over water actually increased aircraft detection ranges. Similarly, the ducting of radar jamming energy can either magnify or reduce its effectiveness.

Additionally the vastly increased capability in computing power and speed brought about by the new generation of desktop computers is now at the disposal of the tactician. Complex simulation programs, which until now required a near main-frame capacity, can be conveniently run on small computers such as the HP-9000 series which are presently maintained in the fleet.

B. THESIS RESEARCH OBJECTIVE

The objective of the research described in this thesis was to develop a computer program that through simulation would provide a capability to predict the effectiveness of

shipboard radar performance against airborne targets in the presence of jamming and anomalous propagation effects. A program was developed which is called FASTS; its development and characteristics are described in what follows.

II. BACKGROUND

The basic issue to be considered in assessing radar detection of a target is the following:

Is the reflected radar energy from the target detectable when superimposed with jamming signals and receiver noise?

The following models for radar and jammer signal propagation, receiver noise, and target detectability were used to determine the probability of detection for airborne targets in FASTS.

A. THE RADAR MODEL

Through the years, various efforts have resulted in the development of descriptive models that predict the performance of radar (and radar jamming) systems. These models are not exact but they do permit meaningful and consistent analysis and as such are most useful.

Until the recent past, general practice has been to assume that the radar and target were located in free space since the non-free space signal propagation effects are considerably more complex and difficult to calculate. The use of computers to perform these calculations has made it possible to quickly evaluate non-free space propagation factors and improve the accuracy of the radar model.

The following is a development of the radar transmission equation. The forms are simplified to allow one to easily

identify the quantities which must be evaluated when considering environmental factors. This derivation follows from A Guide to Basic Pulse-Radar Maximum-Range Calculation by Blake [Ref. 1].

It is convenient to follow the path of the energy from its transmitter to the target and back to the radar receiver. If one can assume that a transmitting antenna radiates isotropically (uniformly in all directions), then the power density (watts per unit area) at any point at distance R is:

$$\text{Power Density at } R = \frac{P_t}{4\pi R^2} \quad (1)$$

where P_t is the total power radiated, and $4\pi R^2$ is the area of a sphere of radius R .

However since radar antennas are directional, the power density at distance R is:

$$\text{Power Density at } R = \frac{P_t G_t}{4\pi R^2} \quad (2)$$

where G_t is the on-axis gain of the transmitting antenna.

If a target at range R intercepts an amount of power contained in an area σ square meters and reradiates it isotropically, the power density returned to the antenna will be:

$$\text{Power Density at Receiving Antenna} = \frac{P_t G_t}{4\pi R^2} \sigma \frac{1}{4\pi R^2} \quad (3)$$

The receiving capture area of an antenna is, by definition, the ratio of power delivered to the radar receiver (P_r) to the field power density:

$$A_c = \frac{P_r}{\text{Power Density}} \quad (4)$$

For a receiving antenna gain of G_r , the capture area is:

$$A_c = \frac{G_r \lambda^2}{4\pi} \quad (5)$$

Combining equations (3), (4) and (5) yields:

$$P_r = \frac{P_t G_t}{4\pi R^2} \sigma \frac{G_r \lambda^2}{4\pi} \quad (6)$$

For radars using the same antenna for transmitting and receiving, G_t and G_r can be assumed to be equal, and thus, with rearranging the equation for radar transmission in free space becomes:

$$P_r = \frac{P_t G^2}{(4\pi)^2 R^4} \sigma \frac{\lambda^2}{4\pi} \quad (7)$$

When free space propagation conditions are not met, this equation will not give a correct result. A solution is provided by inserting into the equation a pattern-propagation factor F which accounts for wave propagation effects due to non-free space conditions and effects of the antenna pattern. When the same antenna is used for transmitting and receiving, the factors are identical and are combined. The equation can now be presented in the following form:

$$P_r = P_t G^2 \sigma \frac{\lambda^2}{4\pi} \left[\frac{F}{4\pi R^2} \right]^2 \quad (8)$$

where the bracketed quantity is composed of factors which are dependant on target and radar relative positions and represents the one-way transmission loss for the radar signal.

B. THE RADAR JAMMING MODEL

Noise jammers produce a signal which adds to the thermal noise already present in the radar receiver. The jamming noise power received is derived in much the same way as for the radar equation and is given by:

$$N = \frac{P_j B_r G_j G_r \lambda^2}{B_j L_p} \left[\frac{F}{4\pi R^2} \right] \quad B_j > B_r \quad (9)$$

where P_j = Jammer Power

B_j = Jammer Bandwidth

B_r = Radar Receiver Noise Bandwidth

G_j = Jammer Antenna Gain

G_r = Radar Antenna Gain

F = Pattern Propagation Factor

R = Jammer to Radar Range

L_p = Polarization Loss Factor

The polarization loss factor included in Equation (9) is required when the polarization of the jamming system does not match that of the radar system. The loss factor would be infinite if the jamming antenna and the radar antenna could be perfectly cross polarized. In general the jammers will not have the same polarization as the radars. In order to accommodate a variety of polarizations, jammers are often either forty five degrees slant polarized or are circularly polarized resulting in an L_p of two. [Ref. 2:p. 3a-1]

C. RADAR ENVIRONMENTAL PROPAGATION LOSSES

The propagation of radar waves is affected by interaction with both the earth's surface and the atmosphere. Under certain conditions, environmental factors can substantially alter propagation factors and therefore be critical. It is necessary to distinguish between two different regions shown in Figure 1 when discussing radar propagation. One is the optical region which extends within the line of sight of the radar. The other is the diffraction region which lies beyond the horizon.




Figure 1. The Optical and Diffraction Regions

1. The Optical Region

Within the optical region, radar energy travels with spherical spreading generally in accord with the free space equation. When targets or radar transmitters are located near a large smooth surface like the ocean a portion of the energy is reflected off that surface. For shallow incidence angles and with smooth seas, nearly 99 percent of the energy is reflected with 180 degrees of phase change. With surface roughness, due to wind, the magnitude of the reflected energy can decrease to about 15 percent of the incident energy (still with 180 degrees of phase difference). As the transmitter to target geometry changes, the relative lengths of the direct and reflected paths also change. The received signal at the target is the vector sum of both the direct and reflected energy which causes received power to vary from 6 dB above (signals in phase) to 20 dB below (signal 180 degrees out of phase) the free space values.

2. Diffraction Effect

Radar energy in the diffraction region is usually due to diffraction by the curvature of the earth or refraction by the earth's atmosphere. The relatively weak field resulting from diffraction, which is predicted by electromagnetic theory, is generally too small to be effective for radar detection. At ranges beyond the radar horizon, propagation is dominated by a mechanism called tropospheric

scatter or troposcatter. This process of wave scattering due to certain heterogeneities causes path loss values that are so high it is impossible for any known radar to successfully detect targets. [Ref. 3]

3. Refraction and Anomalous Propagation

Although radar waves travel in straight lines in free space, waves in the atmosphere are bent or refracted due to the variation of the velocity of propagation with altitude. The effect is to extend the distance of the radar horizon beyond that for straight-line propagation. See Figure 2. The classical method of accounting for refraction is computations is by replacing the actual earth of radius a with an equivalent earth of radius ka and by replacing the




Figure 2. Horizon Extension Due to Refraction

actual atmosphere by a homogeneous atmosphere in which radar waves propagate in straight lines rather than curved lines.

[Ref. 4:p. 449] For standard atmospheric conditions the value of k used is $4/3$. The distance to the radar horizon can be shown to be approximately:

$$d = \sqrt{2 k a h} \quad \text{or}$$

$$d(\text{nautical miles}) = 1.064 \sqrt{k h(\text{ft})} \quad (10)$$

where h is the antenna height.

The most dramatic effects of refraction occur when the gradient of the index of refraction is sufficient to allow initially horizontal rays to be bent to very nearly follow the curvature of the earth. This condition is known as superrefraction, and such rays are said to be trapped. Rays normally can be trapped only if they originate within a layer of such conditions called a duct. Surface ducts extend upward from the surface to a height of a few hundred feet and on rare occasions up to one thousand feet. In the duct rays are bent down toward the ocean until a reflection occurs. The upward reflected ray is then gradually bent downward again until it again reflects from the surface. See Figure 3. A duct can be compared to a leaky waveguide; some fraction of the energy traveling within does escape. Generally energy coupled within a duct has an elevation angle to the duct of less than one degree and probably less than one-half degree [Ref. 5:p. 226]. These anomalous propagation conditions occur for k values greater than two.




Figure 3. Radar Energy Propagation in Surface-based Duct

The ducting conditions restrict the spherical spreading of energy resulting in both extended ranges for energy trapped within the duct and reduced energy, or radar holes, outside the duct. Because the wave is trapped within the duct, vertical spreading of the wavefront is prevented. Since the wave is spreading in only one dimension rather than two, the average rate of power density decrease is reduced to $1/R$ (vice $1/R^2$ for the free space model).

[Ref. 5:p. 227] Therefore a target located in or near a surface duct may be detected at a range beyond the normal free space detection range as well as below the radar horizon.

Figure 4 illustrates a typical one-way signal loss versus range profile demonstrating interference effects in the optical region and increased losses in the diffraction and troposcatter regions.




Figure 4. Required Signal-to-Noise Ratio for Detection with Noncoherent Integration of Pulses; Square-Law Detector, Swerling Case 3 Fluctuation, $P_d = 0.50$ [Ref. 7]

The radar loss module of the IREPS computer package can be used to predict duct propagation for specified refractive index profiles. (For more details, consult Reference 3.)

D. DETECTION MODEL

When a radar target return signal is present within a noise or jamming background, the probability of detection is a function of its visibility factor which is the degree to which the received signal-to-noise (S/N) ratio exceeds a radar-specific detection threshold. The relationship between the detection probability and this excess signal-to-noise quantity is a function of both an associated probability of false alarm (P_{fa})--the probability that noise alone will cause the threshold to be exceeded--and the assumed distribution functions for the level of the signal. For the latter the Swerling Case III model for scan-to-scan fluctuations is considered most appropriate for targets such as jet aircraft and missiles [Ref. 6:p. 276].

Detection probability on a scan is enhanced by the integration or combining of signals by either radar display persistance or other electronic means. The benefit of integration is primarily due to the reduction or smoothing of noise variation [Ref. 5:p. 42]. The effect is to lower the required visibility for target detection. See Figure 5.




Figure 5. Path Loss for a 5000 MHz Transmitter at 90 feet and a Receiver at 500 feet for a Standard Atmosphere

A relationship between detection probability and excess signal-to-noise ratio was developed by the Johns Hopkins University Applied Physics Laboratory [Ref 7.]. The relationship is:

$$P_d = .5 \cdot 1 + \sin [(\text{excess } (S/J)) (\pi/18)] \quad (11)$$

for $P_{fa} = 10^{-6}$

$$N = 10$$

and $-9 \leq S/J \leq 9$

to data obtained from Reference 7. (See Figure 6.)

E. OPERATOR FACTOR

Experts have postulated that when an operator becomes tired, bored or partially distracted, his efficiency is reduced and the probability of operator detection of a target is similarly diminished. This can be expressed in terms of an operator factor, P_o , which is defined as the probability that an operator will see a target signal that is detectable by an alert and perfect operator. It follows, therefore, that P , the probability that a scanned target is seen by the operator, can be expressed in equation form as:

$$P = P_o P_d \quad (12)$$

where P_o is the operator factor, and P_d is the previously derived probability of detection.

The nature of an operator factor is controversial. The operator factor often has been used to explain all differences between actual and theoretical performance. Although




Figure 6. Probability of Detection versus Excess Signal-to-Noise Ratio for Probability of False Alarm of 10^{-6} and an Integration Factor of 10

originally proposed to be constant for a given operator or operator and experiment, research has shown operator performance to vary with signal strength, display brightness, radial and azimuthal position on the scope and numerous other factors [Ref. 8].

Scolnik and others lend support to a simple model of operator efficiency under good conditions. Scolnik's model uses the following relationship to determine the probability an operator will detect a target:

$$P = 0.7 (P_d)^2 \quad (13)$$

This can be interpreted as follows: An operator must first see a target signal on some scan and then see the target signal on the successive scan for detection to occur [Ref. 4:p. 253]. For this model, the operator factor for the first scan could be considered to be equal to 0.7, and that for the second scan, to be 1.

III. THE PROBLEM SOLUTION

A. PROGRAM OVERVIEW

The Fleet Anti-Ship Tactics Simulator (FASTS) is written using the HP 9000 Series 500 BASIC Language System for use on the HP 9000 Series Model 520 Computer. The program source code is contained in Appendix A. It employs the general structure and computational methods used in the Modified Jamming Aircraft and Radar Simulation (JARSM), a PL/I LANGUAGE program supported by the IBM 3033 system [Refs. 7 and 9]. Several modifications have been implemented to JARSM aircraft maneuvering and radar processing routines, the largest of which incorporates mechanisms for calculating radar path signal losses using modules from the IREPS program developed by NOSC.

FASTS simulates a many-on-many war-at-sea scenario involving ship-based early warning radars, strike aircraft and supporting radar jammers. It provides the tactics designer a testbed for evaluating strike tactics against a defensive radar network and for estimating the impact of certain environmental conditions on radar detection.

FASTS is implemented on an unbounded x-y coordinate grid and is controlled by a main routine clock which steps from time zero to a finish time provided by the user. A separate

parameter data file is appended automatically to the program for each scenario. Scenario data includes:

1. Radar parameters for up to 15 radar types
2. Radar locations for up to 15 radar systems
3. Jammer parameters for up to 15 jammer types
4. Aircraft radar cross section data for up to 15 aircraft
5. Aircraft location and flight profile data
6. Scenario time increment
7. Environmental data

Specific input parameters and format are defined in Appendix B.

There are four types of output available from FASTS: a time history of aircraft position, velocity, and probability of detection; a geographic plot of aircraft tracks and visibility; a plot of aircraft detectability versus time; and a simulation-based table of expected first-detection ranges for each aircraft and radar combination.

The program is written in structured format. Program flow is controlled via the Main Routine illustrated in Figure 7.

B. INITIALIZATION SUBROUTINE (INIT)

The most critical part of the FASTS program from the user's point of view is the data input. Subroutine INIT reads scenario parameters from the input data file (Appendix B refers)




Figure 7. FASTS Main Routine

and processes them for program use. The following specific data elements are required:

1. Environmental parameters
 - a. Effective earth radius factor
 - b. Duct height (ft)
 - c. Wind velocity (knots)
2. Time parameters
 - a. Simulation time increment (sec)
 - b. Finish time (sec)
3. Radar type parameters
 - a. Effective radiated power (dB)
 - b. Frequency (MHz)
 - c. Antenna gain (dB)
 - d. Receiver figure of noise (dB)
 - e. Receiver noise bandwidth (MHz)
 - f. Receiver loss (dB)
 - g. Scan period (sec)
 - h. Antenna type
 - i. Azimuth bandwidth (degrees)
 - j. Elevation bandwidth (degrees)
 - k. Azimuth sidelobe gain (dB)
 - l. Antenna pattern
 - m. Antenna polarization
4. Radar site parameters
 - a. Type of radar
 - b. Location coordinates (x,y in nm)
 - c. Antenna altitude (ft)

5. Jammer type parameters
 - a. Effective radiated power (watts)
 - b. Bandwidth (MHz)
 - c. Frequency (MHz)
6. Aircraft type parameters--Radar aspect angle and associated radar cross section
7. Aircraft parameters
 - a. Initial location, altitude, heading and speed
 - b. Aircraft flight profile containing changes to each aircraft's position/velocity data and jammer status

The program time increment, D_t , is set to the minimum radar scanning interval (over all scan rates) if it is found to be less than the time increment read from the data file. Lastly frequently used constants for radar equation and jammer power equation calculations are computed for each radar and radar-jammer combination.

C. AIRCRAFT MODULE (UPDAC)

Subroutine UPDAC in FASTS controls the flight path for each aircraft in the scenario. The position, altitude and airspeed for each aircraft are updated at each clock increment. The aircraft is flown or controlled through the use of tactical commands issued from the scenario data file.

Seven different tactical commands are available:

1. JAM ON--Initiate jamming with a designated type of jammer
2. JAM OFF--Cease jamming with a designated type of jammer
3. CLIMB--Climb or dive to a specific altitude at a specific rate

4. TURN--Fly to a specific heading at a specific rate
5. HOME--Turn aircraft at each time iteration toward a specific radar site
6. FOLLOW--Maneuver with a specific aircraft

These instructions are stored and executed sequentially according to their initiation times. Due to the discrete time intervals of the simulation, the aircraft flight path is constant between update points. Thus, its flight path consists of a sequence of straight line segments. If the velocity of an aircraft is reduced to zero knots, it is removed from the simulation. This feature can be used to terminate aircraft tracking before the end of the simulation. Aircraft velocity is automatically set to zero whenever its velocity decreases to less than ten knots or its time-to-close the target of a HOME command is less than the simulation time increment.

The FOLLOW command was implemented as a convenience to enable aircraft to proceed in the company of another without having to repeat all maneuvering commands of the flight leader. This command is particularly useful in modeling missiles since missiles must remain co-positioned with the firing aircraft until launch. When an aircraft FOLLOW command is executed, all other maneuvering commands are cancelled. On execution of a subsequent maneuvering command, the FOLLOW command is cancelled and the aircraft retains the current position and velocity parameters.

Each aircraft in the simulation is capable of employing jammers which are turned on and off using profile commands. All jammers are initially off. A limitation of the program is that each aircraft may carry only one jammer of each type. Use of multiple jammers with the same parameters can be accomplished by defining different type jammers with identical specifications when building the data file. The flow diagram for Subroutine UPDACP is contained in Figure 8.

D. RADAR MODULE (UPDRD)

The radar subroutine is the heart of the FASTS program-- all other program modules support it by either providing data inputs or processing its solutions for output. The subroutine evaluates aircraft position and aspect at each time interval and determines signal visibility. Logic flow is illustrated in Figure 9. The model considers antenna position, radar beam shape, atmospheric effects on attenuation and propagation, and relative position and power of each of the radar jammers.

Parameters for up to fifteen radar types are entered with the initial data file. Up to fifteen radar systems, with parameters of one of the radar types, may be fixed at any location or altitude on the x-y position grid. Co-location of radars is permitted. All radars radiate throughout the simulation; parameters and positions are held constant. Each antenna scans in a clockwise direction according to its input scan rate starting at the zero degree position.




Figure 8a. Subroutine UPDAC




Figure 8b. Subroutine UPDACC (Cont'd)




Figure 9a. Subroutine UPDRD




Figure 9b. Subroutine UPDRD (Cont'd)

Subroutine UPDRD evaluates detection probabilities considering each radar in turn.

1. Path Losses

One-way radar signal path losses are calculated between the site and each target using subroutine IREP. See Figure 10. The subroutine returns a value of the path loss obtained by dividing the loss-versus-range curve, Figure 4, into four sections and applying the appropriate formulas for each section. The first section extends from the radar site to the last range in the optical region where the direct and reflected waves are exactly in phase (RPEAK); the second, to the physical end of the optical region (OPMAX); the third, to the range at which the radar field attenuation becomes dominated by single mode diffraction and tropospheric scattering (DMIN); and the fourth section lies beyond.

Within the optical region, a spherical spreading wave model is used. Multipath effects caused by wave reflections off of a wind roughened surface and losses due to antenna vertical beam pattern are computed. At RPEAK, signal path losses are calculated to the maximum envelope of the interference null peaks. At ranges within the intermediate region between OP MAX and DMIN, loss is computed by linear interpolation. Beyond DMIN diffraction and troposcatter losses are calculated directly.

The FASTS subroutine IREP duplicates the loss module of the IREP Revision 2.2 program as closely as possible to




Figure 10. Subroutine IREP

permit future updating or modification. Variable names have been modified only to enable structural dovetailing with subroutine UPDRD and to prevent duplication of variable names. The one-way signal loss calculated by the IREPS program contains the radar equation factor for the antenna capture area, A_c , for an antenna of unity gain. Since the antenna capture area was already incorporated in the radar and jamming equations computed in subroutine IREP, the quantity:

$$A_c = \frac{\lambda^2}{4\pi} = \frac{c^2}{4\pi f^2}$$

was factored out of the IREP loss figure.

2. Noise Power

Noise power coupled into each receiver is computed by summing antenna thermal noise power and the noise power received from all aircraft jammers. Thermal noise power is computed as follows:

$$P_{no} = k T B_n F_n$$

where $k = 1.38E-23$ watt-sec/ $^\circ$ K (Boltzman's constant)

$$T = 290^\circ K$$

B_n = Receiver noise bandwidth (Hz)

F_n = Receiver noise figure

The jamming power constants, (Jampwr) are computed in subroutine INIT and are equivalent to the quantity contained in the unbracketed portion of Equation (9). A polarization loss factor of two is assumed for all jammers. Power transmitted by each jammer is attenuated by the one-way IREP

loss figure and the sidelobe loss based on the angular displacement of the target aircraft from the jammer. FASTS contains methods, developed for JARSM, which compute the sidelobe loss for two general azimuth pattern shapes:

$$[\sin(x) / x]^2 \text{ and } \left[\frac{\pi}{2} \frac{\cos(x)}{\pi/2 - x^2} \right]^2$$

where x is the angle of displacement of the signal from the antenna axis in radians. These general forms are adjusted using the radar azimuth beamwidth and the level of the first sidelobe to approximate real antenna patterns. Figure 11 illustrates signal loss as a function of angular displacement for both antenna pattern forms.

3. Signal Power

The constant $Rdreqn$ is computed in the INIT subroutine to represent the combined value of all radar equation factors excepting radar cross section, σ (meter²), and the transmission loss factor. (Refer to Equation (8).) These additional quantities are position and aspect dependent and, therefore, are recomputed on each pass through subroutine UPDRD. The radar cross section is calculated by interpolation using the aircraft/radar aspect angle to enter a table of radar cross section values input via the data file. Since by reciprocity, the path from target to radar is the same as from radar to target, signal transmission loss is computed by doubling the one-way IREP loss figure.




Figure 11. Radar Azimuth Antenna Patterns,
Four Degree Beamwidth

4. Probability of Detection

Computation of the probability of detection for each aircraft/radar pair is made at each time increment. If the program determines that a radar has not scanned a particular aircraft, the associated probability is set to zero. Recall that the time increment can be no greater than the minimum radar scanning interval, and so it is quite possible to have incremental periods wherein the antenna axis of a radar does not cross all targets. If the aircraft is scanned by the radar, Equation (11) is used to determine the probability of detection based on the excess signal-to-noise ratio observed at the radar. The determination of the excess S/J ratio is made using the computed values for signal and noise power. The excess S/J ratio may be further reduced by a radar-specific visibility factor which shifts the value of the detection threshold to a value above unity. Figure 5 illustrates the visibility factor requirements for a representative radar system to achieve a 0.5 probability of detection. Note that the visibility factor is also a function of the selected probability of false alarm and the level of pulse integration. See Reference 7 for additional background.

E. PROGRAM OUTPUT

The subroutine Output processes simulation data at each iteration for direct output or for summary computations to be performed at the end of the simulation. Logic flow

diagrams for the subroutine are contained in Figure 12.

User selection of program output is made via interactive keyboard entry. Additionally the user is able to enter an output start time which determines the simulation time for the beginning of all output data displays and computations. Four output formats are available. All output products can be printed or displayed on the CRT.

1. Data

Simulation data is printed for each aircraft following each time step iteration. Aircraft position coordinates, altitude, heading, speed, and radar detection probabilities can be sent to the CRT display or the system printer. The 80-column format of these displays limits output to simulations with four or fewer radar systems. The data output format is illustrated in Figure 13.

2. X-Y Plot

The X-Y Plot output selection displays a coordinate mapping of radar sites and aircraft positions throughout the simulation. The user selects plot coverage by entering coordinates for right, left, top, and bottom display boundaries. Aircraft movement tracks are displayed by solid or dotted lines reflecting susceptibility to detection by a selected radar system: A dotted line indicates a probability of detection less than 0.5; a solid line shows this threshold is met or exceeded. Normally all aircraft tracks are displayed in




Figure 12a. Subroutine Output




Figure 12b. Subroutine Output (Cont'd)




Figure 12c. Subroutine Output (Cont'd)

FASTS DATA OUTPUT							DATASET: SAMPLE		
ACFT	TIME	DX	DY	ALT	HEADG	SPEED	RADAR 1	RADAR 2	
1	110.0	52.7	71.0	5000.0	180.0	600.0	.9150	1.0000	
2	110.0	52.7	71.0	5000.0	180.0	600.0	0.0000	.3928	
ACFT	TIME	DX	DY	ALT	HEADG	SPEED	RADAR 1	RADAR 2	
1	115.0	51.8	71.0	5000.0	180.0	600.0	.9238	1.0000	
2	115.0	51.8	71.0	5000.0	180.0	600.0	0.0000	1.0000	
ACFT	TIME	DX	DY	ALT	HEADG	SPEED	RADAR 1	RADAR 2	
1	120.0	51.0	71.0	5000.0	180.0	600.0	.9878	1.0000	
2	120.0	51.0	71.0	5000.0	180.0	600.0	0.0000	1.0000	

Figure 13. FASTS Data Output for Three Time Steps

white. Tracks for aircraft with jammers that are active against the selected radar are plotted in magenta. A sample of the X-Y Plot format is illustrated in Figure 14.




Figure 14. FASTS X-Y Plot Output

3. Probability of Detection per Scan Plot

The probability of detection per scan, P_d , for each aircraft by a selected radar is plotted against simulation time as depicted in Figure 15. The values for P_d , bounded by 0 and 1, are depicted on an unlabeled linear scale for each aircraft. The 0.5 probability of detection threshold reference is indicated by a dotted line for each aircraft. This plot

highlights time segments of high, low, or changing aircraft vulnerability to detection and permits comparative analysis between different aircraft and flight profiles. The user is cautioned not to interpret this to be a depiction of cumulative probabilities.




Figure 15. FASTS Probability of Detection per Scan Plot Output

4. First Detection Statistics

An estimate of the range of the first operator detection for each aircraft by each radar is made using statistical simulation and modeling of operator performance.

Throughout the program, fifty parallel detection simulations are maintained. At each iteration, if an aircraft is scanned, a random number, distributed uniformly on the interval (0.1), is drawn to support each of the fifty simulations. Using Equation (13), a detection is said to occur if the probabilities of detection on two successive scans exceed the random number drawn for each event. The probability of detection for the first of these two scans is reduced by thirty percent to compensate for the unalerted operator. If an operator detection is obtained, the range is recorded for later statistical computations. After the finish time has been reached, the fifty ranges are processed by subroutine Output-stats. See Figure 16. The ranges are sorted, and mean, standard deviation, and quantile statistics are computed over all simulations which experienced a detection. The percentage of simulations in which the aircraft was detected is computed as an estimator of an aircraft's probability of detection for the mission.

All statistics represent simulation events occurring after the user entered start time. The feature of start time selection allows the user to determine, for example, the range for the first operator detection of an aircraft following its descent to a low altitude where masking by the radar horizon occurs. In any case, first operator detection statistics can lose meaning if the aircraft is already detectable when the statistical computations are commenced.

A sample output for First-Detection Statistics is illustrated in Figure 17.




Figure 16. Subroutine Output-stats

FASTS STATISTICS OUTPUT
START TIME: 400

DATASET: SAMPLE

AIRCRAFT	1	DETECTION RANGE STATISTICS			PCT DET		
RADAR	MEAN	STD DEV	.25 QNT	.50 QNT	.75 QNT	NOT DET	PCT DET
1	NOT DET	NOT DET	NOT DET	NOT DET	NOT DET	NOT DET	0
2	NOT DET	NOT DET	NOT DET	NOT DET	NOT DET	NOT DET	0
AIRCRAFT	2	DETECTION RANGE STATISTICS			PCT DET		
RADAR	MEAN	STD DEV	.25 QNT	.50 QNT	.75 QNT	NOT DET	PCT DET
1	38.140	.945	37.140	38.390	38.390	1.000	1.000
2	42.330	1.213	41.568	42.818	42.818	1.000	1.000

Figure 17. FASTS Statistics Output

IV. FASTS VERIFICATION

Considerable program verification was accomplished during the creation of the program. The proper operation of the data initialization, aircraft maneuvering, radar scanning and input/output features was confirmed as each module was assembled into the program. Variable tracing techniques and analysis of output data and graphics were used. To determine if FASTS was operating as intended, several aircraft/jammer flight profiles were simulated for which the results were easily predicted.

Verification of the radar simulation was accomplished by confirming proper operation of the environmental signal loss routine and analysis of the model output data with respect to aircraft detection at the radar horizon, jammer burnthrough ranges, and detection ranges for aircraft in a standoff jamming environment.

A. LOSS COMPUTATION TEST

Values for one-way signal transmission losses were traced for aircraft opening a radar site at altitudes of 500, 1000, and 5000 feet and compared with IREPS Revision 2.2 Loss Display data. Parameters for the AN/SPS-10 radar system and standard day atmospheric conditions were employed. The signal loss data compared within 2 dB for all three cases over ranges up to 160 nautical miles.

B. RADAR HORIZON TEST

FASTS simulations were conducted in which aircraft flew outbound from a radar site at 100, 200, and 500 feet. Using standard day atmospheric conditions and an antenna height of 100 feet, the last ranges at which the radar visibility threshold was exceeded were noted and found to be in agreement with the predicted theoretical radar horizon. Data for the tests are presented in Table 1 and Figure 18.

TABLE I
RADAR HORIZON TEST RESULTS

	100	200	Altitude (ft) 500	1000
Predicted Range (nm)	24.6	29.7	39.8	51.1
Observed Range (nm)	25	28	37	47




Figure 18. Radar Horizon Test

The deviation of the test results of up to eight percent from the predicted values are not considered to reflect any imprecision in the program. The radar horizon represents the end of the optical region beyond which the rate of signal attenuation shows a marked increase and, thus, is an upper bound approached by the ranges at which the returned power exceeds the radar's visibility threshold.

C. JAMMER SELF-SCREENING TEST

Two FASTS simulations were conducted in which aircraft carrying active jammers closed toward a radar site. The ranges at which the radar's visibility threshold was exceeded were compared with those predicted by equating the radar and jammer power equations (Equations (8) and (9)) and solving for range. The inherent assumptions for the equations of isotropic and non-reflected radiation were satisfied by a program modification setting the program variable for the pattern factor (FFAC) equal to unity. Results, presented in Table II, confirmed proper operation of noise power and detection probability computations.

D. STANDOFF JAMMER TESTS

1. Azimuth Test

Verification of the radar azimuthal antenna pattern modeling was accomplished through use of a multi-aircraft scenario. The jammer and twelve additional aircraft closed the target radar simultaneously from fifty nautical miles at

TABLE II
JAMMER SELF-SCREENING TEST RESULTS

	Simulation 1	Simulation 2
Predicted Range (nm)	17.03	35.26
Observed Range (nm)	17	35
Parameters:		
Pt (kw)	100	1000
Gt	10,000	10,000
Br (MHz)	0.5	0.1
Pj (kw)	0.8	14.0
Bj (MHz)	100	150
(m)	25	25

500 feet using one degree separation of inbound headings. The $(\sin x/x)^2$ azimuth antenna pattern--Type 1--with a four degree beamwidth and 20 dB loss in the first sidelobe was used. Figure 19 depicts the scenario and demonstrates the expected reduction of jammer protection afforded aircraft with increasing displacement from the jamming axis. Pattern nulls can also be discerned.

2. Range Test

This test was conducted to observe the effects of altitude, atmospheric ducting and jamming on the target range required to exceed the radar visibility threshold. An effective earth radius, k, of 3.92 and a duct height of 996 feet were used. In six simulations, targets flying at altitudes of 500 feet (in the duct) and 2000 feet (above the duct) closed a radar site. Jammer aircraft, when used, flew at 500 feet or 2000 feet, either with or directly above or below the target. The six simulations were repeated for standard day atmospheric conditions. The target observation ranges are presented in Table III.




Figure 19. Standoff Jammer Test

TABLE III
RANGE TEST RESULTS

Target Altitude (ft)	None	Standard Day			None	Standard Day		
		Jammer 500 ft	Altitude 2000 ft	Jammer 500 ft		Jammer 500 ft	Altitude 2000 ft	
500	34	17	15	> 120	20	18		
2000	62	55	28	93	46	29		
.								
Parameters:								
Pt (kw)		100						
Gt		10,000						
Br (MHz)		0.5						
Pj (kw)		0.8						
Bj (MHz) (m)		100 25						

Without jamming and under standard day conditions, the targets were seen as they crossed their radar horizon ranges. Predictably, ducting extended the detection range for the low target and due to duct leakage effects, considerably extended the detection range for the target operating above the duct..

When jamming was employed, detection ranges were reduced in all cases.

The effect of locating the jammer within the duct is seen in an increased detection range (over that for nonconducting conditions) for the target located within the duct which is caused by reduced transmission losses for both the radar and jammer signals. Reduced detection ranges for a target located above the duct are consistent with the increased jammer efficiency within the duct and the spherical propagation loss associated with the radar-to-target signal path.

When both the jammer and target are above the duct, detection ranges are shown to be nearly equal to those for standard day conditions, as expected, since spherical spreading laws are dominant.

Other verification tests are, no doubt, possible. However, these tests are sufficient to show that FASTS does perform accurately and consistently.

V. SAMPLE IMPLEMENTATION

An example of a tactical simulation is described in this chapter which includes a scenario definition, the initial tactical plan, the data file construction, a program execution outline and an analysis of the program output.

A. SCENARIO

In this example, FASTS is used to analyze an air strike against two ships located 300 nautical miles from base. The ships are defended by surface-to-air weapons, and so a standoff delivery of air-to-surface missiles (ASM's) is desired. Two ASM attack aircraft, one anti-radiation missile (ARM) aircraft, and a supporting tactical jammer aircraft are available.

The aircraft will proceed together toward the target at medium altitude (5000 feet) and descend to 1000 feet at 75 nautical miles from the target. At 50 nautical miles, the ASM aircraft split from the formation, turning 50 degrees right and left of the target bearing, and accelerate to attack speed. The ARM aircraft continues to close the target, fires his missile at 30 nautical miles, and retires. The jammer slows slightly, commences jamming, and establishes a figure-eight pattern at 30 nautical miles.

At 2 minutes and 35 seconds after the split, the first ASM aircraft turns left toward the ships, fires his missile

from 30 nautical miles at the rightmost ship, and turns to retreat. The second ASM aircraft turns right three minutes following the split, fires his missile from 30 nautical miles at the leftmost ship, and retires.

Near simultaneous impact of ASM's is desired; the ARM should arrive earlier to support the ASM's penetrating of the ships' radar defenses.

B. DATA FILE CONSTRUCTION

The data file is constructed as described in Appendix B. The listing is provided in Figure 20. Once constructed, the data file is easily modified to permit adjustment to the tactical scenario. The data file must be saved using the SAVE or RE-SAVE command in order to prevent loss of the file when the FASTS program is loaded.

C. PROGRAM EXECUTION

The source program is brought into the computer memory by entering the command LOAD "FASTS". On entering RUN, the program execution is begun, and the user is prompted to enter the data file name; the data file is retrieved and appended to the FASTS program. Following interactive queries to define the desired output form, the simulation is commenced.

The X-Y Plot output option is selected first and reviewed to verify the proper maneuvering geometry for the aircraft and proper radar positioning. Verification of the CLIMB and ACCEL commands is performed by reviewing the DATA

```

10 flat ! DATASET NAME
20 DATA WASI
30 !
40 !IREPS K DUCT HT (FT) WIND
50 DATA 1.33, 0, 8
60 !
70 ! NAC NJM NRD NACTYP NRDTYP DT TFIN
80 DATA 7, 2, 2, 2, 2, 10, 1000
90 !
100 Rdrdat : !
110 ! RDATYP RDALAT RDALONG RDALT
120 DATA 1, 0, 0, 80 ! RDR 1
130 DATA 2, 0, 5, 80 ! RDR 2
140 !
150 ! RDSCNTYP RDDBTYP RMAXTYP RUZEROTYP
160 DATA 5, 0, 250, 0 ! RDR 1
170 DATA 5, 1, 125, 0 ! RDR 2
180 !
190 !
200 ! RDFRQTYP RDGANTYP RDFTNTP RDNBWTP LOSSTYP
210 DATA 90, 1000, 40, .5, 10 ! RDR 1
220 DATA 102, 850, 35, 7, 0.1, 7 ! RDR 2
230 DATA 98, 31,
240 !
250 !
260 ! RDASLTYP RDASLTYP RDELBWTYP CSCSQTP GTYPEFTYP HPOLAR
270 DATA 4, -20, 4, 0, 1 ! RDR 1
280 DATA 3, -20, 7, 0, 1 ! RDR 2
290 DATA 3.5, -20, 4, 1, 1 , 0
300 !

```

```

310 Jmdata:!
320   ! JMBW
330 DATA 100,    JMFRQ      1000,
340 DATA 150,    800
350   ! 900,    14000
360   !
370   ! ALPHA    RCS
380 DATA 0,     14
390 DATA 180,   14
400 DATA 9999,  00.0
410   !
420 DATA 0,     -3
430 DATA 180,   -3
440 DATA 9999,  0
450   !
460 Acdata:!
470   ! ACTYPE
480 DATA 1,     ACALAT    100,
490 DATA 1,     ACLONG    0,
500 DATA 1,     ACALT     0,
510 DATA 1,     ACHDG     50000,
520 DATA 2,     180,      180,
530 DATA 2,     360,      360
540 DATA 2,     180,      360
550   !

```

Figure 20b. Data File Listing (Cont'd)

	TIME	CHANGE	X	Y
560	!ACFT1			
570	DATA 1,	6,	-3,	1
580	DATA 250,	4,	-100,	1000 ! DECEND TO 1000 FT
590	DATA 500,	3,	-5,	300 ! DECELL TO 300 KTS
600	DATA 500,	1,	1,	0 ! JAMMER 1 ON
610	DATA 500,	1,	2,	0 ! JAMMER 2 ON
620	DATA 740,	5,	-3,	181 ! TURN
630	DATA 660,	5,	3,	180 ! TURN
640	DATA 980,	5,	3,	0.45 ! TURN
650	DATA 9999			
660	DATA 9999			
670	!			
680	!ACFT2			
690	DATA 1,	7,	1,	0 ! FOLLOW JAMMER
700	DATA 500,	3,	5,	420 ! ACCEL TO 420
710	DATA 500,	5,	3,	230 ! TURN
720	DATA 655,	6,	3,	1 ! HOME TO 1
730	DATA 740,	5,	-3,	360 ! TURN AFTER SHOT
740	DATA 9999			
750	!			
760	!ACFT3			
770	DATA 1,	7,	1,	0 ! FOLLOW JAMMER
780	DATA 500,	3,	5,	420 ! ACCEL TO 420
790	DATA 500,	5,	-3,	130 ! TURN
800	DATA 680,	6,	3,	2 ! HOME TO 2
810	DATA 750,	5,	-3,	360 ! TURN AFTER SHOT
820	DATA 9999			
830	!			

Figure 20c. Data File Listing (Cont'd)

```

840 1ACFT4      0          ! FOLLOW JAMMER
850 DATA 1,      1,          ! MAINTAIN 360 KTS
860 DATA 500,     5,          ! TURN AFTER SHOT
870 DATA 700,     5,          !
880 DATA 9999     -3,         !
890 !          

900 1ACFT5      0          ! FOLLOW SHOOTER(R)
910 DATA 1,      2,          ! HOME TO RDR 1
920 DATA 730,     3,          !
930 DATA 730,     3,          ! ACCEL
940 DATA 730,     4,          ! FALL TO 50 FT
950 DATA 9999     -100,       !
960 !          

970 1ACFT6      0          ! FOLLOW SHOOTER(L)
980 DATA 1,      3,          ! HOME TO RDR 2
990 DATA 740,     3,          !
1000 DATA 740,     3,          ! ACCEL
1010 DATA 740,     4,          ! FALL TO 50 FT
1020 DATA 9999     -100,       !
1030 !          

1040 1ACFT7      0          ! FOLLOW SHOOTER(C)
1050 DATA 1,      4,          ! HOME TO RDR 1
1060 DATA 700,     3,          !
1070 DATA 700,     3,          ! ACCEL
1080 DATA 700,     4,          ! CLIMB TO 10000 FT
1090 DATA 9999     -100,       !

```

Figure 20d. Data File Listing (Cont'd)

output information. If the simulation is seen to be operating properly, the X-Y Plot figure may be sent to the printer. Figures 21 through 24 represent plots of the strike for 100 and 50 mile ranges displaying visibility thresholds for each radar.

The program is run again, and the Probability of Detection Plot output is selected. Graphs are printed showing the probability of detection for each aircraft relative to each radar system. (See Figures 25 and 26.)

The first Detection Statistics output is obtained on the final run. The initiation time for the statistics compilation is chosen to be twenty seconds after the launch of the second ASM to allow both missiles to fall below their radar horizon altitudes. Figure 27 contains the statistics output for the missiles, i.e., aircraft 5, 6, and 7.

D. EVALUATION OF RESULTS

Analysis of the X-Y Plot and Probability of Detection per Scan Plot shows the strike group would almost certainly have been acquired by enemy radars and tracked from the radar horizon at 90 miles until they descended at 75 miles. Jamming protection after the formation split at 50 miles only provided 50 to 80 seconds of coverage for the ASM aircraft due to their increasing displacement from the jamming axis. The ASM aircraft should expect to be tracked continuously by both ships from this burnthrough point through weapon delivery and their outbound turn maneuver.




Figure 21. X-Y Plot for Radar 1; 105 nm Range




Figure 22. X-Y Plot for Radar 2; 105 nm Range




Figure 23. X-Y Plot for Radar 1; 55 nm Range




Figure 24. X-Y Plot for Radar 2; 55 nm Range




Figure 25. Probability of Detection per Scan Plot for Radar 1




Figure 26. Probability of Detection per Scan Plot for Radar 2

FASTS STATISTICS OUTPUT
START TIME: 760

DATASET: WASI

AIRCRAFT	S	DETECTION RANGE STATISTICS				PCT DET
RADAR	MEAN	STD DEV	.25 QNT	.50 QNT	.75 QNT	PCT DET
1	11.762	1.674	10.907	11.670	13.198	1.000
2	14.342	.749	13.900	14.260	14.622	1.000

AIRCRAFT	6	DETECTION RANGE STATISTICS				PCT DET
RADAR	MEAN	STD DEV	.25 QNT	.50 QNT	.75 QNT	PCT DET
1	11.605	.923	10.713	11.403	12.101	1.000
2	14.399	.963	13.781	14.163	14.545	1.000

AIRCRAFT	7	DETECTION RANGE STATISTICS				PCT DET
RADAR	MEAN	STD DEV	.25 QNT	.50 QNT	.75 QNT	PCT DET
1	NOT DET	NOT DET	NOT DET	NOT DET	NOT DET	0
2	18.541	.323	18.260	18.762	18.762	1.000

Figure 27. First Detection Statistics for Simulated Missiles

Due to his close alignment with the jamming axis, the ARM aircraft probably would not be detected by either ship's radar until just prior to launching his missile. Radar tracking would be solid through his outbound turn but would then degrade rapidly.

Both ASM's can be seen to be covered by jamming until well within their theoretical radar horizon of 19.7 miles. The statistical simulation predicts mean detection ranges for the ASM's of 11.8 and 11.6 miles by radar 1. Radar 2 ranges, 14.3 and 14.4 miles, were slightly higher due to the missiles' displacement from the jammer axis.

The ARM would not have been detected by radar 1; radar 2 may have detected the missile at as far as 18 nautical miles (from ship 2) when it would have been about 90 seconds from impact.

Missile coordination was satisfactory with ASM's impacting their targets with eight seconds separation following the arrival of the ARM by 1 minute and 32 seconds.

E. FOLLOW-ON SIMULATIONS

With the above results serving as a baseline, the scenario data file now can be modified to investigate and compare alternative plans or conditions. Such easily incorporated changes might include:

- Reduced altitudes for ASM launching aircraft
- Jammers accompanying ASM launching aircraft
- Different relative positionings of enemy ships
- Non-standard atmospheric conditions

VI. RESULTS AND CONCLUSIONS

The FASTS program developed in this thesis provides a consistent tool for use in the tactical planning process. It has demonstrated potential utility for: designing and simulating plans for coordinated tactical strikes; investigating radar visibility of aircraft under both standard and anomalous propagation conditions; and evaluating the effect of jamming on aircraft detection in a dynamic scenario.

Certain limitations exist in FASTS which must be recognized by a user in order to properly interpret the simulation results. Specifically, FASTS does not model:

1. Ship motion or the effect of wind which could easily alter the critical relative geometry of the simulation elements;
2. Radar transmission loss for targets above 10,000 feet altitude with verified accuracy;
3. Effects of jammer antenna blanking caused by maneuvering of the jammer aircraft;
4. Radar returns from sea clutter, an effect enhanced under ducting conditions, which may greatly reduce an operator's ability to discern an otherwise detectable target.

Areas for potential improvement to FASTS which could provide an increased simulation capability include incorporation of:

1. A standardized data base to include parameters for aircraft, radars, and jammers;
2. Missile profile routines to assess launch parameters and determine missile flight path vectors.

3. Transmission loss modeling for targets above 10,000 feet altitude;
4. Techniques for optimizing jammer placement as developed by T.W. White [Ref. 11] as a potential maneuvering control for jammer aircraft; and
5. Streamlined data and computation routines.

It is hoped that any future development effort for FASTS will not lose sight of its original objective--to provide a tactics testbed which can be used easily and interpreted by a fleet tactics planner. Evolution into a stochastic battle model would beget an increased level of complexity contrary to its intent.

APPENDIX A. FASTS PROGRAM SOURCE CODE

```

1C !      *-*-* Fleet Anti-Ship Tactics Simulator *-*-*-  

20 !  

30 ! FASTS supports the evaluation of a many-on-many scenario involving  

40 ! strike aircraft, support jammers, and air search radars. It is  

50 ! essentially a geometric model that computes the probability of  

60 ! a radar's detecting a target aircraft as a function of the S/J ratio  

70 ! observed at the radar receiver. The program draws directly from both  

80 ! the Modified Jamming Aircraft and Radar Simulation (JARSM) Program/  

90 ! Johns-Hopkins Univ. APL and NOSC's IREPS radar loss model.  

100 !  

110 ! *****  

120 ! BEGIN FASTS  

130 ! *****  

140 !  

150 OPTION BASE 1  

160 !  

170 INTEGER Nac,Njm,Nrd,Nsi,Nactyp,Ncp  

180 INTEGER Actype(15),Alpha(15,360),Ndeg(15),Change(15,15)  

190 INTEGER Cmd(15),Ac(15,15),Acy(15,15),Dtype(15,2),Atsite(15)  

200 INTEGER Rdtyp(15),Nrdtyp,Output_choice,Rdr_choice,Rule,Hpolar(15,2)  

210 INTEGER Tc,Fdno  

220 INTEGER Inde(15,360),Ndeg  

230 INTEGER A,I,J,F,M,Q,QG,K,Tt  

240 !  

250 ! INTEGER VARIABLES USED AS LOGICAL TYPES  

260 INTEGER Acc(15),Cimb(15),Turn(15),Hhom(15),Csseq(15,2),Cross  

270 INTEGER Jsmac(15,15),Nojam(15,15),Rdbtbtyp(15),Rdbtb(15),Scarned(15,15)  

280 INTEGER Graphics_flag,Stop_flag,Follow(15),Stopnext(15)  

290 !

```

```

300 REAL AcLat(15),AcLong(15),AcAlt(15),AcVel(15),Achdg(15),HdLat(15)
310 REAL HdLong(15)
320 REAL Acacc1(15),Acc1mb(15),Acturn(15),Tacc1(15),Tturn(15)
330 REAL Tc1mb(15),Rcs(15,360),Cloc1(15,15)
340 REAL Jmbdw(15),Jmfra(15),Jmfp(15),Jmpol(15),Jmef(15,15)
350 REAL Rderptyp(15,2),Rdfrqtyp(15),Rdfntyp(15,2),Rdfntyp(15,15)
360 REAL Rdnbwtyp(15),Losstyp(15),Rdscantyp(15),Rmaxtyp(15),Rvzerotyp(15)
370 REAL Rdalt(15),Rdatt(15),Rdlat(15),Rdlong(15)
380 REAL Rdant(15,2),Rderp(15,2),Rdfrq(15),Rvzero(15)
390 REAL Rdgan(15,2),Rdfn(15),Rdmft(15),Rdnbw(15),Rdsrn(15)
400 REAL Rman(15),Loss(15),Rdazbw(15,2),Rdazs1(15,2),Phi0(15,2)
410 REAL Rate(10),Deg_scanned(15),Exp2(15),Rdreqn(15,2),Jampwr(15,2,15)
420 REAL R(15),Rr(15),H4(15),Phi(15),Theta(15)
430 REAL Pival(2),Fstlob(2),Seclob(2),Farlob(2),Xzero1(2),Xzero2(2)
440 REAL X3db(2),Coeff(2,3),X1(2),X2(2)
450 REAL Array(15,360),Irep_loss(15,2)
460 REAL Buffer(15,21),Old_buffr(15,21),Sim_rng(15,15,50)
470 I
480 ON ERROR GOTO Endit
490 GOTO Dsn ! APPEND DATASET TO PROGRAM SOURCE CODE
500 !
510 Main: ! -••• Main Program * * *-
520 !
530 GOUE Init
540 GOUE Setup
550 Stepclac1 T=T+dt
560 IF T>fin OR T>9999 THEN GOTO Exit
570 GOUE Updac
580 GOUE Updrd
590 GOUE Outpt
600 GOTO Stepclac1
610 !
620 ! -••• End Main Program * * *-

```

```

300 REAL Ac1lat(15),Ac1long(15),Ac2lat(15),Ac2vel(15)
310 REAL Achdg(15),Hd1lat(15),Hd1long(15)
320 REAL Acacc1(15),Accimb(15),Acturn(15),Tacc1(15),Tturn(15)
330 REAL Tc1mb(15),Rcs(15,360),Cloc1(15,15)
340 REAL Jmbdw(15),Jmfrq(15),Jmerp(15),Jmpol(15),Jmef(15,15)
350 REAL Rde rptyp(15,2),Rdfraqtyp(15),Rdgantyp(15,2),Rdfntyp(15)
360 REAL Rdnbwtyp(15),Losstyp(15),Rds cantyp(15),Rmaxtyp(15),Rvzerotyp(15)
370 REAL Raalt(15),Rdart(15),Rd1lat(15),Rd1long(15)
380 REAL Rdant(15,2),Rderp(15,2),Rdfrq(15),Rvzero(15)
390 REAL Rdgan(15,2),Rdfn(15),Rdmct(15),Rdnbw(15),Rds cn(15)
400 REAL Rmax(15),Loss(15),Rdazbw(15,2),Rdazs1(15,2),Phi0(15,2)
410 REAL Rate(10),Deg_scanned(15),E:p2(15),Rdreqn(15,2),Jampwr(15,2,15)
420 REAL R(15),Rr(15),H4(15),Phi(15),Theta(15)
430 REAL Pival(2),Fstlob(2),Seclob(2),Farlob(2),Xzero1(2),Xzero2(2)
440 REAL X3db(2),Coeff(2,3),X1(2),X2(2),Sim_rng(15,15,50)
450 REAL Array(15,360),Irep_los(15,2),Buffr(15,21),Old_buffr(15,21)
460 |
470 ON ERROR GOTO Endit
480 GOTO Dsn ! APPEND DATASET TO PROGRAM SOURCE CODE
490 |
500 Main: ! -=*** Main Program ***=-
```

```

510 |
520 GOSUB Init
530 GOSUB Setup
540 Stepcloci T=T+Dt
550 IF T>fin OR T>9999 THEN GOTO Exit
560 GOSUB Updac
570 GOSUB Updrd
580 GOSUB Outpt
590 GOTO Stepcloci
600 |
610 ! -=*** End Main Program ***=-
```

```
620 !
EZ0 D$n! APPEND DATA SET
640 PRINTER IS CRT
650 PRINT PAGE
660 GINIT
670 GRAPHICS OFF
680 ! APPEND DATA SET FILE TO PROGRAM SOURCE CODE.
690 DISP "ENTER DATASET FILE NAME: "
700 ENTER KBD;D$_.name$;
710 PRINT TABXY(1,20); "LOADING DATASET FILE: ";D$_.name$;
720 DISP
730 GET D$_.name$,Dat
740 EDTD Main
750 !
```

```

750 Init   ! --*** INITIALIZE PROGRAM NON-ZERO VARIABLES***=-
770 RANDOMIZE 92847
780 C=.1E1890  ! NM PER SEC / 1.0 E-6
790 Fid180=PI/180
800 D180pi=180./PI
810 Gfac=2./3
820 Graphics_flag=0
830 zero=0
840 Rdr_choice=16
850 Ncp=15 ! MAX NUMBER OF FLIGHT COMMAND PROCEDURES FOR EACH AIRCRAFT
860 READ Pival(*) ! ANTENNA HORIZ BEAM MODELING PARAMETERS
870 DATA 1.0,0.4052E
880 READ Fstlob(*)
890 DATA -12.27,-22.1
900 READ Seclob(*)
910 DATA -30,-30
920 READ Farlob(*)
930 DATA -35,-35
940 READ xzerol(*),xzero2(*)
950 DATA 1,1.5,2,2.5
960 READ x3db(*)
970 DATA 1.39156,1.8677
980 Coeff(1,1)=0.00348
990 Coeff(2,1)=0.0000754
1000 Coeff(1,2)=-0.047931
1010 Coeff(2,2)=-0.001292
1020 Coeff(1,3)=0.16522
1030 Coeff(2,2)=0.005657
1040 READ x1(*),x2(*)
1050 DATA 1.875,2.25,
1060 !

```

```

1070 ! DATA FOR FOLLOWING 'READ' STATEMENTS AT END OF PROGRAM (LABEL: DAT)
1080 READ Ds_name$  

1090 PRINT "DATASET" ;Ds_name$  

1100 WAIT 2  

1110 READ Kfac,Ht_ductft,Wind  

1120 READ Nac,Njm,Nrd,Nactyp,Nrdtyp,Dt,Tfin  

1130 FOR R=1 TO Nrd ! READ RADAR TYPE AND POSIT DATA
1140 READ Rdtyp(R),Rdlat(R),Rdlng(R),Rdalt(R)
1150 NEXT R  

1160 !  

1170 ! READ PARAMETERS FOR EACH RADAR TYPE
1180 FOR R=1 TO Nrdtyp
1190 READ Rdscntyp(R),Rdbtbtyp(R),Rmantyp(R),Rvzerotyp(R)
1200 NEXT R
1210 FOR F=1 TO Nrdtyp
1220 READ Rderptyp(R,1),Rdfrqtyp(R),Rdgantyp(R,1),Rdfntyp(R),Rdnbwtyp(R),Los
    typ(R)
1230 IF Rdbtbtyp(R)=1 THEN READ Rderptyp(R,2),Rdgantyp(R,2)
1240 NEXT R
1250 Q=1
1260 FOR R=1 TO Nrdtyp
1270 READ Rdazbwtyp(R,Q),Fdazsltyp(R,Q),Rdelbwtyp(R,Q),Cscsqtyp(R,Q),Dtproperty
    p(R,Q),Hpolari(R,Q)
1280 IF Q=1 AND Fdbtbtyp(R)=1 THEN ! IF RADAR HAS A BACK-TO-BACK ANTENNA,
    ! NEXT DATA LINE CONTAINS 2ND ANTENNA
    ! FRAMEETERS
    Q=2
1290 GOTO 1270
1300
1310 END IF
1320 Q=1
1330 NEXT R

```

```

1340 FOR I=1 TO Njm ! READ JAMMER PARAMETERS
1350   READ Jmbdw(I),Jmfrq(I),Jmerp(I)
1360 NEXT I
1370 FOR I=1 TO Nactyp ! READ RADAR CROSS SECTION DATA
1380   J=0
1390 Nextrcs:!
1400   J=J+1
1410   READ Alpha(I,J),Rcs(I,J)
1420   IF (Alpha(I,J)<>9999) THEN    GOTO Nextrcs
1430 Ndeg(I)=J-1
1440 NEXT I
1450 !
1460 FOR A=1 TO Nac ! READ ACFT TYPE AND INITIAL POSITION AND VELOCITY
1470   READ Actype(A),Aclat(A),Aclong(A),Acalt(A),Acchg(A),Acvel(A)
1480 NEXT A
1490 FOR A=1 TO Nac ! READ AIRCRAFT FLIGHT PROFILE DATA
1500   St1p_flag(A)=0
1510   Follow(A)=0
1520 Crrnd(A)=1
1530 Tt=0
1540 Nexttime:!
1550   Tt=Tt+1
1560   READ Cloct(A,Tt)
1570   IF Cloct(A,Tt)<>9999 THEN
1580     READ Change(A,Tt),Acc(A,Tt),Acy(A,Tt)
1590     GOTO Nexttime
1600   END IF
1610 NEXT A
1620 Minscan=100
1630

```

```

1640 ! MATCHES GENERAL TYPE PARAMETERS TO EACH RADAR
1650 !
1660 FOR P=1 TO Nrd ! DETERMINES INITIAL ANTENNA POSIT
1670   Rdsen(R)=Rdsctyp(Rdtyp(R))
1680   Rdbtb(R)=Rdbtbtyp(Rdtyp(R))
1690   IF Rdbtb(R) THEN Rdant(R,2)=180
1700   Rmax(R)=Rmaxtyp(Rdtyp(R))
1710   Rdfrq(R)=Rdfrqtyp(Rdtyp(R))
1720   Rdfn(R)=Rdfntyp(Rdtyp(R))
1730   Rdnbw(R)=Rdnbwtyp(Rdtyp(R))
1740   Loss(R)=Lossotyp(Rdtyp(R))
1750   Rvzero(R)=Rvzerotyp(Rdtyp(R))
1760   Q=1
1770   Rderp(R,Q)=Rderptyp(Rdtyp(R),Q)
1780   Ragan(F,Q)=Ragantyp(Rdtyp(R),Q)
1790   Rdazbw(F,Q)=Rdazbwtyp(Rdtyp(R),Q)
1800   Rdazs1(R,Q)=Rdazs1typ(Rdtyp(R),Q)
1810   Rdelbw(R,Q)=Rdelbwtyp(Rdtyp(R),Q)
1820   Cscsq(R,Q)=Cscsqtyp(Rdtyp(R),Q)
1830   Dtype(R,Q)=Dtyp(Rdtyp(R),Q)
1840   IF Q=1 AND Rdbtb(R)=1 THEN
1850     Q=2
1860   GOTO 1770
1870 END IF
1880 !

```

1980 | DETERMINE MIN ANTENNA SCANNING TIME OVER ALL RADARS
1990 | IF Rdbtb(R) < ! THEN
1900 | Temp1=Rdsctr(R)+.5
1910 | Temp1=Rdsctr(R)+.5
1920 ELSE
1930 | Temp1=Rdsctr(R)
1940 END IF
1950 Minscan=MIN(Minscan,Temp1)
1960 NEXT R
1970 IF Dt Minscan THEN Dt=Minscan | SET TIME INCREMENT TO MIN SCAN TIME
1980 | IF LESS THAN INITIALLY DEFINED
1990 |

```

2000 !
2010 ! INITIALIZE RADAR AND JAMMER PROGRAM CONSTANTS
2020 !
2030 FOR R=1 TO Nrd
2040 IF Rdbtb(R) THEN
2050   Q=2
2060 ELSE
2070   Q=1
2080 END IF
2090 FOR Qq=1 TO Q
2100   Rdart(R)=SQR(Pdalt(R))
2110   Deg_scanned(R)=360.*Dt/Rdsdn(R)
2120   Temp1=ABS(Rdgan(R,Qq))-ABS(Loss(R))
2130   Temp2=10.*Temp1/10.
2140   Temp3=(C^2)/(4.*PI*Rdfrq(R)^2)
2150   Temp4=10.*Rderp(R,Qq)/10
2160   Rdeqn(R,Qq)=Temp2*Temp3*Temp4*2.9155E-7
2170   FOR J=1 TO Njm
2180     Jampur(R,Qq,J)=(Jmerp(J)*Rdnbw(R)*Temp2*Temp3)/(Jmbdw(J)*2)
2190     Temp5=Jmbdw(J)*.5
2200     IF Qq=1 AND ABS(Rdfrq(R)-Jmfrq(J)) Temp5 THEN Nojam(R,J)=1
2210     NEXT J
2220     NEXT Qq
2230     NEXT R
2240   RETURN
2250   !
2260   !

```

```

2270 ! - - * * OUTPUT CHOICE AND SETUP ROUTINE * * * -
2280 Setup :-
2290   PRINTER IS CRT
2300   PRINT PAGE
2310   PRINT TABXY(5,5),Ds_name$;" DATASET LOAD COMPLETE"
2220   PRINT TABXY(5,7);"SELECT OUTPUT MODE"
2330   PRINT TABXY(10,9),"[1] DATA"
2340   PRINT TABXY(10,10),"[2] X-Y PLOT"
2350   PRINT TABXY(10,11),"[3] PROB OF DETECTION PLOT"
2360   PRINT TABXY(10,12),"[4] FIRST-DETECTION STATS"
2370   PRINT TABXY(5,13);"USE RETURN KEY"
2380 Setup1:-
2390   ENTER KBD:Output_choice
2400   IF Output_choice=1 AND Output_choice<>3 AND Output_choice<>0
        output_choice>4 THEN
2410   BEEP
2420   DISP
2430   GOTO Setup1
2440   END IF
2450   IF Output_choice=2 OR Output_choice=3 THEN
2460     PRINT TABXY(5,15);"FOR GRAPHICS, ENTER RADAR OF INTEREST"
2470 Setup2:-
2480   ENTER KBD:Rdr_choice
2490   IF Rdr_choice Nrd THEN
2500   BEEP
2510   DISP
2520   GOTO Setup2
2530   END IF
2540   PRINT Rdr_choice
2550   END IF

```

```

2560 PRINT TAB(5,18), "ENTER OUTPUT START TIME: ";
2570 ENTER FBD,Output_start
2580 PRINT Output_start
2590 WAIT 1.5
2600 PRINT PAGE
2610 |
2620 | PPINT OUTPUT HEADINGS
2630 |
2640 IF Output_choice=1 OR Output_choice=4 THEN
2650   ON KEY 0 LABEL "0) PRINT" GOTO Printit
2660   ON KEY 7 LABEL "7) CRT" GOTO Crtit
2670 WAIT
2680 Printit
2690   PRINTER IS 401
2700   Printno=401
2710 END IF
2720 Crtit OFF KEY
2730 IF Output_choice=1 THEN
2740   PPINT "FASTE DATA OUTPUT"; SPA(10), "DATASET: ", Us_name$|
2750   OFF FBD
2760   PRINT
2770 END IF
2780 IF Output_choice=4 THEN
2790   PRINT "FASTE STATISTICS OUTPUT"; TAB(39), "DATASET: ", Us_name$|
2800   PRINT "START TIME: ", Output_start
2810 ELSE "WORD MSG"
2820 END IF
2830 RETURN
2840

```

```

2850 ! - = * * * UPDATES AIRCRAFT POSITION, VELOCITY, AND JAMMER PARAMETERS * * * =
2860
2870 Updac1
2880
2890 Updac1 ! UPDATE ACFT POSITS AND PASS DATA TO BUFFER ARRAY
2900 A=A+1
2910 Buffer(A,1)=T
2920 IF Acvel(A)=0 THEN
2930   IF A=Nac THEN RETURN
2940   GOTO Updac1
2950 END IF
2960 Temp=Dt*Acvel(A)/3600
2970 Temp1=Acndg(A)*P1d180
2980 Aclat(A)=Aclat(A)+Temp*COS(Temp1)
2990 Aclong(A)=Aclong(A)+Temp*SIN(Temp1)
3000 Buffer(A,2)=Aclat(A)
3010 Buffer(A,3)=Aclong(A)
3020 Buffer(A,4)=Acclt(A)
3030 Buffer(A,5)=Accdg(A)
3040 Buffer(A,6)=Acvel(A)
3050 Updac2 ! CHECK FLAG VARIABLES TO SEE IF ACFT IS IN A MANEUVER
3060 IF Accel(A) THEN GOSEE Accel
3070 Buffer(A,E)=Accel(A)
3080 IF Climb(A) THEN GOSEE Climb
3090 Buffer(A,4)=Acclt(A)
3100 IF Turn(A) THEN GOSEE Turn
3110 Buffer(A,S)=Accdg(A)
3120 IF Horiz(A) THEN GOSEE Horiz
3130 Tr=Cmd(A)

```

```

3140 IF Cloct(A,Tc) T THEN ! TIME FOR NEXT MANEUVER?
3150   ON Change(A,Tc) GOSUB One,Two,Three,Four,Five,Six,Seven
3160   Cmd(A)=Cmd(A)+1 ! UPDATE COMMAND LINE POINTER
3170 END IF
3180 IF A>Nac THEN GOTO Updat1
3190 FOP A=1 TO Nac
3200 IF Follow(A) THEN
3210   AcLat(A)=AcLat(Follow(A))
3220   AcLong(A)=AcLong(Follow(A))
3230   AcVel(A)=AcVel(Follow(A))
3240   Achdg(A)=Achdg(Follow(A))
3250   AcAlt(A)=AcAlt(Follow(A))
3260   Buffr(A,2)=AcLat(A)
3270   Buffr(A,3)=AcLong(A)
3280   Buffr(A,4)=AcAlt(A)
3290   Buffr(A,5)=Achdg(A)
3300   Buffr(A,6)=AcVel(A)
3310 END IF
3320 NEXT A
3330 RETURN
3340

```

```

3350 One   ! TURN JAMMER ON
3360 Jamacc(Ac,(A,Tc),A)=1
3370 RETURN
3380 Two   ! TURN JAMMER OFF
3390 Jamacc(Ac,(A,Tc),A)=0
3400 RETURN
3410 Three  ! START ACCELERATION
3420 Acc(A)=1 ! FLAG ON
3430 Follow(A)=Ø
3440 Taccl(A)=ABS((Acy(A,Tc)-Accel(A))/Acc(A,Tc)) ! ACCEL TIME
3450 Accacc(A)=Sgn(Acy(A,Tc)-Accel(A))*ABS(Fcs(A,Tc)) ! ACCEL RATE
3460 RETURN
3470 Four   ! START CLIMB
3480 Climb(A)=1 ! FLAG ON
3490 Follow(A)=Ø
3500 Tcimb(A)=ABS((Acy(A,Tc)-Accalt(A))/Acc(A,Tc)) ! CLIMB TIME
3510 Accimb(A)=Sgn(Acy(A,Tc)-Accalt(A))*ABS(Fc(A,Tc)) ! CLIMB RATE
3520 RETURN
3530 Five   ! START TURN
3540 Turn(A)=1 ! FLAG ON
3550 Hhom(A)=0 ! TERMINATE ANY ACTIVE HOMING MANEUVER
3560 Follow(A)=Ø
3570 Temp=Acc(A,Tc)-Acchdg(A) ! DEGREES OF TURN
3580 Acturn(A)=rc*(A,Tc) ! TURN RATE
3590 IF 'Temp' < 0 AND (acturn(A)<0) THEN Temp=360-Temp
3600 IF 'Temp' > 0 AND (acturn(A)>0) THEN Temp=360+Temp
3610 IF 'Temp' = 0 AND (acturn(A)=0) THEN Temp=-Temp
3620 Turn(A)=Acc(Temp/Acc(A,Tc)) ! TIME FOR TURN
3630 RETURN

```

```

3640 S1. ! START HOMING
      Hhom(A)=1 ! FLAG ON
      Turn(A)=0 ! TERMINATE ANY ACTIVE TURN
3650
3660
3670 Follow(A)=Ø
      ! DEFINE HOMING TGT PARAMETERS
3680
3690 Rang=Acy(A,Tc)
      Hdlat(A)=Rdlat(Rdno)
      Hdlong(A)=Rdlong(Rdno)
      !
3700
3710
3720
3730 Acturn(A)=Accx(A,Tc) ! TURN RATE
3740 RETURN
3750 Seven !
3760 Follow(A)=Accx(A,Tc)
      Accx(A)=0
      Climb(A)=0
      Turn(A)=0
      Home(A)=0
      !
3770
3780
3790
3800
3810 RETURN
3820 Accell !
3830   IF Tacc1(A)=Dt THEN
      Accel(A)=Accel(A)+Accel(A)*Dt ! UPDATE SPEED
      Tacc1(A)=Tacc1(A)-Dt ! UPDATE ACCEL TIME REMAINING
3840
3850
3860 ELSE
      Accel(A)=Ø ! FL66 OFF
      Accel(A)=Accel(A)+Accel(A)*Tacc1(A) ! UPDATE VELOCITY
3870
3880 END IF
3890   IF novel(A)=10 THEN novel(A)=Ø ! CLAMP SLOW MOTORS TO ZERO
3900
3910 RETURN

```

```

2920 Climb !
2930   IF Tclimb(A) > 0 THEN
2940     Acalt(A)=Acalt(A)+Acclmb(A)*Dt  ! UPDATE ALTITUDE
2950     Tclimb(A)=Tclimb(A)-Dt  ! CLIMB TIME REMAINING
2960   ELSE
2970     Climb(A)=0  ! FLAG OFF
2980     Acalt(A)=Acalt(A)+Acclmb(A)*Tclimb(A)  ! UPDATE ALTITUDE
2990   END IF
3000 RETURN
3010 Turn !
3020   IF Tturn(A).Dt THEN
3030     Achdg(A)=Achdg(A)+Acturn(A)*Dt  ! UPDATE HEADING
3040     Tturn(A)=Tturn(A)-Dt  ! TURN TIME REMAINING
3050   ELSE
3060     Turn(A)=0  ! FLAG OFF
3070     Achdg(A)=Achdg(A)+Acturn(A)*Tturn(A)  ! UPDATE HEADING
3080   END IF
3090   IF Achdg(A) > 360 THEN Achdg(A)=Achdg(A)+360
3100   IF Achdg(A) < -360 THEN Achdg(A)=Achdg(A)-360
3110 RETURN

```

```

4120 Home   ! COMPUTE HEADING TO HOMING TGT
4130   Dlat=Hdlat(A)-AcLat(A)
4140   Dlong=Hdlong(A)-AcLong(A)
4150   IF SQR(Dlat^2+Dlong^2)<Acvel(A)*Dt/3600 THEN
4160     Acvel(A)=0
4170   RETURN
4180
4190 END IF
4200   IF Dlat=0 AND Dlong<0 THEN Head=90
4210   IF Dlat=0 AND Dlong>=0 THEN Head=270
4220   IF Dlat <0 THEN Head=ATN(ABS(Dlong/Dlat))*180/p1
4230   IF Dlat >0 AND Dlong =0 THEN Head=360-Head
4240   IF Dlat <0 AND Dlong <0 THEN Head=180+Head
4250   IF Dlat <0 AND Dlong>0 THEN Head=180-Head
4260   Temp=Achdg(A)-Head
4270   ! DEFINE TURN RATE I.E. DIRECTION OF TURN
4280   Acturn(A)=ABS(Acturn(A))
4290   IF Temp>0 AND Temp<180 THEN Acturn(A)=-Acturn(A)
4300   IF Temp >180 THEN Acturn(A)=-Acturn(A)
4310   IF Temp <180 THEN Temp=360-Temp
4320   IF Temp >180 THEN Temp=360+Temp
4330   Turn(A)=ABS(Temp/Acturn(A)) ! TIME FOR TURN
4340   ISSUE Turn
4350 RETURN
4360   !
4370   !

```

```

4380
4390      ===== UPDATE RADAR ANTENNA POSITION, DETERMINE IF AIRCRAFT HAS * * *
4400      - * * * BEEN SCANNED, AND DETERMINE PROBABILITY OF DETECTION. * * *
4410 Updrd1 I
4420      I=0
4430 Updrd1 I
4440      I=I+1
4450      IF I > Nrd GR I Rdr_choice THEN RETURN
4460      IF Output_choice=2 OR Output_choice=3 THEN
4470      I=Rdr_choice
4480      Dt=Rdsrn(I)
4490      IF Rdbrb(I) THEN Dt=Dt/2
        Beg_scanned(I)=360.*Dt/Rdsrn(I)
4510      END IF
4520      n=0
4530 Updrd2 I
4540
4550      A=A+1
4560      IF A Nac THEN GOTO Updrd3
        Scanned(n,I)=0
4580      IF Acvel(n)=0 THEN GOTO Updrd2
4590      Dn=Action(A,-Pdlong,I)
4600      IF Dn=C THEN Dn=.0001
        Ifc=ncat(A,-Pdlat,I)
4620      If Df=C THEN Df=.0001
        Temp=(Dn2+Df2)
4630      Dn=ncat(A,-Pdlat,I)/sqrt(Temp)
4640      If Dn=C THEN Dn=.001
4650      Temp=Dn2
4660      If (n=Temp+Temp) + STANT RADAR SQUARED
4670      If A=SQR(Rr(A)) + STANT RANGE
4680

```

```

4690      D,v=SOF,Temp )
4700      Xr=U,
4710      YY=Dy
4720      GOSUB Atan2
4730      Phi(A)=Atng*D180P1
4740      IF Phi(A)<Q THEN Phi(A)=Phi(A)+360
4750      Q=1
4760      GOSUB Irep   ! RETURNS ALoss
4770      Irep_Loss(A,1)=ALoss  ! ONE WAY TRANSMISSION LOSS
4780      IF Rdbtb(I) THEN
4790          Q=2
4800      GOSUB Irep
4810      Irep_Loss(A,2)=ALoss
4820      END IF
4830      Q=1
4840      6010 Updrd2
4850      Updrd2 !
4860      Cross=0
4870      Rdant(I,Q)=Rdant(I,Q)+Deg_scanned(I) ! NEW ANTENNA POSIT
4880      IF Rdant(I,Q)=360 THEN Cross=1
4890      IF Rdant(I,Q)=360 THEN Rdant(I,Q)=Rdant(I,Q)-360
4900      Temp2=Rdant(I,0)-Deg_scanned(I) ! OLD ANTENNA POSIT
4910

```

```

4920      !***CHECK TARGETS FOR POSSIBLE DETECTION***  

4930  

4940      H=0  

4950      Updrd4 :  

4960      H=H+1  

        IF A NaC THEN  

        IF Rdbtb(I) AND Q=1 THEN  

          Q=2  

          GOTO Updrd3  

        ELSE  

          GOTO Updrd1  

        END IF  

      END IF  

5040      IF Acvel(A)=Q OF R(A).Rma,(I) THEN GOTO Updrd4  

5050      IF Cross THEN ! WAS THE AIRCRAFT SCANNED?  

5060      IF Phi(A)=Rdant(I,Q) AND Phi(A).Temp2+360 THEN Updrd4  

5070      ELSE  

5080      IF Phi(A)=Rdant(I,Q) OR Phi(A).Temp2 THEN Updrd4  

5090      END IF  

5100      Scanned(A,I)=1  

5110      !  

5120      !  

5130      !***CALCULATE JAMMING POWER***  

5140      ! SUMS FWF INTO RADAR FROM ALL APPLICABLE JAMMERS  

5150      Tot_noise=1.38E-23*290*10*(Rdfn(I)/10*Fdnbw(I)*1E6  

5160      J=0  

5170      Updrd5 :  

5180      J=J+1  

5190      IF J !Jm THEN GOTO Updrd7  

5200      If Ncian(I,J) THEN GOTO Updrd5  

5210      I=0

```

```

5220 Updrd6 !
5230 L=L+1
5240 IF L = Nac THEN GOTO Updrd5
5250 IF Jamaz(J,L)=0 OR Acvel(L)=0 THEN GOTO Updrd6
5260 Delphi=Phi(L)-Phi(A) ! ANGLE BETWEEN JAMMER AND TGT ACFT
5270 IF Delphi == 180 THEN Delphi=Delphi+360
5280 IF Delphi == 180 THEN Delphi=Delphi-360
5290 GOSUE Antpat ! RETURNS SLD: SIDELOBE LOSS DUE TO DELPHI
5300 Temp=-ABS(Sdl)-Irrep_loss(L,Q)
5310 Temp1=10.*((Temp/10.)
5320 Tot_noise=Tot_noise+(Jampwr(1,Q,J)*Temp1) ! SUMS FOR TOTAL JAMMING P
      WR
5330 GOTO Updrd6
5340 !
5350 !**** CALCULATE RADAR CROSS SECTION ****
5360 !
5370 Updrd7 !
5380 M=factype(A)
5390 Aspect=180+Phi(A)-Achdg(A)
5400 IF Aspect == 360 THEN Aspect=Aspect-360
5410 IF Aspect == 0 THEN Aspect=Aspect+360
5420 GOSUE Trpolt
5430 Sigma=10.* (Sigdb/10.)
5440 !

```

```

5450 !••••• CALCULATE PROBABILITY OF DETECTION•••••
5460
5470   Signal=10*LET(Rdreqn(I,Q)*Sigma)-2*Irep_loss(A,0)
5480   Tot_noise=10*LET(Tot_noise)
5490   Se=Signal-Tot_noise-Rvzero(I) ! SIGNAL EXCESS
      IF Se < -9 THEN Pd=0
      IF Se > 9 THEN Pd=1
      IF Se < -9 AND Se > 9 THEN Pd=(1+SIN(Se*PI/18))/2
      Buffer(A,I+6)=Pd
      GOTO Updrd4
      !
5550 Output !
5560 IF Output_start T THEN RETURN
5570 Nrdp6=Nrd+6
5580 SELECT Output_choice
5590
5600
5610 CASE 1 ! DATA OUTPUT
      IF Nrd 4 THEN
        DISP "OUTPUT FORMAT CAN HANDLE ONLY 4 OR FEWER RADARS."
      WAIT 1.5
      GO TO Setup
      END IF
      ! HEADSEP AND FORMAT
      PF INT "ACFT TIME" DX
      PF Y ALT HEAD SPEED "
      FOR P=1 TO Nrd
        PRINT "RADAR" R.
      IF P=Nrd THEN PRINT
      NEXT P

```

```

5730 PRINT    ! PRINTING ROUTINE
5740 FOR A=1 TO Nac
5750 IF Acvel(A) > 0 THEN
5760   PRINT USING "3D.#";A
5770   FOR J=1 TO 6
5780     PRINT USING "5D.0#";Buffr(A,J)
5790   Old_buffr(A,J)=Buffr(A,J)
5800
5810 NEXT J
5820 FOR J=1 TO Nrd
5830 IF NOT Scanned(A,J) THEN
5840   PRINT "*****";
5850 ELSE
5860   PRINT USING "2D.4D#";Buffr(A,J+6)
5870 END IF
5880 NEXT J
5890 PRINT
5900 END IF
5910 NEXT A
5920 PRINT
5930 CASE 2 : GRAPHICS OUTPUT
5940 Graphics_flag=1 ! FIRST TIME THEU ROUTINE
5950 If Graphics_flag=1 Then picstart
5960 CHITI
5970 Rledges !
5980 Graphics_flag=1 ! FIRST TIME THEU ROUTINE
5990 CHITI PAGE
5990 PRINT TAB(1,1,5);"INPUT SCREEN BODEES" ; USEF FORMAT INPUT
6000 PRINT "LEFT ";
6010 PRINT "+";
6020 PAPER +PDLleft_edge
6030 DISP

```

```

6040 PRINT Left_edge
6050 PRINT "RIGHT"
6060 ENTER KBD,Right_edge
6070 DISP
6080 PRINT Right_edge
6090 IF Right_edge = Left_edge THEN
6100   DISP "RIGHT EDGE LESS THEN LEFT EDGE. TRY AGAIN."
6110   WAIT 2
6120   GOTO Rledges
6130 END IF
6140 Tledges:
6150   PRINT TAB(Y(1,S)),"BOTTOM"
6160   ENTER FBD,Bottom_edge
6170 DISP
6180   PRINT Bottom_edge
6190   PRINT "TOP"
6200   ENTER KBD,Top_edge
6210 DISP
6220 PRINT Top_edge
6230 IF Top_edge = Bottom_edge THEN
6240   DISP "TOP EDGE IS LESS THAN BOTTOM EDGE. TRY AGAIN."
6250   WAIT 2
6260   DISP
6270   PRINT TAB(Y(1,S)),""
6280   GOTO Tledges
6290
6300 END IF
6310 PRINT "DECAYED ? Y OR N"
6320 ENTER FBD,Tics4
6330 PRINT PAGE
6340

```

```

5350 PEN 2 ! RED
5360 Dw=Top_edge-Bottom_edge
5370 WINDOW 1.5*Left_edge,1.2*Right_edge,Bottom_edge-.1*Dw,Top_edge+.1*Dw
5380 CLIP Left_edge,Right_edge,Bottom_edge,Top_edge
5390 IF Tics$[1] = "N" THEN
      LGRID 5,5
    ELSE
      LAXES 5,5,Left_edge,Bottom_edge,2,2,1
    END IF
5400 PEN 6 ! BLUE
5410 FOR R=1 TO Nrd ! LABEL RADAR LOCATIONS
      PLOT RdLong(R),RdLat(R),-2
      LABEL CHR$(8);"(@"
      NEXT R
5430 PEN 2 ! RED
5440 PLOT Left_edge,Top_edge,-2 ! LABEL PLOT
5450 LABEL "DATASET :Us_name$"
5460 PLOT (Left_edge+Right_edge)/2,Top_edge,-2
5470 LABEL "RADAR OF INTEREST :";Rdr_choice
5480 GRAPHICS ON

```

```

E550 Picstart !  

F560 FOF A=1 TO Nac  

6570 IF Acvel(A) > 0 THEN ! PLOT MOVING AIRCRAFT ONLY  

6580 IF Ship_flag(A)=0 THEN Strip  

6590 IF Old_buffer(A,Rdr_choice+6)=.5 THEN  

6600 IF Buffer(A,Rdr_choice+6)=.5 THEN  

6610 LINE TYPE 1 ! SOLID LINE IF DET PROB .5  

6620 PEN 1 ! COLOR WHITE  

END IF  

6630 ELSE  

6640 LINE TYPE 2 ! DOTTED  

6650 PEN 5 ! BLUE  

END IF  

6660 Jar_flag=0  

6670 FOR J=1 TO Num  

6680 IF Jamac(J,A) AND NOT Nojam(Pdr_choice,J) THEN Jar_flag=1  

6690 NEXT J  

6700 IF Jar_flag THEN  

6710 PEN 4 ! GREEN FOR AIRCRAFT WITH ACTIVE JAMMERS  

6720 END IF  

6730 PLOT Old_buffer(A,2),Old_buffer(A,2),-2 ! MOVE PEN TO LAST POSIT  

6740 PLOT Buffer(A,2),Buffer(A,2),-1 ! DRAW LINE TO NEW POSIT  

6750 IF Last1="R" THEN  

6760 If Buffer(1,2) MOD 60 LT THEN ! PLOT 1 MINUTE TICS  

6770 If Buffer(2,2) LT Left_edge AND Buffer(2,2) Right_edge THEN  

6780 If Buffer(1,2) Bottom_edge AND Buffer(2,2) Top_edge THEN  

6790 PLOT Buffer(A,2),Buffer(A,2),-2  

6800 LINE TYPE 1  

6810 LABEL Init(Buffer(A,1),E0)  

6820 END IF  

6830 END IF  

6840 END IF  

6850 END IF  

6860 END IF  

6870 END IF

```

```

5380 51P! !      Start_flag(A)=1
6990      Old_buffr(A,2)=Buffr(A,2)
6900      Old_buffr(A,3)=Buffr(A,3)
6910      Old_buffr(A,Rdr_choice+6)=Buffr(A,3)
6920      IF Buffr(A,Rdr_choice+6) .NE. THEN
6930          Old_buffr(A,Rdr_choice+6)=Buffr(A,Rdr_choice+6)
6940      END IF
6950      END IF
6960      NEXT A
6970      FOR R=1 TO Nrd ! RELABLES RADARS
6980          PEN 6 ! BLUE
6990          PLCT Rdlatong(R),Rdlat(R),-2
7000          LABEL CHR$(8); "Q"
7010      NEXT R
7020      !
7030      CASE 3 ! PROBE DETECTION PLOT
7040      IF Graphics_flag THEN Plotstart
7050      GINIT
7060      Graphics_flag=1
7070      PEN 2
7080      WINDOW 1.1*Output_start-.1*Tfin,Tfin,-.25*Nac,Nac+.2
7090      CLIP Output_start,Tfin,0,Nac+6fac
7100      LAYES 10,1,Output_start,0,E,1
7110      LINE TYPE 2
7120      FOR A=1 TO Nac
7130          PLCT Output_start,A,-2
7140          PLCT Tfin,A,-1
7150      NEXT A

```

```

?160 LINE TYPE 1 ! SOLID
?170 PLOT Output_start,Nac+1,-2
?180 LABEL "DATASET: ",Ds_name$
?190 PLOT (Output_start+fin)/2,Nac+1,-2
?200 LABEL "FADAR OF INTEREST: ",Rdr_choice
?210 GRAPHICS ON
?220 PEN 1
?230 Plotstart:=
?240 FOR A=1 TO Nac
?250 IF Acvel(A) > 0 THEN !PLOT ONLY MOVING TITS
?260 IF Ship_flag(A) THEN
?270 PLOT Tlast,Old_buftr(A,Rdr_choice+6)*Gfac+A-Gfac/2,-2
?280 PLOT T,Euttr(A,Rdr_choice+5)*Gfac+A-Gfac/2,-1
?290 END IF
?300 Ship_flag(A)=1
?310 Old_buftr(A,Rdr_choice+5)=Buftr(A,Rdr_choice+6)
?320 END IF
?330 NEXT A
?340 Tlast=T
?350

```

```

    CASE 4 ! STATISTICS ROUTINE
    Tsim=50 ! NUMBER OF SIMULATIONS
    Rule=2 ! OPERATOR FACTOR DETECTION FACTOR
    FOR A=1 TO Nac
        FOR R=1 TO Nrd
            Nrdp5=R+6
            IF Scanned(A,R) THEN
                FOR S=1 TO Tsim
                    IF Sim_rng(A,R,S)=0 THEN ! Sim_rng IS COUNTING RADAR HITS
                        ! USE OPERATOR EFFICIENCY = .7*(Pd) FOR 1st HIT
                    IF Sim_rng(A,R,S)=0 THEN
                        Chance=.7*Buffr(A,Nrdp5)
                    ELSE
                        Chance=Buffr(A,Nrdp5)
                    END IF
                    IF Chance=RND THEN ! CONSECUTIVE RADAR HIT?
                        Sim_rng(A,R,S)=Sim_rng(A,R,S)-1 ! INCREMENT COUNTER
                    ELSE
                        Sim_rng(A,R,S)=0 ! RE-INITI CONSECUTIVE HIT COUNTER
                    END IF
                IF Sim_rng(A,R,S)=Rule THEN ! DETECTION RULE MET?
                    Temp=(Buffr(A,2)-PdInt(R))**2+(Buffr(A,3)-RdInt(R))**2
                    Sim_rng(A,R,S)=Temp ! STORES DETECTION RANGE
                END IF
            END IF
            Nrdp5=R+6
            END IF
        END FOR
        Rule=2
        FOR S=1 TO Tsim
            IF Sim_rng(A,R,S)=Rule THEN ! DETECTION RULE MET?
                Temp=(Buffr(A,2)-PdInt(R))**2+(Buffr(A,3)-RdInt(R))**2
                Sim_rng(A,R,S)=Temp ! STORES DETECTION RANGE
            END IF
        END FOR
        Rule=2
    END FOR
    RETURN

```

```

7680 '
7690 Output_stats !
7700 FOR A=1 TO Nac
7710 DISP "SORTING"
7720 FOR R=1 TO Nrd ! BUBBLE SORT OF SIMULATION DETECTION RANGES
7730 REPEAT
7740 Sorted=1
7750 FOR S=1 TO Tsim-1
    IF Sim_rng(A,R,S) < Sim_rng(A,R,S+1) THEN
        Sorted=0
7760     Dummy=Sim_rng(A,R,S)
    Sim_rng(A,R,S)=Sim_rng(A,R,S+1)
    Sim_rng(A,R,S+1)=Dummy
    END IF
7770     NEXT S
7780 UNTIL Sorted
7790
7800 '
7810
7820 '
7830
7840 '
7850 COMPUTE STATISTICS
7860 FP_HIT
7870 PRINT
7880 PRINT "AIRCRAFT ",A," DETECTION RANGE STATISTICS"
7890 PRINT "RADAR MEAN STD DEV .25 QNT .50 QNT .75 QNT"
    PCY DET"
7900 FOR F=1 TO Nrd
7910 PRINT F,
7920 Start=1

```

```

7930 Start1 ! DETERMINE INDEX FOR FIRST NON-ZERO DETECTION RANGE
7940 IF Start = Tsim THEN
7950   IF Sim_rng(A,F,Start) = 0 THEN
7960     Start=Start+1
7970     GOTO Start1
7980   END IF
7990 END IF
8000
8010
8020 IF Start=Tsim+1 THEN ! TARGET NOT DETECTED IN ANY OF SIMULATIONS
8030   PRINT " NOT DET NOT DET NOT DET NOT DET"
8040 ELSE ! TARGET DETECTED AT LEAST ONE TIME
8050   Mean=ct dev=0
8060
8070   FOR S=Start TO Tsim
8080     Mean=Mean+Sim_rng(A,R,S)
8090   NEXT S
8100   Mean=Mean/(Tsim-Start+1)
8110
8120   FOR S=Start TO Tsim
8130     Stdev=Stdev+(Sim_rng(A,R,S)-Mean)^2
8140   NEXT S
8150   IF Tsim < Start THEN
8160     Stdev=Sqr(Stdev/(Tsim-Start))
8170   ELSE
8180     Stdev=0
8190   END IF
8200

```

```

8210   ! DETERMINE QUANTILES
8220   Dummy=(Tsim-Start+1)/4
8230   IF Dummy MOD 1=0 THEN
8240     Qt25=S1m_rng(A,R,Start+Dummy-1)+S1m_rng(A,R,Start+Dummy)/2
8250   ELSE
8260     Qt25=S1m_rng(A,R,Start+Dummy)+S1m_rng(A,R,Start+Dummy)/2
8270   END IF
8280   Dummy=Dummy+Dummy
8290   IF Dummy MOD 1=0 THEN
8300     Qt50=S1m_rng(A,R,Start+Dummy-1)+S1m_rng(A,R,Start+Dummy)/2
8310   ELSE
8320     Qt50=Qt50+INT(Dummy)
8330   END IF
8340   Dummy=Dummy*2/2
8350   IF Dummy MOD 1=0 THEN
8360     Qt75=S1m_rng(A,R,Start+Dummy-1)+S1m_rng(A,R,Start+Dummy)/2
8370   ELSE
8380     Qt75=S1m_rng(A,R,Start+INT(Dummy))
8390   END IF
8400   F=tdate=(Tsim-Start+1)/150
8410   P420  PRINT "P420"
8420   P430  PRINT "P430"
8430   P440  PRINT "P440"
8440   P450  PRINT "P450"
8450   P460  PRINT "P460"
8460   P470  PRINT "P470"
8470   P480  PRINT "P480"

```

```

8480      IF M=Nac THEN Flip
8490      IF Printne >401 THEN
8500          DISP "DEPRESS CONT"
8510          PAUSE
8520          DISP
8530          END IF
8540          Flip NEXT A
8550          RETURN
8560
8570  Trpolt1 USES ASPECT TO SOLVE RADAR Y-SECTION! BY INTERPOLATION
8580          OUTPUT Sigdb
8590          IF Value Index(M,1) THEN GOTO Trpolt2
8600          . . .
8610          E1=Index(M,1)
8620          E2=0
8630          Trpolt1
8640          I1=I1+1
8650          IF I1 >deg(M) THEN GOTO Trpolt3
8660          E2=Alpha(M,I1)
8670          IF Aspect =E2 THEN E1=E2
8680          IF Aspect <E2 THEN GOTO Trpolt1
8690          Diff=Aspect-E1
8700          Outdb=Pic(M,I1-1)+Diff*(Pic(M,I1)-Pic(M,I1-1))/Diff(E2-E1)
8710          RETURN
8720          Trpolt1
8730          Next =Aspect +250
8740          Trpolt1
8750          Outf=Aspect-Arcsin(M,Alpha(M))
8760          Sigdb=Arcsin(M,Neg(M)+Diff*Arcsin(M,1)-Arcsin(M,Alpha(M,1)+360
-4*Lane(M,Alpha(M,1)))
8770          RETURN

```

```

5760
5790 Antpat : RETURNS JAMMING ATTENUATION DUE TO AZIMUTH SEPARATION
8200 Limit=-40
8810 Zero=0
8820 Xlob8=8.5
8830 Sdi=P1*d2=PI/2.
8840 JJ=Dtype(1,0)
8850 Conv=(3db(JJ)/(Rdazbw(1,0)*0.5))
8860 Adel=AESiDelphi*Conv
8870 IF Adel=Zero THEN
8880   Sdi=Zero
8890   RETURN
8900 END IF
8910 IF Adel >0*Conv THEN
8920   Sdi=Farlob(JJ)
8930   RETURN
8940 END IF
8950 IF JJ=1 THEN
8960   IF Rdazbw(1,0)=2 AND Adel < Xlob8*PI THEN
8970     Sdi=Farlob(JJ)
8980   RETURN
8990 END IF
9000 Temp=SIN(Adel)/Adel )^2
9010 IF Temp =1E-4 THEN
9020   Adel=Limit
9030   RETURN
9040 END IF
9050 Temp=-10.*LST(Pival(J))/Temp
9060 If Adel =(Zero(JJ)*PI) THEN
9070   Sdi=Temp
9080   RETURN

```

```

9090
9100
9110
9120
9130
END IF
IF Adel > zero2(JJ)*PI THEN Temp1=Temp1-(Fstlob(JJ)-Rdazsi(I, Q))
IF Adel < zero2(JJ)*PI THEN Temp1=Temp1-6
IF Temp1>Limit THEN Temp1=Limit
END IF
9140
IF JJ=2 THEN
 1F Adel \X2(JJ)*P1 THEN
    Sdi=Seclob(JJ)
  RETURN
END IF
9150
IF Adel =x1(JJ)*P1 THEN
  Temp=Coeff(JJ,1)*Adel^2+Coeff(JJ,2)*Adel+Coeff(JJ,3)
ELSE
  IF ABS(Adel-P1d2) = 1E-5 THEN
    Temp=0.25
  ELSE
    Temp=(P1d2*COS(Adel)/(P1d2^2-Adel^2))^.2
  END IF
END IF
9160
9170
9180
9190
9200
9210
9220
9230
9240
9250
9260
9270
9280
9290
9300
9310
9320
9330
9340
9350
9360
9370
END IF
IF JJ=2 THEN
  Sdi=Seclob(JJ)
  RETURN
END IF
Temp1=-10*LGT(Ptval(JJ)/Temp)
END IF
Sdi=Temp1
RETURN

```

```

238C Atang= RETURN( ARC(PARIANS) OF ANGLE SUBTENDED BY X, AT YY
9390          IF X > 0 AND YY < 0 THEN Atng=ATN(X,YY)
9400          IF X < 0 AND YY > 0 THEN Atng=PI+ATN(X,YY)
9410          IF X < 0 AND YY < 0 THEN Atng=2*PI+ATN(X,YY)
9420          IF X > 0 AND YY > 0 THEN Atng=PI+ATN(X,YY)
9430          RETURN
9440
9450
9460 1rep ! RETURNS 1-WAY SIGNAL LOSS BETWEEN RADAR AND TARGET ACFT.
9470          ! ALGORITHMS AND SOURCE CODE DERIVED FROM IREPS REV 2.2,
9480          ! LOSS SUBROUTINE (NOSE, SAN DIEGO, CA.)
9490 Antbwr=1.745E-2*Rdelbw(I,Q)
9500 Anteltr=.01745
9510 Elma=r1.047
9520 IF NOT (scsq(1,0)) THEN
9530     Antfac=1.391577*SIN(Antbwr/2)
9540     Patrfac=-(Elma,r=Anteltr)
9550 ELSE
9560     Elma,r=Anteltr+.75525
9570 END IF
9580 GO305 Surface_init
9590 GO306 Diffraction_const

```

```

9E00 IF R1_m = Dmin THEN
9E10   RANGE IS LESS THAN MINIMUM DIFFRACTION FIELD RANGE
9E20   GO SUB Optical_Limit
9E30   IF R1_m > Omax THEN
9E40     Rng=Dmin
9E50   GO SUB Diffraction
9E60   ! INTERPOLATE BTWN OPMAX AND DMIN TO OBTAIN ALoss
9E70   ALoss=Oloss+(Oloss-Dloss)*(R1_m-Omax)/(Omax-Dmin)
9E80   ELSE
9E90   IF Atheta_2*PI THEN
9E91     ! RANGE IS LESS THAN OPMAX AND GREATER THAN OPEAR
9E92     Then, i=2*PI
9E93     GO SUB P1mda
9E94     ! RETURNS RANGE OF 1ST OPTICAL PEAK
9E95     Opear=Rnext
9E96     Rng=Opear
9E97     IF R1_m > Opear THEN
9E98       GO SUB Oloss
9E99       PIloss=ALoss
9E100      ! INTERPOLATE TO OBTAIN LOSS BTWN OPMAX AND 1ST OPTICAL PEAK
9E101      ALoss=PIloss-(PIloss-PIloss)*(R1_m-Opear)/(Opear-Omax)
9E102      ELSE
9E103        ! LOSS IS IN THE ENVELOPE REGION (R1_m - OPEAR)
9E104        Pi=Pi_m
9E105        GO SUB Theta
9E106        Eng=Pi_m
9E107        Theta=LwCP1
9E108        GO SUB Oloss
9E109      END IF

```

```

ELSE
  ! LOSS IS IN THE ENVELOPE REGION ( RIM .OPEAK )
  9920
  9930
  9940
  9950
  9960
  9970
  9980
  9990
  10000
  10010
  10020
  10030
  10040
  10050
  10060
  10070
  10080
  10090
  10100
  10110
  10120
  10130
  10140
  10150
  10160
  10170

  ! LOSS IS IN THE ENVELOPE REGION ( RIM .OPEAK )
  9910
  9920
  9930
  9940
  9950
  9960
  9970
  9980
  9990
  10000
  10010
  10020
  10030
  10040
  10050
  10060
  10070
  10080
  10090
  10100
  10110
  10120
  10130
  10140
  10150
  10160
  10170

  ! LOSS IS SOLELY DIFFRACTION OF TRAPOSCATTERP
  Rng=RIM
  GOSUB Theta
  Rng=RIM
  Atheta=Twpcl
  GOSUB CP_Loss
  END IF
END IF
ELSE
  ! LOSS IS SOLELY DIFFRACTION OF TRAPOSCATTERP
  Rng=RIM
  GOSUB Diffraction
  GLoss=Diff
END IF
ALoss=ALoss-26.65-2.0*LGT(Pdfrq(I)) ! Remove Antenna Area
RETURN

```

```

10180 TwoPI=2*PI
10190 HalfPI=PI/2
10195 PI4cwl=.04198*Rdfrq(1)-4*PI OVER WAVELENGTH
10200 10200 Horizon=3.572*(SOR(Kfac*Ht)+SOR(Kfac*Hr))
10210 10210 Dmin=Horizon*30.2*(Kfac*Kfac/Rdfrq(1))^(1/3)
10220 10220 Hbfreq=.02094*Rdfrq(1)*5.1E-3*Wind*Wind
10230 10230 Hfo1=Hbfreq*.159155
10240 10240 IF Rdfrq(1) 1500 THEN 10290
10250 10250 Epsilon=80
10260 10260 Sigma=4.3
10270 10270 6010 10350
10280 10280 IF Rdfrq(1) 3000 THEN 10330
10290 10290 Epsilon=80-.000733*(Rdfrq(1)-1500)
10300 10300 Sigma=4.3+.000148*(Rdfrq(1)-1500)
10310 10310 6010 10350
10320 10320 Epsilon=6.9-.00243*(Rdfrq(1)-3000)
10330 10330 Sigma=6.52+.001314*(Rdfrq(1)-3000)
10340 10340 Sigma=Sigma*18000/Rdfrq(1)
10350 10350 Delx=Armax/50
10360 10360 Delx2=Delx./2

```

```

10380 Rmag=1
10390 Phi1=Pi
10400 Ref_flag=0
10410 RETURN
10420
10430
10440 Optical_limit ! GEOMETRIC MODEL FOR HR 10F FT
10450 Altrap=0 ! DUCTING NOT USED IN OPTICAL REGION
10460 Dh=(Hr-Ht)*1E-3
10470 Ae2=Ae*2E-3
10480 Twoae=2*Ae
10490 Thefac=4.193E-5*Rdfreq(1)
10500 Vfac=(Ht+Hr)*Ae*1E-3
10510 Aetht=Ae*Ht*1E-3
10520 A1=SQR(Psi1^2+2E-3*Ht/Ae)
10530 D1=D2=(A1-Psi1)*Ae
10540 IF Hr Ht THEN D2=D2+(SQR(A1^2+2*Dh/Ae)-A1)*Ae
10550 D=D1+D2
10560 Htp=Ht-D1^2/Ae^2
10570 Hrp=Hr-D2^2/Ae^2
10580 Apd=Thefac*Htp*Hrp/D
10590 IF Hpolari(1,0)=0 THEN
      Simepsi=SIN(Psi1);
10600 ENDIF
10610 GOSUB Ref
10620 ETE, IF
10630 Atheta=Apd+Phi
10640 Heiphase=Phi(0)-Twoae
10650 Fnow=0
10660 IF (And Heiphase) OP (Psi1/Psi1m, THEN C2
10670 C1 = GRADIENT ANGLE LIMIT

```

```

10580      Inneat=PI
10590      GOTO 10830
10700  C2 = 1   QUARTER WAVELENGTH LIMIT
10710  Thet=t=3*HalfPI
10720  Rnow=.95*Horizon
10730  GO SUB Rimda
10740  Rnow=Knext
10750  IF Hpolar(1,0)=0 THEN
10760    Psi=Htp*1E-3/D1
10770    S1nPsi=SIN(Psi)
10780  GO SUB Ref
10790  Ref_flag=1
10800  Theta=Apd+Phi
10810  END IF
10820  GOTO C1
10830  RnG=Rsave=Rnow
10840  Opma.=Rng
10850  GO SUB Optloss
10860  Optloss=Aloss
10870  RETURN
10880  -
10890  Optloss=OPTICAL REGION LOSS
10910  R=rng
10920  IF Ref_flag THEN 10930
10930  Psi=Htp*1E-3/D1
10940    S1nPsi=1/HtP*Ref
10950  Halfone=Fn/Fc*1/wave
10960  IF Halfone>1 THEN RETURN
10970  Gamma=D1/Ae

```

```

10980 Beta=-. (Gamma+P51)
10990 CCSUS F_factor
11000 Losfac=Fterm+9.686•LOG(Rng)
11010 IF Ffac=1E-7 THEN Aloss=Losfac+7@)
11020 IF Ffac<1E-7 THEN Aloss=Losfac-4.543•LOG(Ffac)
11030 E_Loss=-E.686•LOG(Patd)
11040 RETURN
11050 I
11060 I
11070 R1mda: I SUBROUTINE TO FIND RANGE WHERE A SPECIFIED VALUE OF THETA OCCURS
11080 I R1MDA USES A FINITE DERIVATIVE IN A NEWTON ITERATION FOR THETA
11090 I INPUTS: RNOW; D1; THEXT; HIP, ATHTA
11100 I OUTPUTS: RNEXT
11110 I SUBROUTINES USED: THETA
11120 I CONSTANTS: HORIZN
11130 Iseave=D1
11140 I=RNOW
11150 Dinc=MIN(.1,D*.01)
11160 FOR Icount=1 TO 10
11170 GOSUB Theta
11180 F=Attheta
11190 D=D+Dinc
11200 GOSUB Theta
11210 F1=Attheta
11220 FP=(F1-F)/Dinc
11230 Dd=(F-Fnext)/FP
11240 IF Dd>0 THEN 11270
11250 I=0,I2
11260 GOTO 11320

```

```

11270 IF Horizon D+Dd THEN 11300
11280 D=(Horizon+D)/2
11290 GOTO 11320
11300 D=D+Dd
11310 IF (ABS(Dd), Dinc) AND (D Rnow) THEN 11330
11320 NEXT Icount
11330 Rnext=0
11340 RETURN
11350
11360
11370 Theta! ! SUBROUTINE FOR TOTAL PHASE DIFF, THETA, BTWN DIR AND REFL RAYS
11380 ! SOLVES A CUBIC EQN TO FIND REFLECTION POINT RANGE DI
11390 ! INPUTS D
11400 ! OUTPUTS ATHETA, DI; APD; HTP; PSI; SINPSI
11410 ! CONSTANTS QFAC; ATHTH; PHI; AE2; THEFAC
11420 ! SUBROUTINES USED REF
11430 At=-1.5*D
11440 V=.5*D^2-Qfac
11450 w=Athth*D
11460 F0P Inde.=1 TQ 10
11470 D1sq=D1^2
11480 Fd1=D1*D1^2+At*D1sq+Q*D1+w
11490 Fpd1=z*D1sq+z*D1+q
11500 Delz=Fd1-Fd1
11510 D1=D1-Delz
11520 If (D1 D+ At) (D1 Q+ THETH) 11550
11530 D1=0.2
11540 GOTO 11560
11550 If AE2 (Delz) .10C THEN 11570
11560 NEXT Inde.

```

```

11570 D2=0-D1
11580 HtP=Ht-E1*D1*He^2
11590 HrP=Hr-E2*D2*re^2
11600 IF NGT Ref_flag THEN 11640
11610 Psi=HtP*1E-3/D1
11620 Sumpsi=5*IN(Psi)
11630 60SUB Ref
11640 Apd=Thefac*Htp*Hcp/D
11650 Atmeta=Apd+Phi
11660 RETURN
11670

11680 !
11690 Diffraction_const: ! DIFFRACTION/TROPOSCATTER REGION CONSTRAINTS
11700 Freq=Fdfreq(I)
11710 IF Ht_duct=0 THEN Evap_duct
11720 ! CONSTRAINTS FOR GROUND-BASED DUCT
11730 Atten=0
11740 Tlrfac=2
11750 Tl=Hr/Ht_duct
11760 IF (Freq =150) AND (Tl=.8) THEN Fz=-60*(Tl-.5)^2
11770 IF (Freq =150) AND (Tl=.8) THEN Fz=1.14*Tl^(-6.26)-10
11780 IF (Freq 150) AND (Tl=1) THEN Fz=10-200*(Tl-.5)^4
11790 IF (Freq 150) AND (Freq =350) AND (Tl=1) THEN Fz=7.5*Tl^(-13.3)-10
11800 IF (Freq 350) AND (Tl =1) THEN Fz=12.5*Tl^(-8)-15
11810 Difac=Fstern-Fz+E_1c55
11820 661C Tropo

```

```

11830 Evap_duct ! STANDARD DIFF. CONSTANTS
11840 Tirfac=1
11850 Rfac=4.705E-2*Freq"(1/J)
11860 Zfac=2.214E-3*Freq"(2/J)
11870 Hmin=1/Zfac
11880 Zt=MAX(Hmin,Ht*Zfac)
11890 Zr=MAX(Hmin,Hr*Zfac)
11900 C1=-14.8
11910 C2=.49
11920 C3=-36.9
11930 C4=-.1
11940 CS=102
11950 Fzt=C1*(Zt/4.72)^C2+C3*(Zt/4.72)^C4+C5
11960 Fzr=C1*(Zr/4.72)^C2+C3*(Zr/4.72)^C4+C5
11970 Atten=1.973*Rfac
11980 TIm=216.7
11990 Diffac=51.1+TIm-Fzt-Fzr+4.343*LOG(Rfac)
12000 Tropo !
12010 Tfac=.08994/Rfac
12020 Trfac=1J.029*LOG(Freq)+49.9-Tfacc*Hcrrn+Eloss
12030 RETURN
12040 !
12050 !
12060 Diffraction ! RETURNS LOSS IN DIFFRACTION/TROPOSCATTER REGION & RNG
12070 ! INPUTS RNG
12080 ! OUTPUTS DIFF
12090 ! CONSTANTS : Tfac, Tropac, Difac, Atten, Tlpfac
12100 Tir=4.343*LOG(Rng)
12110 Tloss=Tfac*Rng+2*Tir+Trfac
12120 Diff=Difac+Tir*Tfacc+Atten*Rng
12130 Dif=Dif-Tloss

```

```

12140 IF D1f -1E THEN RETURN
12150 IF D1f 1E THEN
12160 D1f=D1f-4.343*L06(1+EXP(D1f/4.343))
12170 ELSE
12180 D1ff=Tloss
12190 END IF
12200 RETURN
12210 RETURN
12220 !
12230 !
12240 Aantpat ! *** ANTENNA PATTERN FUNCTION SUBROUTINE ***
12250 ! INPUTS. ELEVATION ANGLE FOR WHICH ANTENNA PATTERN DESIRED. ANGLE
12260 ! OUTPUTS NORMALIZED ANTENNA PATTERN FACTOR : PATFAC
12270 ! CONSTANTS ANTELR, ANTFLC, ANTWR, PATFAC,
12280 Patfac=1
12290 Apat=Angle-AngleIr
12300 IF Cosq(1,0) THEN 12380
12310 IF ABS(Apat) 1E-6 THEN RETURN
12320 IF Angle Antelr+Patfac THEN 12350
12330 Patfac=0.03
12340 RETURN
12350 Ufac=Antfac*SIN(Apat)
12360 Patfac=ABS(SIN(Ufac))/Ufac
12370 FE1URH
12380 Patfac=MIN(1,MAX(.03,1+Apat/Anthur))
12390 IF Apat > Anthur THEN Patfac=Anthur/51N(ABS(Apat))
12400 RETURN
12410 !

```

```

12420 !  

12430 Ruf = RETURN SURFACE ROUGHNESS COEFFICIENT FOR SPECIFIED GRAZING ANGLE  

12440 ! INPUT. SURFACE ROUGHNESS IS FUNCTION OF WIND SPEED.  

12450 ! INPUTS GRAZING ANGLE PSI; SIN(PSI)  

12460 ! OUTPUTS NORMALIZED MAGNITUDE OF REFLECTED SIGNAL : RUF  

12470 ! CONSTANTS HFREQ; HFOL  

12480 Eterm=-2*(Hbfreq*Sinpsi)^2  

12490 IF Eterm = .95555 THEN 12520  

12500 Ruf=EXP(Eterm)  

12510 RETURN  

12520 Hfpsi=HFOL*PSI  

12530 IF Hfpsi .26 THEN Ruf=.15  

12540 IF Hfpsi .15 THEN Ruf=.5018913-SQR(.2090248-(Hfpsi-.55189)^2)  

12550 RETURN  

12560 !  

12570 !  

12580 Ref = REFLECTION COEFFICIENT  

12590 Rr=Epsi1on-COS(PSI)^2  

12600 Ar=(Fr*Fr+Sigom*Sigom)^.25  

12610 Th=ATN(Sigom/Fr)/2  

12620 R.=R*COS(TH)  

12630 Ry=R*SIN(TH)  

12640 Aa=Edsi1on*Sinpsi-R.  

12650 Ab=S:90m*Sinpsi-Ry  

12660 Ac=Edsi1on*Sinpsi+R.  

12670 Ad=S:90m*Sinpsi+Ry  

12680 R.=((ha+hc+hd*Ad)/(Ac+hc+hd*Ad))  

12690 Ry=((hb+hc-hd*Ad)/(Ac+hc+hd*Ad))  

12700 Rmag=SQR(R..*R.+Ry*Ry)

```

```

12710 IF Rz < 0 THEN
12720   Phi=ATN(Pz/Rz)
12730   IF Ra < 0 THEN Phi=Phi+PI
12740 ELSE
12750   IF Ry < 0 THEN Phi=-HALFPI
12760   IF Ry>0 THEN Phi=HALFPI
12770   IF Rz=0 THEN Phi=0
12780 END IF
12790 Phi=-Phi
12800 IF Phi < 0 THEN Phi=Phi+TWOPI
12810 IF NOT Hpolar(1,0) THEN RETURN
12820 R=.50R*(1+Rmag*Rmag*.52*COS(PI-Phi))
12930 Az=ASIN(Rmag*SIN(Phi+PI)/R)
12840 Phi=PI-Az
12850 Rmag=R/.2
12860 Phi=-Phi
12870 IF Phi < 0 THEN Phi=Phi+TWOPI
12880 RETURN
1222
12290
12900
12910 F_factor ! RETURN VALUE OF PATTERN PROPAGATION FACTOR F
12920 ! INPUTS ANGLES PSI, ALPHA, BETA, GAMMA, HR, RMAG,
12930 ! ALTHETA, PNTFAC
12940 ! OUTPUTS FFAC
12950 ! SUBROUTINES CALLED ANTPAI, RUF
12960 Angle=Alpha
12970 GOSUE MANTDAT
12980 Patd=Fatrac
12990 Angle=Beta
13000 GOSUE Hartpat
13010 GOSUE Ruf

```

```

13020 Divfac=1/SQR(1+2*Gamma/Sinpsi)
13030 Dr=Divfac*Patfac*Rmag*Ruf
13040 Ffac=Patd^2+Dr^2+2*Dr*Patd*Cos(theta)
13050 RETURN
13060
13070 EXIT
13080 SELECT Output_choice
13090 CASE 1 ! DATA
13100 CASE 2 ! Y-Y PLOT
13110 ON KEY 0 LABEL "0) DUMP" GOTO Dumpit
13120 CASE 3 ! PD PLOT
13130 ON KEY 0 LABEL "0) DUMP" GOTO Dumpit
13140 CASE 4 ! STATUS
13150 GOSEE Output_Status
13160 END SELECT
13170 ON KEY 7 LABEL " 7) EXIT" GOTO Endit
13180 WAIT
13190
13200 Dumpit:
13210 DUMP GRAPHICS TO 401
13220 PRINTER IS CRT
13230 GOTO Endit
13240 Endit:
13250 SPGRAPHICS OFF
13260 PRINT PAGE
13270 PRINTER IS CRT
13280 DISP "CLEARING DATA FILE"
13290 LOAD "FILESTE",Final
13300 Final DISP "FILE"
13310 END
13340 Dat.i DATASET NAME

```

APPENDIX B. FASTS DATA INPUT GUIDE

A. FILE STRUCTURE

The FASTS data file is composed of a series of BASIC language DATA statements with interspersed lines of comment to aid in file building and readability. When the program is executed, the user is prompted to enter the name of the data file containing the simulation run parameters. The file is then physically attached to the end of the source code and becomes a part of the FASTS program. Statements or commands in subroutine IREP read the parameters from the DATA statements and assign them to the program variables.

Each line containing data begins with the key word DATA. Numerical quantities may be in decimal or integer format and must be separated by commas. Omission of a comma is the most common mistake made in building a data file.

Data elements are read sequentially; hence no parameters may be omitted.

Since the exclamation point, and all information to its right, are ignored during execution, it is used to provide lines for spacing, parameter list headings, and user comments needed to make the file more easily interpreted.

The data file has eight major sections: IREPS; Size; Radar Site; Radar Parameters; Jammer Parameters; Aircraft Initialization; and Aircraft Flight Profile.

1. IREPS

This section contains parameters defining atmospheric conditions.

Parameter Definitions:

K Equivalent earth radius (dimensionless)

DUTC HT Altitude of the top of the first trapping layer above the earth's surface (ft)

WIND Wind speed (knots)

Data Source:

For the standard day, K=1.33 and DUCT HT=0 are used.

Parameters for actual conditions may be determined from the IREPS system output. To determine K, run the IREPS program with data for current or predicted atmospheric conditions selecting the Radar Loss Display option. On completion, enter K and depress the ENTER key; the value for K will be displayed. Duct height may be read directly from the IREPS Propagation Conditions Summary display.

2. Size

This section contains time parameters and specifies the number of data elements present in the data file for radars, jammers, and aircraft.

Parameter Definitions:

NAC Total number of aircraft in the simulation (15 max)

NJM Total number of jammers types in simulation (15 max)

NRD Total number of radars in the simulation (15 max)

NACTYP Total number of aircraft types defined (15 max)

NRDTYPE Total number of radar types defined (15 max)

DT Simulation time increment--upper bound (sec)

TFIN Simulation end time (sec)

3. Radar Site

This section contains parameters specifying the type and location of each radar.

Parameter Definitions:

RDTYP Type specification for the radar

RDLAT Y-axis radar location coordinate (nm)

RDLONG X-axis radar location coordinate (nm)

RDALT Radar antenna altitude (ft)

4. Radar Parameters

This section contains parameters for each of the different types of radar systems. Note that parameters for as many as fifteen different types of radar systems may be entered as a data base even though each is not actually used in the simulation.

Parameter Definitions:

RDSCNTYP Radar antenna scan time (sec)

RDBTBYP Antenna design (1 = Back-to-Back; 0 = Single)

RMAXTYP Radar maximum range (nm)

RVZEROTYP Detection visibility threshold (dB)

RDERPTYP Radar effective radiated power (dB)

RDFRQTYT Radar frequency (MHz)

RDGANTYP Radar receiving antenna gain (dB)

RDFNTYP Radar receiver noise figure (dB)

RDNBWTYP	Radar noise bandwidth (MHz)
LOSSTYP	Radar receiver loss (dB)
RDAZBWTYP	Radar antenna pattern azimuth beamwidth (deg)
RDAZSLTYP	Antenna pattern gain in the first side lobe (dB)
RDELBWTYP	Radar antenna pattern elevation beamwidth (deg)
CSCSQTYP	Vertical antenna pattern (1 = $\csc^2 \theta$; 2 = $\sin \theta/\lambda$)
DTYPETYP	Horizontal antenna pattern (1 = Type 1; 2 = Type 2)
HPOLAR	Radar beam polarization (1 = horizontal; 2 = vertical)

Data Source:

Parameter data for most threat radar systems is found in:

Defense Intelligence Agency, Radar Handbook--Eurasian Communist Countries, DST-1710H-507-80-Vol. 3, December 1980

Effective radiated power may be computed as the product of the transmitter power times the gain of the antenna.

Data may be converted to decibel (dB) notation by the use of the following relationship:

$dB = 10 \log (X)$ where X is the parameter to be converted.

5. Jammer Parameters

This section contains radar jammer parameters listed for each jammer type.

Parameter Definitions:

JMBW	Jammer bandwidth (MHz)
JMFRQ	Jammer frequency (MHz)
JMERP	Jammer effective radiated power

Data Source:

Data for jammer parameters may be found in:

Commander, Operational Test and Evaluation Squadron FIVE,
EA-6B Tactical Employment Guide, OTG 533-01-80 series

6. Aircraft Parameters

This section contains radar cross section data listed for each aircraft type. Up to 360 entries of aspect angle and associated radar cross section may be entered for each aircraft. Note that data for as many as fifteen aircraft may be contained in the parameter file as a data base even if each is not used in the simulation.

Parameter Definitions:

ALPHA Aircraft aspect angle (deg)

RCS Radar cross section gain for ALPHA (dB)

Data Source:

Radar cross section data for aircraft may be found in the tactical manual or supplemental NATOPS manual for each aircraft.

7. Aircraft Initialization

This section contains parameters specifying the type and initial position and velocity for each aircraft in the simulation.

Parameter Definitions:

ACTYP Type specification for the aircraft

ACLAT Y-axis coordinate, aircraft initial position (nm)

ACLONG X-axis coordinate, aircraft initial position (nm)

ACALT Aircraft initial altitude (ft)
ACHDG Aircraft initial heading (deg)
ACVEL Aircraft initial speed (knots)

8. Aircraft Flight Profile

This file contains a subfile for each aircraft. Lines within each subfile contain up to fifteen commands for that aircraft and are listed in order of the command initiation time.

Parameter Definitions:

TIME Command initiation time (sec)
A 9999 entry indicates the end of the an aircraft's profile command list.

CHANGE Command type
1 = Jam ON
2 = Jam OFF
3 = Accelerate (decelerate)
4 = Climb (Descend)
5 = Turn
6 = Home
7 = Follow

X Command parameter
Jam ON/Jam OFF Jammer type number
Accelerate Rate (knots/sec)
Climb Rate (feet/sec)
Turn Rate (deg/sec)
Home Rate (deg/sec)
Follow Aircraft to be followed

Note: The parameters for accelerate, climb, and turn are signed quantities with negative values indicating decelerate, descend, and turn left.

Y Command target parameter
Jam ON/Jam OFF Must be 0
Accelerate New speed (knots)
Climb New altitude (feet)
Turn New heading (deg)
Home Radar site number
Follow Must be 0

B. DATA FOR DUAL ANTENNA RADARS

Radar systems having two antennas mounted in back-to-back fashion can be simulated by FASTS.

If the variable RDBTB is read as 1 for a radar system, the program will seek data parameters for the second antenna system. These parameters are listed in the data file line directly following the line containing the data for the first system. Data for the following parameters must be entered: RDERPTYP, RDGANTYP, RDAZBWTYP, RDAZSLTYP, RDELBWTYP, CSCSQTYP, DTYPETYP, and HPOLAR.

C. SAMPLE DATA FILE

The following is a sample data file containing multiple radars, radar types, aircraft, and aircraft types:

10	DATA	DATASET NAME
20	DATA	WHS1
30		
40	!IREPS	K
50	DATA	1.33,
60		0,
70	!NAC	NJM
80	DATA	7,
90		2,
100	Rdrdat:	!
110		RDTYP
120	DATA	1,
120	DATA	2,
140		
150		RDSCTYP
160	DATA	5,
170	DATA	5,
180		
190		RDERPTYP
200		RDFRTYP
210	DATA	90,
220	DATA	102,
230	DATA	98,
240		
250		RDAZBTYP
260		RDAZSLTYP
270	DATA	4,
280	DATA	3,
290	DATA	3.5,
300		
		DUCT HT (FT)
		WIND
		8
		NACTYP
		NRDTP
		DT
		TFIN
		10,
		1000
		RDLAT
		RDLONG
		RDALT
		80
		1 RDR 1
		80
		1 RDR 2
		RMAXTYP
		RVZEROTYP
		250,
		0
		1 RDR 1
		125,
		0
		1 RDR 2
		RDFNTYP
		RDGANTYP
		10,
		.5,
		1 RDR 1
		7,
		0.1,
		7
		1 RDR 2
		RDNBTYP
		LOSSTYP
		HPOLAR
		1
		1 RDR 1
		1
		1 RDR 2
		0

310	Jmdata:						
320		JMBW	JMFHQ	JMFRP			
330	DATA	100,	1000,	800			
340	DATA	150,	900,	14000			
350							
360							
370		ALPHA	RCS				
380	DATA	0,	14				
390	DATA	180,	14				
400	DATA	9999,	00.0				
410							
420	DATA	0,	-3				
430	DATA	180,	-3				
440	DATA	9999,	0				
450							
460	Acdata:						
470		ACTYPE	ACLAT	ACLONG	ACALT	ACHDG	ACVEL
480	DATA	1,	100,	0,	5000,	180,	260
490	DATA	1,	100,	0,	5000,	180,	360
500	DATA	1,	100,	0,	5000,	180,	360
510	DATA	1,	100,	0,	5000,	180,	360
520	DATA	2,	100,	0,	5000,	180,	360
530	DATA	2,	100,	0,	5000,	180,	360
540	DATA	2,	100,	0,	5000,	180,	360
550							

	TIME	CHANGE	X	Y
560	! ACFT1			
570	DATA 1,	6,	3,	1
580	DATA 250,	4,	-100,	1000 ! DECEND TO 1000 FT
590	DATA 500,	3,	-5,	300 ! DECELL TO 300 KTS
600	DATA 500,	1,	1,	0 ! JAMMER 1 ON
610	DATA 500,	1,	2,	0 ! JAMMER 2 ON
620	DATA 500,	5,	-3,	181 ! TURN
630	DATA 740,	5,	3,	180 ! TURN
640	DATA 860,	5,	3,	045 ! TURN
650	DATA 980,	5,		
660	DATA 9999			
670	!			
680	! ACFT2			
690	DATA 1,	7,	1,	0 ! FOLLOW JAMMER
700	DATA 500,	3,	5,	420 ! ACCEL TO 420
710	DATA 500,	5,	3,	230 ! TURN
720	DATA E55,	6,	3,	1 ! HOME TO 1
730	DATA 740,	5,	-3,	360 ! TURN AFTER SHOT
740	DATA 9999			
750	!			
760	! ACFT3			
770	DATA 1,	7,	1,	0 ! FOLLOW JAMMER
780	DATA 500,	3,	5,	420 ! ACCEL TO 420
790	DATA 500,	5,	-3,	130 ! TURN
800	DATA 680,	6,	3,	2 ! HOME TO 2
810	DATA 750,	5,	-3,	360 ! TURN AFTER SHOT
820	DATA 9999			
830	!			

840	IACFT4							
850	DATA	1,	7,	1,	0	! FOLLOW JAMMER		
660	DATA	500,	3,	5,	360	! MAINTAIN 360 KTS		
870	DATA	700,	5,	-3,	360	! TURN AFTER SHOT		
880	DATA	9999						
890	!							
900	IACFT5							
910	DATA	1,	7,	2,	0	! FOLLOW SHOOTER(R)		
920	DATA	730,	6,	3,	1	! HOME TO RDR 1		
930	DATA	730,	3,	50,	550	! ACCEL		
940	DATA	730,	4,	-100,	50	! FALL TO 50 FT		
950	DATA	9999						
960	!							
970	IACFT6							
980	DATA	1,	7,	3,	0	! FOLLOW SHOOTER(L)		
990	DATA	740,	6,	3,	2	! HOME TO RDR 2		
1000	DATA	740,	3,	50,	550	! ACCEL		
1010	DATA	740,	4,	-100,	50	! FALL TO 50 FT		
1020	DATA	9999						
1030	!							
1040	IACFT7							
1050	DATA	1,	7,	4,	0	! FOLLOW SHOOTER(C)		
1060	DATA	700,	6,	3,	1	! HOME TO RDR 1		
1070	DATA	700,	3,	50,	750	! ACCEL		
1080	DATA	700,	4,	1000,	10000	! CLIMB TO 10000 FT		
1090	DATA	9999						

LIST OF REFERENCES

1. Naval Research Laboratory Report 6930, A Guide to Basic Pulse-Radar Maximum Radar Calculation. Part II-Derivations of Equations, Bases of Graphs and Additional Explanations, by L. V. Blake, December 31, 1969.
2. Hoisington, D. B., Electronic Warfare, Naval Postgraduate School, Monterey, California, July 1979.
3. Naval Ocean Systems Center Technical Document 481, IREPS Revision 2.2 User's Manual, by C. P. Hattan, et. al., September 1981.
4. Scolnik, M. I., Introduction to Radar Systems, 2nd edition, McGraw-Hill Book Company, Inc., New York, 1980.
5. Blake, L. V., Radar Range-Performance Analysis, D.C. Heath and Company, Lexington, MA, 1980.
6. Swerling, P., "Probability of Detection for Fluctuating Targets", IRE Transportation Information Theory, IT-6, v. 271, pp. 273-308, April 1960.
7. Naval Research Laboratory Report 6930, A Guide to Basic Pulse-Radar Maximum Radar Calculation, Part I-Equations, Definitions and Aids to Calculations, by L. V. Blake, December 23, 1969.
8. Baker, C. H., Man and Radar Displays, The MacMillan Company, New York, 1962.
9. Johns Hopkins University Applied Physics Laboratory Report NWA-84-027, The Modified Jamming Aircraft and Radar Simulation, by J. E. Hubbs and G. W. Loughran, May 1984.
10. Johns Hopkins University Applied Physics Laboratory Report NAS-84-039, HARM Strike Simulation by D. J. O'Connor and C. M. Barrack, October 26, 1984
11. White, T. W., Positioning of Jamming Aircraft Using the Integrated Refractive Effects Prediction System, MS Thesis, Naval Postgraduate School, Monterey, California, October 1982.

INITIAL DISTRIBUTION LIST

No. Copies

1. Defense Technical Information Center
Cameron Station
Alexandria, Virginia 22304-6145 2
2. Library, Code 0142
Naval Postgraduate School
Monterey, California 93943-5100 2
3. Department Chairman, Code 55
Department of Operations Research
Naval Postgraduate School
Monterey, California 93943-5100 1
4. Professor N. R. Forrest, Code 55
Department of Operations Research
Naval Postgraduate School
Monterey, California 93943-5100 1
5. Professor A. F. Andrus, Code 55As
Department of Operations Research
Naval Postgraduate School
Monterey, California 93943-5100 1
6. LCDR Paul Fischbeck, Code 55Fb
Department of Operations Research
Naval Postgraduate School
Monterey, California 93943-5100 1
7. The Johns Hopkins University
Attn: C. M. Barrack
Applied Physics Laboratory
Laurel, Maryland 20707 1
8. Naval Ocean System Center
Attn: C. P. Hattan
San Diego, California 92152 1
9. Naval Tactical Support Activity
Attn: CDR F. O. Barrett
P.O. Box 1042
Silver Spring, Maryland 20910 1

10. Dr. M. Leonardo
Naval Air Development Center
Warminster, Pennsylvania 18974-5000 1
11. LCDR Karl. A. Kail
Fleet Liaison Action Group
Naval Air Development Center
Warminster, Pennsylvania 19974 1

334

Thesis

B23741

c.1

Barrett

FASTS: a radar simulation model for the development and analysis of aircraft anti-ship tactics.



thesB23741
FASTS: a radar simulation model for the



3 2768 000 62578 4
DUDLEY KNOX LIBRARY