

Stealthbox®

INSTALLATION GUIDE for the SB-D-TRKCTR/12W3v2 (1994-2002 Dodge Ram)



This Stealthbox is a product which requires professional installation skills and tools.

Please read this installation guide thoroughly before beginning the project. It will guide you step by step through the installation. Several of the steps in this process may require two people to accomplish.

It is absolutely vital that the enclosure be properly mounted to the vehicle according to these instructions. Failure to mount the enclosure properly presents two problems: 1) The sub-bass performance will suffer due to the movement of the enclosure caused by the force exerted by the woofer(s) and 2) A loose enclosure presents a serious safety hazard in the event of a collision or sudden deceleration.

Please enjoy your JL Audio Stealthbox responsibly.

JL AUDIO®
Ahead of the Curve™

www.jlaudio.com

START HERE This enclosure is not designed to be a passenger seat. We do not recommend it to be used as such.

→ If you are dealing with a 1997-2002 there will be a small black box bolted to the underside of the center seat. This is the seatbelt sensor and must be handle with care. See STEP 9.



STEP 1: Slide the sat bolts out of the elastic loops on the center cushion.

STEP 2: Unbolt the center seat from underneath the cushion using a 13mm socket.

STEP 3: Detach the cover from the center cushion by unlatching the plastic strips from the metal bars on its underside. Do not remove it completely at this point.




STEP 4: Remove the arm rest from the center cushion by unbolting the pair of 8mm bolts from each side.

Exercise care in separating the two pieces so as not to rip the fabric.

STEP 5: Remove the seat cover from the bottom cushion.

STEP 6: Place the factory seat cover over the enclosure.



STEP 7: Slide the arm rest brackets through the cutouts in the seat cover and bolt into the inserts provided in the enclosure, using the bolts that were removed in STEP 4.

STEP 8: Working on the underside of the enclosure, fold the plastic strips under the fabric. Using the supplied screws, screw through the fabric and the plastic strips into the enclosure. Screw all four flaps in.

Do not screw into any areas of the enclosure other than the pre-drilled holes!

Continued on Next Page →

Cont.
From
Previous
Page



STEP 9: If you are dealing with a truck that has the seat belts sensor (black box). Attach this black box to the driver's seat floor brackets. Make sure that the mounting of this black box is exactly the way it was positioned by the factory. If not, the seat belts will not function correctly.

STEP 10: Test the woofer for proper functioning. Run speaker wire to the enclosure's mounting location and attach to the enclosure.



STEP 11: Bolt the enclosure into place using the factory bolts that were removed in **STEP 2**.

DO NOT completely tighten till all four 8mm bolts have been threaded.

STEP 12: Slide the seat belts back through the elastic loops attached to the enclosure.



**CONGRATULATIONS!
INSTALL COMPLETE.**

Included Hardware:
(8) Wafer-head screws


Difficulty Of Installation:



Specifications:

- Enclosure Type:** Acoustic Suspension (Sealed)
- Driver Type:** 12W3v2
- Nominal Impedance:** 4Ω
- Cont. Power Handling:** 300 Watts

JL Audio recommends using a high quality amplifier such as the JL Audio 250/1. The diagram below shows the recommended crossover, infrasonic filter and equalizer settings for the 250/1 when being used to power your Stealthbox®.



The JL Audio 250/1 is a very versatile audio component. Please consult the owner's manual for detailed information about installing and tuning this amplifier.

Mid/High Frequency Driver Information:

Front Location Driver Size:
6"x9"

Applicable JL Audio Products:
N/A

Rear Location Driver Size:
5.25"

Applicable JL Audio Products:
TR,VR,XR 525-CXi

