

MITSUBISHI CNC

Specifications Manual MDS-D/DH Series



MELDAS is a registered trademark of Mitsubishi Electric Corporation.

Other company and product names that appear in this manual are trademarks or registered trademarks of their respective companies.

Introduction

Thank you for selecting the Mitsubishi numerical control unit. This instruction manual describes the handling and caution points for using this AC servo/spindle.Incorrect handling may lead to unforeseen accidents, so always read this instruction manual thoroughly to ensure correct usage. In order to confirm if all function specifications described in this manual are applicable, refer to the specifications for each CNC.

Notes on Reading This Manual

- (1) Since the description of this specification manual deals with NC in general, for the specifications of individual machine tools, refer to the manuals issued by the respective machine manufacturers. The "restrictions" and "available functions" described in the manuals issued by the machine manufacturers have precedence to those in this manual.
- (2) This manual describes as many special operations as possible, but it should be kept in mind that items not mentioned in this manual cannot be performed.

Precautions for safety

Please read this manual and auxiliary documents before starting installation, operation, maintenance or inspection to ensure correct usage. Thoroughly understand the device, safety information and precautions before starting operation.

The safety precautions in this instruction manual are ranked as "WARNING" and "CAUTION".

<u></u> ∆ DANGER	When there is a potential risk of fatal or serious injuries if handling is mistaken.
<u>∧</u> WARNING	When a dangerous situation, or fatal or serious injuries may occur if handling is mistaken.
⚠ CAUTION	When a dangerous situation may occur if handling is mistaken leading to medium or minor injuries, or physical damage.

Note that some items described as "ACAUTION" may lead to major results depending on the situation. In any case, important information that must be observed is described.

The signs indicating prohibited and mandatory matters are explained below.



Indicates a prohibited matter. For example, "Fire Prohibited" is indicated as (%).







The meaning of each pictorial sign is as follows.

CAUTION	CAUTION rotated object	CAUTION HOT	Danger Electric shock risk	Danger explosive
Prohibited	Disassembly is prohibited	KEEP FIRE AWAY	General instruction	Earth ground

After reading this specifications and instructions manual, store it where the user can access it easily for reference.

The numeric control unit is configured of the control unit, operation board, servo drive unit, spindle drive unit, power supply, servomotor and spindle motor, etc.

In this section "Precautions for safety", the following items are generically called the "motor".

- Servomotor
- Linear servomotor
- Spindle motor

In this section "Precautions for safety", the following items are generically called the "unit".

- Servo drive unit
- Spindle drive unit
- Power supply unit
- · Scale interface unit
- · Magnetic pole detection unit



Important matters that should be understood for operation of this machine are indicated as a POINT in this manual.

⚠ WARNING

1. Electric shock prevention

- Do not open the front cover while the power is ON or during operation. Failure to observe this could lead to electric shocks.
- ⚠ Do not operate the unit with the front cover removed. The high voltage terminals and charged sections will be exposed, and can cause electric shocks.
- ⚠ Do not remove the front cover and connector even when the power is OFF unless carrying out wiring work or periodic inspections. The inside of the units is charged, and can cause electric shocks.
- Since the high voltage is supplied to the main circuit connector while the power is ON or during operation, do not touch the main circuit connector with an adjustment screwdriver or the pen tip. Failure to observe this could lead to electric shocks.
- Wait at least 15 minutes after turning the power OFF, confirm that the CHARGE lamp has gone out, and check the voltage between P and N terminals with a tester, etc., before starting wiring, maintenance or inspections. Failure to observe this could lead to electric shocks.
- ⚠ Ground the unit and motor. For the motor, ground it via the drive unit.
- Miring, maintenance and inspection work must be done by a qualified technician.
- Mire the servo drive unit and servomotor after installation. Failure to observe this could lead to electric shocks.
- ⚠ Do not touch the switches with wet hands. Failure to observe this could lead to electric shocks.
- ⚠ Do not damage, apply forcible stress, place heavy items on the cables or get them caught. Failure to observe this could lead to electric shocks.
- After assembling the built-in IPM spindle motor, if the rotor is rotated by hand etc., voltage occurs between the terminals of lead. Take care not to get electric shocks.

2. Injury prevention

When handling a motor, perform operations in safe clothing.



A In the system where the optical communication with CNC is executed, do not see directly the light generated from CN1A/CN1B connector of drive unit or the end of cable. When the light gets into eye, you may feel something is wrong for eye.

(The light source of optical communication corresponds to class1 defined in JISC6802 or IEC60825-1.)

The linear servomotor, direct-drive motor and built-in IPM spindle motor uses permanent magnets in the rotor, so observe the following precautions.

(1)Handling

- The linear servomotor, direct-drive motor and built-in IPM spindle motor could adversely affect medical electronics such as pacemakers, etc., therefore, do not approach the rotor.
- Do not place magnetic materials as iron.
- When a magnetic material as iron is placed, take safety measure not to pinch fingers or hands due to the magnetic attraction force.
- Remove metal items such as watch, piercing jewelry, necklace, etc.
- Do not place portable items that could malfunction or fail due to the influence of the magnetic force.
- When the rotor is not securely fixed to the machine or device, do not leave it unattended but store it in the package properly.

(2)Transportation and storage

- Correctly store the rotor in the package to transport and store.
- During transportation and storage, draw people's attention by applying a notice saying "Strong magnet-Handle with care" to the package or storage shelf.
- Do not use a damaged package.

(3)Installation

• Take special care not to pinch fingers, etc., when installing (and unpacking) the linear servomotor.

CAUTION

1. Fire prevention

- ⚠ Install the units, motors and regenerative resistor on non-combustible material. Direct installation on combustible material or near combustible materials could lead to fires.
- Always install a circuit protector and contactor on the servo drive unit power input as explained in this manual. Refer to this manual and select the correct circuit protector and contactor. An incorrect selection could result in fire.
- ⚠ Shut off the power on the unit side if a fault occurs in the units. Fires could be caused if a large current continues to flow.
- When using a regenerative resistor, provide a sequence that shuts off the power with the regenerative resistor's error signal. The regenerative resistor could abnormally overheat and cause a fire due to a fault in the regenerative transistor, etc.
- ⚠ The battery unit could heat up, ignite or rupture if submerged in water, or if the poles are incorrectly wired.
- Cut off the main circuit power with the contactor when an alarm or emergency stop occurs.

2. Injury prevention

- ⚠ Do not apply a voltage other than that specified in this manual, on each terminal. Failure to observe this item could lead to ruptures or damage, etc.
- ⚠ Do not mistake the terminal connections. Failure to observe this item could lead to ruptures or damage, etc.
- △ Do not mistake the polarity (+,-). Failure to observe this item could lead to ruptures or damage, etc.
- Do not touch the radiation fin on unit back face, regenerative resistor or motor, etc., or place parts (cables, etc.) while the power is turned ON or immediately after turning the power OFF. These parts may reach high temperatures, and can cause burns or part damage.
- Structure the cooling fan on the unit back face, etc., etc so that it cannot be touched after installation. Touching the cooling fan during operation could lead to injuries.
- A Take care not to suck hair, clothes, etc. into the cooling fan.


CAUTION

3. Various precautions


Observe the following precautions. Incorrect handling of the unit could lead to faults, injuries and electric shocks, etc.

(1) Transportation and installation

- Correctly transport the product according to its weight.
- ① Use the motor's hanging bolts only when transporting the motor. Do not transport the machine when the motor is installed on the machine.
- ⚠ Do not stack the products above the tolerable number.
- ⚠ Follow this manual and install the unit or motor in a place where the weight can be borne.
- ⚠ Do not get on top of or place heavy objects on the unit.



⚠ Do not hold the cables, axis or detector when transporting the motor.



- ⚠ Do not hold the connected wires or cables when transporting the units.
- ⚠ Do not hold the front cover when transporting the unit. The unit could drop.
- Always observe the installation directions of the units or motors.
- ⚠ Secure the specified distance between the units and control panel, or between the servo drive unit and other devices.
- ⚠ Do not install or run a unit or motor that is damaged or missing parts.
- ⚠ Do not block the intake or exhaust ports of the motor provided with a cooling fan.
- ⚠ Do not let foreign objects enter the units or motors. In particular, if conductive objects such as screws or metal chips, etc., or combustible materials such as oil enter, rupture or breakage could occur.
- ⚠ Provide adequate protection using a material such as connector for conduit to prevent screws, metallic detritus, water and other conductive matter or oil and other combustible matter from entering the motor through the power line lead-out port.
- ⚠ The units, motors and detectors are precision devices, so do not drop them or apply strong impacts to them.

ACAUTION

↑ Store and use the units under the following environment conditions.

Environment	Unit	Motor	
Ambient temperature	Operation: 0 to 55°C(with no freezing), Storage / Transportation: -15°C to 70°C (with no freezing)	Operation: 0 to 40°C(with no freezing), Storage: -15°C to 70°C (Note2) (with no freezing)	
Ambient humidity	Operation: 90%RH or less (with no dew condensation) Storage / Transportation: 90%RH or less (with no dew condensation)	Operation: 80%RH or less (with no dew condensation), Storage: 90%RH or less (with no dew condensation)	
Atmosphere	Indoors (no direct sunlight) With no corrosive gas, inflammable gas, oil mist, dust or conductive fine particles		
Altitude	Operation/Storage: 1000 meters or less above sea level, Transportation: 13000 meters or less above sea level	Operation: 1000 meters or less above sea level, Storage: 10000 meters or less above sea level	
Vibration/impact	According to each unit or motor specification		

(Note 1) For details, confirm each unit or motor specifications in addition.

(Note 2) -15°C to 55°C for linear servomotor.


- Securely fix the servomotor to the machine. Insufficient fixing could lead to the servomotor slipping off during operation.
- ⚠ Always install the servomotor with reduction gear in the designated direction. Failure to do so could lead to oil leaks.
- Mhen installing a coupling to a servomotor shaft end, do not apply an impact by hammering, etc. The detector could be damaged.
- ⚠ Do not apply a load exceeding the tolerable load onto the servomotor shaft. The shaft could break.
- Mhen inserting the shaft into the built-in IPM spindle motor, do not heat the rotor higher than 130°C. The magnet could be demagnetized, and the specifications characteristics will not be ensured.
- Always use a nonmagnetic tool (explosion-proof beryllium copper alloy safety tool: NGK Insulators, etc.) when installing the linear servomotor.
- Always provide a mechanical stopper on the end of the linear servomotor's travel path.
- If the unit has been stored for a long time, always check the operation before starting actual operation. Please contact the Service Center, Service Station, Sales Office or delayer.

(2) Wiring

- Correctly and securely perform the wiring. Failure to do so could lead to abnormal operation of the motor.
- ⚠ Do not install a condensing capacitor, surge absorber or radio noise filter on the output side of the drive unit.
- ⚠ Correctly connect the output side of the drive unit (terminals U, V, W). Failure to do so could lead to abnormal operation of the motor.
- Mhen using a power regenerative power supply unit, always install an AC reactor for each power supply unit.
- ⚠ In the main circuit power supply side of the unit, always install an appropriate circuit protector or contactor for each unit. Circuit protector or contactor cannot be shared by several units.

⚠ CAUTION

- ⚠ Always connect the motor to the drive unit's output terminals (U, V, W).
- ⚠ Do not directly connect a commercial power supply to the servomotor. Failure to observe this could result in a fault.
- ⚠ When using an inductive load such as a relay, always connect a diode as a noise measure parallel to the load.
- Mhen using a capacitance load such as a lamp, always connect a protective resistor as a noise measure serial to the load.
- Do not reverse the direction of a diode which connect to a DC relay for the control output signals such as contractor and motor brake output, etc. to suppress a surge. Connecting it backwards could cause the drive unit to malfunction so that signals are not output, and emergency stop and other safety circuits are inoperable.



- ↑ Do not connect/disconnect the cables connected between the units while the power is ON.
- ⚠ Securely tighten the cable connector fixing screw or fixing mechanism. An insecure fixing could cause the cable to fall off while the power is ON.
- ⚠ When using a shielded cable instructed in the instruction manual, always ground the cable with a cable clamp, etc.
- ⚠ Always separate the signals wires from the drive wire and power line.
- ⚠ Use wires and cables that have a wire diameter, heat resistance and flexibility that conforms to the system.
- (3) Trial operation and adjustment
- ⚠ Check and adjust each program and parameter before starting operation. Failure to do so could lead to unforeseen operation of the machine.
- ⚠ Do not make remarkable adjustments and changes of parameter as the operation could become unstable.
- ⚠ The usable motor and unit combination is predetermined. Always check the combinations and parameters before starting trial operation.
- ⚠ The linear servomotor does not have a stopping device such as magnetic brakes. Install a stopping device on the machine side.


ACAUTION

(4) Usage methods

- In abnormal state, install an external emergency stop circuit so that the operation can be stopped and power shut off immediately.
- ⚠ Turn the power OFF immediately if smoke, abnormal noise or odors are generated from the unit or motor.
- On not disassemble or repair this product.
- Never make modifications.
- Mhen an alarm occurs, the machine will start suddenly if an alarm reset (RST) is carried out while an operation start signal (ST) is being input. Always confirm that the operation signal is OFF before carrying out an alarm reset. Failure to do so could lead to accidents or injuries.
- Reduce magnetic damage by installing a noise filter. The electronic devices used near the unit could be affected by magnetic noise. Install a line noise filter, etc., if there is a risk of magnetic noise.
- ⚠ Use the unit, motor and regenerative resistor with the designated combination. Failure to do so could lead to fires or trouble.
- The brake (magnetic brake) of the servomotor are for holding, and must not be used for normal braking.
- There may be cases when holding is not possible due to the magnetic brake's life, the machine construction (when ball screw and servomotor are coupled via a timing belt, etc.) or the magnetic brake's failure. Install a stop device to ensure safety on the machine side.
- After changing the programs/parameters or after maintenance and inspection, always test the operation before starting actual operation.
- Do not enter the movable range of the machine during automatic operation. Never place body parts near or touch the spindle during rotation.
- Follow the power supply specification conditions given in each specification for the power (input voltage, input frequency, tolerable sudden power failure time, etc.).
- ⚠ Set all bits to "0" if they are indicated as not used or empty in the explanation on the bits.
- ⚠ Do not use the dynamic brakes except during the emergency stop. Continued use of the dynamic brakes could result in brake damage.
- If a circuit protector for the main circuit power supply is shared by several units, the circuit protector may not activate when a short-circuit fault occurs in a small capacity unit. This is dangerous, so never share the circuit protector.
- ⚠ Mitsubishi spindle motor is dedicated to machine tools. Do not use for other purposes.

(5) Troubleshooting

- If a hazardous situation is predicted during power failure or product trouble, use a servomotor with magnetic brakes or install an external brake mechanism.
- ⚠ Use a double circuit configuration that allows the operation circuit for the magnetic brakes to be operated even by the external emergency stop signal.
- Always turn the main circuit power of the motor OFF when an alarm occurs.
- ⚠ If an alarm occurs, remove the cause, and secure the safety before resetting the alarm.



⚠ CAUTION

(6) Maintenance, inspection and part replacement

- Always backup the programs and parameters before starting maintenance or inspections.
- ⚠ The capacity of the electrolytic capacitor will drop over time due to self-discharging, etc. To prevent secondary disasters due to failures, replacing this part every five years when used under a normal environment is recommended. Contact the Service Center, Service Station, Sales Office or delayer for repairs or part replacement.
- ⚠ Do not perform a megger test (insulation resistance measurement) during inspections.
- If the battery low warning is issued, back up the machining programs, tool data and parameters with an input/output unit, and then replace the battery.
- ⚠ Do not short circuit, charge, overheat, incinerate or disassemble the battery.
- For after-purchase servicing of the built-in motor (including the detector), supplies of servicing parts and repairs can only be offered.
- For maintenance, part replacement, and services in case of failures in the built-in motor (including the detector), take necessary actions at your end. For spindle drive unit, Mitsubishi can offer the after-purchase servicing as with the general spindle drive unit.
- Mhen a failure has occurred in the built-in motor (including the detector), some period of time can be required to supply the servicing parts or repair. Prepare the spare parts at your end whenever possible.

(7) Disposal

- ⚠ Take the batteries and backlights for LCD, etc., off from the controller, drive unit and motor, and dispose of them as general industrial wastes.
- ⚠ Do not disassemble the unit or motor.
- ⚠ Dispose of the battery according to local laws.
- Always return the secondary side (magnet side) of the linear servomotor to the Service Center or Service Station.
- Mhen incinerating optical communication cable, hydrogen fluoride gas or hydrogen chloride gas which is corrosive and harmful may be generated. For disposal of optical communication cable, request for specialized industrial waste disposal services that has incineration facility for disposing hydrogen fluoride gas or hydrogen chloride gas.

(8) Transportation

- ⚠ The unit and motor are precision parts and must be handled carefully.
- According to a United Nations Advisory, the battery unit and battery must be transported according to the rules set forth by the International Civil Aviation Organization (ICAO), International Air Transportation Association (IATA), International Maritime Organization (IMO), and United States Department of Transportation (DOT), etc.

(9) General precautions

The drawings given in this manual show the covers and safety partitions, etc., removed to provide a clearer explanation. Always return the covers or partitions to their respective places before starting operation, and always follow the instructions given in this manual.

Treatment of waste

The following two laws will apply when disposing of this product. Considerations must be made to each law. The following laws are in effect in Japan. Thus, when using this product overseas, the local laws will have a priority. If necessary, indicate or notify these laws to the final user of the product.

- (1) Requirements for "Law for Promotion of Effective Utilization of Resources"
 - (a) Recycle as much of this product as possible when finished with use.
 - (b) When recycling, often parts are sorted into steel scraps and electric parts, etc., and sold to scrap contractors. Mitsubishi recommends sorting the product and selling the members to appropriate contractors.
- (2) Requirements for "Law for Treatment of Waste and Cleaning"
 - (a) Mitsubishi recommends recycling and selling the product when no longer needed according to item (1) above. The user should make an effort to reduce waste in this manner.
 - (b) When disposing a product that cannot be resold, it shall be treated as a waste product.
 - (c) The treatment of industrial waste must be commissioned to a licensed industrial waste treatment contractor, and appropriate measures, including a manifest control, must be taken.
 - (d) Batteries correspond to "primary batteries", and must be disposed of according to local disposal laws.

Disposal



(Note) This symbol mark is for EU countries only.

This symbol mark is according to the directive 2006/66/EC Article 20 Information for endusers and Annex II.

Your MITSUBISHI ELECTRIC product is designed and manufactured with high quality materials and components which can be recycled and/or reused.

This symbol means that batteries and accumulators, at their end-of-life, should be disposed of separately from your household waste.

If a chemical symbol is printed beneath the symbol shown above, this chemical symbol means that the battery or accumulator contains a heavy metal at a certain concentration. This will be indicated as follows:

Hg: mercury (0,0005%), Cd: cadmium (0,002%), Pb: lead (0,004%)

In the European Union there are separate collection systems for used batteries and accumulators. Please, dispose of batteries and accumulators correctly at your local community waste collection/recycling centre.

Please, help us to conserve the environment we live in!

本製品の取扱いについて

(日本語 /Japanese)

本製品は工業用 (クラス A) 電磁環境適合機器です。販売者あるいは使用者はこの点に注意し、住商業環境以外での使用をお願いいたします。

Handling of our product

(English)

This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

본 제품의 취급에 대해서

(한국어 /Korean)

이 기기는 업무용 (A 급) 전자파적합기기로서 판매자 또는 사용자는 이 점을 주의하시기 바라며 가정외의 지역에서 사용하는 것을 목적으로 합니다.

Contents

1	Introduction1	-	1
	1-1 Servo/spindle drive system configuration	1 -	- 2
	1-1-1 System configuration		
	1-2 Explanation of type		
	1-2-1 Servomotor type		
	1-2-2 Servo drive unit type		
	1-2-3 Spindle motor type		
	1-2-4 Tool spindle motor type		
	1-2-5 Spindle drive unit type		
	1-2-6 Power supply unit type		
	1-2-7 AC reactor type		
2	Specifications2	2 -	1
	2-1 Servomotor		
	2-1-1 Specifications list		
	2-1-2 Torque characteristics		
	2-2 Spindle motor		
	2-2-1 Specifications		
	2-2-2 Output characteristics	. 2 - 3	35
	2-3 Tool spindle motor	. 2 - 4	44
	2-3-1 Specifications	. 2 - 4	44
	2-3-2 Output characteristics	. 2 - 4	48
	2-4 Drive unit	. 2 - :	50
	2-4-1 Installation environment conditions	. 2 -	50
	2-4-2 Servo drive unit	. 2 - :	51
	2-4-3 Spindle drive unit	. 2 - :	53
	2-4-4 Power supply unit	. 2 - :	55
	2-4-5 Unit outline dimension drawing	. 2 - !	56
	2-4-6 AC reactor	. 2 - !	57
	2-4-7 Explanation of each part		
3	Function Specifications3	3 -	1
	Function specifications list	3 -	- 2
	3-1 Base control functions	3 -	- 5
	3-1-1 Full closed loop control	3 -	- 5
	3-1-2 Position command synchronous control		
	3-1-3 Speed command synchronous control		
	3-1-4 Distance-coded reference position control		
	3-1-5 Spindle's continuous position loop control		
	3-1-6 Coil changeover control		
	3-1-7 Gear changeover control		
	3-1-8 Orientation control		
	3-1-9 Indexing control		
	3-1-10 Synchronous tapping control		
	3-1-11 Spindle synchronous control		
	3-1-12 Spindle/C axis control		
	3-1-13 Proximity switch orientation control		
	3-1-14 Power regeneration control		
	3-1-15 Resistor regeneration control		
	3-2 Servo/Spindle control functions		
	3-2-1 Torque limit function		

	3-2-2 Variable speed loop gain control	;	3 -	- 9
	3-2-3 Gain changeover for synchronous tapping control	;	3 .	- 9
	3-2-4 Speed loop PID changeover control			
	3-2-5 Disturbance torque observer			
	3-2-6 Smooth High Gain control (SHG control)			
	3-2-7 High-speed synchronous tapping control (OMR-DD control)			
	3-2-8 Dual feedback control	. ૩ ૩	_	11
	3-2-9 HAS control			
	3-2-10 Control loop gain changeover			
	3-2-11 Spindle output stabilizing control			
	3-2-12 High-response spindle acceleration/deceleration function			
	3-3 Compensation control function			
	3-3-1 Jitter compensation			
	3-3-2 Notch filter			
	3-3-3 Adaptive tracking-type notch filter			
	3-3-4 Overshooting compensation			
	3-3-5 Machine end compensation control			
	3-3-6 Lost motion compensation type 2			
	3-3-7 Lost motion compensation type 3			
	3-3-8 Lost motion compensation type 4	. 3	-	16
	3-3-9 Spindle motor temperature compensation function			
	3-4 Protection function			
	3-4-1 Deceleration control at emergency stop			
	3-4-2 Vertical axis drop prevention/pull-up control			
	3-4-3 Earth fault detection			
	3-4-4 Collision detection function			
	3-4-5 Safety observation function			
	3-4-6 Fan stop detection			
	3-4-7 Open-phase detection			
	3-4-8 Contactor weld detection			
	3-5 Sequence functions			
	3-5-1 Contactor control function.			
	3-5-2 Motor brake control function			
	3-5-3 External emergency stop function			
	3-5-4 Specified speed output			
	3-5-5 Quick READY ON sequence			
	3-6 Diagnosis function			
	3-6-1 Monitor output function			
	3-6-2 Machine resonance frequency display function			
	3-6-3 Machine inertia display function			
	3-6-4 Motor temperature display function			
	3-6-5 Load monitor output function			
	3-6-6 Open loop control function			
	3-6-7 Power supply voltage display function	. 3	- 1	27
4	Characteristics	L.	_	1
•				•
	4-1 Servomotor	4	4 .	- 2
	4-1-1 Environmental conditions			
	4-1-2 Quakeproof level			
	4-1-3 Shaft characteristics			
	4-1-4 Machine accuracy			
	4-1-5 Oil / water standards			
	4-1-6 Installation of servo motor			
	4-1-7 Overload protection characteristics			
	4-1-8 Magnetic brake			
	4-1-9 Dynamic brake characteristics			
	4-2 Spindle motor			
	4-2-1 Environmental conditions			
	4-2-2 Shaft characteristics	. 4	-	22

	4-2-3 Machine accuracy	4 - 23
	4-2-4 Installation of spindle motor	4 - 23
	4-3 Tool spindle motor	4 - 24
	4-3-1 Environmental conditions	
	4-3-2 Shaft characteristics	
	4-3-3 Tool spindle temperature characteristics	
	4-4 Drive unit	
	4-4-1 Environmental conditions	
	4-4-2 Heating value	
	4-4-3 Drive unit arrangement	4 - 28
_		- 4
5	Dedicated Options	5 - 1
	-	
	5-1 Servo options	
	5-1-1 Dynamic brake unit (MDS-D-DBU)	
	5-1-2 Battery option (ER6V-C119B, A6BAT, MDS-A-BT, MDS-BTBOX-36)	
	5-1-3 Ball screw side detector (OSA105-ET2, OSA166-ET2N)	
	5-1-4 Machine side detector	
	5-2 Spindle options	
	5-2-1 Spindle side ABZ pulse output detector (OSE-1024 Series)	
	5-2-2 Spindle side PLG serial output detector (TS5690, MU1606 Series)	
	5-2-3 Spindle side accuracy serial output detector (ERM280, MPCI Series)	
	5-3 Detector interface unit	
	5-3-1 Serial output interface unit for ABZ analog detector MDS-B-HR	
	5-3-2 Serial signal division unit MDS-B-SD	5 - 36
	5-3-3 Pulse output interface unit for ABZ analog detector IBV Series	
	(Other manufacturer's product)	5 - 38
	5-3-4 Serial output interface unit for ABZ analog detector EIB192M	
	(Other manufacturer's product)	5 - 39
	5-3-5 Serial output interface unit for ABZ analog detector EIB392M	
	(Other manufacturer's product)	5 - 40
	5-3-6 Serial output interface unit for ABZ analog detector ADB-20J Series	
	(Other manufacturer's product)	
	5-4 Drive unit option	
	5-4-1 Optical communication repeater unit (FCU7-EX022)	
	5-4-2 DC connection bar	
	5-4-3 Side protection cover	
	5-5 Cables and connectors	
	5-5-1 Cable connection diagram	
	5-5-2 List of cables and connectors	
	5-5-3 Optical communication cable specifications	5 - 57
C	Chariffestions of Davinhard Davings	6 4
O	Specifications of Peripheral Devices	6 - 1
	6-1 Selection of wire	6 0
	6-1-1 Example of wires by unit	
	6-2 Selection of circuit protector and contactor	
	6-2-1 Selection of circuit protector	
	6-2-2 Selection of contactor	
	6-3 Selection of earth leakage breaker	
	6-4 Branch-circuit protection (for control power supply)	
	6-4-1 Circuit protector	
	6-4-2 Fuse protection	
	6-5 Noise filter	
	6-6 Surge absorber	
	6-7 Relay	6 - 14

7 Selection	7 - 1
7-1 Selection of the servomotor	7 - 2
7-1-1 Outline	
7-1-2 Selection of servomotor capacity	7 - 3
7-1-3 Motor shaft conversion load torque	7 - 11
7-1-4 Expressions for load inertia calculation	7 - 12
7-2 Selection of the spindle motor	7 - 13
7-3 Selection of the power supply unit	7 - 14
7-3-1 Calculation of spindle output	7 - 14
7-3-2 Calculation of servo motor output	7 - 16
7-3-3 Selection of the power supply unit	7 - 17
7-3-4 Required capacity of power supply	7 - 19
7-3-5 Example for power supply unit and power supply facility capacity	7 - 20
Appendix 1 Cable and Connector Specifications	S
Appe	ndix 1 - 1
Appendix 1-1 Selection of cable	
Appendix 1-1-1 Cable wire and assembly	
Appendix 1-2 Cable connection diagram	Appendix 1 - 4
Appendix 1-2-1 Battery cable	
Appendix 1-2-2 Power supply communication cable and connector	
Appendix 1-2-3 Optical communication repeater unit cable	
Appendix 1-2-4 Servo / tool spindle detector cable	
Appendix 1-2-5 Brake connector (Brake connector for motor brake control output)	
Appendix 1-2-6 Spindle detector cable	
Appendix 1-3 Main circuit cable connection diagram	
Appendix 1-4 Connector outline dimension drawings	
Appendix 1-4-1 Connector for drive unit	
Appendix 1-4-2 Connector for servo and tool spindle	
Appendix 1-4-3 Connector for spindle	Appendix 1 - 25
Appendix 2 Restrictions for Lithium Batteries	
Appe	ndix 2 - 1
Appendix 2-1 Restriction for Packing	
Appendix 2-1-1 Target Products	
Appendix 2-1-2 Handling by User	
Appendix 2-1-3 Reference	
Appendix 2-2 Products information data sheet (ER battery)	
Appendix 2-3 Issuing Domestic Law of the United States for Primary Lithium Battery	
Transportation	
Appendix 2-3-1 Outline of Regulation	
Appendix 2-3-2 Target Products	
Appendix 2-3-3 Handling by User	
Appendix 2-3-4 Reference	
Appendix 2-4 Restriction related to EU Battery Directive	• •
Appendix 2-4-1 Important Notes	
Appendix 3 Compliance to EC DirectivesAppe	ndix 3 - 1
Appendix 3-1 Compliance to EC Directives	
Appendix 3-1-1 European EC Directives	
Appendix 3-1-2 Cautions for EC Directive compliance	

Appendix 4 EMC Installation Guidelines Appe	
Appendix 4-1 Introduction	Appendix 4 - 2
Appendix 4-2 EMC instructions	
Appendix 4-3 EMC measures	
Appendix 4-4 Measures for panel structure	Appendix 4 - 3
Appendix 4-4-1 Measures for control panel unit	Appendix 4 - 3
Appendix 4-4-2 Measures for door	
Appendix 4-4-3 Measures for operation board panel	
Appendix 4-4-4 Shielding of the power supply input section	
Appendix 4-5 Measures for various cables	
Appendix 4-5-1 Measures for wiring in panel	
Appendix 4-5-2 Measures for shield treatment	
Appendix 4-5-3 Servo/spindle motor power cable	
Appendix 4-5-4 Servo/spindle motor feedback cable	
Appendix 4-6 EMC countermeasure parts	
Appendix 4-6-1 Shield clamp fitting	
Appendix 4-6-2 Ferrite core	
Appendix 4-6-3 Power line filter	
Appendix 4-6-4 Surge protector	Appendix 4 - 15
Appendix 5 EC Declaration of Conformity	
Appe	ndix 5 - 1
Appendix 5-1 Compliance to EC Directives	Appendix 5 - 2
Appendix 5-1-1 Low voltage equipment	
with UL/c-UL StandardAppe	
Appendix 6-1 Operation surrounding air ambient temperature	Appendix 6 - 2
Appendix 6-1 Operation surrounding air ambient temperature	Appendix 6 - 2 Appendix 6 - 2
Appendix 6-1 Operation surrounding air ambient temperature	Appendix 6 - 2 Appendix 6 - 2 Appendix 6 - 2
Appendix 6-1 Operation surrounding air ambient temperature	Appendix 6 - 2 Appendix 6 - 2 Appendix 6 - 2 Appendix 6 - 2
Appendix 6-1 Operation surrounding air ambient temperature	Appendix 6 - 2 Appendix 6 - 2 Appendix 6 - 2 Appendix 6 - 2 Appendix 6 - 2
Appendix 6-1 Operation surrounding air ambient temperature	Appendix 6 - 2 Appendix 6 - 2
Appendix 6-1 Operation surrounding air ambient temperature	Appendix 6 - 2 Appendix 6 - 3
Appendix 6-1 Operation surrounding air ambient temperature Appendix 6-2 Notes for AC servo/spindle system Appendix 6-2-1 General Precaution Appendix 6-2-2 Installation Appendix 6-2-3 Short-circuit ratings (SCCR) Appendix 6-2-4 Peripheral devices Appendix 6-2-5 Field Wiring Reference Table for Input and Output (Power Wiring) Appendix 6-2-6 Motor Over Load Protection	Appendix 6 - 2 Appendix 6 - 3 Appendix 6 - 3
Appendix 6-1 Operation surrounding air ambient temperature	Appendix 6 - 2 Appendix 6 - 3 Appendix 6 - 6 Appendix 6 - 6
Appendix 6-1 Operation surrounding air ambient temperature	Appendix 6 - 2 Appendix 6 - 3 Appendix 6 - 6 Appendix 6 - 6 Appendix 6 - 6
Appendix 6-1 Operation surrounding air ambient temperature	Appendix 6 - 2 Appendix 6 - 3 Appendix 6 - 6 Appendix 6 - 6 Appendix 6 - 7 Appendix 6 - 7
Appendix 6-1 Operation surrounding air ambient temperature	Appendix 6 - 2 Appendix 6 - 3 Appendix 6 - 6 Appendix 6 - 6 Appendix 6 - 7 Appendix 6 - 7 Appendix 6 - 7 Appendix 6 - 7 Appendix 6 - 8
Appendix 6-1 Operation surrounding air ambient temperature	Appendix 6 - 2 Appendix 6 - 3 Appendix 6 - 6 Appendix 6 - 6 Appendix 6 - 7 Appendix 6 - 7 Appendix 6 - 7 Appendix 6 - 8 Appendix 6 - 8
Appendix 6-1 Operation surrounding air ambient temperature	Appendix 6 - 2 Appendix 6 - 3 Appendix 6 - 6 Appendix 6 - 6 Appendix 6 - 7 Appendix 6 - 7 Appendix 6 - 7 Appendix 6 - 8 Appendix 6 - 8 Appendix 6 - 8
Appendix 6-1 Operation surrounding air ambient temperature	Appendix 6 - 2 Appendix 6 - 3 Appendix 6 - 6 Appendix 6 - 6 Appendix 6 - 7 Appendix 6 - 7 Appendix 6 - 8 Appendix 6 - 8 Appendix 6 - 8 Appendix 6 - 8
Appendix 6-1 Operation surrounding air ambient temperature	Appendix 6 - 2 Appendix 6 - 3 Appendix 6 - 6 Appendix 6 - 6 Appendix 6 - 7 Appendix 6 - 7 Appendix 6 - 7 Appendix 6 - 8 Appendix 6 - 8 Appendix 6 - 8
Appendix 6-1 Operation surrounding air ambient temperature	Appendix 6 - 2 Appendix 6 - 3 Appendix 6 - 6 Appendix 6 - 6 Appendix 6 - 7 Appendix 6 - 7 Appendix 6 - 8 Appendix 7 - 1 Appendix 7 - 1
Appendix 6-1 Operation surrounding air ambient temperature	Appendix 6 - 2 Appendix 6 - 3 Appendix 6 - 6 Appendix 6 - 6 Appendix 6 - 7 Appendix 6 - 7 Appendix 6 - 8 Appendix 7 - 1 Appendix 7 - 2 Appendix 7 - 2 Appendix 7 - 2
Appendix 6-1 Operation surrounding air ambient temperature Appendix 6-2 Notes for AC servo/spindle system	Appendix 6 - 2 Appendix 6 - 3 Appendix 6 - 6 Appendix 6 - 6 Appendix 6 - 7 Appendix 6 - 7 Appendix 6 - 8 Appendix 7 - 2
Appendix 6-1 Operation surrounding air ambient temperature Appendix 6-2 Notes for AC servo/spindle system	Appendix 6 - 2 Appendix 6 - 3 Appendix 6 - 6 Appendix 6 - 6 Appendix 6 - 7 Appendix 6 - 7 Appendix 6 - 8 Appendix 7 - 2 Appendix 7 - 3
Appendix 6-1 Operation surrounding air ambient temperature Appendix 6-2 Notes for AC servo/spindle system	Appendix 6 - 2 Appendix 6 - 6 Appendix 6 - 6 Appendix 6 - 6 Appendix 6 - 7 Appendix 6 - 7 Appendix 6 - 8 Appendix 7 - 2 Appendix 7 - 2 Appendix 7 - 2 Appendix 7 - 2 Appendix 7 - 3 Appendix 7 - 3 Appendix 7 - 3 Appendix 7 - 3

Appendix 7-2 Response to the China environment restrictions	Appendix 7 - 6
Appendix 7-2-1 Outline of the law on the pollution prevention and control	
for electronic information products	Appendix 7 - 6
Appendix 7-2-2 Response to the drive product for Mitsubishi NC	Appendix 7 - 6
Appendix 7-2-3 Indication based on "Pollution suppression marking request	
for electronic information product"	Appendix 7 - 7

Outline for MDS-D/DH Series Instruction Manual (IB-1500025-H)

1 Installation

- 1-1 Installation of servomotor
 - 1-1-1 Environmental conditions
 - 1-1-2 Quakeproof level
 - 1-1-3 Cautions for mounting load (prevention of impact on shaft)
 - 1-1-4 Installation direction
 - 1-1-5 Shaft characteristics
 - 1-1-6 Machine accuracy
 - 1-1-7 Coupling with the load
 - 1-1-8 Oil/water standards
 - 1-1-9 Installation of servomotor
 - 1-1-10 Cable stress
- 1-2 Installation of spindle motor
 - 1-2-1 Environmental conditions
 - 1-2-2 Cautions for mounting fittings
 - 1-2-3 Shaft characteristics
 - 1-2-4 Machine accuracy
 - 1-2-5 Coupling with the fittings
 - 1-2-6 Ambient environment
 - 1-2-7 Installation of spindle motor
 - 1-2-8 Connection
 - 1-2-9 Cable stress
- 1-3 Installation of tool spindle motor
 - 1-3-1 Environmental conditions
 - 1-3-2 Shaft characteristics
- 1-4 Installation of the drive unit
 - 1-4-1 Environmental conditions
 - 1-4-2 Installation direction and clearance
 - 1-4-3 Prevention of entering of foreign matter
 - 1-4-4 Panel installation hole work drawings (Panel cut drawings)
 - 1-4-5 Heating value
 - 1-4-6 Heat radiation countermeasures
- 1-5 Installation of the spindle detector
 - 1-5-1 Spindle side ABZ pulse output detector (OSE-1024 Series)
 - 1-5-2 Spindle side PLG serial output detector (TS5690, MU1606 Series)
 - 1-5-3 Installation accuracy diagnosis for PLG detector
- 1-6 Noise measures

2 Wiring and Connection

- 2-1 Part system connection diagram
- 2-2 Main circuit terminal block/control circuit connector
 - 2-2-1 Names and applications of main circuit terminal block signals and control circuit connectors
 - 2-2-2 Connector pin assignment
- 2-3 NC and drive unit connection
- 2-4 Connecting with optical communication repeater unit
- 2-5 Motor and detector connection

- 2-5-1 Connection of the servomotor
- 2-5-2 Connection of the full-closed loop system
- 2-5-3 Connection of the speed command synchronization control system
- 2-5-4 Connection of the spindle motor
- 2-5-5 Connection of tool spindle motor
- 2-6 Connection of power supply
 - 2-6-1 Power supply input connection
 - 2-6-2 Connecting the grounding cable
- 2-7 Wiring of the motor brake
 - 2-7-1 Wiring of the motor magnetic brake
 - 2-7-2 Dynamic brake unit wiring
- 2-8 Peripheral control wiring
 - 2-8-1 Input/output circuit wiring
 - 2-8-2 Wiring of an external emergency stop
 - 2-8-3 Safety observation function
 - 2-8-4 Specified speed output
 - 2-8-5 Spindle coil changeover
 - 2-8-6 Specifications of proximity switch

3 Setup

- 3-1 Initial setup
 - 3-1-1 Setting the rotary switch
 - 3-1-2 Setting DIP switch
 - 3-1-3 Transition of LED display after power is turned ON
- 3-2 Setting the initial parameters for the servo drive unit
 - 3-2-1 Setting of servo specification parameters
 - 3-2-2 Setting of machine side detector
 - 3-2-3 Setting of distance-coded reference scale
 - 3-2-4 Setting of speed command synchronous control
 - 3-2-5 List of standard parameters for each servomotor
 - 3-2-6 Servo parameters
- 3-3 Setting the initial parameters for the spindle drive
 - 3-3-1 Setting of parameters related to the spindle
 - 3-3-2 List of standard parameters for each spindle motor
 - 3-3-3 Spindle specification parameters
 - 3-3-4 Spindle parameters

4 Servo Adjustment

- 4-1 D/A output specifications for servo drive unit
 - 4-1-1 D/A output specifications
 - 4-1-2 Output data settings
 - 4-1-3 Setting the output magnification
- 4-2 Servo adjustment procedure
- 4-3 Gain adjustment
 - 4-3-1 Current loop gain
 - 4-3-2 Speed loop gain
 - 4-3-3 Position loop gain
- 4-4 Characteristics improvement
 - 4-4-1 Optimal adjustment of cycle time
 - 4-4-2 Vibration suppression measures
 - 4-4-3 Improving the cutting surface precision
 - 4-4-4 Improvement of characteristics during

acceleration/deceleration

4-4-5 Improvement of protrusion at quadrant changeover

4-4-6 Improvement of overshooting

4-4-7 Improvement of the interpolation control path

4-5 Adjustment during full closed loop control

4-5-1 Outline

4-5-2 Speed loop delay compensation

4-5-3 Dual feedback control

4-6 Settings for emergency stop

4-6-1 Deceleration control

4-6-2 Vertical axis drop prevention control

4-6-3 Vertical axis pull-up control

4-7 Protective functions

4-7-1 Overload detection

4-7-2 Excessive error detection

4-7-3 Collision detection function

4-8 Servo control signal

4-8-1 Servo control input (NC to Servo)

4-8-2 Servo control output (Servo to NC)

5 Spindle Adjustment

5-1 D/A output specifications for spindle drive unit

5-1-1 D/A output specifications

5-1-2 Setting the output data

5-1-3 Setting the output magnification

5-2 Adjustment procedures for each control

5-2-1 Basic adjustments

5-2-2 Gain adjustment

5-2-3 Adjusting the acceleration/deceleration operation

5-2-4 Orientation adjustment

5-2-5 Synchronous tapping adjustment

5-2-6 High-speed synchronous tapping

5-2-7 Spindle C axis adjustment (For lathe system)

5-2-8 Spindle synchronization adjustment (For lathe system)

5-2-9 Deceleration coil changeover valid function by emergency stop

5-2-10 High-response acceleration/deceleration function

5-2-11 Spindle cutting withstand level improvement

5-3 Settings for emergency stop

5-3-1 Deceleration control

5-4 Spindle control signal

5-4-1 Spindle control input (NC to Spindle)

5-4-2 Spindle control output (Spindle to NC)

6 Troubleshooting

6-1 Points of caution and confirmation

6-1-1 LED display when alarm or warning occurs

6-2 Protective functions list of units

6-2-1 List of alarms

6-2-2 List of warnings

6-3 Troubleshooting

6-3-1 Troubleshooting at power ON

6-3-2 Troubleshooting for each alarm No.

6-3-3 Troubleshooting for each warning No.

6-3-4 Parameter numbers during initial parameter error

6-3-5 Troubleshooting the spindle system when there is no alarm or warning

7 Maintenance

7-1 Periodic inspections

7-1-1 Inspections

7-1-2 Cleaning of spindle motor

7-2 Service parts

7-3 Adding and replacing units and parts

7-3-1 Replacing the drive unit

7-3-2 Replacing the unit fan

7-3-3 Replacing the battery

7-3-4 Replacing the fuse

Appendix 1 Cable and Connector Specifications

Appendix 1-1 Selection of cable

Appendix 1-1-1 Cable wire and assembly

Appendix 1-2 Cable connection diagram

Appendix 1-2-1 Battery cable

Appendix 1-2-2 Power supply communication cable and connector

Appendix 1-2-3 Optical communication repeater unit cable

Appendix 1-2-4 Servo / tool spindle detector cable

Appendix 1-2-5 Brake connector (Brake connector for motor brake control output)

Appendix 1-2-6 Spindle detector cable

Appendix 1-3 Main circuit cable connection diagram

Appendix 1-4 Connector outline dimension drawings

Appendix 1-4-1 Connector for drive unit

Appendix 1-4-2 Connector for servo and tool spindle

Appendix 1-4-3 Connector for spindle

Appendix 2 Cable and Connector Assembly

Appendix 2-1 CM10-SPxxS-x(D6) plug connector

Appendix 2-2 CM10-APxxS-x(D6) angle plug connector

Appendix 2-3 CM10-SP-CV reinforcing cover for straight plug

Appendix 2-4 CM10-AP-D-CV reinforcing cover for angle plug

Appendix 2-5 1747464-1 plug connector

Appendix 2-5-1 Applicable products

Appendix 2-5-2 Applicable cable

Appendix 2-5-3 Related documents

Appendix 2-5-4 Assembly procedure

Appendix 3 Precautions in Installing Spindle Motor

Appendix 3-1 Precautions in transporting motor

- Appendix 3-2 Precautions in selecting motor fittings
- Appendix 3-3 Precautions in mounting fittings
- Appendix 3-4 Precautions in coupling shafts
- Appendix 3-5 Precautions in installing motor in machine
- Appendix 3-6 Other Precautions
- Appendix 3-7 Example of unbalance correction
- Appendix 3-8 Precautions in balancing of motor with key

Appendix 4 Compliance to EC Directives

Appendix 4-1 Compliance to EC Directives

Appendix 4-1-1 European EC Directives

Appendix 4-1-2 Cautions for EC Directive

compliance

Appendix 5 EMC Installation Guidelines

Appendix 5-1 Introduction

Appendix 5-2 EMC instructions

Appendix 5-3 EMC measures

Appendix 5-4 Measures for panel structure

Appendix 5-4-1 Measures for control panel unit

Appendix 5-4-2 Measures for door

Appendix 5-4-3 Measures for operation board panel

Appendix 5-4-4 Shielding of the power supply input section

Appendix 5-5 Measures for various cables

Appendix 5-5-1 Measures for wiring in panel

Appendix 5-5-2 Measures for shield treatment

Appendix 5-5-3 Servo/spindle motor power cable

Appendix 5-5-4 Servo/spindle motor feedback cable

Appendix 5-6 EMC countermeasure parts

Appendix 5-6-1 Shield clamp fitting

Appendix 5-6-2 Ferrite core

Appendix 5-6-3 Power line filter

Appendix 5-6-4 Surge protector

Appendix 6 EC Declaration of Conformity

Appendix 6-1 Compliance to EC Directives Appendix 6-1-1 Low voltage equipment

Appendix 7 Higher Harmonic Suppression Measure Guidelines

Appendix 7-1 Higher harmonic suppression measure guidelines


Appendix 7-1-1 Calculating the equivalent capacity of the higher harmonic generator

Introduction

1 Introduction


1-1 Servo/spindle drive system configuration

1-1-1 System configuration




1-2 Explanation of type

1-2-1 Servomotor type




Motor rating nameplate


(1) 200V series < HF Series >



< HP Series >




< HF-KP Series >




1 Introduction

(2) 400V series


< HF-H Series>




< HP-H Series >



< HC-H Series >



1-2-2 Servo drive unit type




Rating nameplate

- (1) 200V series
 - < MDS-D Series >
 - (a) 1-axis servo drive unit

MDS	-D-	(1)																													
(1) Unit Ty	pe	Compatible		HF□												HP□															
MDS-D		motor type	75	105	54	104	154	224	204	354	123	223	303	453	703	903	142	302	54	104	154	224	204	354	454	704	903	1103	23	43	73
	Unit width	Stall torque Unit nominal (N·m) maximum current	2.0	3.0	2.9	5.9	9.0	12.0	13.7	22.5	7.0	12.0	22.5	37.2	49.0	58.8	11.0	20.0	3.0	5.9	9.0	12.0	13.7	22.5	31.9	49.0	70.0	110.0	0.64	1.3	2.4
V1-20		20A	•	•							•						•												•	•	•
V1-40		40A			•	•						•						•	•	•											\Box
V1-80	60mm	80A					•	•	•				•								•	•	•								
V1-160		160A								•				•										•	•						
V1-160W	90mm	160A													•											•					
V1-320	120mm	320A														•											•				
V1-320W	150mm	320A																										•			

[•] Indicates the compatible motor for each servo drive unit.

(b) 2-axis servo drive unit



Indicates the compatible motor for each servo drive unit.

CAUTION!

The dynamic brake unit (MDS-D-DBU) is required for the MDS-D-V1-320W.

1 Introduction

- (2) 400V series
 - < MDS-DH Series >
 - (a) 1-axis servo drive unit

MDS-DH- (1)

(1) Unit typ		Compatible motor type					HF-H	10									HP-	НП					HC-H□
MDS-DF	1	Companie motor type	75	105	54	104	154	204	354	453	703	903	54	104	154	224	204	354	454	704	903	1103	1502S-S10
	Unit width	Stall torque Unit nominal (N·m) maximum current		3.0	2.9	5.9	9.0	13.7	22.5	37.2	49.0	58.8	3.0	5.9	9.0	12.0	13.7	22.5	31.9	49.0	70.0	110.0	146.0
V1-10		10A	•	•																			
V1-20	60mm	20A			•	•							•	•									
V1-40	OUTITI	40A					•	•							•	•	•						
V1-80		80A							•	•								•	•				
V1-80W	90mm	80A									•									•			
V1-160	120mm	160A										•									•		
V1-160W	150mm	160A																				•	
V1-200	240mm (Note)	200A																					•

[•] Indicates the compatible motor for each servo drive unit.

(Note) DC connection bar is required. Always install a large capacity drive unit in the left side of power supply unit, and connect with DC connection bar.

(b) 2-axis servo drive unit

MDS-DH- (1)


(1) Unit typ			Compatible motor					HF-H	10									HF	P-H_				
MDS-DH			type	75	105	54	104	154	204	354	453	703	903	54	104	154	224	204	354	454	704	903	1103
	Unit width	Unit nominal maximum current	Stall torque (N·m) Axis		3.0	2.9	5.9	9.0	13.7	22.5	37.2	49.0	58.8	3.0	5.9	9.0	12.0	13.7	22.5	31.9	49.0	70.0	110.0
V2-1010		10+10A	LM	•	•																		
V2-2010		20+10A	L			•	•							•	•								
V2-2010		201104	М	•	•																		
V2-2020	60mm	20+20A	LM			•	•							•	•								
V2-4020		40+20A	L					•	•							•	•	•					
V2-4020		40+20A	М			•	•							•	•								
V2-4040	1	40+40A	LM					•	•							•	•	•					
V2-8040	\vdash	80+40A	L							•	•								•	•			
v2-0040	90mm	00+40A	М					•	•							•	•	•					
V2-8080	1	80+80A	LM							•	•								•	•			
V2-8080W	120mm	80+80A	LM							•	•	•							•	•	•		

[•] Indicates the compatible motor for each servo drive unit.

CAUTION!

The dynamic brake unit (MDS-D-DBU) is required for the MDS-DH-V1-160W and MDS-DH-V1-200.


1-2-3 Spindle motor type



Rating nameplate


(1) 200V series

< SJ-D Series >



(Note) This explains the model name system of a spindle motor, and all combinations of motor types listed above do not exist.

< SJ-V Series >




(Note 1) The built-in spindle motor is available by special order.

(Note 2) This explains the model name system of a spindle motor, and all combinations of motor types listed above do not exist.

1 Introduction

(2) 400V series


< SJ-V Series >



(Note 1) The built-in spindle motor is available by special order.


(Note 2) This explains the model name system of a spindle motor, and all combinations of motor types listed above do not exist.

1-2-4 Tool spindle motor type




Rating nameplate


(1) 200V series <HF-KP Series>



<HF-SP Series>



<HF Series>



1 Introduction

< Combination with spindle drive unit >

(a) 1-axis spindle drive unit

Unit Type		Compatible							HF	· 🗆								HF-KP[HF-S	3P□
MDS-D-		motor type	75	105	54	104	154	224	204	354	123	223	303	453	703	903	46	56	96	226	406
	Unit width	Rated torque (N·m)		2.4	1.6	3.2	4.8	7.0	6.4	11.1	5.7	10.5	14.3	37.2	49.0	58.8	0.64	0.8	1.43	3.5	6.37
SP-20		20 A	•	•							•						•	•	•		
SP-40	60mm	40 A			•	•						•									
SP-80		80 A					•	•	•				•							•	
SP-160	90mm	160 A								•				•	•						•
SP-200	120mm	200 A																			
SP-240	150mm	240 A																			
SP-320	13011111	320 A														•					
SP-400	240mm	400 A																			
SP-640	300mm	640 A																			

[•] Indicates the compatible motor for each spindle drive unit.


(b) 2-axis spindle drive unit

Unit Type			Compatible							HF[]								HF-KP[HF-	
MDS-D-			motor type	75	105	54	104	154	224	204	354	123	223	303	453	703	46	56	96	226	406
	Unit width	Rated output	Rated torque (N·m)	1.8	2.4	1.6	3.2	4.8	7.0	6.4	22.5	5.7	10.5	14.3	14.3	22.3	0.64	0.8	1.43	3.5	6.37
SP2-2020		20+20A	LM	•	•							•					•	•	•		Г
SP2-4020	60mm	40+20A	L			•	•						•								
3F 2-4020	Oomin		M	•	•							•					•	•	•		
SP2-4040S		40+40A	LM			•	•						•								
SP2-4040		40+40A	LM			•	•						•								
SP2-8040		80+40A	L					•	•	•				•						•	
01 2 00-10	90mm	001407	M			•	•						•								
SP2-16080S		160±80∆	L								•				•	•					•
3F 2-100003		160+80A	M					•	•	•				•						•	
SP2-8080		80+80A	LM					•	•	•				•						•	
SP2-16080	120mm	160+80A	L								•				•	•					•
5. 2 10000		10010074	M					•	•	•				•						•	

[•] Indicates the compatible motor for each spindle drive unit.

(Note) A 2-axis spindle drive unit (MDS-D-SP2) drives two tool spindle motors only. A spindle motor other than tool spindle motor is not usable.

1-2-5 Spindle drive unit type



Rating nameplate

(1) 200V series

< MDS-D Series >

MDS-D-


(a) 1-axis spindle drive unit

(1)



(Note) DC connection bar is required. Always install a large capacity drive unit in the left side of power supply unit, and connect with DC connection bar.

(b) 2-axis spindle drive unit




(2) 400V series

< MDS-DH Series >

(1)

MDS-DH-



(Note) DC connection bar is required. Always install a large capacity drive unit in the left side of power supply unit, and connect with DC connection bar.

1 Introduction


1-2-6 Power supply unit type



Rating nameplate

(1) 200V series

< MDS-D Series >



(1) Type MDS-D-	Power su Rated output	pply unit Unit width	Compatible AC reactor	Compatible contactor (Mtsubishi) (Note 1)	Compatible circuit protector (Mtsubishi) (Note 1)
CV-37	3.7kW	60mm wide	D-AL-7.5K	S-N12-AC200V	NF63-CW3P-20A
CV-75	7.5kW	- outili wide	D-AL-1.5K	S-N25-AC200V	NF63-CW3P-40A
CV-110	11.0kW	90mm wide	D-AL-11K	3-1423-AC200V	NF63-CW3P-50A
CV-185	18.5kW	30mm wide	D-AL-18.5K	S-N65-AC200V	NF125-CW3P-100A
CV-300	30.0kW	150mm wido	D-AL-30K	S-N80-AC200V	NF250-CW3P-125A
CV-370	37.0kW	150mm w ide (Note 2)	D-AL-37K	S-N150-AC200V	NF250-CW3P-175A
CV-450	45.0kW		D-AL-45K	3-14130-AC200V	NF250-CW3P-200A
CV-550	55.0kW	300mm wide (Note 2)	D-AL-55K	S-N180-AC200V	NF250-CW3P-225A


⁽Note 1) This is an optional part, and must be prepared by the user.

(Note 2) When connecting with a large capacity drive unit, DC connection bar is required.

Always install a large capacity drive unit in the left side of power supply unit, and connect with DC connection bar.

(2) 400V series

< MDS-DH Series >




	Power su	ipply unit		Compatible contactor	Compatible
(1) Type MDS-DH-	Rated output	Unit width	Compatible AC reactor		circuit protector (Mitsubishi) (Note 1)
CV-37	3.7kW		DH-AL-7.5K	S-N12-AC400V	NF63-CW3P-10A
CV-75	7.5kW	90mm wide	DI FAL-7.5K	3-1112-AC400V	NF63-CW3P-20A
CV-110	11.0kW	90mm wide	DH-AL-11K	S-N21-AC400V	NF63-CW3P-30A
CV-185	18.5kW		DH-AL-18.5K	S-N25-AC400V	NF63-CW3P-40A
CV-300	30.0kW	150mm wide	DH-AL-30K	S-N50-AC400V	NF125-CW3P-75A
CV-370	37.0kW		DH-AL-37K	S-N65-AC400V	NF125-CW3P-100A
CV-450	45.0kW	(Note 2)	DH-AL-45K	0-1100-710-100V	NF125-CW3P-100A
CV-550	55.0kW		DH-AL-55K	S-N80-AC400V	NF250-CW3P-125A
CV-750	75.0kW	(Note 2)	DH-AL-75K	S-N150-AC400V	NF250-CW3P-200A

⁽Note 1) This is an optional part, and must be prepared by the user.

⁽Note 2) When connecting with a large capacity drive unit, DC connection bar is required. Always install a large capacity drive unit in the left side of power supply unit, and connect with DC connection bar.

1-2-7 AC reactor type




Top surface of AC reactor

(1) 200V series

D-AL-

< MDS-D Series >



MDS-D-CV-550

MDS-DH-CV-300

MDS-DH-CV-370 MDS-DH-CV-450

MDS-DH-CV-550

MDS-DH-CV-750

(2) 400V series

55K

DH-AL-

30K


37K

45K

55K 75K

< MDS-DH Series >

55.0kW



30.0kW

37.0kW

45.0kW 55.0kW

75.0kW

1 Introduction

2-1 Servomotor

2-1-1 Specifications list

(1) 200V series < HF Series >

					HF	Series			
S	ervomotor type			ABS sp	ecifications:	HF □ -A74N	/-A51/-A48		
		HF75	HF105	HF54	HF104	HF154	HF224	HF204	HF354
Compatible	MDS-D-V1-	20	20	40	40	80	80	80	160
servo drive		2020 (L,M)	2020 (L,M)	4020 (L)	4020 (L)	8040 (L)	8040 (L)	8040 (L)	16080 (L)
unit type	MDS-D-V2-	4020 (L,W)	4020 (L,W)	4040 (L,M)	4040 (L,M)	8080 (L,M)	8080 (L,M)	8080 (L,M)	160160 (L,M)
		, ,	` ,	8040 (L)	8040 (M)	16080 (M)	16080 (M)	16080 (M)	160160W (L,M)
	Rated output [kW]	0.75	1.0	0.5	1.0	1.5	2.2	2.0	3.5
Continuous	Rated current [A]	2.8	3.6	1.8	3.6	5.8	8.5	6.8	13.8
characteris-	Rated torque [N•m]	1.8	2.4	1.6	3.2	4.8	7.0	6.4	11.1
tics	Stall current [A]	3.2	4.6	3.2	6.6	11.0	14.5	14.6	22.0
	Stall torque [N•m]	2.0	3.0	2.9	5.9	9.0	12.0	13.7	22.5
Power facility	capacity [kVA]	1.5	2.0	1.1	2.0	2.8	4.1	3.7	6.4
Rated rotation		40	000				3000		
Maximum rota	tion speed [r/min]	50	000				4000		
Maximum curr	ent [A]	14.0	15.5	16.8	29.0	52.0	57.0	57.0	116.0
Maximum torq	ue [N•m]	8.0	11.0	13.0	23.3	42.0	46.5	47.0	90.0
Power rate at o [kW/s]			11.2	4.1	8.4	12.7	20.7	10.6	16.5
Motor inertia [I	kg•cm²]	2.6	5.1	6.1	11.9	17.8	23.7	38.3	75.0
Motor inertia w	vith brake [kg•cm²]	2.8	5.3	8.3	14.1	20.0	25.9	48.0	84.7
Maximum moto inertia ratio	or shaft conversion load		Gener	n-speed, high- al machine too al machine (no	ol (interpolation	on axis): 5 tim	es or less of r es or less of r	motor inertia	
Motor side det	ector		A74N: 16,	000,000 pulse				0,000 pulse/re	ev
Degree of prot	ection			IP67 (The shaft-thro	ough portion i	s excluded.)		
	Ambient temperature			Stora	eration: 0 to 4 age: -15°C to	70°C (with no	freezing)		
	Ambient humidity			Storage: 9	80%RH or les 90%RH or less	s (with no dev	v condensatio	n)	
Environment	Atmosphere		Indoors (r	,		•	•	oil mist, or du	st
	Altitude				on: 1000 mete e: 10000 mete				
	Vibration			X,Y:24.5m	n/s ² (2.5G)				(2.5G) Y:29.4m/ s ² (3G)
Flange size [m	m]	90 SQ.	90 SQ.	130 SQ.	130 SQ.	130 SQ.	130 SQ.	176 SQ.	176 SQ.
Total length (e	xcluding shaft) [mm]	126.5	162.5	118.5	140.5	162.5	184.5	143.5	183.5
Flange fitting of	diameter [mm]	φ80	φ80	φ110	φ110	φ110	φ110	φ114.3	φ 114.3
Shaft diameter	[mm]	φ14	φ14	φ24	φ24	φ24	φ24	φ35	φ35
	t / with brake [kg]	2.5/3.9	4.3/5.7	4.8/6.8	6.5/8.5	8.3/10.3	10.0/12.0	12.0/18.0	19.0/25.0
Heat-resistant						(155°C)		1	
/NI=4= 4\ TI=	o abovo characteristi					,			•

- (Note 1) The above characteristics values are representative values. The maximum current and maximum torque are the values when combined with the drive unit.
- (Note 2) Use the HF motor in combination with the MDS-D Series drive unit compatible with the 200VAC input. This motor is not compatible with the conventional MDS-B/C1/CH Series.
- (Note 3) The total length will be 3.5mm longer when using an A51 or A74N detector.



< HF Series >

					HF S	eries			
s	ervomotor type			ABS sp	ecifications: H	F □ -A74N / -	A51 / -A48		
		HF123	HF223	HF303	HF453	HF703	HF903	HF142	HF302
	MDS-D-V1-	20	40	80	160	160W	320	20	40
Compatible servo drive unit type	MDS-D-V2-	2020 (L,M) 4020 (M)	4020 (L) 4040 (L,M) 8040 (M)	8040 (L) 8080 (L,M) 16080 (M)	16080 (L) 160160 (L,M) 160160W (L,M)	160160W (L,M)	-	2020 (L,M) 4020 (M)	4020 (L) 4040 (L,M) 8040 (M)
	Rated output [kW]	1.2	2.2	3.0	4.5	7.0	9.0	1.4	3.0
Continuous	Rated current [A]	5.2	9.0	10.7	13.4	16.6	27.2	3.9	10.9
characteris-	Rated torque [N•m]	5.7	10.5	14.3	14.3	22.3	28.7	6.7	14.3
tics	Stall current [A]	6.4	10.2	15.8	34.0	36.4	56.0	6.4	20.0
	Stall torque [N•m]	7.0	12.0	22.5	37.2	49.0	58.8	11.0	20.0
	capacity [kVA]	2.3	4.1	5.5	8.1	12.5	16.1	2.7	5.5
Rated rotation			2000			3000		-	000
	tion speed [r/min]		3000		3500		000	_	000
Maximum curr	• •	15.5	29.0	48.0	104.2	108.4	204.0	15.5	29.0
Maximum torq		17.0	32.0	64.0	122.0	152.0	208.0	26.5	50.0
Power rate at ([kW/s]	continuous rated torque	27.3	46.5	27.3	18.3	32.2	42.1	25.2	27.3
Motor inertia [flotor inertia [kg•cm²]		23.7	75.0	112.0	154.0	196.0	17.8	75.0
Motor inertia v	Motor inertia with brake [kg•cm²]		25.9	84.7	121.7	163.7	205.7	20.0	84.7
Maximum mot inertia ratio	or shaft conversion load		Genera Genera	al machine to al machine (n	ool (interpolation ion-interpolation Resolution per	axis): 5 times axis): 7 times motor revoluti	or less of mo or less of mo on	tor inertia tor inertia	
			A74N: 16,					000 pulse/rev	
Degree of prot	ection				(The shaft-through	5 1	,		
	Ambient temperature			Stor	eration: 0 to 40° age: -15°C to 70)°C (with no fr	eezing)		
	Ambient humidity			Storage: 9	80%RH or less (90%RH or less (with no dew c	ondensation)	,	
	Atmosphere		Indoors (r		0 //	0 ,	U ,	mist, or dust	
Environment	Altitude			•	on: 1000 meters e: 10000 meters		,		
	Vibration	X,Y:24.5n	n/s ² (2.5G)		X:24.5m/s ² (2.50 Y:29.4m/s ² (3G)		X,Y:9.8m/ s ² (1G)	205.7 20.0 s of motor inertia ess of motor inertia ess of motor inertia ess of motor inertia 448: 260,000 pulse/rev ided.) g), ng) lensation), ensation) le gas, oil mist, or dust a level, a level Y:9.8m/ s² (1G) X,Y:24.5m/ s² (2.5G) 204 SQ. 130 SQ. 330 162.5	X:24.5m/s ² (2.5G) Y:29.4m/s ² (3G)
Flange size [m	nm]	130 SQ.	130 SQ.	176 SQ.	176 SQ.	176 SQ.	204 SQ.	130 SQ.	176 SQ.
Total length (e	excluding shaft) [mm]	140.5	184.5	183.5	223.5	263.5	330	162.5	183.5
Flange fitting	diameter [mm]	φ110	φ110	φ114.3	φ114.3	φ114.3	φ 180	φ110	φ114.3
Shaft diameter	r [mm]	φ24	φ24	φ35	φ35	φ35	φ42	φ24	φ35
Mass Withou	t / with brake [kg]	6.5/8.5	10.0/12.0	19.0/25.0	26.0/32.0	32.0/38.0	45.0/51.0	8.3/10.3	19.0/25.0
Heat-resistant	class		•		F (1	55°C)			

- (Note 1) The above characteristics values are representative values. The maximum current and maximum torque are the values when combined with the drive unit.
- (Note 2) Use the HF motor in combination with the MDS-D Series drive unit compatible with the 200VAC input. This motor is not compatible with the conventional MDS-B/C1/CH Series.
- (Note 3) The total length will be 3.5mm longer when using an A51 or A74N detector.



< HP Series >

				HP Series		
s	ervomotor type		ABS specifi	ications: HP 🗆 -A74N	/ -A51/ -A48	
		HP54	HP104	HP154	HP224	HP204
Compatible	MDS-D-V1-	40	40	80	80	80
servo drive		4020 (L)	4020 (L)	8040 (L)	8040 (L)	8040 (L)
unit type	MDS-D-V2-	4040 (L,M)	4040 (L,M)	8080 (L,M)	8080 (L,M)	8080 (L,M)
1, po		8040 (M)	8040 (M)	16080 (M)	16080 (M)	16080 (M)
	Rated output [kW]	0.5	1.0	1.5	2.2	2.0
Continuous	Rated current [A]	1.8	3.6	5.0	7.4	7.2
characteris-	Rated torque [N•m]	1.6	3.2	4.8	6.4	6.4
tics	Stall current [A]	3.6	6.8	9.4	14.0	15.4
	Stall torque [N•m]	3.0	5.9	9.0	12.0	13.7
Power facility	capacity [kVA]	1.1	2.0	2.8	4.1	3.7
Rated rotation	•		•	3000		•
	tion speed [r/min]			4000		
Maximum curr		16.8	25.6	52.0	57.0	57.0
Maximum torq		11.0	19.2	36.5	46.0	43.0
Power rate at ([kW/s]	continuous rated torque	5.5	13.0	19.0	20.0	14.0
Motor inertia [kg•cm²]	4.6	7.7	12.0	20.0	29.0
Motor inertia v	vith brake [kg•cm²]	5.1	8.2	12.5	20.5	34.5
Maximum mot inertia ratio	or shaft conversion load		High-speed, high-accu eneral machine tool (in eneral machine (non-int	terpolation axis): 5 time	es or less of motor in	ertia
Motor side det	ector	A74N	Resolution	olution per motor revol A51: 1,000,000 pulse		ulse/rev
Degree of prot	ection		IP67 (The	shaft-through portion is	s excluded.)	
	Ambient temperature			on: 0 to 40°C (with no f -15°C to 70°C (with no	0,,	
	Ambient humidity		•	RH or less (with no dev	,,,	
Environment	Atmosphere	Indoo	ors (no direct sunlight);	no corrosive gas, infla	mmable gas, oil mist,	, or dust
	Altitude		•	000 meters or less abo	,	
	Vibration		X,Y:24.5m	n/s ² (2.5G)		X:24.5m/s ² (2.5G) Y:29.4m/s ² (3G)
Flange size [m	m]	130 SQ.	130 SQ.	130 SQ.	130 SQ.	180 SQ.
	xcluding shaft) [mm]	133.5	152.5	171.5	204.5	172.5
Flange fitting	diameter [mm]	φ110	φ110	φ110	φ110	φ114.3
Shaft diameter	[mm]	φ24	φ24	φ24	φ24	φ35
Mass Withou	t / with brake [kg]	6.0/7.3	7.0/8.5	8.0/9.5	12.0/13.9	14.0/15.9
Heat-resistant	class			F (155°C)		•

- (Note 1) The above characteristics values are representative values. The maximum current and maximum torque are the values when combined with the drive unit.
- (Note 2) Use the HP motor in combination with the MDS-D Series drive unit compatible with the 200VAC input. This motor is not compatible with the conventional MDS-B/C1/CH Series.
- (Note 3) The total length will be 3.5mm longer when using an A51 or A74N detector.



< HP Series >

				HP Series		
s	Rated output [kW] Rated current [A] Rated torque [N•m] Stall current [A] Stall torque [N•m] Per facility capacity [kVA] d rotation speed [r/min] mum rotation speed [r/min] mum torque [N•m] Per rate at continuous rated torque solution in the state of th		ABS specifi	cations: HP 🗆 -A74N	/ -A51/ -A48	
		HP354	HP454	HP704	HP903	HP1103
0	MDS-D-V1-	160	160	160W	320	320W
servo drive unit type	MDS-D-V2-	16080 (L) 160160 (L,M) 160160W (L,M)	16080 (L) 160160 (L,M) 160160W (L,M)	160160W (L,M)	-	-
	Rated output [kW]	3.5	4.5	7.0	9.0	11.0
Continuous	Rated current [A]	15.2	14.2	19.2	22.2	25.2
characteris-	Rated torque [N•m]	11.1	14.3	22.3	28.7	35.0
tics	Stall current [A]	31.0	32.0	42.0	54.0	79.0
	Stall torque [N•m]	22.5	31.9	49.0	70.0	110.0
Power facility	capacity [kVA]	6.4	8.1	12.5	16.1	19.6
Rated rotation	speed [r/min]		1	3000		
Maximum rota	tion speed [r/min]		4000		30	000
Maximum curr	ent [A]	116.0	116.0	116.0	172.0	212.0
Maximum torq	ue [N•m]	66.0	95.0	120.0	170.0	260.0
Power rate at ([kW/s]	continuous rated torque	33.0	36.0	59.0	52.0	48.0
Motor inertia [kg•cm²]	37.0	55.0	82.0	163.0	255.0
		42.5	60.5	87.5	187.0	279.0
Maximum mot inertia ratio	or shaft conversion load	Ge	eneral machine tool (in neral machine (non-int	racy machine: 3 times terpolation axis): 5 time erpolation axis): 10 tim	es or less of motor ine es or less of motor ine	rtia
		A74N	l: 16,000,000pulse/rev	olution per motor revolu A51: 1,000,000 pulse/	rev, A48: 260,000 pul	se/rev
Degree of prot	ection			shaft-through portion is		
	Ambient temperature		Storage:	n: 0 to 40°C (with no for -15°C to 70°C (with no	freezing)	
Farrisan mant	Ambient humidity		Storage: 90%F	RH or less (with no dew RH or less (with no dew	condensation)	
Environment	Atmosphere	Indoo	` .	no corrosive gas, inflar	•	or dust
	Altitude			000 meters or less abo 000 meters or less abo	ve sea level	
	Vibration	X:24.5	m/s ² (2.5G) Y:29.4m	/s ² (3G)	X,Y:9.8r	n/s ² (1G)
Flange size [m	m]	180 SQ.	180 SQ.	180 SQ.	220 SQ.	220 SQ.
Total length (e	xcluding shaft) [mm]	195.5	225.5	305.5	346.5	419.5
Flange fitting of	diameter [mm]	φ114.3	φ114.3	φ114.3	φ200	φ200
Shaft diameter		φ35	φ35	φ35	φ 55	φ55
Mass Withou	t / with brake [kg]	17.0/22.0	21.0/26.0	37.0/43.0	51.0/61.4	74.0/84.4
Heat-resistant	class		•	F (155°C)		•

- (Note 1) The above characteristics values are representative values. The maximum current and maximum torque are the values when combined with the drive unit.
- (Note 2) Use the HP motor in combination with the MDS-D Series drive unit compatible with the 200VAC input. This motor is not compatible with the conventional MDS-B/C1/CH Series.
- (Note 3) The total length will be 3.5mm longer when using an A51 or A74N detector.



< HF-KP Series >

			HF-KP Series	
s	ervomotor type		Absolute position standard	
		HF-KP23JW04-S6	HF-KP43JW04-S6	HF-KP73JW04-S6
Compatible	MDS-D-V1-	20	20	20
servo drive	MDS-D-V2-	2020 (L,M)	2020 (L,M)	2020 (L,M)
unit type	WID3-D-V2-	4020 (M)	4020 (M)	4020 (M)
	Rated output [kW]	0.2	0.4	0.75
Continuous	Rated current [A]	1.4	2.7	5.2
characteris-	Rated torque [N•m]	0.64	1.3	2.4
tics	Stall current [A]	1.4	2.7	5.2
	Stall torque [N•m]	0.64	1.3	2.4
	capacity [kVA]	0.6	0.9	1.5
	speed [r/min]	<u>.</u>	3000	
Maximum rota	tion speed [r/min]		6000	
Maximum curr	rent [A]	4.3	8.5	15.5
Maximum torq	ue [N•m]	1.9	3.8	7.2
Power rate at ([kW/s]	continuous rated torque	16.9	38.6	39.9
Motor inertia [kg•cm²]	0.23	0.42	1.43
Motor inertia v	vith brake [kg•cm²]	0.31	0.50	1.63
Maximum mot inertia ratio	or shaft conversion load	General machine (r	on-interpolation axis): 15 times or le	ess of motor inertia
Motor side det	tector	Resolut	on per motor revolution: 260,000 pu	ilse/rev
Degree of prot	ection	IP65	(The shaft-through portion is exclude	led.)
	Ambient temperature		peration: 0 to 40°C (with no freezing rage: -15°C to 70°C (with no freezing	**
	Ambient humidity	•	80%RH or less (with no dew conde 90%RH or less (with no dew conde	**
Environment	Atmosphere	Indoors (no direct sun	ight); no corrosive gas, inflammable	gas, oil mist, or dust
	Altitude		ion: 1000 meters or less above sea ge: 10000 meters or less above sea	
	Vibration		X,Y: 49m/s ² (5G)	
Flange size [m	nm]	60 SQ.	60 SQ.	80 SQ.
Total length (e	excluding shaft) [mm]	98	119.9	134.2
Flange fitting	diameter [mm]	φ50	φ50	φ70
Shaft diameter	r [mm]	φ14	φ14	φ19
Mass Withou	t / with brake [kg]	1.2/1.8	1.7/2.3	2.9/4.1
Heat-resistant			B (130°C)	1

- (Note 1) The above characteristics values are representative values. The maximum current and maximum torque are the values when combined with the drive unit.
- (Note 2) Use the HF-KP motor in combination with the MDS-D Series drive unit compatible with the 200VAC input. This motor is not compatible with the conventional MDS-B/C1/CH Series.



(2) 400V series < HF-H Series >

				HF-H Series		
S	ervomotor type		ABS specific	ations: HF-H 🗆 -A74N	N / -A51 / -A48	
		HF-H75	HF-H105	HF-H54	HF-H104	HF-H154
0	MDS-D-V1-	10	10	20	20	40
Compatible servo drive unit type	MDS-D-V2-	1010 (L,M) 2010 (M)	1010 (L,M) 2010 (M)	2010 (L) 2020 (L,M) 4020 (M)	2010 (L) 2020 (L,M) 4020 (M)	4020 (L) 4040 (L,M) 8040 (M)
	Rated output [kW]	0.75	1.0	0.5	1.0	1.5
Continuous	Rated current [A]	1.4	1.8	0.9	1.8	2.9
characteris-	Rated torque [N•m]	1.8	2.4	1.6	3.2	4.8
tics	Stall current [A]	1.6	2.3	1.6	3.3	5.5
	Stall torque [N•m]	2.0	3.0	2.9	5.9	9.0
Power facility	capacity [kVA]	1.5	2.0	1.1	2.0	2.8
Rated rotation	•	40	000		3000	
	tion speed [r/min]	50	000		4000	
Maximum curr		7.0	7.75	8.4	14.5	26.0
Maximum torq		8.0	11.0	13.0	23.3	42.0
Power rate at ([kW/s]	continuous rated torque	12.3	11.2	4.1	8.4	12.7
Motor inertia [kg•cm²]	2.6	5.1	6.1	11.9	17.8
Motor inertia v	vith brake [kg•cm²]	2.8	5.3	8.3	14.1	20.0
Maximum mot inertia ratio	or shaft conversion load	G	High-speed, high-accu eneral machine tool (in eneral machine (non-in	terpolation axis): 5 time terpolation axis): 7 time	es or less of motor ine es or less of motor ine	rtia
Motor side det	ector	A74N	l: 16,000,000 pulse/rev		/rev, A48: 260,000 pu	lse/rev
Degree of prot	ection		·	shaft-through portion is		
	Ambient temperature		Storage:	on: 0 to 40°C (with no for -15°C to 70°C (with no	freezing)	
Environment	Ambient humidity		Storage: 90%F	RH or less (with no dev RH or less (with no dew	condensation)	
Environment	Atmosphere	Indoo	ors (no direct sunlight);			or dust
	Altitude			000 meters or less abo		
	Vibration			X,Y:24.5m/s ² (2.5G)		
Flange size [m	im]	90 SQ.	90 SQ.	130 SQ.	130 SQ.	130 SQ.
Total length (e	excluding shaft) [mm]	126.5	162.5	118.5	140.5	162.5
Flange fitting	diameter [mm]	φ80	φ80	φ110	φ110	φ110
Shaft diameter	r [mm]	φ14	φ14	φ24	φ24	φ24
Mass Withou	t / with brake [kg]	2.5/3.9	4.3/5.7	4.8/6.8	6.5/8.5	8.3/10.3
Heat-resistant	class		·I	F (155°C)		1

- (Note 1) The above characteristics values are representative values. The maximum current and maximum torque are the values when combined with the drive unit.
- (Note 2) Use the HF-H motor in combination with the MDS-DH Series drive unit compatible with the 400VAC input. This motor is not compatible with the conventional MDS-B/C1/CH Series.
- (Note 3) The total length will be 3.5mm longer when using an A51 or A74N detector.



< HF-H Series >

		HF-H Series					
Servomotor type			ABS specific	ations: HF-H 🗆 -A74N	N / -A51 / -A48		
		HF-H204	HF-H354	HF-H453	HF-H703	HF-H903	
Compatible	MDS-D-V1-	40	80	80	W08	160	
servo drive		4020 (L)	8040 (L)	8040 (L)			
unit type	MDS-D-V2-	4040 (L,M)	8080 (L,M)	8080 (L,M)	8080W (L,M)	-	
unit typo		8040 (M)	8080W (L,M)	8080W (L,M)			
	Rated output [kW]	2.0	3.5	4.5	7.0	9.0	
Continuous	Rated current [A]	3.4	6.9	6.7	8.3	13.6	
characteris-	Rated torque [N•m]	6.4	11.1	14.3	22.3	28.7	
tics	Stall current [A]	7.3	14.0	17.0	18.2	28.0	
	Stall torque [N•m]	13.7	22.5	37.2	49.0	58.8	
	capacity [kVA]	3.7	6.4	8.1	12.5	16.1	
Rated rotation				3000			
Maximum rota	tion speed [r/min]	4	000	3500	3	000	
Maximum curr		28.5	58.0	52.1	54.2	102.0	
Maximum torq		47.0	90.0	122.0	152.0	208.0	
Power rate at continuous rated torque [kW/s]		10.6	16.5	18.3	32.2	42.1	
Motor inertia [kg•cm²]		38.3	75.0	112.0	154.0	196.0	
Motor inertia with brake [kg•cm²]		48.0	84.7	121.7	163.7	205.7	
Maximum mot inertia ratio	h motor shaft conversion load tio High-speed, high-accuracy machine: 3 times or less of motor inertia General machine tool (interpolation axis): 5 times or less of motor inertia General machine (non-interpolation axis): 7 times or less of motor inertia				ertia		
Motor side det	ector	A741	Res N: 16,000,000 pulse/rev	olution per motor revol r, A51: 1,000,000 pulse		ılse/rev	
Degree of prot	ection	IP67 (The shaft-through portion is excluded.)					
	Ambient temperature		•	on: 0 to 40°C (with no for -15°C to 70°C (with no	0//		
F	Ambient humidity	Operation: 80%RH or less (with no dew condensation), Storage: 90%RH or less (with no dew condensation)					
Environment	Atmosphere	Indo	ors (no direct sunlight);			or dust	
	Altitude	Operation: 1000 meters or less above sea level, Storage: 10000 meters or less above sea level					
Vibration			X:24.5m/s ² (2.5G)	Y:29.4m/s ² (3G)		X,Y:9.8m/s ² (1G)	
Flange size [mm]		176 SQ.	176 SQ.	176 SQ.	176 SQ.	204 SQ.	
	Total length (excluding shaft) [mm]		183.5	223.5	263.5	330	
• •	diameter [mm]	φ114.3	φ114.3	φ114.3	φ114.3	φ 180	
Shaft diameter		φ35	φ35	φ35	φ35	φ42	
	t / with brake [kg]	12.0/18.0	19.0/25.0	26.0/32.0	32.0/38.0	45.0/51.0	
Heat-resistant			1	F (155°C)		1	
Heat-resistant class F (155°C)							

- (Note 1) The above characteristics values are representative values. The maximum current and maximum torque are the values when combined with the drive unit.
- (Note 2) Use the HF-H motor in combination with the MDS-DH Series drive unit compatible with the 400VAC input. This motor is not compatible with the conventional MDS-B/C1/CH Series.
- (Note 3) The total length will be 3.5mm longer when using an A51 or A74N detector.



< HP-H Series >

		HP-H Series					
Servomotor type		ABS specifications: HP-H □ -A74N/ -A51/ -A48					
		HP-H54	HP-H104	HP-H154	HP-H224	HP-H204	
Campatible	MDS-D-V1-	20	20	40	40	40	
Compatible servo drive		2010 (L)	2010 (L)	4020 (L)	4020 (L)	4020 (L)	
unit type	MDS-D-V2-	2020 (L,M)	2020 (L,M)	4040 (L,M)	4040 (L,M)	4040 (L,M)	
unit type		4020 (M)	4020 (M)	8040 (M)	8040 (M)	8040 (M)	
	Rated output [kW]	0.5	1.0	1.5	2.2	2.0	
Continuous	Rated current [A]	0.9	1.8	2.5	3.7	3.6	
characteris-	Rated torque [N•m]	1.6	3.2	4.8	6.4	6.4	
tics	Stall current [A]	1.8	3.4	4.7	7.0	7.7	
	Stall torque [N•m]	3.0	5.9	9.0	12.0	13.7	
Power facility	capacity [kVA]	1.1	2.0	2.8	4.1	3.7	
Rated rotation speed [r/min]				3000		•	
Maximum rota	tion speed [r/min]			4000			
Maximum curr	rent [A]	8.4	12.8	26.0	28.5	28.5	
Maximum torq	ue [N•m]	11.0	19.2	36.5	46.0	43.0	
Power rate at ([kW/s]	continuous rated torque	5.5	13.0	19.0	20.0	14.0	
Motor inertia [kg•cm²]		4.6	7.7	12.0	20.0	29.0	
Motor inertia with brake [kg•cm²]		5.1	8.2	12.5	20.5	34.5	
Maximum mot inertia ratio	High-speed, high-accuracy machine: 3 times or less of motor inertia General machine tool (interpolation axis): 5 times or less of motor inertia General machine (non-interpolation axis): 10 times or less of motor inertia			ertia			
Motor side det	tector	Resolution per motor revolution A74N: 16,000,000pulse/rev, A51: 1,000,000 pulse/rev, A48: 260,000 pulse/rev					
Degree of prot	tection	IP67 (The shaft-through portion is excluded.)					
	Ambient temperature			n: 0 to 40°C (with no f -15°C to 70°C (with no			
	Ambient humidity	Operation: 80%RH or less (with no dew condensation), Storage: 90%RH or less (with no dew condensation)					
Environment	Atmosphere	Indoors (no direct sunlight); no corrosive gas, inflammable gas, oil mist, or dust					
	Altitude			000 meters or less abo	,		
	Vibration		X:24.5m/s ² (2.5G) Y:29.4m/s ² (3G)				
Flange size [mm]		130 SQ.	130 SQ.	130 SQ.	130 SQ.	180 SQ.	
	excluding shaft) [mm]	133.5	152.5	171.5	204.5	172.5	
_ ,	diameter [mm]	φ110	φ110	φ110	φ110	φ114.3	
Shaft diameter		φ24	φ24	φ24	φ24	φ35	
	t / with brake [kg]	6.0/7.3	7.0/8.5	8.0/9.5	12.0/13.9	14.0/15.9	
Heat-resistant			l .	F (155°C)			

- (Note 1) The above characteristics values are representative values. The maximum current and maximum torque are the values when combined with the drive unit.
- (Note 2) Use the HP-H motor in combination with the MDS-DH Series drive unit compatible with the 400VAC input. This motor is not compatible with the conventional MDS-B/C1/CH Series.
- (Note 3) The total length will be 3.5mm longer when using an A51 or A74N detector.



< HP-H Series >

		HP-H Series					
S	ervomotor type		ABS specific	ations: HP-H 🗆 -A74N	V -A51/ -A48		
		HP-H354	HP-H454	HP-H704	HP-H903	HP-H1103	
Compatible	MDS-D-V1-	80	80	80W	160	160W	
servo drive		8040 (L)	8040 (L)				
unit type	MDS-D-V2-	8080 (L,M)	8080 (L,M)	8080W (L,M)	-	-	
		8080W (L,M)	8080W (L,M)				
	Rated output [kW]	3.5	4.5	7.0	9.0	11.0	
Continuous	Rated current [A]	7.6	7.1	9.6	11.1	12.6	
characteris-	Rated torque [N•m]	11.1	14.3	22.3	28.7	35.0	
tics	Stall current [A]	15.5	16.0	21.0	27.0	39.5	
	Stall torque [N•m]	22.5	31.9	49.0	70.0	110.0	
	capacity [kVA]	6.4	8.1	12.5	16.1	19.6	
Rated rotation				3000			
	tion speed [r/min]		4000			000	
Maximum curr		58.0	58.0	58.0	86.0	106.0	
Maximum torq	•	66.0	95.0	120.0	170.0	260.0	
Power rate at continuous rated torque [kW/s]		33.0	36.0	59.0	52.0	48.0	
Motor inertia [kg•cm²]		37.0	55.0	82.0	163.0	255.0	
Motor inertia with brake [kg•cm²]		42.5	60.5	87.5	187.0	2790	
Maximum motor shaft conversion load inertia ratio High-speed, high-accuracy machine: 3 times or less of motor inertia General machine tool (interpolation axis): 5 times or less of motor inertia General machine (non-interpolation axis): 10 times or less of motor inertia			rtia				
Motor side det	ector	A74N		olution per motor revolu , A51: 1,000,000 pulse/		se/rev	
Degree of prot	ection	IP67 (The shaft-through portion is excluded.)					
	Ambient temperature		Storage:	on: 0 to 40°C (with no front of the control of the	freezing)		
Ambient humidity Operation: 80%RH or less (with no dew con Storage: 90%RH or less (with no dew con					condensation)		
Environment	Atmosphere	Indoo		no corrosive gas, inflan	• .	or dust	
	Altitude			000 meters or less above 000 meters or less above			
Vibration		X:24.5	5m/s ² (2.5G) Y:29.4m/	s ² (3G)	X,Y:9.8r	n/s ² (1G)	
Flange size [mm]		180 SQ.	180 SQ.	180 SQ.	220 SQ.	220 SQ.	
	Total length (excluding shaft) [mm]		225.5	305.5	346.5	419.5	
Flange fitting	~	φ114.3	φ114.3	φ114.3	φ200	φ200	
Shaft diameter		φ35	φ35	φ35	φ55	φ55	
	t / with brake [kg]	17.0/22.0	21.0/26.0	37.0/43.0	51.0/61.4	74.0/84.4	
Heat-resistant				F (155°C)		<u> </u>	
Tearlesistant class							

- (Note 1) The above characteristics values are representative values. The maximum current and maximum torque are the values when combined with the drive unit.
- (Note 2) Use the HP-H motor in combination with the MDS-DH Series drive unit compatible with the 400VAC input. This motor is not compatible with the conventional MDS-B/C1/CH Series.
- (Note 3) The total length will be 3.5mm longer when using an A51 or A74N detector.



< HC-H Series >


		HC-H Series					
:	Servomotor type	ABS specifications: HC-H □ -A74N / -A51 / -A48					
		HC-H1502S-S10					
Compatible	MDS-DH-V1	200					
servo drive unit type	MDS-DH-V2	-					
	Rated output [kW]	15.0					
Continuous	Rated current [A]	38.8					
characteris-	Rated torque [N•m]	71.6					
tics	Stall current [A]	76.8					
	Stall torque [N•m]	146.0					
Power facility	capacity [kVA]	26.7					
Rated rotation		2000					
Maximum rota	tion speed [r/min]	2500					
Maximum curr	ent [A]	160.0					
Maximum torq		280.0					
Power rate at o	continuous rated torque [kW/s]	104.5					
Motor inertia [l	kg•cm²]	550					
Motor inertia with brake [kg•cm²]							
Maximum motor shaft conversion load inertia ratio		High-speed, high-accuracy machine: 3 times or less of motor inertia General machine tool (interpolation axis): 5 times or less of motor inertia General machine (non-interpolation axis): 10 times or less of motor inertia					
Motor side det		Resolution per motor revolution A74N: 16,000,000pulse/rev, A51: 1,000,000 pulse/rev, A48: 260,000 pulse/rev					
Degree of prot	ection	IP44 (The shaft-through portion is excluded.)					
	Input voltage	3-phase 400V					
Cooling fan	Maximum power consumption	85W					
	Ambient temperature	Operation: 0 to 40°C (with no freezing), Storage: -15°C to 70°C (with no freezing)					
	Ambient humidity	Operation: 80%RH or less (with no dew condensation), Storage: 90%RH or less (with no dew condensation)					
Environment	Atmosphere	Indoors (no direct sunlight); no corrosive gas, inflammable gas, oil mist, or dust					
	Altitude	Operation: 1000 meters or less above sea level, Storage: 10000 meters or less above sea level					
Vibration		X,Y:9.8m/s ² (1G)					
Flange size [m	m]	280 SQ.					
Total length (e	xcluding shaft) [mm]	605					
Flange fitting of	diameter [mm]	φ250					
Shaft diameter	[mm]	φ60					
Mass Without	/ with brake [kg]	160/					
Heat-resistanc	e class	F (155°C)					

- (Note 1) The above characteristics values are representative values. The maximum current and maximum torque are the values when combined with the drive unit.
- (Note 2) Use the HC-H motor in combination with the MDS-DH Series drive unit compatible with the 400VAC input. This motor is not compatible with the conventional MDS-B/C1/CH Series.




2-1-2 Torque characteristics

(1) 200V series < HF Series >




(Note) The above graphs show the data when applied the input voltage of 200VAC. When the input voltage is 200VAC or less, the short time operation range is limited.

< HF Series >




(Note) The above graphs show the data when applied the input voltage of 200VAC. When the input voltage is 200VAC or less, the short time operation range is limited.




(Note) The above graphs show the data when applied the input voltage of 200VAC. When the input voltage is 200VAC or less, the short time operation range is limited.

< HF-KP Series >




(Note) The above graphs show the data when applied the input voltage of 200VAC. When the input voltage is 200VAC or less, the short time operation range is limited.

(2) 400V series < HF-H Series >




(Note) The above graphs show the data when applied the input voltage of 380VAC. When the input voltage is 380VAC or less, the short time operation range is limited.



(Note) The above graphs show the data when applied the input voltage of 380VAC. When the input voltage is 380VAC or less, the short time operation range is limited.

< HC-H Series >

[HC-H1502S-S10]



(Note) The above graphs show the data when applied the input voltage of 380VAC. When the input voltage is 380VAC or less, the short time operation range is limited.

2-2 Spindle motor

2-2-1 Specifications

(1) 200V series

< SJ-D Series (Standard) >

Spindle motor	type	SJ-D3.7/100-01	SJ-D5.5/100-01	SJ-D7.5/100-01	SJ-D11/80-01		
	MDS-D-SP-	80	80	160	160		
Compatible spindle drive unit type	MDS-D-SP2-	8040 (L) 16080S (M) 8080 (L,M) 16080 (M)	8040 (L) 16080S (M) 8080 (L,M) 16080 (M)	16080S (L) 16080 (L)	16080S (L) 16080 (L)		
Output	Continuous rating [kW]	2.2	3.7	5.5	7.5		
Output capacity	Short time rating [kW]	3.7 (15-minute rating)	5.5 (30-minute rating)	7.5 (30-minute rating)	11 (30-minute rating)		
Power facility	capacity [kVA]	6.7	9.9	13.4	19.6		
Base rotation	speed [r/min]	1500	1500	1500	1500		
Maximum rota	tion speed [r/min]	10000	10000	10000	8000		
Frame No.		B90	D90	A112	B112		
Continuous ra	ted torque [N•m]	14.0	23.6	35.0	47.7		
GD ² [kg•m ²]		0.030	0.053	0.094	0.122		
Inertia [kg•m²]		0.0074	0.013	0.023	0.031		
Tolerable radial load [N]		980	1470	1960	1960		
	Input voltage	3-phase 200V					
Cooling fan	Maximum power consumption	38W	38W	50W	50W		
	Ambient temperature	Operation: 0 to 40°C (with no freezing), Storage: -20°C to 65°C (with no freezing)					
	Ambient humidity	Operation: 90%RH or less (with no dew condensation), Storage: 90%RH or less (with no dew condensation)					
Environment	Atmosphere	Indoors (no direct sunlight); no corrosive gas, inflammable gas, oil mist, or dust					
	Altitude	Operation: 1000 meters or less above sea level, Storage: 1000 meters or less above sea level Transportation: 10000 meters or less above sea level					
Degree of prot				gh portion is excluded.)			
Flange size [m	ım]	174 SQ.	174 SQ.	204 SQ.	204 SQ.		
• ,	excluding shaft) [mm]	327	417	439	489		
	diameter [mm]	φ150	φ150	φ180	φ180		
Shaft diameter	r [mm]	φ28	φ28	φ32	φ48		
Mass [kg]		26	39	53	64		
Heat-resistant	class		F (1	55°C)			

(Note) The tolerable radial load is the value calculated at the center of output shaft.



< SJ-DJ Series (Compact & lightweight specifications) >

Spindle motor	type	SJ-DJ5.5/100-01	SJ-DJ7.5/100-01	SJ-DJ11/100-01	SJ-DJ15/80-01		
	MDS-D-SP-	80	160	160	200		
Compatible spindle drive unit type	MDS-D-SP2-	8040 (L) 16080S (M) 8080 (L,M) 16080 (M)	16080S (L) 16080 (L)	16080S (L) 16080 (L)	-		
	Continuous rating [kW]	3.7	5.5	7.5	11		
Output capacity	Short time rating [kW]	5.5 (25%ED rating)	7.5 (15-minute rating)	11 (15-minute rating)	15 (15-minute rating) (15%ED rating)		
Power facility	capacity [kVA]	9.9	13.4	19.6	26.7		
Base rotation	speed [r/min]	(Continuous) 2000 / (Short time) 1500					
Maximum rota	tion speed [r/min]	10000	10000	10000	8000		
Frame No.		B90	D90	A112	B112		
Continuous ra	Continuous rated torque [N•m] 17.7 26.3 35.8						
GD ² [kg•m ²]		0.030	0.053	0.094	0.122		
Inertia [kg•m²]		0.0074	0.013	0.023	0.031		
Tolerable radia	al load [N]	980	1470	1960	1960		
	Input voltage	3-phase 200V					
Cooling fan	Maximum power consumption	38W	38W	50W	50W		
	Ambient temperature	Operation: 0 to 40°C (with no freezing), Storage: -20°C to 65°C (with no freezing)					
	Ambient humidity	Operation: 90%RH or less (with no dew condensation), Storage: 90%RH or less (with no dew condensation)					
Environment	Atmosphere	,	o direct sunlight); no corrosiv	0 ,	•		
Altitude Operation: 1000 meters or less above sea level, 5 Transportation: 10000 meter				, ,	ess above sea level,		
Degree of prof	ection		IP54 (The shaft-through	gh portion is excluded.)			
Flange size [m	m]	174 SQ.	174 SQ.	204 SQ.	204 SQ.		
	xcluding shaft) [mm]	327	417	439	489		
Flange fitting		φ 150	φ150	φ180	φ180		
Shaft diameter	r [mm]	φ28	φ28	φ32	φ48		
Mass [kg]		26	39	53	64		
Heat-resistant class F (155°C)							

(Note) The tolerable radial load is the value calculated at the center of output shaft.



< SJ-V Series (Standard) >

Spindle motor type		SJ-VL0.75-01T	SJ-VL1.5-01T	SJ-V2.2-01T	SJ-V3.7-01T	SJ-V5.5-01ZT		
	MDS-D-SP-	20	20	40	80	80		
Compatible spindle drive unit type	MDS-D-SP2-	2020 (L,M) 4020 (M)	2020 (L,M) 4020 (M)	4020 (L) 4040S (L,M) 4040 (L,M) 8040 (M)	8040 (L) 16080S (M) 8080 (L,M) 16080 (M)	8040 (L) 16080S (M) 8080 (L,M) 16080 (M)		
0	Continuous rating [kW]	0.4	0.75	1.5	2.2	3.7		
Output capacity	Short time rating [kW]	0.75 (10-minute rating)	1.5 (10-minute rating)	2.2 (15-minute rating)	3.7 (15-minute rating)	5.5 (30-minute rating)		
Power facility of	capacity [kVA]	1.5	2.8	4.1	6.7	9.9		
Base rotation s	speed [r/min]	1500	1500	1500	1500	1500		
Maximum rotat	tion speed [r/min]	10000	10000	10000	10000	12000		
Frame No.		A71	B71	A90	B90	D90		
Continuous rat	ted torque [N•m]	2.55	4.77	9.5	14.0	23.6		
GD ² [kg•m ²]		0.0053	0.0096	0.027	0.035	0.059		
Inertia [kg•m²]		0.0013	0.0024	0.007	0.009	0.0148		
Tolerable radial load [N]		490	490	980	980	980		
	Input voltage	Single-phase 200V	Single-phase 200V	Single-phase 200V	Single-phase 200V	Single-phase 200V		
Cooling fan	Maximum power consumption	14W	14W	36W	36W	36W		
	Ambient temperature	Operation: 0 to 40°C (with no freezing), Storage: -20°C to 65°C (with no freezing)						
	Ambient humidity	Operation: 90%RH or less (with no dew condensation), Storage: 90%RH or less (with no dew condensation)						
Environment	Atmosphere		· 0 //	no corrosive gas, inflar	U , ,			
	Altitude Operation: 1000 meters or less above sea level, Storage: 1000 meters or less above sea Transportation: 10000 meters or less above sea level					ove sea level,		
Degree of prote	ection			IP44				
Flange size [m	m]	130 SQ.	130 SQ.	174 SQ.	174 SQ.	174 SQ.		
Total length (excluding shaft) [mm]		265	325	300	330	425		
Flange fitting diameter [mm]		φ110	φ110	φ 150	φ150	φ 150		
Shaft diameter	[mm]	φ22	φ22	φ28	φ28	φ28		
Mass [kg]		15	20	25	30	49		
Heat-resistant	class			F (155°C)				

(Note) The tolerable radial load is the value calculated at the center of output shaft.



< SJ-V Series (Standard) >

Spindle motor	type	SJ-V7.5-01ZT	SJ-V7.5-03ZT	SJ-V11-01ZT	SJ-V11-13ZT	SJ-V15-01ZT	
Compatible	MDS-D-SP-	160	160	160	200	200	
spindle drive unit type	MDS-D-SP2-	16080S (L) 16080 (L)	16080S (L) 16080 (L)	16080S (L) 16080 (L)	-	-	
Output	Continuous rating [kW]	5.5	5.5	7.5	7.5	11	
capacity	Short time rating [kW]	7.5	7.5	11	11	15	
	0	(30-minute rating)	(30-minute rating)	(30-minute rating)	(30-minute rating)	(30-minute rating)	
Power facility of	apacity [kVA]	13.4	13.4	19.6	19.6	26.7	
Base rotation s	peed [r/min]	1500	1500	1500	1500	1500	
Maximum rotat	ion speed [r/min]	12000	12000	8000	8000	8000	
Frame No.		A112	A112	B112	B112	A160	
Continuous rat	ed torque [N•m]	35	35	47.7	47.7	70	
GD ² [kg•m ²]		0.098	0.098	0.12	0.12	0.23	
Inertia [kg•m²]		0.0245	0.0245	0.03	0.03	0.0575	
Tolerable radia	l load [N]	980	980	1960	1960	2940	
	Input voltage	3-phase 200V	3-phase 200V	3-phase 200V	3-phase 200V	3-phase 200V	
Cooling fan	Maximum power consumption	40W	40W	40W	40W	63W	
	Ambient temperature	Opera	ation: 0 to 40°C (with no	freezing), Storage: -20	°C to 65°C (with no free	ezing)	
	Ambient humidity	Operation: 90%RH	or less (with no dew co	ndensation), Storage: 9	90%RH or less (with no	dew condensation)	
Environment	Atmosphere	Indoors (no direct sunlight); no corrosive gas, inflammable gas, oil mist, or dust					
	Altitude	Operation: 1000 meters or less above sea level, Storage: 1000 meters or less above sea level					
		Transportation: 10000 meters or less above sea level					
Degree of prote			IP44				
Flange size [mm]		204 SQ.	204 SQ.	204 SQ.	204 SQ.	250 SQ.	
Total length (excluding shaft) [mm]		440	440	490	490	469.5	
Flange fitting diameter [mm]		φ 180 φ 32	φ180	φ180	φ180	φ230	
	Shaft diameter [mm]		φ32	φ48	φ48	φ48	
Mass [kg]		60	60	70	70	110	
Heat-resistant	class			F (155°C)			

(Note) The tolerable radial load is the value calculated at the center of output shaft.



< SJ-V Series (Standard) >

Spindle motor	type	SJ-V15-09ZT	SJ-V18.5-01ZT	SJ-V18.5-04ZT	SJ-V22-01ZT	SJ-V22-04ZT	
Compatible	MDS-D-SP-	200	200	240	240	320	
spindle drive unit type	MDS-D-SP2-	-	-	-	-	-	
Output	Continuous rating [kW]	11	15	15	18.5	18.5	
capacity	Short time rating [kW]	15	18.5	18.5	22	22	
capacity	Short time rating [KW]	(30-minute rating)	(30-minute rating)	(30-minute rating)	(30-minute rating)	(30-minute rating)	
Power facility of	apacity [kVA]	26.7	32.8	32.8	39.0	39.0	
Base rotation s	speed [r/min]	1500	1500	1500	1500	1500	
Maximum rotat	ion speed [r/min]	8000	8000	8000	8000	8000	
Frame No.		A160	A160	A160	B160	B160	
Continuous rat	ed torque [N•m]	70	95.5	95.5	118	118	
GD ² [kg•m ²]		0.23	0.23	0.23	0.319	0.319	
Inertia [kg•m²]		0.0575	0.0575	0.0575	0.08	0.08	
Tolerable radia	l load [N]	2940	2940	2940	2940	2940	
	Input voltage	3-phase 200V	3-phase 200V	3-phase 200V	3-phase 200V	3-phase 200V	
Cooling fan	Maximum power consumption	63W	63W	63W	63W	63W	
	Ambient temperature	Operation: 0 to 40°C (with no freezing), Storage: -20°C to 65°C (with no freezing)					
Ambient humidity Environment Atmosphere		Operation: 90%RH or less (with no dew condensation), Storage: 90%RH or less (with no dew condensation)					
		Indoors (no direct sunlight); no corrosive gas, inflammable gas, oil mist, or dust					
	Altitude	Operation: 1000 meters or less above sea level, Storage: 1000 meters or less above sea Transportation: 10000 meters or less above sea level					
Degree of prote	ection		· · · · · · · · · · · · · · · · · · ·	IP44			
Flange size [mi	m]	250 SQ.	250 SQ.	250 SQ.	250 SQ.	250 SQ.	
Total length (excluding shaft) [mm]		469.5	469.5	469.5	539.5	539.5	
Flange fitting diameter [mm]		φ230	φ230	φ230	φ230	φ 230	
Shaft diameter	[mm]	φ 48	φ48	φ48	φ 55	φ55	
Mass [kg]		110	110	110	135	135	
Heat-resistant	class			F (155°C)		1	

(Note) The tolerable radial load is the value calculated at the center of output shaft.



< SJ-V Series (Standard) >

Power facility capacity [kVA]	Spindle motor	type	SJ-V26-01ZT	SJ-V37-01ZT	SJ-V45-01ZT	SJ-V55-01ZT		
unit type MDS-D-SP2- - - - Output capacity Continuous rating [kW] 22 30 37 45 Short time rating [kW] 26 (30-minute rating) 37 (30-minute rating) 45 (30-minute rating) 55 (30-minute rating) Power facility capacity [kVA] 46.1 65.5 79.6 97.2 Base rotation speed [r/min] 1500 1150 1500 1150 Maximum rotation speed [r/min] 8000 6000 6000 4500 Frame No. C160 B180 B180 A225 Continuous rated torque [N•m] 140 249 236 374 GD² [kg·m²] 0.37 1.36 1.36 3.39 Inertia [kg·m²] 0.0925 0.34 0.34 0.848 Tolerable radial load [N] 2940 3920 3920 5880 Maximum power consumption 63W 175W 175W 115W Environment Ambient temperature Operation: 90%RH or less (with no dew condensation), Storage: -20°C to 65°C (with no freezing) <		MDS-D-SP-	320	400	640	640		
capacity Short time rating [kW] 26 (30-minute rating) 37 (30-minute rating) 45 (30-minute rating) 55 (30-minute rating) Power facility capacity [kVA] 46.1 65.5 79.6 97.2 Base rotation speed [r/min] 1500 1150 1500 1150 Maximum rotation speed [r/min] 8000 6000 6000 4500 Frame No. C160 B180 B180 A225 Continuous rated torque [N•m] 140 249 236 374 GD² [kg•m²] 0.37 1.36 1.36 3.39 Inertia [kg•m²] 0.0925 0.34 0.34 0.848 Tolerable radial load [N] 2940 3920 3920 5880 Cooling fan Maximum power consumption 63W 175W 175W 115W Ambient temperature Operation: 90%RH or less (with no freezing), Storage: -20°C to 65°C (with no freezing) Ambient humidity Operation: 90%RH or less (with no dew condensation), Storage: 90°C to 65°C (with no dew condensation) Altitude Operation: 1000 meters or less above sea level, Storage: 1000 meters or less above sea level	•	MDS-D-SP2-	-	-	-	-		
Power facility capacity [kVA]	Output	Continuous rating [kW]	22	30	37	45		
Sase rotation speed [r/min] 1500 1150 1500 1150	•	• • •	26 (30-minute rating)	37 (30-minute rating)	45 (30-minute rating)	55 (30-minute rating)		
Maximum rotation speed [r/min] 8000 6000 6000 4500	Power facility of	apacity [kVA]	46.1	65.5	79.6	97.2		
C160 B180 B180 A225	Base rotation s	peed [r/min]	1500	1150	1500	1150		
Continuous rated torque [N•m]	Maximum rotat	ion speed [r/min]	8000	6000	6000	4500		
Degree of protection Cooking fam Cooki	Frame No.		C160	B180	B180	A225		
Inertia [kg•m²] 0.0925 0.34 0.34 0.848	Continuous rat	ed torque [N•m]	140	249	236	374		
Tolerable radial load [N] 2940 3920 3920 5880 Cooling fan Maximum power consumption 63W 175W 175W 115W Ambient temperature Operation: 0 to 40°C (with no freezing), Storage: -20°C to 65°C (with no freezing) Ambient humidity Operation: 90%RH or less (with no dew condensation), Storage: 90%RH or less (with no dew condensation) Atmosphere Indoors (no direct sunlight); no corrosive gas, inflammable gas, oil mist, or dust Operation: 1000 meters or less above sea level, Storage: 1000 meters or less above sea level Transportation: 10000 meters or less above sea level Flange size [mm] 250 SQ. 320 SQ. 320 SQ. 480 SQ.	GD ² [kg•m ²]		0.37	1.36	1.36	3.39		
Input voltage 3-phase 200V 3-phase 200V 3-phase 200V 3-phase 200V 3-phase 200V 3-phase 200V	Inertia [kg•m²]		0.0925	0.34	0.34	0.848		
Maximum power consumption 63W 175W 175W 115W	Tolerable radia	l load [N]	2940	3920	3920	5880		
Consumption 63W 175W 1		Input voltage	3-phase 200V	3-phase 200V	3-phase 200V	3-phase 200V		
Ambient temperature Ambient humidity Operation: 0 to 40°C (with no freezing), Storage: -20°C to 65°C (with no freezing) Ambient humidity Operation: 90%RH or less (with no dew condensation), Storage: 90%RH or less (with no dew condensation) Atmosphere Indoors (no direct sunlight); no corrosive gas, inflammable gas, oil mist, or dust Operation: 1000 meters or less above sea level, Storage: 1000 meters or less above sea level Transportation: 10000 meters or less above sea level Degree of protection IP44 Flange size [mm] 250 SQ. 320 SQ. 320 SQ. 480 SQ.	Cooling fan		63W	175W	175W	115W		
Ambient humidity Atmosphere Altitude Altitude Altitude Ambient humidity Operation: 90%RH or less (with no dew condensation), Storage: 90%RH or less (with no dew condensation) Indoors (no direct sunlight); no corrosive gas, inflammable gas, oil mist, or dust Operation: 1000 meters or less above sea level, Storage: 1000 meters or less above sea level Transportation: 10000 meters or less above sea level IP44 Flange size [mm] 250 SQ. 320 SQ. 480 SQ.		•						
Environment Atmosphere Indoors (no direct sunlight); no corrosive gas, inflammable gas, oil mist, or dust Altitude Operation: 1000 meters or less above sea level, Storage: 1000 meters or less above sea level Transportation: 10000 meters or less above sea level Degree of protection IP44 Flange size [mm] 250 SQ. 320 SQ. 320 SQ. 480 SQ.		•	1 (6)					
Altitude Operation: 1000 meters or less above sea level, Storage: 1000 meters or less above sea level Transportation: 10000 meters or less above sea level Degree of protection IP44 Flange size [mm] 250 SQ. 320 SQ. 480 SQ.			Operation: 90%RH or less (with no dew condensation), Storage: 90%RH or less (with no dew condensation)					
Transportation: 10000 meters or less above sea level	Environment	Atmosphere	Indoors (no direct sunlight); no corrosive gas, inflammable gas, oil mist, or dust					
Degree of protection IP44 Flange size [mm] 250 SQ. 320 SQ. 320 SQ. 480 SQ.		Altitude	, ,					
Flange size [mm] 250 SQ. 320 SQ. 320 SQ. 480 SQ.								
•								
Total langth (evaluding shaft) [mm] 505.5 700 700	•	•						
		· /· ·	585.5	700	700	724		
Flange fitting diameter [mm] ϕ 230 ϕ 300 ϕ 300 ϕ 450		•	,	,	,	,		
Shaft diameter [mm] ϕ 55 ϕ 60 ϕ 60 ϕ 75	Shaft diameter	[mm]	·	φ60	'	φ75		
Mass [kg] 155 300 300 450	Mass [kg]		155			450		
Heat-resistant class F (155°C)	Heat-resistant	class		F (15	55°C)			

(Note) The tolerable radial load is the value calculated at the center of output shaft.



< SJ-V Series (High-speed) >

Spindle motor	type	SJ-VL2.2-02ZT	SJ-V3.7-02ZT	SJ-V11-06ZT	SJ-V11-08ZT		
	MDS-D-SP-	40	80	200	200		
Compatible spindle drive unit type	MDS-D-SP2-	4020 (L) 4040S (L,M) 4040 (L,M) 8040 (M)	8040 (L) 16080S (M) 8080 (L,M) 16080 (M)	-	-		
Output	Continuous rating [kW]	1.5	2.2	5.5	7.5		
capacity	Short time rating [kW]	2.2 (15-minute rating)	3.7 (15-minute rating)	7.5 (30-minute rating)	11 (30-minute rating)		
Power facility of	apacity [kVA]	4.1	6.7	13.4	19.6		
Base rotation s	peed [r/min]	3000	3000	1500	1500		
Maximum rotat	ion speed [r/min]	15000	15000	12000	8000		
Frame No.		B71	A90	A112	B112		
Continuous rat	ed torque [N•m]	4.77	7.0	35.0	47.7		
GD ² [kg•m ²]		0.0096	0.027	0.098	0.12		
Inertia [kg•m²]		0.0024	0.007	0.025	0.03		
Tolerable radial load [N]		196	245	980	1470		
	Input voltage	Single-phase 200V	Single-phase 200V	3-phase 240V	3-phase 240V		
Cooling fan	Maximum power consumption	14W	42W	40W	40W		
	Ambient temperature	Operation: 0 to 40°C (with no freezing), Storage: -20°C to 65°C (with no freezing)					
	Ambient humidity	Operation: 90%RH or less (with no dew condensation), Storage: 90%RH or less (with no dew condensation)					
Environment	Atmosphere	Indoors (no direct sunlight); no corrosive gas, inflammable gas, oil mist, or dust					
Altitude Operation: 1000 meters or less above sea level, Storage: 1000 meters Transportation: 10000 meters or less above sea level					ss above sea level		
Degree of prote	ection		IP	44			
Flange size [m	-	130 SQ.	174 SQ.	204 SQ.	204 SQ.		
	ccluding shaft) [mm]	325	300	440	490		
Flange fitting d	iameter [mm]	φ110	φ150	φ180	φ 180		
Shaft diameter	[mm]	φ22	φ28	φ32	φ48		
Mass [kg]		20	25	60	70		
Heat-resistant class F (155°C)							

(Note) The tolerable radial load is the value calculated at the center of output shaft.



< SJ-V Series (High-speed) >

Spindle drive unit type	Spindle motor t	type	SJ-V22-06ZT	SJ-V18.5-04ZT	SJ-V30-02ZT			
unit type MDS-D-SP2- - - Output capacity Continuous rating [kW] 11 15 18.5 Short time rating [kW] 15 (30-minute rating) 18.5 (30-minute rating) 22 (30-minute rating) Power facility capacity [kVA] 26.7 32.8 39.0 Base rotation speed [r/min] 1500 1500 1500 Maximum rotation speed [r/min] 8000 8000 8000 Frame No. A160 A160 B160 Continuous rated torque [N•m] 70.0 95.5 118 GD² [kg•m²] 0.23 0.23 0.32 Inertia [kg•m²] 0.06 0.0575 0.08 Tolerable radial load [N] 1960 2940 1960 Maximum power consumption 63W 63W 63W Maximum power consumption 63W 63W 63W Ambient temperature Operation: 90%RH or less (with no freezing), Storage: -20°C to 65°C (with no freezing) Ambient humidity Operation: 90%RH or less (with no dew condensation), Storage: 90%RH or less (with no dew condensation)	Compatible	MDS-D-SP-	240	240	320			
capacity Short time rating [kW] 15 (30-minute rating) 18.5 (30-minute rating) 22 (30-minute rating) Power facility capacity [kVA] 26.7 32.8 39.0 Base rotation speed [r/min] 1500 1500 1500 Maximum rotation speed [r/min] 8000 8000 8000 Frame No. A160 A160 B160 Continuous rated torque [N•m] 70.0 95.5 118 GD² [kg•m²] 0.23 0.23 0.23 0.32 Inertia [kg•m²] 0.06 0.0575 0.08 Tolerable radial load [N] 1960 2940 1960 Maximum power consumption 63W 63W Maximum power consumption 63W 63W Ambient temperature Operation: 0 to 40°C (with no freezing), Storage: -20°C to 65°C (with no freezing) Ambient humidity Operation: 90%RH or less (with no dew condensation), Storage: 90%RH or less (with no dew condensation) Altitude Operation: 1000 meters or less above sea level, Storage: 1000 meters or less above sea level	spindle drive unit type	MDS-D-SP2-	-	-	-			
Power facility capacity [kVA] 26.7 32.8 39.0	Output	Continuous rating [kW]	11	15	18.5			
Base rotation speed [r/min]	capacity	Short time rating [kW]	15 (30-minute rating)	18.5 (30-minute rating)	22 (30-minute rating)			
Maximum rotation speed [r/min] 8000 8000 8000	Power facility of	apacity [kVA]	26.7	32.8	39.0			
A160	Base rotation s	peed [r/min]	1500	1500	1500			
Continuous rated torque [N•m] 70.0 95.5 118	Maximum rotat	ion speed [r/min]	8000	8000	8000			
December 2 December 3 December 3 December 4 December 4 December 4 December 4 December 5 December 6 Dec	Frame No.		A160	A160	B160			
Inertia [kg•m²] 0.06 0.0575 0.08 Tolerable radial load [N] 1960 2940 1960 Cooling fan Input voltage 3-phase 240V 3-phase 240V 3-phase 240V Maximum power consumption 63W 63W Ambient temperature Operation: 0 to 40°C (with no freezing), Storage: -20°C to 65°C (with no freezing) Ambient humidity Operation: 90%RH or less (with no dew condensation), Storage: 90%RH or less (with no dew condensation) Atmosphere Indoors (no direct sunlight); no corrosive gas, inflammable gas, oil mist, or dust Operation: 1000 meters or less above sea level Storage: 1000 meters or less above sea level	Continuous rat	ed torque [N•m]	70.0	95.5	118			
Tolerable radial load [N] 1960 2940 1960 3-phase 240V 3-phase 240V 3-phase 240V 3-phase 240V 63W 63W Ambient temperature Ambient humidity Operation: 90%RH or less (with no dew condensation), Storage: -20°C to 65°C (with no freezing) Atmosphere Indoors (no direct sunlight); no corrosive gas, inflammable gas, oil mist, or dust Operation: 1000 meters or less above sea level, Storage: 1000 meters or less above sea level	GD ² [kg•m ²]		0.23	0.23	0.32			
Input voltage 3-phase 240V 3-phase 240V 3-phase 240V 3-phase 240V	Inertia [kg•m²]		0.06	0.0575	0.08			
Cooling fan Maximum power consumption Ambient temperature Ambient humidity Atmosphere Indoors (no direct sunlight); no corrosive gas, inflammable gas, oil mist, or dust Operation: 1000 meters or less above sea level, Storage: 1000 meters or less above sea level	Tolerable radia	l load [N]	1960	2940	1960			
consumption 63W 63W 63W 63W 63W 63W 63W 63	Input voltage		3-phase 240V	3-phase 240V	3-phase 240V			
Ambient temperature Operation: 0 to 40°C (with no freezing), Storage: -20°C to 65°C (with no freezing) Ambient humidity Operation: 90%RH or less (with no dew condensation), Storage: 90%RH or less (with no dew condensation) Atmosphere Indoors (no direct sunlight); no corrosive gas, inflammable gas, oil mist, or dust Operation: 1000 meters or less above sea level, Storage: 1000 meters or less above sea level	Cooling fan	•	63W	63W	63W			
Ambient humidity Operation: 90%RH or less (with no dew condensation), Storage: 90%RH or less (with no dew condensation) Atmosphere Indoors (no direct sunlight); no corrosive gas, inflammable gas, oil mist, or dust Operation: 1000 meters or less above sea level, Storage: 1000 meters or less above sea level		•	Operation: 0 to 40°C (with no freezing). Storage: -20°C to 65°C (with no freezing).					
Environment Atmosphere Indoors (no direct sunlight); no corrosive gas, inflammable gas, oil mist, or dust Operation: 1000 meters or less above sea level, Storage: 1000 meters or less above sea level		•	1 (3/) 0 (6/					
Operation: 1000 meters or less above sea level, Storage: 1000 meters or less above sea level	Environment		, ,					
I Altitude	Liiviioiiiiciit	Autiosphere						
	Altitude		, ,					
Degree of protection IP44	Degree of prote	ection		IP44				
Flange size [mm] 250 SQ. 250 SQ. 250 SQ.	Flange size [mi	m]	250 SQ.	250 SQ.	250 SQ.			
Total length (excluding shaft) [mm] 469.5 469.5 539.5	Total length (ex	ccluding shaft) [mm]	469.5	469.5	539.5			
Flange fitting diameter [mm] ϕ 230 ϕ 230 ϕ 230	Flange fitting d	iameter [mm]	φ230	φ230	φ230			
Shaft diameter [mm] φ 48 φ 48 φ 55	Shaft diameter	[mm]	ϕ 48	φ48	φ55			
Mass [kg] 125 110 155	Mass [kg]		125	110	155			
Heat-resistant class F (155°C)	Heat-resistant	class		F (155°C)				

(Note) The tolerable radial load is the value calculated at the center of output shaft.



< SJ-V Series (Wide range constant output) >

Spindle motor type		SJ-V11-01T	SJ-V11-09T	SJ-V15-03T	SJ-V18.5-03T
Compatible	MDS-D-SP-	160	160	200	240
spindle drive unit type	MDS-D-SP2-	16080S (L)	16080S (L)	_	_
		16080 (L)	16080 (L)		
Output	Continuous rating [kW]	3.7	5.5	7.5	9
capacity	Short time rating [kW]	5.5 (30-minute rating)	7.5 (30-minute rating)	9 (30-minute rating)	11 (30-minute rating)
Power facility capacity [kVA]		9.9	13.4	16.1	19.6
Base rotation speed [r/min]		750	750	750	750
Maximum rotation speed [r/min]		6000	6000	6000	6000
Frame No.		B112	A160	A160	B160
Continuous rated torque [N•m]		47.1	70.0	95.5	115
GD ² [kg•m ²]		0.12	0.23	0.23	0.32
Inertia [kg•m²]		0.03	0.06	0.06	0.08
Tolerable radial load [N]		1960	2940	2940	2940
Cooling fan	Input voltage	3-phase 240V	3-phase 240V	3-phase 240V	3-phase 240V
	Maximum power consumption	40W	63W	63W	63W
Environment	Ambient temperature	Operation: 0 to 40°C (with no freezing), Storage: -20°C to 65°C (with no freezing)			
	Ambient humidity	Operation: 90%RH or less (with no dew condensation), Storage: 90%RH or less (with no dew condensation)			
	Atmosphere	Indoors (no direct sunlight); no corrosive gas, inflammable gas, oil mist, or dust			
	Altitude	Operation: 1000 meters or less above sea level, Storage: 1000 meters or less above sea level			
		Transportation: 10000 meters or less above sea level			
Degree of protection		IP44			
Flange size [mm]		204 SQ.	250 SQ.	250 SQ.	250 SQ.
Total length (excluding shaft) [mm]		490	469.5	469.5	539.5
Flange fitting diameter [mm]		φ 180	φ230	φ230	φ230
Shaft diameter [mm]		φ48	φ 48	φ48	φ55
Mass [kg]		70	110	110	135
Heat-resistant class		F (155°C)			

(Note) The tolerable radial load is the value calculated at the center of output shaft.



< SJ-V Series (Wide range constant output) >

Spindle motor	type	SJ-V22-05T	SJ-V22-09T	SJ-VK22-19ZT			
Compatible	MDS-D-SP-	320	320	32	20		
spindle drive unit type	MDS-D-SP2-	-	-	-			
Output	Continuous rating [kW]	11	15	13	18.5		
capacity	Short time rating [kW]	15 (30-minute rating)	18.5 (30-minute rating)	18.5 (15-minute rating)	22 (30-minute rating)		
Power facility of	apacity [kVA]	26.7	32.8	32.8	39.0		
Base rotation s	peed [r/min]	750	500	330	575		
Maximum rotat	ion speed [r/min]	6000	4500	750	6000		
Frame No.		B160	A180	B1	80		
Continuous rat	ed torque [N•m]	140	239	310	307.3		
GD ² [kg•m ²]		0.32	1.23	1.3	36		
Inertia [kg•m²]		0.08	0.31	0.34			
Tolerable radia	l load [N]	2940	3920	3920			
	Input voltage	3-phase 240V	3-phase 200V	3-phase 200V			
Cooling fan	Maximum power	63W	175W	175W			
	consumption						
	Ambient temperature		(0//	Storage: -20°C to 65°C (with r	0/		
	Ambient humidity	•	,), Storage: 90%RH or less (wi	,		
Environment	Atmosphere	,	0 //	prosive gas, inflammable gas, oil mist, or dust			
	Altitude	Operation: 1000 n		l, Storage: 1000 meters or les	ss above sea level		
				ers or less above sea level			
Degree of prote				44			
Flange size [mi	•	250 SQ.	320 SQ.	320 SQ.			
	ccluding shaft) [mm]	539.5	631	700			
Flange fitting d	•	φ230	φ300	φ300			
Shaft diameter	[mm]	φ 55	φ60	φ60			
Mass [kg]		135	280	30	00		
Heat-resistant	class		F (15	55°C)			

(Note) The tolerable radial load is the value calculated at the center of output shaft.



< SJ-VL Series (Low-inertia) >

Spindle motor	type	SJ-VL11-05FZT- S01	SJ-VL11-10FZT	SJ-VL11-10FZT	SJ-VL11-07ZT	SJ-VL11-07ZT		
Compatible	MDS-D-SP-	160	160	160	160	160		
spindle drive unit type	MDS-D-SP2-	16080S (L) 16080 (L)	16080S (L) 16080 (L)	-	16080S (L) 16080 (L)	16080S (L) 16080 (L)		
Output	Continuous rating [kW]	1.5	2.2 3.7		5.5	7.5		
capacity	Short time rating [kW]	3 (10-minute rating)	3.7 (15-minute rating)	5.5 (15-minute rating)	7.5 (30-minute rating)	11 (15-minute rating)		
Power facility of	apacity [kVA]	5.5	6.7	9.9	13.4	19.6		
Base rotation s	peed [r/min]	5000	1700	3000 (10-minute rating: 2500)	1500	2200		
Maximum rotat	ion speed [r/min]	20000	15000	15000	12000	12000		
Frame No.		B71	D90	D90	B112	B112		
Continuous rat	ed torque [N•m]	2.8	12.4	11.8	35	32.6		
GD ² [kg•m ²]		0.0096	0.021	0.021	0.072	0.072		
Inertia [kg•m²]		0.0024	0.00525	0.00525	0.018	0.018		
Tolerable radia	l load [N]	980	245	245	980	980		
	Input voltage	Single-phase 200V	Single-phase 200V	Single-phase 200V	3-phase 240V	3-phase 240V		
Cooling fan	Maximum power consumption	14W	41W	41W	40W	40W		
	Ambient temperature	Operation: 0 to 40°C (with no freezing), Storage: -20°C to 65°C (with no freezing)						
	Ambient humidity	Operation: 90%RH or less (with no dew condensation), Storage: 90%RH or less (with no dew condensation)						
Environment	Atmosphere		· 0 //	no corrosive gas, inflan	0 ,			
	Altitude	Operation: 1		ve sea level, Storage: 1 10000 meters or less a		ove sea level		
Degree of prote	ection	IP44						
Flange size [mi	Flange size [mm]		174 SQ.	174 SQ.	204 SQ.	204 SQ.		
Total length (ex	ccluding shaft) [mm]	335	441	441	490	490		
Flange fitting diameter [mm]		φ110	φ 150	φ 150	φ180	φ 180		
Shaft diameter	[mm]	φ22	φ28	φ28	φ32	φ32		
Mass [kg]		20	40	40	70	70		
Heat-resistant	class			F (155°C)				

(Note) The tolerable radial load is the value calculated at the center of output shaft.



(2) 400V series

< SJ-4-V Series (Standard) >

Spindle motor t	уре	SJ-4-V2.2-03T	SJ-4-V3.7-03T	SJ-4-V5.5-07T	SJ-4-V7.5-12T	SJ-4-V11-18T	SJ-4-V15-18T	
Compatible spindle drive unit type	MDS-DH-SP-		20		40		100	
	Continuous rating [kW]	1.5	2.2	3.7	5.5	7.5	11	
Output		2.2	3.7	5.5	7.5	11	15	
capacity	Short time rating [kW]	(15-minute	(15-minute	(30-minute	(30-minute	(30-minute	(30-minute	
		rating)	rating)	rating)	rating)	rating)	rating)	
Power facility of		4.1	6.7	9.9	13.4	19.6	26.7	
Base rotation s	•				500			
	ion speed [r/min]		000		000		000	
Frame No.		A90	B90	D90	A112	B112	A160	
	ed torque [N•m]	9.5	14.0	23.5	35.0	47.7	70.0	
GD ² [kg•m ²]	[kg•m²] 0.0		0.035	0.059	0.098	0.12	0.23	
Inertia [kg•m²]		0.007	0.009	0.015	0.025	0.025 0.03 0.06		
Tolerable radia	l load [N]	98	80	1470	19	060	2940	
	Input voltage	Single-phase 400V					3-phase 400V	
Cooling fan	Maximum power		30W		70	70W		
	consumption					72W		
	Ambient temperature	'		(with no freezing),	· ·	`	07	
	Ambient humidity	Operation: 90%	RH or less (with no	dew condensation	dew condensation), Storage: 90%RH or less (with no dew condensation)			
Environment	Atmosphere		`	ınlight); no corrosiv	o ,	0 ,		
	Altitude	Operatio		ess above sea level ortation: 10000 met			sea level,	
Degree of prote	ection			IP	44			
Flange size [mr	n]	174 SQ.	174 SQ.	174 SQ.	204 SQ.	204 SQ.	250 SQ.	
Total length (ex	cluding shaft) [mm]	300	330	425	440	490	469.5	
Flange fitting diameter [mm]		φ 150	φ 150	φ 150	φ 180	φ 180	φ230	
Shaft diameter [mm]		φ28	φ28	φ28	φ32	φ 48	φ48	
Mass [kg]		25 30 49 60 70					110	
Heat-resistant	class		•	F (15	55°C)	•	•	
/A.L. (A) T.L.					4.40) (4.0 50)	11 /000 / 40	0.440.0011.	

(Note 1) The rated output is guaranteed at the rated input voltage (380 to 440VAC 50Hz / 380 to 480VAC 60Hz) to the power supply unit. If the input voltage fluctuates and drops below 380VAC, the rated output may not be attained.

(Note 2) The tolerable radial load is the value calculated at the center of output shaft.



< SJ-4-V Series (Standard) >

Spindle motor t	уре	SJ-4-V18.5-14T	SJ-4-V22-15T	SJ-4-V26-08T	SJ-4-V37-04T	SJ-4-V45-02T	SJ-4-V55-03T	
Compatible spindle drive unit type	MDS-DH-SP-	100	11	60	200	32	20	
	Continuous rating [kW]	15	18.5	22	30	37	45	
Output capacity	Short time rating [kW]	18.5 (30-minute rating)	22 (30-minute rating)	26 (30-minute rating)	37 (30-minute rating)	45 (30-minute rating)	55 (30-minute rating)	
Power facility c	apacity [kVA]	32.8	39.0	46.1	65.5	79.6	97.2	
Base rotation s	peed [r/min]		1500		1150	1500	1150	
Maximum rotati	on speed [r/min]		6000			3450		
Frame No.		A160	B160	C160	A180	B180	A225	
Continuous rate	ed torque [N•m]	95.5	118	140	249	236	374	
GD ² [kg•m ²]		0.23	0.32	0.38	1.23	1.23 2.19 3.39		
Inertia [kg•m²]		0.06	0.08	0.10	0.31	0.55 0.85		
Tolerable radial	load [N]		2940		39	20	5880	
	Input voltage	3-phase 400V						
Cooling fan	Maximum power consumption	72W			Refer to	each motor specifi	ications.	
	Ambient temperature	Op	eration: 0 to 40°C	(with no freezing),	Storage: -20°C to 6	5°C (with no freezir	ng)	
	Ambient humidity	Operation: 90%	RH or less (with no	dew condensation), Storage: 90%RH	or less (with no dev	w condensation)	
Environment	Atmosphere	Ir	ndoors (no direct su	unlight); no corrosiv	e gas, inflammable	gas, oil mist, or dus	st	
	Altitude	Operation		ess above sea level ortation: 10000 met	, ,		sea level,	
Degree of prote	ction	IP44						
Flange size [mm]		250 SQ.	250 SQ.	250 SQ.	320 SQ.	320 SQ.	480 SQ.	
Total length (ex	cluding shaft) [mm]	469.5	539.5	585.5	631 700 724			
Flange fitting diameter [mm]		φ230	φ230	φ230	φ300	φ300	φ 450	
Shaft diameter	[mm]	φ48	φ55	φ55	φ60	φ60	φ75	
Mass [kg]		110	135	155	280	390	450	
Heat-resistant of	lass			F (15	55°C)			

(Note 1) The rated output is guaranteed at the rated input voltage (380 to 440VAC 50Hz / 380 to 480VAC 60Hz) to the power supply unit. If the input voltage fluctuates and drops below 380VAC, the rated output may not be attained.

(Note 2) The tolerable radial load is the value calculated at the center of output shaft.



< SJ-4-V Series (High-speed) >

Spindle motor ty	/pe	SJ-4-V3.7-05ZT	SJ-4-V7.5-13ZT	SJ-4-V11-22ZT	SJ-4-V11-23ZT	SJ-4-V22-18ZT	SJ-4-V30-15ZT
Compatible spindle drive unit type	MDS-DH-SP-	20	80	100		160	
	Continuous rating [kW]	2.2	5.5	5.5	7.5	11	18.5
Output		3.7	7.5	7.5	11	15	22
capacity	Short time rating [kW]	(15-minute	(30-minute	(30-minute	(30-minute	(30-minute	(30-minute
		rating)	rating)	rating)	rating)	rating)	rating)
Power facility ca		6.7	13.4	13.4	19.6	26.7	39.0
Base rotation sp		3000			1500		
Maximum rotation	on speed [r/min]	15000		000		8000	
Frame No.		A90		12	B112	A160	B160
Continuous rate	d torque [N•m]	7.0	35.0	35.0	47.7	70.0	118
GD ² [kg•m ²]		0.027	0.098	0.098	0.12	0.23	0.32
Inertia [kg•m²]		0.007	0.025	0.025	0.03	0.06 0.08	
Tolerable radial	load [N]	490	98	30	1470	19	60
Cooling fan	Input voltage	Single-phase 400V	3-phase 400V				
Cooling lan	Maximum power consumption	30W		70W	72W		
	Ambient temperature	0	peration: 0 to 40°C	(with no freezing),	Storage: -20°C to 6	5°C (with no freezin	ig)
	Ambient humidity	Operation: 90%	RH or less (with no	dew condensation), Storage: 90%RH	or less (with no dev	v condensation)
Environment	Atmosphere	Į.	ndoors (no direct su	ınlight); no corrosiv	e gas, inflammable	gas, oil mist, or dus	st
	Altitude	Operatio		ess above sea level ortation: 10000 met	, ,	eters or less above s ea level	sea level,
Degree of protect	ction			IP	44		
Flange size [mm]		174 SQ.	204 SQ.	204 SQ.	204 SQ.	250 SQ.	250 SQ.
Total length (excluding shaft) [mm]		300	440	440	490	469.5	539.5
Flange fitting diameter [mm]		φ150	φ 180	φ180	φ 180	φ230	φ230
Shaft diameter [mm]	φ28	φ32	φ32	φ48	φ48	φ 55
Mass [kg]		25	60 70 125 155				
Heat-resistant c	lass			F (15	55°C)		

(Note 1) The rated output is guaranteed at the rated input voltage (380 to 440VAC 50Hz / 380 to 480VAC 60Hz) to the power supply unit. If the input voltage fluctuates and drops below 380VAC, the rated output may not be attained.

(Note 2) The tolerable radial load is the value calculated at the center of output shaft.



< SJ-4-V Series (Wide range constant output)>

Spindle motor t	уре	SJ-4-V11-18T	SJ-4-V11-21T	SJ-4-V15-20T	SJ-4-V18.5-17T	SJ-4-V22-16T		
Compatible spindle drive unit type	MDS-DH-SP-	8	0	100	10	60		
Output	Continuous rating [kW]	3.7	5.5	7.5	9	11		
capacity	Short time rating [kW]	5.5 (30-minute rating)	7.5 (30-minute rating)	9 (30-minute rating)	11 (30-minute rating)	15 (30-minute rating)		
Power facility ca	apacity [kVA]	9.9	13.4	16.1	19.6	26.7		
Base rotation si				750				
	on speed [r/min]			6000				
Frame No.		B112	A1	60	B1	60		
Continuous rate	ed torque [N•m]	47.1	70.0	95.5	115	140		
GD ² [kg•m ²]		0.12	0.23	0.23	0.32	0.32		
Inertia [kg•m²]		0.03	0.06	0.06	0.08 0.08			
Tolerable radial	load [N]	1960		29	940			
	Input voltage	3-phase 400V						
Cooling fan	Maximum power consumption	70W 72W						
	Ambient temperature	Operation: 0 to 40°C (with no freezing), Storage: -20°C to 65°C (with no freezing)						
	Ambient humidity	Operation: 90%RH or less (with no dew condensation), Storage: 90%RH or less (with no dew condensation)						
Environment	Atmosphere	Indo	ors (no direct sunlight);	no corrosive gas, inflar	nmable gas, oil mist, or	dust		
	Altitude	Operation: 1		ve sea level, Storage: 1 : 10000 meters or less a		ve sea level,		
Degree of prote	ction			IP44				
Flange size [mn	1]	204 SQ.	250 SQ.	250 SQ.	Q. 250 SQ. 250 SQ.			
Total length (ex	cluding shaft) [mm]	490	469.5	469.5	539.5	539.5		
Flange fitting diameter [mm]		φ180	φ230	φ230	φ230	φ230		
Shaft diameter	mm]	φ 48	φ48	φ48	φ 55	φ55		
Mass [kg]		70	11	10	1;	35		
Heat-resistant c	lass			F (155°C)				

(Note 1) The rated output is guaranteed at the rated input voltage (380 to 440VAC 50Hz / 380 to 480VAC 60Hz) to the power supply unit. If the input voltage fluctuates and drops below 380VAC, the rated output may not be attained.

(Note 2) The tolerable radial load is the value calculated at the center of output shaft.



< SJ-4-VS Series (Hollow shaft) >

Spindle motor t	ype	SJ-4-VS7.5-13ZT	SJ-4-VS22-18ZT	SJ-4-VS30-15ZT			
Compatible spindle drive unit type	MDS-DH-SP-	80	160				
Output	Continuous rating [kW]	5.5	11	18.5			
capacity	Short time rating [kW]	7.5 (30-minute rating)	15 (30-minute rating)	22 (30-minute rating)			
Power facility c	apacity [kVA]	13.4	26.7	39.0			
Base rotation s		1500	15	500			
Maximum rotati	on speed [r/min]	12000	80	000			
Frame No.		A112	A160	B160			
Continuous rate	ed torque [N•m]	35.0	70.0	118			
GD ² [kg•m ²]		0.099	0.23	0.32			
Inertia [kg•m²]		0.025	0.058	0.08			
Tolerable radial	load [N]	0 (Note 3)	0 (Note 3)	0 (Note 3)			
	Input voltage	3-phase 400V					
Cooling fan	Maximum power consumption	70W	72	2W			
	Ambient temperature	Operation: 0 to 40°C (with no freezing), Storage: -20°C to 65°C (with no freezing)					
	Ambient humidity	Operation: 90%RH or less (with no dew condensation), Storage: 90%RH or less (with no dew condensation)					
Environment	Atmosphere	Indoors (no direct su	unlight); no corrosive gas, inflammable	gas, oil mist, or dust			
	Altitude	Operation: 1000 meters or less above sea level, Storage: 1000 meters or less above sea level, Transportation: 10000 meters or less above sea level					
Degree of prote	ction		IP44				
Flange size [mr	•	204 SQ.	250 SQ.	250 SQ.			
	cluding shaft) [mm]	440	469.5	539.5			
Flange fitting d		φ180	φ230	φ230			
Shaft diameter	[mm]	φ32	φ 48	φ 55			
Mass [kg]		65	115	140			
Heat-resistant of	class	•	F (155°C)	•			

(Note 1) The rated output is guaranteed at the rated input voltage (380 to 440VAC 50Hz / 380 to 480VAC 60Hz) to the power supply unit. If the input voltage fluctuates and drops below 380VAC, the rated output may not be attained.


(Note 2) Do not apply a radial load.





2-2-2 Output characteristics


(1) 200V series

< SJ-D Series (Standard) >














< SJ-DJ Series (Compact & lightweight specifications) >



















< SJ-V Series (High-speed) >





















< SJ-V Series (Wide range constant output) >





< SJ-VL Series (Low-inertia) >













(2) 400V series


< SJ-4-V Series (Standard) >




< SJ-4-V Series (High-speed) >



< SJ-4-V Series (Wide range constant output) >



< SJ-4-VS Series (Hollow shaft) >



2-3 Tool spindle motor

2-3-1 Specifications

< HF-KP Series >

			HF-KP Series				
Tool sp	indle motor type		HF□-W09				
		HF-KP46	HF-KP56	HF-KP96			
Compatible spindle	MDS-D-SP-	20	20	20			
drive unit type	MDS-D-SP2-	2020 (L,M)	2020 (L,M)	2020 (L,M)			
arive unit type	MD3-D-3F2-	4020 (M)	4020 (M)	4020 (M)			
Continuous charac-	Rated output [kW]	0.4	0.5	0.9			
eristics	Rated current [A]	1.5	1.8	3.6			
	Rated torque [N•m]	0.64	0.80	1.43			
Power facility capacity	[kVA]	0.9	1.1	1.8			
Rated rotation speed	[r/min]		6000				
Maximum rotation spe	ed [r/min]	6000					
Maximum current [A]		5.5	11.3	15.5			
Maximum torque [N•m	1]	2.5	5	6.5			
Motor inertia [kg•cm²]		0.24	0.42	1.43			
Motor side detector		Resolution per motor revolution					
violor side detector			260,000 pulse/rev				
Degree of protection		IP67 (The shaft-through portion is excluded.)					
	Ambient temperature	Operation: 0 to 40°C (with no freezing), Storage: -15°C to 70°C (with no freezing)					
	Ambient humidity	·	30%RH or less (with no dew cor 0%RH or less (with no dew con	,,			
Environment	Atmosphere	- C	ht); no corrosive gas, inflamma	,			
	•	` `	on: 1000 meters or less above s	•			
	Altitude	·	e: 10000 meters or less above s	,			
	Vibration		X,Y: 49m/s ² (5G)				
Flange size [mm]		60 SQ.	60 SQ.	80 SQ.			
Total length (excludin	g shaft) [mm]	118.7	140.6	149.1			
lange fitting diamete	r [mm]	φ50	φ50	φ70			
Shaft diameter [mm]		φ14	φ14	φ19			
Mass [kg]		1.2	1.7	2.9			
Heat-resistant class			B (130°C)				
			-				

- (Note 1) The above characteristics values are representative values. The maximum current and maximum torque are the values when combined with the drive unit.
- (Note 2) A 2-axis spindle drive unit (MDS-D-SP2) drives two tool spindle motors only. A spindle motor other than tool spindle motor is not usable.



< HF-SP Series >

		HF-SP Ser	ries		
Tool sp	pindle motor type	HF-SP□-J\	V09		
		HF-SP226	HF-SP406		
	MDS-D-SP-	80	160		
Compatible spindle drive unit type	MDS-D-SP2-	8040 (L) 16080S (M) 8080 (L,M) 16080 (M)	16080S (L) 16080 (L)		
	Rated output [kW]	2.2	4.0		
Continuous charac-	Rated current [A]	8.2	14.4		
teristics	Rated torque [N•m]	3.5	6.37		
Power facility capacit		4.1	7.3		
Rated rotation speed	[r/min]	6000			
Maximum rotation sp	eed [r/min]	6000			
Maximum current [A]		44.0	95.0		
Maximum torque [N•n	n]	50.0			
Motor inertia [kg•cm²]	11.9	23.7		
Motor side detector		Resolution per mot 260,000 puls			
Degree of protection		IP67 (The shaft-through portion is excluded.)			
	Ambient temperature	Operation: 0 to 40°C (w Storage: -15°C to 70°C (377		
	Ambient humidity	Operation: 80%RH or less (with Storage: 90%RH or less (with	,,		
Environment	Atmosphere	Indoors (no direct sunlight); no corrosive ga	as, inflammable gas, oil mist, or dust		
	Altitude	Operation: 1000 meters or I Storage: 10000 meters or I			
	Vibration	X,Y:24.5m/s ²	(2.5G)		
Flange size [mm]		130 SQ.	130 SQ.		
Total length (excluding	ng shaft) [mm]	140.5	184.5		
Flange fitting diameter	er [mm]	φ110	φ110		
Shaft diameter [mm]		φ24	φ24		
Mass [kg]		6.8	10.0		
Heat-resistant class		F (155°C	C)		

- (Note 1) The above characteristics values are representative values. The maximum current and maximum torque are the values when combined with the drive unit.
- (Note 2) A 2-axis spindle drive unit (MDS-D-SP2) drives two tool spindle motors only. A spindle motor other than tool spindle motor is not usable.



< HF Series >

			HF Series							
Tool spin	idle motor type				HF□·	-A48				
		HF75	HF105	HF54	HF104	HF154	HF224	HF204	HF354	
	MDS-D-SP-	20	20	40	40	80	80	80	160	
Compatible spindle drive unit type	MDS-D-SP2-	2020 (L,M) 4020 (M)	2020 (L,M) 4020 (M)	4020 (L) 4040S (L,M) 4040 (L,M) 8040 (M)	4020 (L) 4040S (L,M) 4040 (L,M) 8040 (M)	8040 (L) 16080S(M) 8080 (L,M) 16080 (M)	8040 (L) 16080S(M) 8080 (L,M) 16080 (M)	8040 (L) 16080S(M) 8080 (L,M) 16080 (M)	16080S(L) 16080 (L)	
Continuous	Rated output [kW]	0.75	1.0	0.5	1.0	1.5	2.2	2.0	3.5	
characteris-	Rated current [A]	2.8	3.6	1.8	3.6	5.8	8.5	6.8	13.8	
tics	Rated torque [N•m]	1.8	2.4	1.6	3.2	4.8	7.0	6.4	11.1	
Power facility of		1.5	2.0	1.1	2.0	2.8	4.1	3.7	6.4	
Rated rotation	•	40				30				
	tion speed [r/min]	40	00			30				
Maximum curre	• •	14.0	15.5	16.8	29.0	52.0	57.0	57.0	116.0	
Maximum torqu	ue [N•m]	8.0	11.0	13.0	23.3	42.0	46.5	47.0	90.0	
Motor inertia [k	kg•cm²]	2.6	5.1	6.1	11.9	17.8	23.7	38.3	75.0	
Motor side dete	ector			F	Resolution per r 260,000		า			
Degree of prote	ection			IP67 (T	he shaft-throug	gh portion is ex	cluded.)			
	Ambient tempera- ture	Operation: 0 to 40°C (with no freezing), Storage: -15°C to 70°C (with no freezing)								
	Ambient humidity	Operation: 80%RH or less (with no dew condensation), Storage: 90%RH or less (with no dew condensation)								
Environment	Atmosphere		Indoors (ı	no direct sunlig	ht); no corrosiv	e gas, inflamma	able gas, oil mi	st, or dust		
	Altitude				n: 1000 meters : 10000 meters		,			
	Vibration				X,Y:24.5m	n/s ² (2.5G)				
Flange size [m	m]	90 SQ.	90 SQ.	130 SQ.	130 SQ.	130 SQ.	130 SQ.	176 SQ.	176 SQ.	
Total length (ex	xcluding shaft) [mm]	126.5	162.5	118.5	140.5	162.5	184.5	143.5	183.5	
Flange fitting diameter [mm]		φ80	φ80	φ110	φ110	φ110	φ110	φ114.3	114.3	
Shaft diameter	[mm]	ϕ 14	φ14	φ24	φ24	φ24	φ 24	φ35	φ35	
Mass [kg]		2.5	4.3	4.8	6.5	8.3	10.0/	12.0	19.0	
Heat-resistant	class				F (15	55°C)				

- (Note 1) The above characteristics values are representative values. The maximum current and maximum torque are the values when combined with the drive unit.
- (Note 2) A 2-axis spindle drive unit (MDS-D-SP2) drives two tool spindle motors only. A spindle motor other than tool spindle motor is not usable.



< HF Series >

		HF Series						
Tool spir	ndle motor type			HF⊡	-A48			
		HF123	HF223	HF303	HF453	HF703	HF903	
	MDS-D-SP-	20	40	80	160	160	320	
Compatible spindle drive unit type	MDS-D-SP2-	2020 (L,M) 4020 (M)	4020 (L) 4040S (L,M) 4040 (L,M) 8040 (M)	8040 (L) 16080S(M) 8080 (L,M) 16080 (M)	16080S(L) 16080 (L)	16080S(L) 16080 (L)	-	
Continuous	Rated output [kW]	1.2	2.2	3.0	4.5	7.0	9.0	
characteris-	Rated current [A]	5.2	9.0	10.7	13.4	16.6	27.2	
tics	Rated torque [N•m]	5.7	10.5	14.3	14.3	22.3	28.7	
Power facility		2.3	4.1	5.5	8.1	12.5	16.1	
Rated rotation			2000			3000		
	tion speed [r/min]		2000			3000		
Maximum curr	• •	15.5	29.0	48.0	104.2	108.4	204.0	
Maximum torq	Maximum torque [N•m]		32.0	64.0	122.0	152.0	208.0	
Motor inertia [l	kg•cm²]	11.9	23.7	75.0	112.0	154.0	196.0	
Motor side det	ector			Resolution per i 260,000	motor revolution pulse/rev			
Degree of prot	ection		IP	67 (The shaft-through	gh portion is exclude	d.)		
	Ambient tempera- ture		,	Operation: 0 to 40°0 Storage: -15°C to 70	C (with no freezing), o°C (with no freezing))		
	Ambient humidity	Operation: 80%RH or less (with no dew condensation), Storage: 90%RH or less (with no dew condensation)						
Environment	Atmosphere		Indoors (no direct s	unlight); no corrosiv	e gas, inflammable g	gas, oil mist, or du	st	
	Altitude	Operation: 1000 meters or less above sea level, Storage: 10000 meters or less above sea level						
	Vibration	X,Y:24.5m/s ² (2.5G)					X,Y:9.8m/s ² (1G)	
Flange size [m	m]	130 SQ.	130 SQ.	176 SQ.	176 SQ.	176 SQ.	204 SQ.	
Total length (excluding shaft) [mm]		140.5	184.5	183.5	223.5	263.5	330	
Flange fitting diameter [mm]		φ110	φ110	φ114.3	φ114.3	φ114.3	φ 180	
Shaft diameter	[mm]	φ24	φ24	φ35	φ35	φ35	φ 42	
Mass [kg]		6.5	10.0	19.0	26.0	32.0	45.0	
Heat-resistant	class		•	F (15	55°C)	•	•	


- (Note 1) The above characteristics values are representative values. The maximum current and maximum torque are the values when combined with the drive unit.
- (Note 2) A 2-axis spindle drive unit (MDS-D-SP2) drives two tool spindle motors only. A spindle motor other than tool spindle motor is not usable.




2-3-2 Output characteristics

< HF-KP Series >


[HF-KP46JW09]



[HF-KP56JW09]




[HF-KP96JW09]




< HF-SP Series >

[HF-SP226JW09]




[HF-SP406JW09]




< HF Series >


[HF75]



[HF105]



(Note) The above graphs show the data when applied the input voltage of 200VAC. When the input voltage is 200VAC or less, the short time operation range is limited.



(Note) The above graphs show the data when applied the input voltage of 200VAC. When the input voltage is 200VAC or less, the short time operation range is limited.

2-4 Drive unit

2-4-1 Installation environment conditions

Common installation environment conditions for servo, spindle and power supply unit are shown below.

	Ambient temperature	Operation: 0 to 55°C (with no freezing), Storage / Transportation: -15°C to 70°C (with no freezing)
	Ambient humidity	Operation: 90%RH or less (with no dew condensation) Storage / Transportation: 90%RH or less (with no dew condensation)
Environ- ment	Atmosphere	Indoors (no direct sunlight) With no corrosive gas, inflammable gas, oil mist, dust or conductive fine particles
	Altitude	Operation/Storage: 1000 meters or less above sea level, Transportation: 13000 meters or less above sea level
	Vibration/impact	4.9m/s ² (0.5G) / 49m/s ² (5G)

2-4-2 Servo drive unit

(1) 200V series < MDS-D Series >

				1-axis servo	drive unit MDS	S-D-V1 Series						
Servo drive MDS-D-V1-	• •	20	40	80	160	160W	320	320W				
Nominal ma	aximum current (peak) [A]	20	40	80	160	160	320	320				
Output	Rated voltage [V]			*	155AC		-					
Output	Rated current [A]	4.6	7.8	14.6	29.6	40.2	59.6	83.4				
Input	Rated voltage [V]				270 to 311DC		•					
iliput	Rated current [A]	7	7	14	30	35	45	55				
	Voltage [V]	200AC (50Hz) / 200 to 230AC (60Hz) Tolerable fluctuation : between +10% and -15%										
	Frequency [Hz]		50/60 Tolerable fluctuation: between +3% and -3%									
Control	Maximum current [A]				0.2							
power	Maximum rush current [A]	[A] 30										
	Maximum rush conductivity time [ms]	6										
Earth leaka	ge current [mA]	1 (Max. 2)										
Control me	thod	Sine wave PWM control method										
		Regenerative braking and dynamic brakes										
Braking	Dynamic brakes	Externa Built-in (MDS-E DBU)										
External an	alog output	0 to +5V, 2ch (data for various adjustments)										
Degree of p	protection			IP20 ([over al] / IP00 [Termin	al block TE1])						
Cooling me	thod			Fo	orced wind cooli	ng						
Mass [kg]				3.8		4.5	5.8	7.5				
Heat radiat	ed at rated output [W]	40	58	96	184	245	366	471				
Noise		Less than 55dB										
Unit outline	dimension drawing	A1	A1	A1	A1	B1	C1	D1				

				2-axis	servo drive u	nit MDS-D-V2	Series					
Servo drive MDS-D-V2-	unit type	2020	4020	4040	8040	8080	16080	160160	160160W			
Nominal ma	ximum current (peak) [A]	20/20	40/20	40/40	80/40	80/80	160/80	160/160	160/160			
Output	Rated voltage [V]		•	•	AC	155	•	•	•			
Output	Rated current [A]	4.6/4.6 7.8/4.6 7.8/7.8 14.6/7.8 14.6/14.6 29.6/14.6 29.6/29.6 40.2/40.2										
Input	Rated voltage [V]				270 to	311DC						
прис	Rated current [A]	14(7 / 7)	14(7 / 7)	14(7 / 7)	21(14 / 7)	28(14 / 14)	44(30 / 14)	60(30 / 30)	70(35 / 35)			
	Voltage [V]	2	:00AC (50Hz)	200 to 230A0	C (60Hz) Tol	erable fluctuat	ion : between	+10% and -15	%			
	Frequency [Hz]			50/60 Tole	able fluctuatio	n : between +	3% and -3%					
Control	Maximum current [A]	0.2										
power	Maximum rush current [A]	30										
	Maximum rush conductivity time [ms]	6										
Earth leaka	ge current [mA]	1 (Max. 4 For two axes)										
Control met	hod	Sine wave PWM control method Current control method										
Braking		Regenerative braking and dynamic brakes										
Diaking	Dynamic brakes				Bui	lt-in						
External an	alog output			0 to +5	V, 2ch (data fo	r various adjus	stments)					
Degree of p	rotection			IP20 ([c	over all] / IP00	[Terminal bloc	ck TE1])					
Cooling me	thod				Forced wi	nd cooling						
Mass [kg]		4.5 5.2										
Heat radiate	ed at rated output [W]	70 88 106 144 182 270 358 480										
Noise		Less than 55dB										
Unit outline	dimension drawing	A1	A1	A1	A1	A1	B1	B1	C1			



(2) 400V series < MDS-DH Series >

		1-axis servo drive unit MDS-DH-V1 Series										
Servo drive	• •	10	20	40	80	80W	160	160W	200			
Nominal ma	aximum current (peak) [A]	10	20	40	80	80	160	160	200			
Output	Rated voltage [V]				34	OAC	_					
Output	Rated current [A]	2.3	3.9	7.3	15.0	20.1	29.8	41.7	76.8			
Input	Rated voltage [V]				513 to	648DC						
iliput	Rated current [A]	0.9	1.6	2.9	6.0	8.0	11.9	16.7	39.0			
	Voltage [V]	380 to 440AC (50Hz) / 380 to 480AC (60Hz) Tolerable fluctuation : between +10% and -15%										
	Frequency [Hz]			50/60 Tole	rable fluctuation	on: between +	-3% and -3%					
Control	Maximum current [A]	0.1										
power	Maximum rush current [A]	18										
	Maximum rush conductivity	12 18										
	time [ms]											
Earth leaka	ige current [mA]	1 (Max. 2)										
Control me	thod	Sine wave PWM control method										
Braking				Regen	erative brakin	g and dynamic	brakes					
Draking	Dynamic brakes			Bui	lt-in			External (M	IDS-D-DBU)			
External an	nalog output			0 to +5\	/, 2ch (data fo	or various adju	stments)					
Degree of p	protection			IP20 ([d	over all] / IP00	[Terminal blo	ck TE1])					
Cooling me	ethod				Forced w	ind cooling						
Mass [kg]			3	.8	4.5	5.8	7.5	16.5				
Heat radiat	ed at rated output [W]	46	68	114	215	269	390	542	735			
Noise		Less than 55dB										
Unit outline	e dimension drawing	A1	A1	A1	A1	B1	C1	D1	E1			

		2-axis servo drive unit MDS-DH-V2 Series											
Servo drive MDS-DH-V2		1010	2010	2020	4020	4040	8040	8080	8080W				
Nominal ma (peak) [A]	aximum current	10/10	20/10	20/20	40/20	40/40	80/40	80/80	80/80				
Output	Rated voltage [V]				340	AC							
Output	Rated current [A]	2.3 / 2.3	3.9 / 2.3	3.9 / 3.9	7.3 / 3.9	7.3 / 7.3	15 / 7.3	15 / 15	20.1 / 20.1				
Input	Rated voltage [V]		•	•	513 to	648DC	•	•	•				
input	Rated current [A]	1.8(0.9 / 0.9)	2.5(1.6 / 0.9)	3.2(1.6 / 1.6)	4.5(2.9 / 1.6)	5.8(2.9 / 2.9)	8.9(6.0 / 2.9)	12(6.0 / 6.0)	16(8.0 / 8.0)				
	Voltage [V]	380 to 440AC (50Hz) / 380 to 480AC (60Hz) Tolerable fluctuation : between +10% and -15%											
	Frequency [Hz]			50/60 Tole	erable fluctuatio	n : between +3°	% and -3%						
Control	Maximum current [A]		0.1										
power	Maximum rush current [A]		18										
	Maximum rush conductivity time [ms]	12											
Earth leaka	ge current [mA]	1 (Max. 4 For two axes)											
Control me	thod	Sine wave PWM control method Current control method											
Braking				Rege	nerative brakinç	g and dynamic b	orakes						
Diaking	Dynamic brakes	Built-in											
External an	alog output			0 to +5	V, 2ch (data fo	r various adjust	ments)						
Degree of p	rotection				IP	20							
Cooling me	thod				Forced wi	nd cooling							
Mass [kg]				3.8			5	.2	6.3				
Heat radiate	ed at rated output [W]	82	104	126	172	218	319	420	528				
Noise		Less than 55dB											
Unit outline	dimension drawing	A1	A1	A1	A1	A1	B1	B1	C1				



2-4-3 Spindle drive unit

(1) 200V series < MDS-D Series >

				1-a	kis spindle d	drive unit M	DS-D-SP Se	eries					
Spindle driv MDS-D-SP-	e unit type	20	40	80	160	200	240	320	400	640			
Nominal ma	ximum current (peak) [A]	20	40	80	160	200	240	320	400	640			
Output	Rated voltage [V]		155AC										
Output	Rated current [A]	4.5 10 18 37 63 79 130 174											
Input	Rated voltage [V]	270 to 311DC											
iliput	Rated current [A]	7 13 20 41 76 95 140								210			
	Voltage [V]		200AC (50H	z) / 200 to 2	30AC (60Hz)	Tolerable	fluctuation:	between +1	0% and -15%	, o			
	Frequency [Hz]			50/60	Tolerable flu	ctuation : be	etween +3%	and -3%					
Control	Maximum current [A]					0.2							
power	Maximum rush current [A]					30							
	Maximum rush conductivity time [ms]	6 9											
Earth leakag	ge current [mA]	6 (Max. 15)											
Control met	hod				Sine wave	PWM conti	rol method						
Braking					Reg	enerative bra	aking						
External ana	alog output			0 to	+5V, 2ch (c	lata for vario	us adjustme	nts)					
Degree of pr	rotection			IP2	20 ([over all]	/ IP00 [Term	inal block TI	Ξ1])					
Cooling met	thod				For	ced wind cod	oling						
Mass [kg]			3.8		4.5	5.8	6.5	7.5	16	6.5			
Heat radiate	d at continuous rated output [W]	55	94	158	290	481	620	806	1045	1427			
Noise		Less than 55dB											
Unit outline	dimension drawing	A1	A1	A1	B1	C1	D1	D2	E1	F1			

				2-axis s	pindle drive ι	ınit MDS-D-S	P Series				
Spindle drive MDS-D-SP-	unit type	2020	4020	4040S	4040	8040	16080S	8080	16080		
Nominal maxi	mum current (peak) [A]	20/20	40/20	40/40	40/40	80/40	160/80	80/80	160/80		
Output	Rated voltage [V]				AC	155					
Output	Rated current [A]	4.5 / 4.5	10 / 4.5	10 / 10	10 / 10	18 / 10	37 / 18	18 / 18	37 / 18		
Input	Rated voltage [V]				270 to	311DC					
прис	Rated current [A]	14(7 / 7)	20(13 / 7)	26(13 / 13)	26(13 / 13)	33(20 / 13)	61(41 / 20)	40(20 / 20)	61(41 / 20)		
	Voltage [V]	2	00AC (50Hz)	200 to 230AC	(60Hz) Tole	rable fluctuati	on : between	+10% and -15	%		
	Frequency [Hz]			50/60 Tole	rable fluctuation	n : between -	+3% and -3%				
Control	Maximum current [A]				0	.2					
power	Maximum rush current [A]				3	0					
	Maximum rush conductiv- ity time [ms]	6									
Earth leakage	current [mA]	6 (Max. 15)									
Control metho	od	Sine wave PWM control method									
Braking					Regenerat	ive braking					
External analo	og output			0 to +5\	/, 2ch (data fo	r various adjus	stments)				
Degree of pro	tection			IP20 ([c	over all] / IP00	[Terminal bloc	k TE1])				
Cooling meth	od				Forced wi	nd cooling					
Mass [kg]	Mass [kg]		4.5	4.5	6.5	6.5	5.2	6.5	6.5		
Heat radiated [W]	at continuous rated output	90	129	168	168	232	428	298	428		
Noise		Less than 55dB									
Unit outline d	imension drawing	A1	A1	A1	B1	B1	B1	C1	C1		



(2) 400V series

< MDS-DH Series >

				1-axis sp	indle drive u	nit MDS-DH-S	SP Series					
Spindle drive MDS-DH-SP-	unit type	20	40	80	100	160	200	320	480			
Nominal maxii	num current (peak) [A]	20	40	80	100	160	200	320	480			
Output	Rated voltage [V]				340)AC						
Cutput	Rated current [A]	9 13 19 30 65 70 103 132										
Input	Rated voltage [V]				513 to	648DC						
прис	Rated current [A]	10	15	21	38	72	82	119	150			
	Voltage [V]	380 to	440AC (50H	lz) / 380 to 480	0AC (60Hz)	Tolerable fluct	uation : betwe	en +10% and	-15%			
	Frequency [Hz]			50/60 Tole	rable fluctuation	on : between +	-3% and -3%					
Control	Maximum current [A]	0.1										
power	Maximum rush current [A]				1	8						
	Maximum rush conductivity time [ms]			12		18						
Earth leakage	current [mA]	6 (Max. 15)										
Control metho	d	Sine wave PWM control method										
Braking					Regenerat	ive braking						
External analo	g output			0 to +5\	/, 2ch (data fo	r various adjus	stments)					
Degree of prot	ection			IP20 ([o	ver all] / IP00	[Terminal bloc	ck TE1])					
Cooling metho	od				Forced wi	nd cooling						
Mass [kg]		3.8	4	.5	5.8	7.5	16	6.5	22.5			
Heat radiated	at continuous rated output [W]	120 200 291 442 749 872 1202 1720										
Noise		Less than 55dB										
Unit outline di	mension drawing	A1	A1	B1	C1	D1	E1	E1	F1			

(Note) Rated output capacity and rated speed of the motor used in combination with the drive unit are as indicated when using the power supply voltage and frequency listed. The torque drops when the voltage is less than specified.



2-4-4 Power supply unit

(1) 200V series

< MDS-D Series >

				Powe	er supply unit	MDS-D-CV	Series					
Power suppl MDS-D-CV-	y unit type	37	75	110	185	300	370	450	550			
Rated outpu	t [kW]	3.7	7.5	11.0	18.5	30.0	37.0	45.0	55.0			
Power facilit	y capacity [kVA]	5.3 11.0 16.0 27.0 43.0 53.0 64.0 78.0										
	Rated voltage [V]	200AC (50Hz) / 200 to 230AC (60Hz) Tolerable fluctuation : between +10% and -15%										
Input	Frequency [Hz]	50/60 Tolerable fluctuation: between +3% and -3%										
	Rated current [A]	15	26	35	65	107	121	148	200			
Output	Rated voltage [V]			•	270 to	311DC	•	•	•			
Output	Rated current [A]	17	30	41	76	144	164	198	238			
	Voltage [V]	20	0AC (50Hz) /	200 to 230AC	(60Hz) Tole	erable fluctua	tion : between	+10% and -1	5%			
-	Frequency [Hz]	50/60 Tolerable fluctuation: between +3% and -3%										
Control	Maximum current [A]	0.2										
power	Maximum rush current [A]	3	8	30								
	Maximum rush conductivity time [ms]	3 6										
Main circuit	method			Conve	rter with powe	r regeneration	n circuit					
Degree of pr	otection	IP20 ([over all] / IP00 [Terminal block TE1])										
Cooling met	hod				Forced wi	nd cooling						
Mass [kg]		4	.0	6	.0		10.0		25.5			
Heat radiate	d at rated output [W]	54	79	124	193	317	396	496	595			
Noise		Less than 55dB										
Unit outline	Init outline dimension drawing		A2	B1	B1	D1	D1	D2	F1			


(2) 400V series


< MDS-DH Series >


		Power supply unit MDS-DH-CV Series											
Power supp MDS-DH-CV	, ,,	37	75	110	185	300	370	450	550	750			
Rated outpu	t [kW]	3.7	7.5	11.0	18.5	30.0	37.0	45.0	55.0	75.0			
Power facilit	ty capacity [kVA]	5.3 11.0 16.0 27.0 43.0 53.0 64.0 78.0 107.0											
	Rated voltage [V]	380 to 440AC (50Hz)/380 to 480AC (60Hz) Tolerable fluctuation : between +10% and -15%											
Input	Frequency [Hz]		50/60 Tolerable fluctuation : between +3% and -3%										
	Rated current [A]	5.2	13	18	35	61	70	85	106	130			
Output	Rated voltage [V]					13 to 648D	Ċ						
Output	Rated current [A]	7.1	15	21	38	72	82	99	119	150			
	Voltage [V]	380	to 440AC (50Hz)/380 to	480AC (60I	Hz) Tolerab	ole fluctuatio	n : between	+10% and -	15%			
	Frequency [Hz]	50/60 Tolerable fluctuation : between +3% and -3%											
Control	Maximum current [A]	0.1											
power	Maximum rush current [A]					18							
	Maximum rush conductivity time [ms]	12											
Main circuit	method			C	onverter with	power rege	neration circ	cuit					
Degree of pr	rotection			IP2	20 ([over all]	/ IP00 [Term	inal block T	E1])					
Cooling met	hod				For	ced wind cod	oling						
Mass [kg]	lass [kg]		6.0 10.0 2							5.5			
Heat radiate	d at rated output [W]	54 79 124 193 317 402 496 595 842											
Noise		Less than 55dB											
Unit outline	dimension drawing	B1	B1	B1	B1	D1	D1	D1	F1	F1			





2-4-5 Unit outline dimension drawing

















2-4-6 AC reactor

An AC reactor must be installed for each power supply unit.

(1) 200V series

< MDS-D Series >

					AC reactor						
AC reactor mo			11K	18.5K	30K	37K	45K	55K			
Compatible po	ower supply unit type	37,75	110	185	300	370	450	550			
Rated capacity	/ [kW]	7.5	11	18.5	30	37	45	55			
Rated voltage	[V]	200	AC (50Hz) / 200	to 230AC (60H	z) Tolerable flu	actuation : betwe	en +10% and -1	15%			
Rated current	[A]	27	40	66	110	133	162	200			
Frequency [Hz	:]	50/60 Tolerable fluctuation: between +3% and -3%									
	Ambient temperature	Operation: -10°C to 60°C (with no freezing), Storage/Transportation: -10°C to 60°C (with no freezing)									
	Ambient humidity			eration: 80%RH ransportation: 8	,		, ,				
Environment	Atmosphere		Wit	Indoo h no corrosive g	ors (no direct sur as, inflammable	O ,	dust				
	Altitude	Operation/Stor	age: 1000 mete	rs or less above	sea level, Trans	portation: 10000	meters or less a	above sea level			
	Vibration / impact			9.8m/s	s ² (1G) / 98m/s ²	(10G)					
Mass [kg]		4.2	3.7	5.3	6.1	8.6	9.7	11.5			


(2) 400V series


< MDS-DH Series >

					AC re	eactor						
AC reactor mo DH-AL-	odel	7.5K	11K	18.5K	30K	37K	45K	55K	75K			
Compatible po	ower supply unit type	37, 75	110	185	300	370	450	550	750			
Rated capacity	/ [kW]	7.5	11	18.5	30	37	45	55	75			
Rated voltage	[V]	380	to 440AC (50H	lz) / 380 to 48	0AC (60Hz)	Tolerable fluct	uation : betwe	en +10% and	-15%			
Rated current	[A]	14	21	37	65	75	85	106	142			
Frequency [Hz	:]	50/60 Tolerable fluctuation: between +3% and -3%										
	Ambient temperature	Operation: -10°C to 60°C (with no freezing), Storage/Transportation: -10°C to 60°C (with no freezing)										
	Ambient humidity		Stora	•		(with no dew cor less (with no	,,	ation)				
Environment	Atmosphere			With no corro	,	irect sunlight) mmable gas, c	oil mist or dust					
	Altitude	Operation/St	orage: 1000 m	neters or less a	above sea leve	el, Transportati	on: 10000 me	ters or less ab	ove sea level			
	Vibration / impact				9.8m/s ² (1G) /	' 98m/s ² (10G)						
Mass [kg]	Mass [kg]		3.7	5.3	6.0	8.5	9.8	10.5	13.0			

Outline dimension drawing


[Unit:mm]






D/DH-AL-7.5K


D/DH-AL-11K






D/DH-AL-18.5K

D/DH-AL-30K







D/DH-AL-37K D/DH-AL-45K

2 - 58

[Unit:mm]








DH-AL-75K

2-4-7 Explanation of each part

(1) 200V series

< MDS-D Series >

(a) Explanation of each 1-axis servo drive unit part





The connector and terminal block layout may differ according to the unit being used. Refer to each unit outline drawing for details.

<Each part name>

		Na	ame	Description
(1)		LED		Unit status indication LED
(2)		SWL		Axis No. setting switch
(3)		SW1		Unused axis setting switch
(4)		CN1A		NC or master axis optical communication connector
(5)		CN1B		Slave axis optical communication connector
(6)	Con- trol	BTA,BTB		For connecting converged battery unit Both BTA and BTB are the same function, and they are internally connected each other.
(7)	Oncuit	BT1		For connecting battery built-in drive unit ER6V-C119B
(8)		CN9		Maintenance connector (usually not used)
(9)		CN4		Power supply communication connector
(10)		CN2		Motor side detector connection connector 5V power supply capacity:0.35A
(11)		CN3		Machine side detector connection connector 5V power supply capacity:0.35A
(12)		CN20		Motor brake/dynamic brake control connector (Key way: X type)
(13)		TE2	L+ L-	Converter voltage input terminal (DC input)
(14)		TE3	L11 L21	Control power input terminal (single-phase AC input)
(15)	Main circuit	TE1	U, V, W,	Motor power supply output connector (3-phase AC output), Motor grounding terminal (for 60mm width)
(16)			U, V, W	Motor power supply output terminal (for 90mm width or more) (3-phase AC output)
(17)		PE	(Grounding terminal, Motor grounding terminal Note that TE1 connector (above "(15)") is used for the motor grounding of the 60mm width unit.

	1-axis servo drive unit MDS-D-V1-					
Туре	20 to 160	160W	320	320W		
Unit width (mm)	60	90	120	150		
(13) TE2	M6 x 16					
(14) TE3	M4 x 12					
(16) TE1	-	M5 x 12		M8 x 12		
(17) 🖶	M4 x 12	M5 x 12		M8 x 12		






The connector and terminal block layout may differ according to the unit being used. Refer to each unit outline drawing for details.

<Each part name>

	Name		Name	Description	
(1)		LED		Unit status indication LED	
(2)		SWL,SWM		Axis No. setting switch (L,M axis)	
(3)		SW1		Unused axis setting switch (L, M axis)	
(4)		CN1A		NC or master axis optical communication connector	
(5)		CN1B		Slave axis optical communication connector	
(6)	ВТА,ВТВ			For connecting converged battery unit Both BTA and BTB are the same function, and they are internally connected each other.	
(7)	Control	BT1		For connecting battery built-in drive unit ER6V-C119B	
(8)	Circuit	CN9		Maintenance connector (usually not used)	
(9)		CN4		Power supply communication connector	
(10)		CN2L		Motor side detector connection connector (L axis) 5V power supply capacity:0.35A	
(11)	CN3L CN2M			Machine side detector connection connector (L axis) 5V power supply capacity:0.35/	
(12)				Motor side detector connection connector (M axis) 5V power supply capacity:0.35A	
(13)		CN3M		Machine side detector connection connector (M axis) 5V power supply capacity:0.35A	
(14)		CN20		Motor brake/dynamic brake control connector (Key way: X type)	
(15)	(15) TE2 L+ Converter voltage input terminal (DC input)		Converter voltage input terminal (DC input)		
(16)	TE3 L11 L21			Control power input terminal (single-phase AC input)	
(17)	Main	TE1	MU, MV, MW,⊕	Motor power supply output connector(3-phase AC output)	
(18)	circuit		LU, LV, LW,	Motor grounding terminal (for 90mm width or less)	
(19)		TE1 MU, MV, MW		Motor power supply output connector(3-phase AC output) (for 120mm width)	
(20)		121	LU, LV, L	niotor power suppry surpur corrections priase no surpur) (tor 120mm within)	
(21)	PE 😩		(Grounding terminal, Motor grounding terminal Note that TE1 connector (above "(17)", "(18)") is used for the motor grounding of the 90mm width or less unit.	

	2-axis servo drive unit MDS-D-V2-				
Туре	2020 to 8080	16080,160160	160160W		
Unit width (mm)	60	120			
(15) TE2	M6×16				
(16) TE3	M4x12				
(19) (20)TE1	-	-	M5×12		
(21) 👜	M4	M5×12			

(c) Explanation of each 1-axis spindle drive unit part





The connector and terminal block layout may differ according to the unit being used. Refer to each unit outline drawing for details.

<Each part name>

Name		ame	Description		
(1)		LED Unit status indication LED		Unit status indication LED	
(2)		SWL		Axis No. setting switch	
(3)		SW1		Unused axis setting switch	
(4)		CN1A		NC or master axis optical communication connector	
(5)	Con-	CN1B		Slave axis optical communication connector	
(6)	trol cir-	BTA,BTB		(Unused)	
(7)	cuit	BT1		(Unused)	
(8)		CN9		Maintenance connector (usually not used)	
(9)		CN4		Power supply communication connector	
(10)		CN2L		Motor side detector connection connector 5V power supply capacity:0.35A	
(11)		CN3L		Spindle side detector connection connector 5V power supply capacity:0.35A	
(12)		TE2	L+ L-	Converter voltage input terminal (DC input)	
(13)		TE3	L11 L21	Control power input terminal (single-phase AC input)	
(14)	circuit TE1		U, V, W,	Motor power supply output connector (3-phase AC output), Motor grounding terminal (for 60mm width)	
(15)			U, V, W	Motor power supply output terminal (3-phase AC output) (for 90mm width or more)	
(16) PE Grounding terminal, Motor grounding terminal Note that TE1 connector (above "(14)") is used for the m width unit.		Note that TE1 connector (above "(14)") is used for the motor grounding of the 60mm			

	Spindle drive unit MDS-D-SP-					
Туре	20,40,80	160	200	240,320	400	640
Unit width (mm)	60	90	120	150	240	300
(12) TE2	M6 x 16			M10 x 20		
(13) TE3	M4 x 12			M4	x 8	
(15) TE1	-	- M5 x 12		M8 x 12	M10 x 20	
(16) 🖶	M4 x 12	M5 x 12		M8 x 12	M10 x 20	





The connector and terminal block layout may differ according to the unit being used. Refer to each unit outline drawing for details.


<Each part name>

	Name		Name	Description		
(1)		LED		Unit status indication LED		
(2)		SWL,SWM		Axis No. setting switch (L,M axis)		
(3)		SW1 Unused axis setting switch (L,M axis)		Unused axis setting switch (L,M axis)		
(4)	CN1A NC or master axis optical communication			NC or master axis optical communication connector		
(5)		CN1B		Slave axis optical communication connector		
(6)	Control	BTA,BTB		(Unused)		
(7)	circuit	BT1		For connecting battery built-in drive unit ER6V-C119B		
(8)		CN9		Maintenance connector (usually not used)		
(9)		CN4		Power supply communication connector		
(10)		CN2L		Motor side detector connection connector (L axis) 5V power supply capacity:0.35A		
(11)		CN3L		Spindle side detector connection connector (L axis) 5V power supply capacity:0.35A		
(12)	CN2M			Motor side detector connection connector (M axis) 5V power supply capacity:0.35A		
(13)		CN3M Spindle side detector connection connector (M axis) 5V pov		Spindle side detector connection connector (M axis) 5V power supply capacity:0.35A		
(14)	TE2		L+ L-	Converter voltage input terminal (DC input)		
(15)		TE3	L11 L21	Control power input terminal (single-phase AC input)		
(16)	- Main □E1		MU, MV, MW,⊕	Motor power supply output connector (3-phase AC output),		
(17)			LU, LV, LW,	Motor grounding terminal (For other than MDS-D-SP2-2020 to 8080)		
(18)	TE1 MU, MV, MW		MU, MV, MW	Motor power supply output terminal (3-phase AC output)		
(19)		'='	LU, LV, LW	(For MDS-D-SP2-16080)		
(20)		PE	(a)	Grounding terminal, Motor grounding terminal Note that TE1 connector (above "(16)","(17)") is used for the motor grounding of MDS-D-SP2- 2020 to 8080 unit.		

	2-axis spindle drive unit MDS-D-SP2-				
Туре	2020, 4020, 4040\$	4040, 8040, 16080S	8080	16080	
Unit width (mm)	60 90		120	120	
(14) TE2	M6×16				
(15) TE3	M4×12				
(18), (19) TE1	- M5×12				
(20)	M4	×12	M5×12		

2 Specifications

(e) Explanation of each power supply unit part



The connector and terminal block layout may differ according to the unit being used. Refer to each unit outline drawing for details.

<Each part name>


		Name		Description
(1)		LED		Power supply status indication LED
(2)		SW1		Power supply setting switch
(3)		CN4		Servo/spindle communication connector (master)
(4)	Control	CN9		Servo/spindle communication connector (slave)
(5)	circuit		CHARGE LAMP	TE2 output charging/discharging circuit indication LED
(6)		CN23A		External emergency stop input connector (Key way: X type)
(7)		CN23B	MC1,MC2	External contactor control connector (Key way: Y type)
(8)		TE2	L+ L-	Converter voltage output terminal (DC output)
(9)	Main	TE3	L11 L21	Control power input terminal (single-phase AC input)
(10)	Main circuit	TE1	L1,L2,L3,	Power input terminal (3-phase AC input), Grounding terminal (for 60mm width)
(11)		'='	L1, L2, L3	Power input terminal (3-phase AC input), (for 90mm width or more)
(12)		PE	(Grounding terminal (for 90mm width or more)

	Power supply unit MDS-D-CV-					
Туре	37, 75	110,185	300 to 450	550		
Unit width (mm)	60	90	150	300		
(8) TE2			M10 x 20			
(9) TE3		M4 x 12		M4 x 8		
(10) TE1	M4 x 12	-	-	-		
(11) TE1	-	M5 x 12	M8 x 16	M10 x 20		
(12) 👜	-	M5 x 12	M8 x 14	M10 x 20		

(2) 400V series

< MDS-DH Series >

(a) Explanation of each 1-axis servo drive unit part



The connector and terminal block layout may differ according to the unit being used. Refer to each unit outline drawing for details.


<Each part name>

		Na	ame	Description				
(1)		LED		Unit status indication LED				
(2)		Control BTA,BTB BT1 CN9 CN9 CN9 CN9 CN4 CN9 CN4 CN2 CN4 CN2 CN4 CN5 CN5 CN5 CN6 CN7 CN7 CN8 CN9 CN8 CN8 CN8 CN8 CN8 CN9 CN8 CN8						
(3)		SW1		Unused axis setting switch				
(4)		CN1A		NC or master axis optical communication connector				
(5)		CN1B		Slave axis optical communication connector				
(6)	Con- trol			Both BTA and BTB are the same function, and they are internally connected each oth-				
(7)	Circuit	circuit BT1		For connecting battery built-in drive unit ER6V-C119B				
(8)		CN9		Maintenance connector (usually not used)				
(9)		CN4		Power supply communication connector				
(10)		CN2		Motor side detector connection connector				
(11)		CN3		Machine side detector connection connector				
(12)		CN20		Motor brake/dynamic brake control connector (Key way: X type)				
(13)		TE2	L+ L-	Converter voltage input terminal (DC input)				
(14)		TE3	L11 L21	Control power input terminal (single-phase AC input)				
(15)	Main circuit	Main II V W 🗭		Motor power supply output connector (3-phase AC output), Motor grounding terminal (for 90mm width or less)				
(16)	U, V, W		U, V, W	Motor power supply output terminal (3-phase AC output) (for 120mm width or more)				
(17)		PE	(Grounding terminal, Motor grounding terminal Note that TE1 connector (above "(15)") is used for the motor grounding of the 90mm width unit or less.				

		1-axis servo drive unit MDS-DH-V1-					
Туре	10 to 80	80W	160	160W	200		
Unit width (mm)	60	60 90		150	240		
(13) TE2			M6×16				
(14) TE3		M4:	×12	M4×8			
(16) TE1		-	M5:	M8×15			
(17) 🖶	M4×12		M5×12	M8×16			

2 Specifications

(b) Explanation of each 2-axis servo drive unit part





The connector and terminal block layout may differ according to the unit being used. Refer to each unit outline drawing for details.

<Each part name>

			Name	Description		
(1)		LED		Unit status indication LED		
(2)		SWL,SWM		Axis No. setting switch (L,M axis)		
(3)		SW1		Unused axis setting switch (L, M axis)		
(4)		CN1A		NC or master axis optical communication connector		
(5)		CN1B		Slave axis optical communication connector		
(6)	Control	BTA,BTB		For connecting converged battery unit Both BTA and BTB are the same function, and they are internally connected each other.		
(7)	circuit	BT1		For connecting battery built-in drive unit ER6V-C119B		
(8)		CN9		Maintenance connector (usually not used)		
(9)		CN4		Power supply communication connector		
(10)		CN2L		Motor side detector connection connector (L axis)		
(11)		CN3L		Machine side detector connection connector (L axis)		
(12)		CN2M		Motor side detector connection connector (M axis)		
(13)		CN3M		Machine side detector connection connector (M axis)		
(14)		CN20		Motor brake/dynamic brake control connector (Key way: X type)		
(15)		TE2	L+ L-	Converter voltage input terminal (DC input)		
(16)	Main	TE3	L11 L21	Control power input terminal (single-phase AC input)		
(17)	circuit	TE1	MU, MV, MW,⊕	Mater neuron cumply output connector/2 phase AC output\ Mater grounding		
(18)		IEI	LU, LV, LW,	Motor power supply output connector(3-phase AC output), Motor grounding		
(19)		PE		Grounding terminal Use TE1 connector for the motor grounding.		

	2-axis servo drive unit MDS-DH-V2-					
Туре	1010 to 4040	8040, 8080	8080			
Unit width (mm)	60	90	120			
(15) TE2		M6×16				
(16) TE3		M4×12				
(19) 🚇	M4x12 M5x12					





The connector and terminal block layout may differ according to the unit being used. Refer to each unit outline drawing for details.


<Each part name>

		Na	ame	Description			
(1)		LED		Unit status indication LED			
(2)		SWL Axis No. setting switch SW1 Unused axis setting switch					
(3)		SW1		Unused axis setting switch			
(4)		CN1A		NC or master axis optical communication connector			
(5)	Con-	CN1B		Slave axis optical communication connector			
(6)	trol cir-	BTA,BTB		(Unused)			
(7)	cuit	BT1		(Unused)			
(8)		CN9		Maintenance connector (usually not used)			
(9)		CN4		Power supply communication connector			
(10)	CN2L			Built-in PLG detector connection connector			
(11)		CN3L		Machine side detector connection connector			
(12)		TE2	L+ L-	Converter voltage input terminal (DC input)			
(13)		TE3	L11 L21	Control power input terminal (single-phase AC input)			
(14)	Main circuit	TE1	U, V, W,	Motor power supply output connector (3-phase AC output), Motor grounding terminal (for 90mm width or less)			
(15)	121		U, V, W	Motor power supply output terminal (3-phase AC output) (for 120mm width or more)			
(16)		PE	(Grounding terminal, Motor grounding terminal Note that TE1 connector (above "(14)") is used for the motor grounding of the 90mm width or less unit.			

		Spindle drive unit MDS-DH-SP-					
Туре	20, 40	80	100	160	200, 320	480	
Unit width (mm)	60	90	120	150	240	300	
(12) TE2			M6	×16			
(13)TE3		M4	×12		M4×8		
(15)TE1	-		M5×12		M8×15		
(16) 🖶	M4×12	M5×12			M8×	M8×16	

2 Specifications

(d) Explanation of each power supply unit part



The connector and terminal block layout may differ according to the unit being used. Refer to each unit outline drawing for details.

<Each part name>

		Name		Description
(1)		LED	Power supply status indication LED	
(2)		SW1		Power supply setting switch
(3)	Con-	CN4		Servo/spindle communication connector (master)
(4)	Con- trol cir-	CN9		Servo/spindle communication connector (slave)
(5)	cuit		CHARGE LAMP	TE2 output charging/discharging circuit indication LED
(6)		CN23A		External emergency stop input connector (Key way: X type)
(7)		CN23B	MC1,MC2	External contactor control connector (Key way: Y type)
(8)		TE2	L+ L-	Converter voltage output terminal (DC output)
(9)	Main circuit	TE3	L11 L21	Control power input terminal (single-phase AC input)
(10)	TE1 L1, L2, L3		L1, L2, L3	Power input terminal (3-phase AC input)
(11)		PE	(Grounding terminal

	Power supply unit MDS-DH-CV-					
Туре	37 to 185	300 to 450	550, 750			
Unit width (mm)	90	150	300			
(8) TE2	M6	×16	M6×16			
(9) TE3	M4	×12	M4×8			
(10) TE1	M5×12 M8×16		M8×15			
(11) 🖨	M5×12	M8×14	M8×16			

Function specifications list

<Power Supply specification>

ltem		MDS-D-CV	MDS-DH-CV	MDS-DM-SPV built-in con- verter	MDS-D- SVJ3NA MDS-D-SVJ3 built-in con- verter	MDS-D- SPJ3NA MDS-D-SPJ3 built-in con- verter
Software ve	rsion	B0	B0	B0	A3	A3
1	1-14 Power regeneration control	•	•	•	-	-
Base control 1-15 Resistor refunctions	1-15 Resistor regeneration control	-	-	-	•	•
4	4-6 Fan stop detection	•	•	•	•	•
Protection	4-7 Open-phase detection	•	•	•	-	-
function	4-8 Contactor weld detection	•	•	•	•	•
5	5-1 Contactor control function	•	•	•	•	•
Sequence	5-3 External emergency stop function	•	•	•	•	•
function	. .	•	•	•	•	-
6 Diagnosis function	6-7 Power supply voltage display function	•	•	-	-	-

<Servo specification>

ltem		MDS-D- V1/V2	MDS-DH- V1/V2	MDS-DM- V3	MDS-DM- SPV2F/3F MDS-DM- SPV2/3	MDS-D- SVJ3NA MDS-D-SVJ3
Software ver	sion	В0	В0	В0	C0/C0	A1/B0
1	1-1 Full closed loop control	•	•	-	• (Note2)	•
Base	1-2 Position command synchronous control	•	•	•	•	•
control	1-3 Speed command synchronous control	•	•	-	-	=
functions	1-4 Distance-coded reference position control	•	•	-	-	-
	2-1 Torque limit function (stopper function)	•	•	•	•	•
	2-2 Variable speed loop gain control	•	•	•	•	•
	2-3 Gain changeover for synchronous tapping control	•	•	•	•	•
2	2-4 Speed loop PID changeover control	•	•	•	•	•
	2-5 Disturbance torque observer	•	•	•	•	•
function	2-6 Smooth High Gain control (SHG control)	•	•	•	•	•
Base control functions 2 Servo control function 3 Compensation control function 4 Protection function 5 Sequence function 6 Diagnosis function	2-7 High-speed synchronous tapping control (OMR-DD control)	•	•	(Only for 1-axis)	(Only for 1-axis)	-
	2-8 Dual feedback control	•	•	-	• (Note2)	•
	2-9 HAS control	•	•	•	•	-
	3-1 Jitter compensation	•	•	•	•	•
3	3-2 Notch filter	Variable frequency: 4 Fixed frequency: 1	Variable frequency: 4 Fixed frequency: 1	Variable frequency: 4 Fixed frequency: 1	Variable frequency: 4 Fixed frequency: 1	Variable frequency: 4 Fixed frequency: 1
•	3-3 Adaptive tracking-type notch filter	•	•	-	-	-
control	3-4 Overshooting compensation	•	•	•	•	•
function	3-5 Machine end compensation control	•	•	•	•	•
	3-6 Lost motion compensation type 2	•	•	•	•	•
	3-7 Lost motion compensation type 3	•	•	•	•	•
	3-8 Lost motion compensation type 4	•	•	-	-	-
	4-1 Deceleration control at emergency stop	•	•	•	•	•
4	4-2 Vertical axis drop prevention/pull-up control	•	•	•	•	•
Protection	4-3 Earth fault detection	•	•	•	•	•
function	4-4 Collision detection function	•	•	•	•	•
	4-5 Safety observation function	•	•	•	•	•
	4-6 Fan stop detection	•	•	•	•	•
5	5-2 Motor brake control function (Note 1)	•	•	•	•	•
Sequence	5-4 Specified speed output	•	•	-	-	-
function	5-5 Quick READY ON sequence	•	•	•	•	-
	6-1 Monitor output function	•	•	•	•	•
6 Diagnosis	6-2 Machine resonance frequency display function	•	•	•	•	•
function	6-3 Machine inertia display function	•	•	•	•	•
	6-4 Motor temperature display function (Only for linear or direct-drive motor)	•	MDS-DH-V1/V2 MDS-DM-SPV2/3 MDS-DM-SPV2/3 B0 B0 C0/C0 • • • • <td>-</td> <td>•</td>	-	•	

⁽Note 1) For the multiaxis drive unit, a control by each axis is not available.

It is required to turn the servo of all axes OFF in the drive unit in order to enable a motor brake output. (Note 2) For the drive unit MDS-DM-SPV2/3, this function is not available.

<Spindle specifications>

	ltem .	MDS-D- SP	MDS-DH- SP	MDS-D- SP2	MDS-DM- SPV2F/3F MDS-DM- SPV2/3	MDS-D- SPJ3NA MDS-D-SPJ3
Software version		В0	В0	В0	C0/C0	A1/B0
	1-5 Spindle's continuous position loop control	•	•	•	•	•
	1-6 Coil changeover control	•	•	-	•	-
1	1-7 Gear changeover control	•	•	•	•	•
Base	1-8 Orientation control	•	•	•	•	•
control	1-9 Indexing control	•	•	•	•	•
functions	1-10 Synchronous tapping control	•	•	•	•	•
	1-11 Spindle synchronous control	•	•	•	•	•
	1-12 Spindle/C axis control	•	•	•	•	•
	1-13 Proximity switch orientation control	•	•	-	•	•
	2-1 Torque limit function	•	•	•	•	•
	2-2 Variable speed loop gain control	•	•	•	•	•
	2-5 Disturbance torque observer	•	•	-	•	•
2	2-6 Smooth High Gain control (SHG control)	•	•	•	•	•
Spindle control	2-7 High-speed synchronous tapping control (OMR-DD control)	•	•	•	•	-
functions	2-8 Dual feedback control	•	•	•	•	•
	2-10 Control loop gain changeover	•	•	•	•	•
	2-11 Spindle output stabilizing control	•	•	•	•	•
	2-12 High-response spindle acceleration/deceleration function	•	•	•	•	•
	3-1 Jitter compensation	•	•	•	•	•
3 Compensa-	3-2 Notch filter	Variable frequency: 4 Fixed frequency: 1				
control	3-4 Overshooting compensation	•	•	•	•	•
function	3-6 Lost motion compensation type 2	•	•	•	•	•
	3-9 Spindle motor temperature compensation function	•	•	•	•	-
	4-1 Deceleration control at emergency stop	•	•	•	•	•
4 Protection	4-3 Earth fault detection	•	•	•	•	•
function	4-5 Safety observation function	•	•	•	•	•
· anothon	4-6 Fan stop detection	•	•	•	•	•
5	5-4 Specified speed output	•	•	•	•	-
Sequence functions	5-5 Quick READY ON sequence	•	•	•	•	-
	6-1 Monitor output function	•	•	•	•	•
6	6-2 Machine resonance frequency display function	•	•	•	•	•
Diagnosis	6-3 Machine inertia display function	•	•	•	•	•
functions	6-4 Motor temperature display function	•	•	•	•	•
	6-5 Load monitor output function	•	•	•	•	• (Note)
	6-6 Open loop control function	•	•	•	•	•

(Note) The motor output effective value cannot be displayed.

3-1 Base control functions


3-1-1 Full closed loop control

The servo control is all closed loop control using the detector's feedback. "Full closed loop control" is the system that directly detects the machine position using a linear scale, whereas the general "semi-closed loop" is the one that detects the motor position.

In a machine that drives a table with a ball screw, the following factors exist between the motor and table end:

- (1) Coupling or ball screw table bracket's backlash
- (2) Ball screw pitch error

These can adversely affect the accuracy. If the table position of the machine side is directly detected with a linear scale, high-accuracy position control which is not affected by backlash or pitch error is possible.



Full closed loop control


3-1-2 Position command synchronous control

This is one of the controls which enable two servo motors to drive the same axis. This is also called "Position tandem control"

The same position command is issued to the 2-axis servo control, and the control is carried out according to each axis' position and speed feedbacks.

<Features>

- (1) The position commands in which machine's mechanical errors (pitch error, backlash, etc.) have been compensated, can be output to each axis.
- (2) Each axis conducts independent position control, therefore the machine posture can be kept constant.
- (3) Deviation between the two axes is always monitored, and if excessive, the alarm is detected.



3-1-3 Speed command synchronous control


This is one of the controls which enable two servo motors to drive the same axis. This is also called "Speed tandem control".

The same position command is issued to the 2-axis servo control, and the control is carried out according to each axis' position and speed feedbacks.

This function is usually used when the control is performed with one linear scale during the full closed loop control.

<Features>

- (1) The position commands in which machine's mechanical errors (pitch error, backlash, etc.) have been compensated, can be output to each axis.
- (2) Each axis conducts independent position control, therefore the machine posture can be kept constant.
- (3) Deviation between the two axes is always monitored, and if excessive, the alarm is detected



3-1-4 Distance-coded reference position control

This is the function to establish the reference point from axis movements of the reference points using a scale with distance-coded reference mark.


Since it is not necessary to move the axis to the reference point, the axis movement amount to establish the reference point can be reduced.

No dog is used as the position is calculated using reference marks. This function can not be used for the linear servomotor and direct-drive motor.

If the distance-coded reference check function is used to verify the motor end detector data, select a battery option before setting the parameter.

3-1-5 Spindle's continuous position loop control

Under this control, position loop control is always applied to spindle, including when speed command is issued (in cutting). There is no need for control changeover nor zero point return during orientation and C axis control changeover. Therefore, the operation can be completed in a shorter time than the previous. In acceleration/deceleration with S command, the acceleration/deceleration and orientation are always controlled with the spindle motor's maximum torque.



3-1-6 Coil changeover control

A signal output from the spindle drive unit controls the changeover of the low-speed and high-speed specification coils in a spindle motor.

The drive unit automatically outputs the coil changeover sequence in accordance with the motor speed.

3-1-7 Gear changeover control

This function enables a spindle motor to perform both high-speed light cutting and low-speed heavy cutting by changing the gear ratio between the motor and spindle.

The gear change is carried out while the spindle is not running.

3-1-8 Orientation control

This control enables a spindle motor to stop at a designated angle when the motor is rotating at a high-speed with a speed command. This control is used for exchanging the tools in machining centers and performing index positioning in lathes, etc.

3-1-9 Indexing control

This control enables positioning of a spindle motor at an arbitrary angle (in increments of 0.01 degrees) from the orientation stop position. This control is used for positioning in lathes for hole drilling, etc.

3-1-10 Synchronous tapping control

Under synchronous tapping control, spindle control is completely synchronized with Z axis servo control, and Z axis is accurately fed by one screw pitch in accordance with one tap revolution. The tap is completely fixed to the spindle head. As a result, feed pitch error is less likely to occur, which allows high-speed, high-accuracy and high-durable tapping.

3-1-11 Spindle synchronous control

This control enables two spindles to run at the same speed. A spindle being driven with a speed command is synchronized with another spindle at a constant rate or acceleration/deceleration rate.

This control is applied such as when a workpiece is transferred between two rotating chucks in lathe or a workpiece is held with two chucks.

3-1-12 Spindle/C axis control

An axis rotating about Z axis is called C axis, whose rotation direction is normally the same as of spindle. This function enables high-accuracy spindle control including interpolation control, like servo axis, when a high-resolution position detector is attached to the spindle motor.

3-1-13 Proximity switch orientation control

Orientation control is carried out based on the leading edge position of the proximity switch output signal (ON/OFF).

3-1-14 Power regeneration control

This control enables the regeneration energy generated when the motor decelerates to return to the power supply.

This is an energy saving method because regeneration energy is hardly converted to heat.

3-1-15 Resistor regeneration control

This control enables the regeneration energy generated when the motor decelerates to convert to heat with regenerative resistance.

The drive system can be downsized because the regeneration capacity is also small in the motor of relatively small capacity.

Select a suitable regenerative resistance according to the load inertia, motor operation speed, etc.

3-2 Servo/Spindle control functions

3-2-1 Torque limit function


This control suppresses the motor output torque with the parameter values (SV013, SV014).

This function is used for stopper positioning control and stopper reference position establishment, by switching the two setting values.

3-2-2 Variable speed loop gain control


< Servo >

If disturbing noise occurs when the motor is rotating at a high speed, such as during rapid traverse, the high speed loop gain during high-speed rotation can be lowered with this function.




< Spindle >

For a high-speed spindle of machining center etc., adequate response can be ensured with this function by suppressing noise and vibration at low speeds and increasing the speed loop gain at high-speeds.



3-2-3 Gain changeover for synchronous tapping control

SV003, SV004 and SV057 are used as the position loop gain for normal control. Under synchronous tapping control, SV049, SV050 and SV058 are used instead to meet the spindle characteristics.



3-2-4 Speed loop PID changeover control

This function is used under full-closed loop control. Normally, machine-end position tracking delays compared with the motor-end position.


Under full-closed position loop control, machine-end position is used for position feedback. Therefore, the motor-end position tends to advance too much, which may cause overshooting of the machine-end position. This function can suppress the generation of overshoot by adding the D (delay) control to the speed control, which is normally controlled with PI (proportional integral), in order to weaken the PI control after the position droop becomes 0.

3-2-5 Disturbance torque observer

The effect caused by disturbance, frictional resistance or torsion vibration during cutting can be reduced by estimating the disturbance torque and compensating it.


3-2-6 Smooth High Gain control (SHG control)

A high-response control and smooth control (reduced impact on machine) were conventionally conflicting elements; however, SHG control enables the two elements to function simultaneously by controlling the motor torque (current FB) with an ideal waveform during acceleration/deceleration.



3-2-7 High-speed synchronous tapping control (OMR-DD control)

Servo drive unit detects the spindle position, and compensates the synchronization errors. This control enables more accurate tapping than the previous.




3-2-8 Dual feedback control

This function is used under full-closed loop control.

When a linear scale is used, the machine-end position, such as a table, is directly detected, which may render the position loop control unstable.

With this control, however, high-frequency components are eliminated from the machine-end feedback signals, which will lead to stable control.




Dual feedback control

3-2-9 HAS control

If the torque output during acceleration/deceleration is close to the servo motor's maximum torque, the motor cannot accelerate with the commanded time constant when the torque is saturated due to input voltage fluctuation, etc. As a result, speed overshoot occurs when a constant speed command is issued, because the position droop for the delay is canceled.

With HAS control, however, this overshoot is smoothened so that the machine operation can be stable.



3-2-10 Control loop gain changeover

Position loop gain and speed loop gain are switched between non-interpolation mode, which is used during speed command, and interpolation mode, which is used during synchronous tapping and C axis control. By switching these gains, optimum control for each mode can be realized.

3-2-11 Spindle output stabilizing control

Spindle motor's torque characteristic is suppressed due to voltage saturation in the high-speed rotation range, therefore the current control responsiveness significantly degrades, which may cause excessive current.

With this control, however, the current and flux commands are compensated to avoid the voltage saturation so that the current control responsiveness will not degrade.

3-2-12 High-response spindle acceleration/deceleration function

This function enables reduction of the spindle motor's setting time (from when the command value becomes 0 until when the motor actually stops) without being affected by the position loop gain, when the spindle motor stops under deceleration stop control using the S command.

This function is not active when the spindle is stopped while performing position control, such as orientation control and synchronous tapping control.

3-3 Compensation control function

3-3-1 Jitter compensation

The load inertia becomes much smaller than usual if the motor position enters the machine backlash when the motor is stopped.

Because this means that an extremely large VGN1 is set for the load inertia, vibration may occur. Jitter compensation can suppress the vibration that occurs at the motor stop by ignoring the backlash amount of speed feedback pulses when the speed feedback polarity changes.

3-3-2 Notch filter


This filter can damp vibrations of servo torque commands at a specified frequency.

Machine vibrations can be suppressed by adjusting the notch filter frequency to the machine's resonance frequency.

Filter depth adjustment is also available that allows stable control even when the filter is set to an extremely low frequency.

<Specifications>

Notch filter	Frequency	Depth compensation
Notch filter 1	50Hz to 2250Hz	Enabled
Notch filter 2	50Hz to 2250Hz	Enabled
Notch filter 3	Fixed at 1125Hz	Disabled
Notch filter 4	50Hz to 2250Hz	Enabled
Notch filter 5	50Hz to 2250Hz	Enabled



For shallow setting by additionally using the depth compensation at 300Hz


3-3-3 Adaptive tracking-type notch filter

Machine's specific resonance frequency tends to change due to aged deterioration or according to machine's operation conditions. Therefore, the frequency may be deviated from the filter frequency set at the initial adjustment. With adaptive tracking-type notch filter, resonance point fluctuation due to the machine's condition change is estimated using the vibration components of the current commands, and effective notch filter frequency, which has been deviated from the setting value, is automatically corrected to suppress the resonance.

3-3-4 Overshooting compensation

The phenomenon when the machine position goes past or exceeds the command during feed stopping is called overshooting.


In OVS compensation, the overshooting is suppressed by subtracting the torque command set in the parameters when the motor stops.



3-3-5 Machine end compensation control

The shape of the machine end during high-speed and high-speed acceleration operation is compensated by compensating the spring effect from the machine end to the motor end.

The shape may be fine during low-speed operation. However, at high speeds, the section from the machine end to the outer sides could swell. This function compensates that phenomenon.




3-3-6 Lost motion compensation type 2

Servo motor always drives the machine opposing to the frictional force, and the torque which is required to oppose the friction during the axis movement is outputted by I control (Integral control) of the speed loop PI control. When the movement direction is changed, the frictional force works in the opposite direction momentarily, however, the machine will stop while the command torque is less than the frictional force as it takes some time to reverse the command torque in I control.

When the movement direction is changed, the frictional force works in the opposite direction momentarily, however, the machine will stop while the command torque is less than the frictional force as it takes some time to reverse the command torque in I control.

With the this lost motion compensation function improves the accuracy worsened by the stick motion.



3-3-7 Lost motion compensation type 3

For a machine model where the travel direction is reversed, the compensation in accordance with the changes in the cutting conditions is enabled by also considering the spring component and viscosity component in addition to the friction.


This function can be used to accommodate quadrant projection changes that accompany feed rate and circular radius changes which could not be compensated by Lost motion compensation type 2.

- 1.Mechanical spring elements can't be ignored.
- 2.Changes between static and dynamic frictions are wide and steep.

Not only frictions but spring element and viscosity element can be compensated, thus quadrant protrusions are suppressed within a wide band.



Conventional control can't perform enough compensation.



Conventional compensation control


Lost motion compensation control type 3

3-3-8 Lost motion compensation type 4

When the difference between static and dynamic friction is large, the friction torque changes sharply at the inversion of the travel direction. When the lost motion type 4 is used together with the type 2 or type 3, the acute change of the friction torque is compensated so that the path accuracy at the travel direction inversion can be enhanced.

3-3-9 Spindle motor temperature compensation function

As for the low-temperature state of the IM spindle motor, the output characteristic may deteriorate in comparison with the warm-up state and the acceleration/deceleration time may become long, or the load display during cutting may become high immediately after operation. This function performs the control compensation depending on the motor temperature with the thermistor built into the spindle motor and suppresses the output characteristic deterioration when the temperature is low. Temperature compensation function is not required for IPM spindle motor in principle.



3-4 Protection function

3-4-1 Deceleration control at emergency stop

When an emergency stop (including NC failure, servo alarm) occurs, the motor will decelerate following the set time constant while maintaining the READY ON state.

READY will turn OFF and the dynamic brakes will function after stopping. The deceleration stop can be executed at a shorter distance than the dynamic brakes.


3-4-2 Vertical axis drop prevention/pull-up control


If the READY OFF and brake operation are commanded at same time when an emergency stop occurs, the axis drops due to a delay in the brake operation.

The no-control time until the brakes activate can be eliminated by delaying the servo READY OFF sequence by the time set in the parameters.

Always use this function together with deceleration control.

When an emergency stop occurs in a vertical machining center, the Z axis is slightly pulled upwards before braking to compensate the drop of even a few µm caused by the brake backlash.





3-4-3 Earth fault detection


When an emergency stop is canceled, the earth fault current is measured using the power module's special switching circuit before Servo ready ON.

Specifying the faulty axis is possible in this detection, as the detection is carried out for each axis.

3-4-4 Collision detection function

Collision detection function quickly detects a collision of the motor shaft, and decelerates and stops the motor. This suppresses the generation of an excessive torque in the machine tool, and helps to prevent an abnormal state from occurring. Impact at a collision will not be prevented by using this collision detection function, so this function does not necessarily guarantee that the machine tool will not be damaged or that the machine accuracy will be maintained after a collision.


The same caution as during regular operation is required to prevent the machine from colliding.



3-4-5 Safety observation function

This function is aimed at allowing a safety access to the machine's working part by opening the protection door, etc. without shutting the power for saving the setup time.

Both the NC control system and drive system (servo and spindle drive units) doubly observe the axis feed rate so that it will not exceed the safety speed. If it exceeds the set safety speed, emergency stop occurs and the power is shut OFF.



3-4-6 Fan stop detection

The rotation of the radiation fin cooling fan is observed and when the fan stops rotating for a breakdown of the fan or an external factor, warning is detected. (The system will not be stopped.) Before sudden system down by the power module overheat, inspection and replacement of the fan are prompted.

3-4-7 Open-phase detection

Disconnection of a phase of the 3-phase input power is detected.

The occurrence of abnormal operation will be avoided by open-phase detection because open-phase does not cause a power failure, however, abnormal operation will occur when the motor load becomes large.

3-4-8 Contactor weld detection

It detects that a contact of the external contactor is welding and cannot be opened.

3-5 Sequence functions

3-5-1 Contactor control function

With this function, the contactor ON/OFF command is output from the power supply unit (or servo/spindle drive unit for integrated type) based on the judgement as to whether it is in emergency stop, emergency stop cancel, spindle deceleration and stop or vertical axis drop prevention control, etc.

3-5-2 Motor brake control function


With this function, the brake ON/OFF command is output from the servo drive unit based on the judgement as to whether it is in emergency stop, emergency stop cancel or vertical axis drop prevention/pull-up control, etc.

When a multiaxis drive unit is connected, all the axes are simultaneously controlled.

3-5-3 External emergency stop function

Besides the emergency stop input from the NC, double-protection when an emergency stop occurs can be provided by directly inputting an external emergency stop, which is a second emergency stop input, to the power supply unit (servo/spindle drive unit for integrated type).

Even if the emergency stop is not input from NC for some reason, the contactors will be activated by the external emergency stop input, and the power can be shut off.



3-5-4 Specified speed output

This function is to output a signal that indicates whether the machine-end speed has exceeded the speed specified with the parameter.

With this function, the protection door, etc. can be locked to secure the machine operator when the machineend speed has exceeded the specified speed. This function can also be used for judging whether the current machine-end speed is higher than the specified speed.

3-5-5 Quick READY ON sequence

With this function, the charging time during READY ON is shortened according to the remaining charge capacity of the power supply unit. When returning to READY ON status immediately after the emergency stop input, the charging time can be shortened according to the remaining charge capacity and the time to READY ON is shortened.


3-6 Diagnosis function

3-6-1 Monitor output function

<Servo drive unit>


Drive unit has a function to D/A output the various control data. The servo adjustment data required for setting the servo parameters to match the machine can be D/A output. Measure using a high-speed waveform recorder, oscilloscope, etc.

(1) D/A output specifications



Item	Explanation
No. of channels	2ch
Output cycle	0.8ms (min. value)
Output precision	12bit
Output voltage range	0V to 2.5V (zero) to +5V
Output magnification setting	-32768 to 32767 (1/100-fold)
Output pin (CN9 connector)	MO1 = Pin 9, MO2 = Pin 19, LG = Pin 1,11
Others	The D/A output for the 2-axis unit is also 2ch. When using the 2-axis unit, always set -1 for the output data (SV061, 62) of the axis that is not to be measured.

When the output data is 0, the offset voltage is 2.5V. If there is an offset voltage, adjust the zero level position in the measuring instrument side.



(2) Output data settings (Standard output)

[#2261] SV061 DA1NO D/A output ch1 data No.

Input the data number you wish to output to the D/A output channel 1. When using the 2-axis drive unit, set "-1" to the axis that the data will not be output.

---Setting range----1 to 127

[#2262] SV062 DA2NO D/A output ch2 data No.

Input the data number you wish to output to the D/A output channel 2. When using the 2-axis drive unit, set "-1" to the axis that the data will not be output.

---Setting range----1 to 127

No.	Output data	Standard output unit		Output cycle
140.	Output data	Linear axis	Rotary axis	
-1	D/A output not selected	For 2-axis drive unit (MDS-D/DH-V2).		
•	·	· ·		drive unit that is not D/A output.
0	Commanded rotation speed		r/min)/V	0.8ms
1	Motor rotation speed	,	r/min)/V	0.8ms
2	Torque command	Motor stall rate	ed ratio 100%/V	0.8ms
3	Torque feedback	Motor stall rate	ed ratio 100%/V	0.8ms
6	Effective current command	100)%/V	0.8ms
7	Effective current feedback	100)%/V	0.8ms
8	Machine vibration frequency	500	Hz/V	0.8ms
9	HAS control droop cancel amount	1mm/V	1°/V	0.8ms
			- I	
30	Collision detection estimated torque	100)%/V	0.8ms
24	Collision detection disturbance estimated	400	20/ Δ/	0.0
31	torque	100)%/V	0.8ms
32	Estimated load inertia ratio	100% /\/ or 1	00kg/V (Note)	0.8ms
32	or moving sections gross weight	100 /6/ V 01 1	ookg/v (Note)	0.01118
35	Disturbance observer estimated disturbance	100)%/V	0.8ms
33	torque	100	7707 V	0.01113
50	Position droop	1µm/V	1/1000°/V	0.8ms
51	Position command	1µm/V	1/1000°/V	0.8ms
52	Position feedback	1µm/V	1/1000°/V	0.8ms
53	Position FΔT	1µm/s/V	1/1000°/s/V	0.8ms
54	Deviation from ideal position	1µm/V	1/1000°/V	0.8ms
34	(considering servo tracking delay)	Ιμπ/ν	1/1000 / V	0.01118
60	Position droop	1mm/V	1°/V	0.8ms
61	Position command	1mm/V	1°/V	0.8ms
62	Position feedback	1mm/V	1°/V	0.8ms
63	Position FΔT	1mm/s/V	1°/s/V	0.8ms
64	Deviation from ideal position	1mm/V	1°/V	0.8ms
04	(considering servo tracking delay)	TITIIII/ V	1 / V	0.0113
70	Position droop	1m/V	1000°/V	0.8ms
71	Position command	1m/V	1000°/V	0.8ms
72	Position feedback	1m/V	1000°/V	0.8ms
73	Position FΔT	1m/s/V	1000°/s/V	0.8ms
74	Deviation from ideal position	1m/V	1000°/V	0.8ms
74	(considering servo tracking delay)	IIII/V	1000-77	U.OIIIS
126	Saw tooth wave	0V :	to 5V	0.8ms
127	2.5V test data	2	.5V	0.8ms

(Note) The estimated load inertia ratio (unit: 100%/V) is applied for the rotary motor, and the moving sections gross weight (unit: 100kg/V) for the linear motor.

(Servo control signal)

	Servo control input (NC to Servo)			Servo control output	t (Servo to NC)
No.	D	etails	No.	Details	
16384	Servo control input 1-0	READY ON command	16480	Servo control output 1-0	In READY ON
16385	Servo control input 1-1	Servo ON command	16481	Servo control output 1-1	In servo ON
16388	Servo control input 1-4	Position loop gain change- over command	16484	Servo control output 1-4	In position loop gain change- over
16390	Servo control input 1-6	Excessive error detection width changeover command	16486	Servo control output 1-6	In excessive error detection width changeover
16391	Servo control input 1-7	Alarm reset command	16487	Servo control output 1-7	In alarm
16392	Servo control input 1-8	Current limit selection command	16488	Servo control output 1-8	In current limit selection
			16492	Servo control output 1-C	In in-position
			16493	Servo control output 1-D	In current limit
			16494	Servo control output 1-E	In absolute position data loss
			16495	Servo control output 1-F	In warning
			16496	Servo control output 2-0	Z phase passed
			16499	Servo control output 2-3	In zero speed
			16503	Servo control output 2-7	In external emergency stop
16409	Servo control input 2-9	Speed monitor command valid	16505	Servo control output 2-9	In speed monitor
16410	Servo control input 2-A	In door closed (controller)	16506	Servo control output 2-A	In door closed (controller)
16411	Servo control input 2-B	In door closed (all drive units)	16507	Servo control output 2-B	In door closed (self drive unit)
16416	Servo control input 3-0	Control axis detachment command	16512	Servo control output 3-0	In control axis detachment

< Spindle drive unit >


Drive unit has a function to D/A output each control data. The spindle adjustment data required to set the spindle parameters matching the machine can be D/A output. The data can be measured with a high-speed waveform recorder or oscilloscope, etc.

(1) D/A output specifications

Item No. of channels

Output cycle


Output pin (CN9 connector)



Explanation 2ch 0.8ms (min. value) Output precision 12bit Output voltage range 0V to 2.5V (zero) to +5V Output magnification setting -32768 to 32767 (1/100-fold)

MO1 = Pin 9, MO2 = Pin 19, LG = Pin 1,11

When the output data is 0, the offset voltage is 2.5V. If there is an offset voltage, adjust the zero level position in the measuring instrument side.



(2) Output data settings (Standard output)

[#13125] SP125 DA1NO D/A output ch1 data No.

Input the desired data number to D/A output channel.

---Setting range----32768 to 32767

[#13126] SP126 DA2NO D/A output ch2 data No.

Input the desired data number to D/A output channel.

---Setting range----32768 to 32767

No.	Output data	Output unit for standard setting	Output cycle
-1	D/A output stop	-	
0	Commanded motor rotation speed	1000(r/min)/V	0.8ms(min)
1	Motor rotation speed	1000(r/min)/V	0.8ms(min)
2	Torque current command	Short time rated ratio 100%/V	0.8ms(min)
3	Torque current feedback	Short time rated ratio 100%/V	0.8ms(min)
35	Disturbance observer estimated disturbance torque	Short time rated torque current value ratio 100%/V	0.8ms(min)
50	Position droop	1/1000°/V	0.8ms(min)
51	Position command	1/1000°/V	0.8ms(min)
52	Position feedback	1/1000°/V	0.8ms(min)
53	Position F∆T	1/1000°/s/V	0.8ms(min)
54	Deviation from ideal position (considering spindle tracking delay)	1/1000°/V	0.8ms(min)
60	Position droop	1°/V	0.8ms(min)
61	Position command	1°/V	0.8ms(min)
62	Position feedback	1°/V	0.8ms(min)
63	Position F∆T	1°/s/V	0.8ms(min)
64	Deviation from ideal position (considering spindle tracking delay)	1°/V	0.8ms(min)
70	Position droop	1000°/V	0.8ms(min)
71	Position command	1000°/V	0.8ms(min)
72	Position feedback	1000 /V	0.8ms(min)
73	Position FAT	1000 / V	0.8ms(min)
74	Deviation from ideal position (considering spindle tracking delay)	1000°/V	0.8ms(min)
110	3.0V output load meter (Note)	40%/V, 120%/3V	0.8ms(min)
126	Saw tooth wave	0V to 5V	0.8ms(min)
127	2.5V test data output	2.5V	0.8ms(min)

(Note) Load meter displays "100%(=2.5V)" when the control power turns ON and the NC is starting. After the NC has been run, it displays "0%(=0V%)".

(Special output)

The result of PLG(TS5690) installation accuracy diagnosis is output to D/A output. D/A output magnification: SP127(DA1MPY) and SP128(DA2MPY) is 0.

PLG installation diagnosis function can be enabled during the rotation, when open loop control is enabled:SP018(SPEC2)/bit1=1.

D/A output No.	Details	Description
120	Motor end PLG installation Gap diagnosis	Motor end PLG installation gap is diagnosed. When the gap is good, 2.5V is output. When the gap is excessive, 2.5V+1V is output. When the gap is too small, 2.5V-1V is output.
121	Motor end PLG installation All errors diagnosis	Motor end PLG installation error (including the gap) is diagnosed. When the installation is good, 2.5V is output. When the installation is incorrect, 2.5V+1V is output.
122	Spindle end PLG installation Gap diagnosis	Spindle end PLG installation gap is diagnosed. Diagnostic procedure is the same as that of motor end PLG.
123	Spindle end PLG installation All errors diagnosis	Spindle end PLG installation error (including the gap) is diagnosed. Diagnostic procedure is the same as that of motor end PLG.

(Spindle control signal)

	Spindle control input (NC to Spindle)			Spindle control output (Spindle to NC)		
No.		Details	No.	De	etails	
16384	Spindle control input 1-0	READY ON command	16480	Spindle control output 1-0	In ready ON	
16385	Spindle control input 1-1	Servo ON command	16481	Spindle control output 1-1	In servo ON	
16391	Spindle control input 1-7	Alarm reset command	16487	Spindle control output 1-7	In alarm	
		Torque limit 1 selection com-				
16392	Spindle control input 1-8	mand	16488	Spindle control output 1-8	In torque limit 1 selection	
16393	Spindle control input 1-9	Torque limit 2 selection com- mand	16489	Spindle control output 1-9	In torque limit 2 selection	
16394	Spindle control input 1-A	Torque limit 3 selection com- mand	16490	Spindle control output 1-A	In torque limit 3 selection	
			16492	Spindle control output 1-C	In in-position	
			16495	Spindle control output 1-F	In warning	
			16496	Spindle control output 2-0	Z phase passed	
			10100			
			16499	Spindle control output 2-3	In zero speed	
			16503	Spindle control output 2-7	In external emergency stop	
			10303	Spiriale control output 2-7	in external emergency stop	
16409	Spindle control input 2-9	Speed monitor command valid	16505	Spindle control output 2-9	In speed monitor	
16410	Spindle control input 2-A	In door closed (controller)	16506	Spindle control output 2-A	In door closed (controller)	
16411	Spindle control input 2-B	In door closed (all drive units)	16507	Spindle control output 2-B	In door closed (self drive unit)	
16432	Spindle control input 4-0	Spindle control mode selection command 1	16528	Spindle control output 4-0	In spindle control mode selection 1	
16433	Spindle control input 4-1	Spindle control mode selection command 2	16529	Spindle control output 4-1	In spindle control mode selection 2	
16434	Spindle control input 4-2	Spindle control mode selection command 3	16530	Spindle control output 4-2	In spindle control mode selection 3	
16436	Spindle control input 4-4	Gear changeover command	16532	Spindle control output 4-4	In gear changeover com- mand	
16437	Spindle control input 4-5	Gear selection command 1	16533	Spindle control output 4-5	In gear selection 1	
16438	Spindle control input 4-6	Gear selection command 2	16534	Spindle control output 4-6	In gear selection 2	
16445	Spindle control input 4-D	L coil selection command	16541	Spindle control output 4-D	In L coil selection	
			16545	Spindle control output 5-1	Speed detection	
			16550	Spindle control output 5-6	In coil changeover	
16458	Spindle control input 5-A	Phase synchronization sup- pression command	16554	Spindle control output 5-A	In phase synchronization suppression	
16459	Spindle control input 5-B	Minimum excitation rate 2 changeover request	16555	Spindle control output 5-B	In minimum excitation rate 2 selection	
16460	Spindle control input 5-C	Speed gain set 2 changeover request	16556	Spindle control output 5-C	In speed gain set 2 selection	
16461	Spindle control input 5-D	Zero point re-detection re- quest	16557	Spindle control output 5-D	Zero point re-detection complete	
16462	Spindle control input 5-E	Spindle holding force up	16558	Spindle control output 5-E	Spindle holding force up completed	
			16559	Spindle control output 5-F	In 2nd in-position	

⁽Note 1) Control signal is bit output. Setting the No. of the table above to the data output(SP125, SP126), and when the scale (SP127, SP128) is set to "0", the output is "0V" for bit 0, and "2.5V" for bit 1.

⁽Note 2) Refer to the section "Spindle control signal" in Instruction Manual for details on the spindle control signal.

3-6-2 Machine resonance frequency display function

If resonance is generated and it causes vibrations of the current commands, this function estimates the vibration frequency and displays it on the NC monitor screen (AFLT frequency).

This is useful in setting the notch filter frequencies during servo adjustment. This function constantly operates with no need of parameter setting.

3-6-3 Machine inertia display function

With this function, the load current and acceleration rate during motor acceleration are measured to estimate the load inertia.

According to the parameter setting, the estimated load inertia is displayed on the NC monitor screen, expressed as its percentage to the motor inertia.

3-6-4 Motor temperature display function

The temperature sensed by the thermal sensor attached to the motor coil is displayed on the NC screen.

3-6-5 Load monitor output function

A spindle motor's load is output as an analog voltage of 0 to 3V (0 to 120%). To use this function, connect a load meter that meets the specifications.

3-6-6 Open loop control function

This function is to run a spindle motor for operation check before or during the adjustment of the spindle motor's detector. This allows the operation in which no detector feedback signals are used.

3-6-7 Power supply voltage display function

The converter bus voltage in main circuit power is displayed on the NC monitor screen.

4

Characteristics

4 Characteristics

4-1 Servomotor


4-1-1 Environmental conditions


Environment	Conditions
Ambient temperature	0°C to +40°C (with no freezing)
Ambient humidity	80% RH or less (with no dew condensation)
Storage temperature	-15°C to +70°C (with no freezing)
Storage humidity	90% RH or less (with no dew condensation)
Atmosphere	Indoors (no direct sunlight)
Autosphere	No corrosive gas, inflammable gas, oil mist or dust
Altitude	Operation / storage: 1000m or less above sea level
Aititude	Transportation: 10000m or less above sea level

4-1-2 Quakeproof level

Series	Motor type	Motor type Avia direction (Y)		
Series	motor type	Axis direction (X)	Direction at right angle to axis (Y)	
	HF75, 105	_	_	
	HF54, 104, 154, 224, 123, 223, 142	24.5m/s ² (2.5G) or less	24.5m/s ² (2.5G) or less	
	HP54, 104, 154, 224			
200V	HF204, 354, 303, 453, 703, 302	24.5m/s ² (2.5G) or less	29.4m/s ² (3G) or less	
series	HP204, 354, 454, 704	2 1.011/0 (2.00) 01 1000	20.111/0 (00) 01 1000	
	HF903	9.8m/s ² (1G) or less	9.8m/s ² (1G) or less	
	HP903, 1103	` '	` ,	
	HF-KP23, 43, 73	49m/s ² (5G) or less	49m/s ² (5G) or less	
	HF-H75, 105		24.5m/s ² (2.5G) or less	
	HF-H54, 104, 154	24.5m/s ² (2.5G) or less		
	HP-H54, 104, 154, 224			
400V	HF-H204, 354, 453, 703	24.5m/s ² (2.5G) or less	29.4m/s ² (3G) or less	
series	HP-H204, 354, 454, 704	24.011/3 (2.00) 01 1033	23.411/3 (30) 01 1033	
	HF-H903	9.8m/s ² (1G) or less	9.8m/s ² (1G) or less	
	HP-H903, 1103	` '	` ,	
	HC-H1502S-S10	9.8m/s ² (1G) or less	9.8m/s ² (1G) or less	

The vibration conditions are as shown below.






4-1-3 Shaft characteristics

There is a limit to the load that can be applied on the motor shaft. Make sure that the load applied on the radial direction and thrust direction, when mounted on the machine, is below the tolerable values given below. These loads may affect the motor output torque, so consider them when designing the machine.

Series	Servomotor	Tolerable radial load	Tolerable thrust load
	HF75T, 105T (Taper shaft)	245N (L=33)	147N
	HF75S, 105S (Straight shaft)	245N (L=33)	147N
	HF54T, 104T, 154T, 224T,123T, 223T, 142T (Taper shaft)	392N (L=58)	490N
	HF54S, 104S, 154S, 224S,123S, 223S, 142S (Straight shaft)	980N (L=55)	490N
	HF204S, 354S, 303S, 453S, 703S, 302S (Straight shaft)	2058N (L=79)	980N
	HF903S (Straight shaft)	2450N (L=85)	980N
200V	HP54T, 104T, 154T, 224T (Taper shaft)	392N (L=52.7)	490N
series	HP54S, 104S, 154S, 224S (Straight shaft)	980N (L=52.7)	490N
	HP204S, 354S, 454S (Straight shaft)	1500N (L=52.7)	490N
	HP704S (Straight shaft)	1300N (L=52.7)	590N
	HP903S (Straight shaft)	2500N (L=52.7)	1100N
	HP1103S (Straight shaft)	2700N (L=52.7)	1500N
	HF-KP23, 43 (Straight shaft)	245N (L=30)	98N
	HF-KP73 (Straight shaft)	392N (L=40)	147N
	HF-H75T, 105T (Taper shaft)	245N (L=33)	147N
	HF-H75S, 105S (Straight shaft)	245N (L=33)	147N
	HF-H54T, 104T, 154T (Taper shaft)	392N (L=58)	490N
	HF-H54S, 104S, 154S (Straight shaft)	980N (L=55)	490N
	HF-H204S, 354S, 453S, 703S (Straight shaft)	2058N (L=79)	980N
4001/	HF-H903S (Straight shaft)	2450N (L=85)	980N
400V series	HP-H54T, 104T, 154T, 224T (Taper shaft)	392N (L=52.7)	490N
Series	HP-H54S, 104S, 154S, 224S (Straight shaft)	980N (L=52.7)	490N
	HP-H204S, 354S, 454S (Straight shaft)	1500N (L=52.7)	490N
	HP-H704S (Straight shaft)	1300N (L=52.7)	590N
	HP-H903S (Straight shaft)	2500N (L=52.7)	1100N
	HP-H1103S (Straight shaft)	2700N (L=52.7)	1500N
	HC-H1502S-S10 (Straight shaft)	3234N (L=140)	1470N

(Note 1) The tolerable radial load and thrust load in the above table are values applied when each motor is used independently.

(Note 2) The symbol L in the table refers to the value of L below.



L: Length from flange installation surface to center of load mass [mm]

- 1. Use a flexible coupling when connecting with a ball screw, etc., and keep the shaft core deviation to below the tolerable radial load of the shaft.
- 2. When directly installing the gear on the motor shaft, the radial load increases as the diameter of the gear decreases. This should be carefully considered when designing the machine.


CAUTION!

- 3. When directly installing the pulley on the motor shaft, carefully consider so that the radial load (double the tension) generated from the timing belt tension is less than the values shown in the table above.
- 4. In machines where thrust loads such as a worm gear are applied, carefully consider providing separate bearings, etc., on the machine side so that loads exceeding the tolerable thrust loads are not applied to the motor.

4-1-4 Machine accuracy


Machine accuracy of the servo motor's output shaft and around the installation part is as below. (Excluding special products)

Accuracy (mm)	Measurement	Flange size [mm]						
, ,	point	Less than 100	100 SQ., 130 SQ.	176 SQ 250 SQ.	280 or over			
Amplitude of the flange surface to the output shaft	а	0.05	0.06	0.08	0.08			
Amplitude of the flange surface's fitting outer diameter	b	0.04	0.04	0.06	0.08			
Amplitude of the output shaft end	С	0.02	0.02	0.03	0.03			




4-1-5 Oil / water standards

(1) The motor protective format uses the IP type, which complies with IEC Standard. (Refer to the section "2-1-1 Specifications list".) However, these Standards are short-term performance specifications. They do not guarantee continuous environmental protection characteristics. Measures such as covers, etc., must be taken if there is any possibility that oil or water will fall on the motor, and the motor will be constantly wet and permeated by water. Note that the motor's IP-type is not indicated as corrosion-resistant.




(2) When a gear box is installed on the servomotor, make sure that the oil level height from the center of the shaft is higher than the values given below. Open a breathing hole on the gear box so that the inner pressure does not rise.

Series	Servomotor	Oil level (mm)
	HF75, 105	15
	HF54, 104, 154, 224, 123, 223, 142	22.5
	HP54, 104, 154, 224	20
	HF204, 354, 303, 453, 302	30
200V	HP204, 354, 454, 704	25
series	HF703	30
	HF903	34
	HP903, 1103	30
	HF-KP23, 43	12.5
	HF-KP73	15
	HF-H75, 105	15
	HF-H54, 104, 154	22.5
	HP-H54, 104, 154, 224	20
400V	HF-H204, 354, 453	30
series	HP-H204, 354, 454, 704	25
Series	HF-H703	30
	HF-H903	34
	HP-H903, 1103	30
	HC-H1502S-S10	45



(3) When installing the servomotor horizontally, set the power cable and detector cable to face downward. When installing vertically or on an inclination, provide a cable trap.



CAUTION!

- 1. The servomotors, including those having IP67 specifications, do not have a completely waterproof (oil-proof) structure. Do not allow oil or water to constantly contact the motor, enter the motor, or accumulate on the motor. Oil can also enter the motor through cutting chip accumulation, so be careful of this also.
- 2. When the motor is installed facing upwards, take measures on the machine side so that gear oil, etc., does not flow onto the motor shaft.

4-1-6 Installation of servo motor

Mount the servo motor on a flange which has the following size or produces an equivalent or higher heat dissipation effect:


Flange size	Servo Motor			
(mm)	HF, HF-H, HP, HP-H, HF-KP			
150x150x6	100W			
250x250x6	200 to 400W			
250x250x12	0.5 to 1.5kW			
300x300x20	2.0 to 7.0kW			
800x800x35	9.0 to 11.0kW			


4-1-7 Overload protection characteristics

The servo drive unit has an electronic thermal relay to protect the servomotor and servo drive unit from overloads. The operation characteristics of the electronic thermal relay are shown below when standard parameters (SV021=60, SV022=150) are set. If overload operation over the electronic thermal relay protection curve shown below is carried out, overload 1 (alarm 50) will occur. If the maximum torque is commanded continuously for one second or more due to a machine collision, etc., overload 2 (alarm 51) will occur.


(1) 200V series

< HF series >







< HP series >




< HF-KP series >









HF-KP73



(2) 400V series




< HP-H series >



< HC-H series >

HC-H1502S-S10



4-1-8 Magnetic brake

- 1. The axis will not be mechanically held even when the dynamic brakes are used. If the machine could drop when the power fails, use a servomotor with magnetic brakes or provide an external brake mechanism as holding means to prevent dropping.
- 2. The magnetic brakes are used for holding, and must not be used for normal braking. There may be cases when holding is not possible due to the life or machine structure (when ball screw and servomotor are coupled with a timing belt, etc.). Provide a stop device on the machine side to ensure safety.

3 When operating the

- 3. When operating the brakes, always turn the servo OFF (or ready OFF). When releasing the brakes, always confirm that the servo is ON first. Sequence control considering this condition is possible by using the brake contact connection terminal on the servo drive unit.
- 4. When the vertical axis drop prevention function is used, the drop of the vertical axis during an emergency stop can be suppressed to the minimum.

(1) Motor with magnetic brake

(a) Types

CAUTION!

The motor with a magnetic brake is set for each motor. The "B" following the standard motor model stands for the motor with a brake.

(b) Applications

When this type of motor is used for the vertical feed axis in a machining center, etc., slipping and dropping of the spindle head can be prevented even when the hydraulic balancer's hydraulic pressure reaches zero when the power turns OFF. When used with a robot, deviation of the posture when the power is turned OFF can be prevented.

When used for the feed axis of a grinding machine, a double safety measures is formed with the deceleration stop (dynamic brake stop) during emergency stop, and the risks of colliding with the grinding stone and scattering can be prevented.


This motor cannot be used for the purposes other than holding and braking during a power failure (emergency stop). (This cannot be used for normal deceleration, etc.)


(c) Features

- [1] The magnetic brakes use a DC excitation method, thus:
 - The brake mechanism is simple and the reliability is high.
 - There is no need to change the brake tap between 50Hz and 60Hz.
 - There is no rush current when the excitation occurs, and shock does not occur.
 - The brake section is not larger than the motor section.
- [2] The magnetic brake is built into the motor, and the installation dimensions are the same as the motor without brake.

(d) Cautions for using a timing belt

Connecting the motor with magnetic brakes and the load (ball screw, etc.) with a timing belt as shown on the left below could pose a hazard if the belt snaps. Even if the belt's safety coefficient is increased, the belt could snap if the tension is too high or if cutting chips get imbedded. Safety can be maintained by using the method shown on the right below.





(2) Magnetic brake characteristics

(a) 200V series

< HF Series >

		Motor type				
ltem		HF75B, HF105B	HF54B, HF104B HF154B, HF224B HF123B, HF223B HF142B	HF204B, HF354B HF303B, HF453 HF703B, HF903B HF302B		
Type (Note 1)			non-exciting operation matenance and emergency	· ·		
Rated voltage			24VDC			
Rated current at 20°C (A)		0.38	0.8	1.4		
Capacity (W)		9	19	34		
Static friction torque (N•m)	2.4	8.3	43.1		
Inertia (Note 2) (kg•cm²)		0.2	2.2	9.7		
Release delay time (Note 3	3) (s)	0.03	0.04	0.1		
Braking delay time (DC OF	FF) (Note 3) (s)	0.03	0.03	0.03		
Tolerable braking work	Per braking (J)	64	400	4,500		
amount Per hour (J)		640	4,000	45,000		
Brake play at motor axis (degree)	0.1 to 0.9	0.2 to 0.6	0.2 to 0.6		
Brake life (Note 4)	No. of braking operations (times)	20,000	20,000	20,000		
Brake life (Note 4)	Work amount per braking (J)	32	200	1,000		

< HP Series >

		Motor type					
ltem		HP54B	HP104B HP154B	HP204B HP224B	HP354B HP454B	HP704B	HP903B HP1103B
Type (Note 1)	Spring closed non-exciting operation magnetic brakes (for maintenance and emergency braking)						
Rated voltage				24\	/DC		
Rated current at 20°C(A)		0.91 0.86 1.0 1.4 1.4 1.7				1.7	
Capacity (W)		21 21 24 34 34 41				41	
Static friction torque (N•m)	3.5 9 12 32 54.9 90				90	
Inertia (Note 2) (kg•cm²)	0.5	0.5	5.5	5.5	5.5	24	
Release delay time (Note3) (s)	0.1	0.1	0.1	0.12	0.3	0.3
Braking delay time (DC OF	FF) (Note3) (s)	0.1	0.1	0.1	0.1	0.1	0.1
Tolerable braking work	Per braking (J)	700	700	700	4,500	4,500	4,500
amount	Per hour (J)	7,000	7,000	7,000	45,000	45,000	45,000
Brake play at motor axis (0.2 to 0.6	0.2 to 0.6	0.2 to 0.6	0.2 to 0.6	0.2 to 0.6	0.2 to 0.6	
Brake life (Note4)	No. of braking operations (times)	20,000	20,000	20,000	20,000	20,000	20,000
Brane me (110te4)	Work amount per braking (J)	200	200	200	1,000	1,000	1,000

- (Note 1) There is no manual release mechanism. If handling is required such as during the machine core alignment work, prepare a separate 24VDC power supply, and electrically release a brake.
- (Note 2) These are the values added to the servomotor without a brake.
- (Note 3) This is the representative value for the initial attraction gap at 20°C.
- (Note 4) The brake gap will widen through brake lining wear caused by braking. However, the gap cannot be adjusted. Thus, the brake life is considered to be reached when adjustments are required.
- (Note 5) A leakage flux will be generated at the shaft end of the servomotor with a magnetic brake.
- (Note 6) When operating in low speed regions, the sound of loose brake lining may be heard. However, this is not a problem in terms of function.

< HF-KP Series >

Ite	m	Motor t	уре			
ite	111	HF-KP23B, HF-KP43B	HF-KP73B			
Type (Note 1)		Spring closed non-exciting operation magnetic brakes				
Type (Note 1)		(for maintenance and emergency braking)				
Rated voltage		24VD	C			
Rated current at 20°C(A)		0.33	0.42			
Capacity (W)		7.9	10			
Static friction torque (N•m		1.3	2.4			
Inertia (Note 2) (kg•cm²)		0.08 0.2				
Release delay time (Note3) (s)	0.03	0.04			
Braking delay time (DC OF	F) (Note3) (s)	0.02	0.02			
Tolerable braking work	Per braking (J)	22	64			
amount	Per hour (J)	220	640			
Brake play at motor axis (degree)		1.2	0.9			
	No. of braking	20,000	20.000			
Brake life (Note4)	operations (times)	20,000	20,000			
	Work amount	22	64			
	per braking (J)					

- (Note 1) There is no manual release mechanism. If handling is required such as during the machine core alignment work, prepare a separate 24VDC power supply, and electrically release a brake.
- (Note 2) These are the values added to the servomotor without a brake.
- (Note 3) This is the representative value for the initial attraction gap at 20°C.
- (Note 4) The brake gap will widen through brake lining wear caused by braking. However, the gap cannot be adjusted. Thus, the brake life is considered to be reached when adjustments are required.
- (Note 5) A leakage flux will be generated at the shaft end of the servomotor with a magnetic brake.
- (Note 6) When operating in low speed regions, the sound of loose brake lining may be heard. However, this is not a problem in terms of function.

(b) 400V series < HF-H Series >

ltem		Motor type					
		HF-H75B, HF-H105B	HF-H54B, HF-H104B HF-H154B	HF-H204B, HF-H354B HF-H453B, HF-H703B HF-H903B			
Type (Note 1)			d non-exciting operation mag				
Type (Note 1)		(for ma	aintenance and emergency b	raking)			
Rated voltage			24VDC				
Rated current at 20°C (A)		0.38	0.8	1.4			
Capacity (W)		9	19	34			
Static friction torque (Ne	m)	2.4	8.3	43.1			
Inertia (Note 2) (kg•cm²)		0.2	2.2	9.7			
Release delay time (Note	e 3) (s)	0.03	0.04	0.1			
Braking delay time (DC 0	OFF) (Note 3) (s)	0.03	0.03	0.03			
Tolerable braking work	Per braking (J)	64	64 400				
amount	Per hour (J)	640	4,000	45,000			
Brake play at motor axis (degree)		0.1 to 0.9	0.2 to 0.6	0.2 to 0.6			
No. of braking		20,000	20,000	20,000			
Brake life (Note 4)	operations (times)						
,	Work amount	32	200	1,000			
	per braking (J)			,			

< HP-H Series >

Item		Motor type							
		HP-H54B	HP-H104B HP-H154B	HP-H204B HP-H224B	HP-H354B HP-H454B	HP-H704B	HP-H903B HP-H1103B		
Type (Note 1)			Spring closed non-exciting operation magnetic brakes (for maintenance and emergency braking)						
Rated voltage			· · · · · · · · · · · · · · · · · · ·	24V	DC				
Rated current at 20°C(A)		0.91 0.86 1.0 1.4 1.4 1.7				1.7			
Capacity (W)		21	21	24	34	34	41		
Static friction torque (N•	3.5	9	12	32	54.9	90			
Inertia (Note 2) (kg•cm²)	0.5	0.5	5.5	5.5	5.5	24			
Release delay time (Note	e3) (s)	0.1	0.1	0.1	0.12	0.3	0.3		
Braking delay time (DC 0	OFF) (Note3) (s)	0.1	0.1	0.1	0.1	0.1	0.1		
Tolerable braking work	Per braking (J)	700	700	700	4,500	4,500	4,500		
amount	Per hour (J)	7,000	7,000	7,000	45,000	45,000	45,000		
Brake play at motor axis (degree)		0.2 to 0.6	0.2 to 0.6	0.2 to 0.6	0.2 to 0.6	0.2 to 0.6	0.2 to 0.6		
Brake life (Note4)	No. of braking operations (times)	20,000	20,000	20,000	20,000	20,000	20,000		
Drake me (Note4)	Work amount per braking (J)	200	200	200	1,000	1,000	1,000		

- (Note 1) There is no manual release mechanism. If handling is required such as during the machine core alignment work, prepare a separate 24VDC power supply, and electrically release a brake.
- (Note 2) These are the values added to the servomotor without a brake.
- (Note 3) This is the representative value for the initial attraction gap at 20°C.
- (Note 4) The brake gap will widen through brake lining wear caused by braking. However, the gap cannot be adjusted. Thus, the brake life is considered to be reached when adjustments are required.
- (Note 5) A leakage flux will be generated at the shaft end of the servomotor with a magnetic brake.
- (Note 6) When operating in low speed regions, the sound of loose brake lining may be heard. However, this is not a problem in terms of function.

(3) Magnetic brake power supply

1. Always install a surge absorber on the brake terminal when using DC OFF.

CAUTION!

2. Do not pull out the cannon plug while the brake power is ON. The cannon plug pins could be damaged by sparks.

(a) Brake excitation power supply

- [1] Prepare a brake excitation power supply that can accurately ensure the attraction current in consideration of the voltage fluctuation and excitation coil temperature.
- [2] The brake terminal polarity is random. Make sure not to mistake the terminals with other circuits.


(b) Bake excitation circuit

When turning OFF the brake excitation power supply (to apply the brake), DC OFF is used to shorten the braking delay time.

A surge absorber will be required. Pay attention to the relay cut off capacity.

<Cautions>

- Provide sufficient DC cut off capacity at the contact.
- · Always use a surge absorber.
- When using the cannon plug type, the surge absorber will be further away, so use shielded wires between the motor and surge absorber.



PS : 24VDC stabilized power supply

ZD1,ZD2 : Zener diode for power supply protection (1W, 24V)

VAR1,VAR2 : Surge absorber


Magnetic brake circuits

4-1-9 Dynamic brake characteristics

If a servo alarm that cannot control the motor occurs, the dynamic brakes will function to stop the servomotor regardless of the parameter settings.

(1) Deceleration torque

The dynamic brake uses the motor as a generator, and obtains the deceleration torque by consuming that energy with the dynamic brake resistance. The characteristics of this deceleration torque have a maximum deceleration torque (Tdp) regarding the motor speed as shown in the following drawing. The torque for each motor is shown in the following table.



Deceleration torque characteristics of a dynamic brake

Motor speed

Max. deceleration torque of a dynamic brake

Motor type	Stall torque	Tdp	Ndp	Motor type	Stall torque	Tdp	Ndp
(200V series)	(N•m)	(N•m)	(r/min)	(400V series)	(N•m)	(N•m)	(r/min)
HF75	2.0	5.43	1825	HF-H75	2.0	5.11	1685
HF105	3.0	10.21	1967	HF-H105	3.0	10.19	1740
HF54	2.9	3.96	758	HF-H54	2.9	3.96	690
HF104	5.9	10.02	1060	HF-H104	5.9	10.04	897
HF154	9.0	15.65	1356	HF-H154	9.0	15.04	1073
HF224	12.0	20.06	1765	HF-H204	13.7	15.83	835
HF204	13.7	15.97	1029	HF-H354	22.5	37.35	657
HF354	22.5	35.28	908	HF-H453	37.2	52.90	619
HF123	7.0	9.79	750	HF-H703	49.0	71.79	374
HF223	12.0	19.95	1059	HF-H903	58.8	89.57	1044
HF303	22.5	30.43	955	HP-H54	3.0	6.32	614
HF453	37.2	53.01	1080	HP-H104	5.9	11.10	824
HF703	49.0	71.93	1070	HP-H154	9.0	18.08	1107
HF903	58.8	89.23	3755	HP-H224	12.0	28.65	1445
HF142	11.0	14.43	547	HP-H204	13.7	28.04	1524
HF302	20.0	29.42	635	HP-H354	22.5	37.93	861
HP54	3.0	6.36	716	HP-H454	31.9	60.58	939
HP104	5.9	11.10	987	HP-H704	49.0	95.47	597
HP154	9.0	17.41	1307	HP-H903	70.0	100.47	936
HP224	12.0	28.74	1848	HP-H1103	110.0	170.39	704
HP204	13.7	26.16	2135	HC-H1502S-S10	146.0	237.80	1828
HP354	22.5	38.44	2072				
HP454	31.9	61.60	1597				
HP704	49.0	88.38	1656				
HP903	70.0	91.73	2984				
HP1103	110.0	158.09	2324				
HF-KP23	0.64	1.04	1272				
HF-KP43	1.3	2.60	1377				
HF-KP73	2.4	2.96	962				


(2) Coasting rotation distance during emergency stop

The distance that the motor coasts (angle for rotary axis) when stopping with the dynamic brakes can be approximated with the following expression.

$$\label{eq:lmax_lmax} \text{L_{MAX}} = \frac{F}{60} \cdot \{\text{t_{e}} + \text{$($1+\frac{J_L}{J_M}$)} \cdot (\text{$A \cdot \text{N^2}$} + \text{$B)$} \}$$

 L_{MAX} : Motor coasting distance (angle) [mm, (deg)] F : Axis feedrate [mm/min, (deg/min)] Ν : Motor speed [r/min] J_{M} : Motor inertia [kg•cm²] J_L : Motor shaft conversion load inertia [kg•cm²] : Brake drive relay delay time [s] (Normally, 0.03s)

A : Coefficient A (Refer to the next page)
B : Coefficient B (Refer to the next page)



Dynamic brake braking diagram

Coasting amount calculation coefficients table

Motor type	J _M (kg•cm²)	А	В	Motor type	J _M (kg∙cm²)	А	В
HF75	2.6	0.46×10 ⁻⁹	4.58×10 ⁻³	HF-H75	2.6	0.53×10 ⁻⁹	4.49×10 ⁻³
HF105	5.1	0.44×10 ⁻⁹	5.15×10 ⁻³	HF-H105	5.1	0.50×10 ⁻⁹	4.56×10 ⁻³
HF54	6.1	3.54×10 ⁻⁹	6.11×10 ⁻³	HF-H54	6.1	3.90×10 ⁻⁹	5.56×10 ⁻³
HF104	11.9	1.95×10 ⁻⁹	6.59×10 ⁻³	HF-H104	11.9	2.31×10 ⁻⁹	5.57×10 ⁻³
HF154	17.8	1.46×10 ⁻⁹	8.07×10 ⁻³	HF-H154	17.8	1.92×10 ⁻⁹	6.65×10 ⁻³
HF224	23.7	1.17×10 ⁻⁹	10.92×10 ⁻³	HF-H204	38.3	5.06×10 ⁻⁹	10.58×10 ⁻³
HF204	38.3	4.07×10 ⁻⁹	12.92×10 ⁻³	HF-H354	75.0	5.33×10 ⁻⁹	6.91×10 ⁻³
HF354	75.0	4.09×10 ⁻⁹	10.11×10 ⁻³	HF-H453	112.0	5.97×10 ⁻⁹	6.86×10 ⁻³
HF123	11.9	2.83×10 ⁻⁹	4.77×10 ⁻³	HF-H703	154.0	10.01×10 ⁻⁹	4.20×10 ⁻³
HF223	23.7	1.96×10 ⁻⁹	6.59×10 ⁻³	HF-H903	196.0	3.66×10 ⁻⁹	11.96×10 ⁻³
HF303	75.0	4.50×10 ⁻⁹	12.32×10 ⁻³	HP-H54	4.6	3.23×10 ⁻⁹	2.34×10 ⁻³
HF453	112.0	3.42×10 ⁻⁹	11.95×10 ⁻³	HP-H104	7.7	2.30×10 ⁻⁹	2.99×10 ⁻³
HF703	154.0	3.49×10 ⁻⁹	11.99×10 ⁻³	HP-H154	12.0	1.64×10 ⁻⁹	3.85×10 ⁻³
HF903	196.0	1.02×10 ⁻⁹	43.18×10 ⁻³	HP-H224	20.0	1.32×10 ⁻⁹	5.28×10 ⁻³
HF142	17.8	3.94×10 ⁻⁹	3.53×10 ⁻³	HP-H204	29.0	2.66×10 ⁻⁹	8.25×10 ⁻³
HF302	75.0	7.01×10 ⁻⁹	8.48×10 ⁻³	HP-H354	37.0	4.45×10 ⁻⁹	4.40×10 ⁻³
HP54	4.6	2.75×10 ⁻⁹	2.71×10 ⁻³	HP-H454	55.0	3.80×10 ⁻⁹	4.46×10 ⁻³
HP104	7.7	1.92×10 ⁻⁹	3.59×10 ⁻³	HP-H704	82.0	5.65×10 ⁻⁹	2.68×10 ⁻³
HP154	12.0	1.44×10 ⁻⁹	4.72×10 ⁻³	HP-H903	163.0	9.39×10 ⁻⁹	10.98×10 ⁻³
HP224	20.0	1.03×10 ⁻⁹	6.74×10 ⁻³	HP-H1103	255.0	9.83×10 ⁻⁹	6.49×10 ⁻³
HP204	29.0	2.04×10 ⁻⁹	12.39×10 ⁻³	HC-H1502S-S10	550.0	2.21×10 ⁻⁹	22.14×10 ⁻³
HP354	37.0	1.82×10 ⁻⁹	10.44×10 ⁻³				
HP454	55.0	2.19×10 ⁻⁹	7.47×10 ⁻³				
HP704	82.0	2.20×10 ⁻⁹	8.04×10 ⁻³				
HP903	163.0	3.23×10 ⁻⁹	38.33×10 ⁻³				
HP1103	255.0	3.21×10 ⁻⁹	23.09×10 ⁻³				
HF-KP23	0.23	0.18×10 ⁻⁹	1.54×10 ⁻³				
HF-KP43	0.42	0.12×10 ⁻⁹	1.16×10 ⁻³				
HF-KP73	1.43	0.49×10 ⁻⁹	2.43×10 ⁻³				

4-2 Spindle motor


4-2-1 Environmental conditions

Environment	Conditions
Ambient temperature	0°C to +40°C (with no freezing)
Ambient humidity	90% RH or less (with no dew condensation)
Storage temperature	-20°C to +65°C(with no freezing)
Storage humidity	90% RH or less (with no dew condensation)
Atmosphere	Indoors (no direct sunlight);
Atmosphere	no corrosive gas, inflammable gas, oil mist or dust
Altitude	Operation/storage: 1000m or less above sea level
Ailliude	Transportation: 10000m or less above sea level

4-2-2 Shaft characteristics

There is a limit to the load that can be applied on the motor shaft. Make sure that the load applied on the radial direction, when mounted on the machine, is below the tolerable values given below. These loads may affect the motor output torque, so consider them when designing the machine.

Series	Spindle motor	Tolerable radial load
	SJ-VL2.2ZT, SJ-V3.7-02ZT	196N
	SJ-VL11-10FZT	245N
	SJ-VL0.75-01T, SJ-VL1.5-01T	490N
	SJ-D3.7/100-01, SJ-DJ5.5/100-01,	
	SJ-V2.2-01T, SJ-V3.7-01T, SJ-V5.5-01ZT, SJ-V7.5-01ZT, SJ-V7.5-03ZT,	980N
	SJ-V11-06ZT, SJ-VL11-05FZT-S01, SJ-VL11-07ZT	
200V	SJ-D5.5/100-01, SJ-DJ7.5/100-01, SJ-V11-08ZT	1470N
series	SJ-D7.5/100-01, SJ-D11/80-01, SJ-DJ11/100-01, SJ-DJ15/80-01	1960N
	SJ-V11-01T, SJ-V11-01ZT, J-V11-13ZT, SJ-V22-06ZT, SJ-V30-02ZT	100011
	SJ-V11-09T, SJ-V15-01ZT, SJ-V15-03ZT, SJ-V15-09ZT, SJ-V18.5-03T,	
	SJ-V18.5-01ZT, SJ-V18.5-04ZT, SJ-V22-05T, SJ-V22-01ZT, SJ-V22-04ZT,	2940N
	SJ-V26-01ZT	
	SJ-V37-01T, SJ-V45-01T, SJ-V22-09T, SJ-VK22-19ZT	3920N
	SJ-V55-01T	5880N
	SJ-4-V3.7-05ZT	490N
	SJ-4-V2.2-03T, SJ-4-V3.7-03T, SJ-4-V7.5-13ZT, SJ-4-V11-22ZT	980N
	SJ-4-V5.5-07T, SJ-4-V11-23ZT	1470N
400V	SJ-4-V7.5-12T, SJ-4-V11-18T, SJ-4-V22-18ZT, SJ-4-V30-15ZT	1960N
series	SJ-4-V11-21T, SJ-4-V15-18T, SJ-4-V15-20T, SJ-4-V18.5-14T, SJ-4-V18.5-17T,	2940N
	SJ-4-V22-15T, SJ-4-V22-16T, SJ-4-V26-08T	294011
	SJ-4-V37-04T, SJ-4-V45-02T	3920N
	SJ-4-V55-03T	5880N



(Note) The load point is at the one-half of the shaft length.


⚠ CAUTION

Consider on the machine side so that the thrust loads are not applied to the spindle motor.

4-2-3 Machine accuracy

Machine accuracy of the spindle motor's output shaft and around the installation part is as below. (Excluding special products)

Accuracy [mm]	Measurement point	Flange size [mm]
Amplitude of the flange surface to the output shaft	а	0.08
Amplitude of the flange surface's fitting outer diameter	b	0.04
Amplitude of the output shaft end	С	0.02




4-2-4 Installation of spindle motor



- 1. Rubber packing for waterproof is attached on the inner surface of the top cover of terminal block.

 After checking that the packing is installed, install the top cover.
- 2. When installing a motor on a flange, chamfer(C1) the part of flange that touches inside low part of the motor.

To yield good cooling performance, provide a space of at least 30mm between the cooling fan and wall. If the motor is covered by a structure and the air is not exchanged, its cooling performance degrades and the motor is unable to fully exercise its performance, which may cause the spindle motor overheat alarm. Do not use the spindle motor in an enclosed space with little ventilation.



4-3 Tool spindle motor

4-3-1 Environmental conditions

Environment	Conditions			
Ambient temperature	0°C to +40°C (with no freezing)			
Ambient humidity	80% RH or less (with no dew condensation)			
Storage temperature	-15°C to +70°C (with no freezing)			
Storage humidity	90% RH or less (with no dew condensation)			
Atmosphere	Indoors (no direct sunlight)			
Atmosphere	No corrosive gas, inflammable gas, oil mist or dust			
Altitude	Operation / storage: 1000m or less above sea level			
Ailituuc	Transportation: 10000m or less above sea level			


4-3-2 Shaft characteristics

There is a limit to the load that can be applied on the motor shaft. Make sure that the load applied on the radial direction and thrust direction, when mounted on the machine, is below the tolerable values given below. These loads may affect the motor output torque, so consider them when designing the machine.

Tool spindle motor	Tolerable radial load	Tolerable thrust load
HF-KP46, 56	245N (L=30)	98N
HF-KP96	392N (L=40)	147N
HF-SP226, 406	980N(L-55	490N
HF75S, 105S	245N (L=33)	147N
HF54S, 104S, 154S, 224S, 123S, 223S	980N (L=55)	490N
HF204S, 303S, 354S,453S,703S	2058N (L=79)	980N
HF903S	2450(L=85)	980N

(Note 1) The tolerable radial load and thrust load in the above table are values applied when each motor is used independently.

(Note 2) The symbol L in the table refers to the value of L below.




L: Length from flange installation surface to center of load mass [mm]


4-3-3 Tool spindle temperature characteristics

< HF-KP Series >


[HF-KP46J(K)W09]



[HF-KP56J(K)W09]




[HF-KP96J(K)W09]




< HF-SP Series >

[HF-SP226J(K)W09]



[HF-SP406J(K)W09]



CAUTION!

- 1. The contour lines 20K to 100K in the graph indicate the temperature rising values from the start-up to saturation.
- 2. The motor temperature tends to rise in a high-speed rotation even if the load rate is low.

4-4 Drive unit

4-4-1 Environmental conditions

Environment	Conditions			
Ambient temperature	0°C to +55°C (with no freezing)			
Ambient humidity	90% RH or less (with no dew condensation)			
Storage temperature	-15°C to +70°C (with no freezing)			
Storage humidity	90% RH or less (with no dew condensation)			
Atmosphere	Indoors (no direct sunlight);			
Admosphere	no corrosive gas, inflammable gas, oil mist, dust or conductive fine particles			
Altitude	Operation/storage: 1000m or less above sea level			
Ailliude	Transportation: 13000m or less above sea level			
Vibration	Operation/storage: 4.9m/s ² (0.5G) or less Transportation: 49m/s ² (5G) or less			

(Note) When installing the machine at 1,000m or more above sea level, the heat dissipation characteristics will drop as the altitude increases. The upper limit of the ambient temperature drops 1°C with every 100m increase in altitude. (The ambient temperature at an altitude of 2,000m is between 0 and 45°C.)

4-4-2 Heating value

The values for the servo drive unit apply at the stall output. The values for the spindle drive unit apply for the continuous rated output. The values for the power supply unit include the AC reactor's heating value.

< MDS-D Series >

Servo drive unit				Spindle drive unit					Power supply unit					
Туре	Heating [V	g value V]	Туре	Heating [V	g value V]	Туре		g value V]	Туре	Heating [V	g value V]	Туре		g value V]
MDS-D-	In- side panel	Out- side panel	MDS-D-	In- side panel	Out- side panel	MDS-D-	In- side panel	Out- side panel	MDS-D-	In- side panel	Out- side panel	MDS-D-	In- side panel	Out- side panel
V1-20	18	22	V2-2020	26	44	SP-20	24	31	SP2-2020	28	62	CV-37	20	34
V1-40	20	38	V2-4020	28	60	SP-40	29	65	SP2-4020	33	96	CV-75	24	55
V1-80	25	71	V2-4040	31	75	SP-80	37	121	SP2-4040S	38	130	CV-110	25	99
V1-160	36	148	V2-8040	35	109	SP-160	54	236	SP2-4040	38	130	CV-185	32	161
V1-160W	44	201	V2-8080	40	142	SP-200	78	404	SP2-8040	46	186	CV-300	45	272
V1-320	59	307	V2-16080	51	219	SP-240	100	520	SP2-16080S	70	358	CV-370	53	343
V1-320W	72	399	V2-160160	62	296	SP-320	118	688	SP2-8080	54	242	CV-450	104	392
			V2-16160W	77	403	SP-400	148	897	SP2-16080	70	358	CV-550	164	431
						SP-640	196	1231						

< MDS-DH Series >

Servo drive unit				Spindle drive unit			Power supply unit				
Туре	Heating	value [W]	Туре	Heating	value [W]	Type	Heating	value [W]	Type MDS-DH-	Heating value [W]	
MDS-DH-	Inside panel	Outside panel	MDS-DH-	Inside panel	Outside panel	MDS-DH-	MDS-DH- Inside panel	Outside panel		Inside panel	Outside panel
V1-10	19	27	V2-1010	28	54	SP-20	32	88	CV-37	20	34
V1-20	22	46	V2-2010	30	74	SP-40	42	158	CV-75	24	55
V1-40	27	87	V2-2020	33	93	SP-80	54	237	CV-110	25	99
V1-80	40	175	V2-4020	39	133	SP-100	73	369	CV-185	32	161
V1-80W	47	222	V2-4040	45	173	SP-160	110	639	CV-300	45	272
V1-160	62	328	V2-8040	57	262	SP-200	126	746	CV-370	53	343
V1-160W	81	461	V2-8080	70	350	SP-320	168	1034	CV-450	104	392
V1-200	105	630	V2-8080W	83	445	SP-480	232	1488	CV-550	164	431
									CV-750	228	614

- 1. Design the panel's heating value taking the actual axis operation (load rate) into consideration.
- 2. The heating values in the above tables are calculated with the following load rates.




Unit	Load rate
Servo drive unit	50%
Spindle drive unit	100%
Power supply unit	100%

4-4-3 Drive unit arrangement

Arrange the drive units in the following procedure.

- (1) Install a power supply unit.
- (2) Arrange drive units in order of the nominal current from largest from the right.
- (3) In the arrangement, the clearance between the units is 1 mm.
- (4) Arrange the drive units with the DC connection length from the power supply unit being 800mm or less. For the arrangement of 800mm or more, multiple power supply units are required.
- (5) Arrange large capacity drive units at the left of the power supply unit with the clearance between the drive units being 1mm.



Arrange drive units in order of nominal current from largest.


1. Arrange large capacity drive units at the left of the power supply unit with the clearance between the drive units being 1mm.



- 2. Power supply units equivalent to the number of large capacity drive units are required.
- 3. When arranging the drive unit at the right of the large capacity power supply unit, remove the side protection cover of the power supply unit.

<For separated arrangement of drive units >

Arranging drive units in the horizontal as much as possible is recommended. Thus, if the drive units must be arranged in the vertical, or if the drive units must be separated by more than 30mm, arrange them with the DC connection length of 500mm or less.



1. D: For MDS-D-V1-320W, MDS-D-SP-240 to 640, the separated wiring is not available.

DH: For MDS-DH-V1-160W to 200, MDS-DH-SP-160 to 480, the separated wiring is not available.

CAUTION!

- 2. If the drive units are separated by more than 30mm, twist the wires used for the DC connection or bundle them with a fixing band in order to prevent two wires from being separated.
- 3. Failure to observe the above arrangement could damage the units.

5

Dedicated Options

5 Dedicated Options

5-1 Servo options

The option units are required depending on the servo system configuration. Check the option units to be required referring the following items.

(1) System establishment in the full closed loop control

Refer to the table below to confirm the interface unit (I/F) and battery option required for the full closed loop control.

(a) Full closed loop control for linear axis

Ma	chine side dete	ector to be used	Detector signal output	Interface unit	Drive unit input signal	Battery option	Remarks
	Rectangular wave signal	SR74, SR84 (MAGNESCALE)	Rectangular wave signal	-	Rectangular wave signal	-	
	output	Various scale	Rectangular wave signal	-	Rectangular wave signal	-	
		LS187, LS487	SIN wave signal	IBV series (HEIDENHAIN)	Rectangular wave signal	-	
Incre-		(HEIDENHAIN)		EIB series (HEIDENHAIN)	Mitsubishi serial signal	-	
mental detector	SIN wave signal output	LS187C, LS487C (HEIDENHAIN)	SIN wave signal	MDS-B-HR-11(P) (MITSUBISHI ELECTRIC)	Mitsubishi serial signal	(Required) Note	Distance-coded reference scale
		Various scale	SIN wave signal	MDS-B-HR-11(P) (MITSUBISHI ELECTRIC)	Mitsubishi serial signal	(Required) Note	Distance-coded reference scale is also available
	Mitsubishi serial signal output	SR75, SR85 (MAGNESCALE)	Mitsubishi serial signal	-	Mitsubishi serial signal	-	
		OSA105ET2, OSA166ET2N (MITSUBISHI)	Mitsubishi serial signal	-	Mitsubishi serial signal	Required	Ball screw end detector
		SR77, SR87 (MAGNESCALE)	Mitsubishi serial signal	-	Mitsubishi serial signal	Not required	
		LC193M, LC493M (HEIDENHAIN)	Mitsubishi serial signal	-	Mitsubishi serial signal	Not required	
Abso-	Mitsubishi serial signal	AT343, AT543, AT545 (Mitutoyo)	Mitsubishi serial signal	-	Mitsubishi serial signal	Not required	
lute position	output	SAM Series (FAGOR)	Mitsubishi serial signal	-	Mitsubishi serial signal	Not required	
detector		SVAM Series (FAGOR)	Mitsubishi serial signal	-	Mitsubishi serial signal	Not required	
		GAM Series (FAGOR)	Mitsubishi serial signal	-	Mitsubishi serial signal	Not required	
		LAM Series (FAGOR)	Mitsubishi serial signal	-	Mitsubishi serial signal	Not required	
	SIN wave signal output	MPS Series (MME Corp.)	SIN wave signal	ADB-20J60 (MME Corp.)	Mitsubishi serial signal	Required	

(Note) When using the distance-coded reference scale, it is recommended to use with distance-coded reference check function. In this case, the battery option is required.

(b) Full closed loop control for rotary axis

Ma	Machine side detector to be used		Detector signal output	Interface unit	Output signal	Battery option	Remarks
Rectangular wave signal output		Various scale	Rectangular wave signal	-	Rectangular wave signal	-	
mental detector	SIN wave signal	ERM280 Series (HEIDENHAIN)	SIN wave signal	EIB series (HEIDENHAIN)	Mitsubishi serial signal	-	
	output	Various scale	SIN wave signal	MDS-B-HR-11(P) (MITSUBISHI ELECTRIC)	Mitsubishi serial signal	-	
	Mitsubishi	RU77 (MAGNESCALE)	Mitsubishi serial signal	-	Mitsubishi serial signal	Not required	
Abso-	serial signal	RCN223M, RCN227M (HEIDENHAIN)	Mitsubishi serial signal	-	Mitsubishi serial signal	Not required	
lute position	lute .	RCN727M, RCN827M (HEIDENHAIN)	Mitsubishi serial signal	-	Mitsubishi serial signal	Not required	
_	SIN wave signal	MPRZ Series (MME Corp.)	SIN wave signal	ADB-20J71 (MME Corp.)	Mitsubishi serial signal	Not required	
output		MPI Series (MME Corp.)	SIN wave signal	ADB-20J60 (MME Corp.)	Mitsubishi serial signal	Required	

<Contact information about machine side detector>

- Magnescale Co., Ltd: http://www.mgscale.com/mgs/
- HEIDENHAIN CORPORATION: http://www.heidenhain.de/
- Mitutoyo Corporation: http://www.mitutoyo.co.jp/
- MHI MACHINE TOOL ENGINEERING CO., LTD: http://www.mme-e.co.jp/
- FAGOR Automation: http://www.fagorautomation.com/



The absolute position system cannot be established in combination with the relative position (incremental) machine side detector and absolute position motor side detector.

5 Dedicated Options

(2) System establishment in the synchronous control

(a) Position command synchronous control

The synchronous control is all executed in the NC, and the each servo is controlled as an independent axis. Therefore, preparing special options for the synchronous control is not required on the servo side.

(b) Speed command synchronization control

The common position control in two axes is performed by one linear scale. Basically, the two axes integrated type drive unit (MDS-D/DH-V2) is used, and the feedback signal is divided for two axes inside the drive unit.

When the two 1-axis type drive units are used in driving the large capacity servomotor, the linear scale feedback signal must be divided outside.

<Required option in the speed command synchronous control>

Machine side detector to be used	For MDS-D/DH-V2	For MDS-D/DH-V1×2units	Remarks
SIN wave signal output scale	MDS-B-HR-11(P) (Serial conversion)	MDS-B-HR-12(P) (Serial conversion/signal division)	
Mitsubishi serial signal output scale	-	MDS-B-SD (Signal division)	Including the case that an interface unit of the scale manufacturer is used with SIN wave output scale.

(Note) The rectangular wave signal output scale speed command synchronous control is not available.




When executing the synchronous control, use the servomotors of which the type and detector specifications are same.

< Speed command synchronization control system configuration >

1) SIN wave signal output scale


< When using MDS-D/DH-V2 >

For the FB signal of the linear scale, the SIN wave signal is converted to Mitsubishi serial signal with the detector conversion unit (MDS-B-HR-11), and that signal is divided to each axis control inside 2-axis drive unit.



<When using two units of MDS-D/DH-V1>

For the FB signal of the linear scale, the SIN wave signal is converted to Mitsubishi serial signal with the detector conversion unit (MDS-B-HR-12), and that signal is divided to each drive unit.




5 Dedicated Options

2) Mitsubishi serial signal output scale


< When using MDS-D/DH-V2 >

The FB signal of the linear scale is divided to each axis control inside 2-axis drive unit. An external option unit is not required.



< When using two units of MDS-D/DH-V1 >

The FB signal of the linear scale is divided to each drive unit with the signal division unit (MDS-B-SD).



5-1-1 Dynamic brake unit (MDS-D-DBU)


The MDS-D-V1-320W and MDS-DH-V1-160W or larger units do not have dynamic brakes built in, so install an external dynamic brake unit.

(1) Specifications

Туре	Coil specifications	Wire size	Compatible drive unit	Mass (kg)
MDS-D-DBU	24VDC 160mA	5.5mm ² or more (For IV wire)	MDS-D-V1-320W MDS-DH-V1-160W or larger	2kg


(2) Outline dimension drawings MDS-D-DBU

[Unit: mm]




5 Dedicated Options

(3) Connecting with the servo drive unit



Internal circuit diagram



⚠ CAUTION

Correctly wire the dynamic brake unit to the servo drive unit.

Do not use for applications other than emergencies (normal braking, etc.). The internal resistor could heat up, and lead to fires or faults.



When you use a motor with a brake, please wire (between 1pin and 3pin) for the CN20 connector.

5-1-2 Battery option (ER6V-C119B, A6BAT, MDS-A-BT, MDS-BTBOX-36)

This battery option may be required to establish absolute position system. Select a battery option from the table below depending on the servo system.

Туре	EER6V-C119B	A6BAT(MR-BAT)	MDS-A-BT-	MDS-BTBOX-36
Installation type	Drive unit with battery holder type	Dedicated case type	Unit and battery integration type	Unit and battery integration type
Hazard class	Not applicable	Not applicable (24 or less)	Class9 (excluding MDS-A-BT-2)	Not applicable
Number of connectable axes	Up to 3 axes	Up to 8 axes (When using dedicated case)	2 to 8 axes	Up to 8 axes
Battery change	Possible	Possible	Not possible	Possible
Appearance	Battery connector bolder Battery ER6V-C119B	Battery A6BAT (MR-BAT) Dedicated case MDS-BTCASE	(3)	(4)

(Note) When using the converged battery option, refer to this section "(5) Converged battery option".

- On January 1, 2003, new United Nations requirements, "United Nations Dangerous Goods Regulations Article 12", became effective regarding the transportation of lithium batteries. The lithium batteries are classified as hazardous materials (Class 9) depending on the unit. (Refer to Appendix 2.)
- 2. The lithium battery must be transported according to the rules set forth by the International Civil Aviation Organization (ICAO), International Air Transportation Association (IATA), International Maritime Organization (IMO), and United States Department of Transportation (DOT), etc. The packaging methods, correct transportation methods, and special regulations are specified according to the quantity of lithium alloys. The battery unit exported from Mitsubishi is packaged in a container (UN approved part) satisfying the standards set forth in this UN Advisory.



- 3. To protect the absolute value, do not shut off the servo drive unit control power supply if the battery voltage becomes low (warning 9F).
- 4. Contact the Service Center when replacing the MDS-A-BT Series and cell battery.
- 5. The battery life (backup time) is greatly affected by the working ambient temperature. The above data is the theoretical value for when the battery is used 8 hours a day/240 days a year at an ambient temperature of 25°C. Generally, if the ambient temperature increases, the backup time and useful life will both decrease.



A6BAT is a battery with same specifications as MR-BAT.

(1) Cell battery (ER6V-C119B)

(a) Specifications


Battery option type		Cell battery
	Sattery Option type	ER6V-C119B (Note1)
Lithium battery series		ER6V
Nominal v	oltage	3.6V
Nominal ca	apacity	2000mAh
	Hazard class	-
D-11	Battery shape	Single battery
Battery safety	Number of batteries used	ER6V x 1
Salety	Lithium alloy content	0.7g
	Mercury content	1g or less
Number of	connectable axes	Up to 3 axes (Note3)
Battery co	ntinuous backup time	Up to 2 axes: Approx. 10000 hours 3 axes connected: Approx. 6600 hours
Battery us (From date	eful life e of unit manufacture)	7 years
Data save	time in battery replacement	Approx. 20 hours at time of delivery, approx. 10 hours after 5 years
Back up time from battery warning to alarm occurrence (Note2)		Up to 2 axes: Approx. 100 hours 3 axes connected: Approx. 60 hours
Mass		20g


- (Note1) ER6V-C119B is a battery built in a servo drive unit. Install this battery only in the servo drive unit that executes absolute position control.
- (Note2) This time is a guideline, so does not guarantee the back up time. Replace the battery with a new battery as soon as a battery warning occurs.
- (Note3) When using ball screw side detector OSA166ET2N/OSA105ET2, both ball screw side detector and motor side detector need to be backed up by a battery, so the number of load shaft should be two.

(b) Installing the cell battery

Open the upper front cover of the servo drive unit.

Connect the battery connector and then put the battery inside.





(Note) When using a cell battery, do not connect the battery unit, MDS-A-BT and MDS-BTBOX-36.



When using a cell battery built-in drive unit, the wiring between units is not required. The cell battery can be changed in each drive unit.

(2) Cell battery (A6BAT)

Always use the cell battery (A6BAT) in combination with the dedicated case (MDS-BTCASE).

(a) Specifications

Battery option type		Cell battery	
		A6BAT (MR-BAT)	
Lithium I	battery series	ER17330V	
Nominal voltage		3.6V	
Nominal	capacity	1700mAh	
	Hazard class	-	
Dottom.	Battery shape	Single battery	
Battery safety	Number of batteries used	A6BAT (MR-BAT) x 1	
	Lithium alloy content	0.48g	
	Mercury content	1g or less	
Number	of connectable axes	1 axis / (per 1 battery)	
Battery of	continuous backup time	Approx. 10000 hours	
•	useful life ate of unit manufacture)	5 years	
Data sav	e time in battery replacement	Approx. 20 hours at time of delivery, approx. 10 hours after 5 years	
Back up time from battery warning to			
alarm occurrence		Approx. 80 hours	
(Note)			
Mass		17g	


(Note) This time is a guideline, so does not guarantee the back up time. Replace the battery with a new battery as soon as a battery warning occurs.

(b) Specifications of the dedicated case MDS-BTCASE

Туре	MDS-BTCASE
Number of batteries installed	Up to 8 A6BATs (MR-BATs) (Install either 2, 4, 6 or 8 A6BATs (MR-BATs))
Number of connectable axes	Max. 8 axes (It varies depending on the number of batteries installed.) When A6BAT (MR-BAT) x 2, 1 to 2 axis/axes When A6BAT (MR-BAT) x 4, 3 to 4 axes When A6BAT (MR-BAT) x 6, 5 to 6 axes When A6BAT (MR-BAT) x 8, 7 to 8 axes

(c) Installing the cell battery

Open the cover of the dedicated case. Connect the battery connector and then put the battery inside.



(d) Installing A6BAT (MR-BAT) to battery case


Open the cover of the dedicated case. Connect the battery connector and then put the battery inside.

[1] Incorporate batteries in order, from the connector CON1 on the top of the case. In the same way, install batteries to holders in order, from the holder on the top.




Example of incorporated batteries (Photo: 8 batteries incorporated)


Corresponding to MDS-A-BT-2




Corresponding to MDS-A-BT-4




Corresponding to MDS-A-BT-6




Corresponding to MDS-A-BT-8



[2] Attach a seal indicating the number of incorporated batteries to the part shown below.



(e) Outline dimension drawing of the dedicated case MDS-BTCASE




(3) Battery unit (MDS-A-BT)

(a) Specifications

Battery option type			Batte	ry unit	
Dattery 0	ption type	MDS-A-BT-2	MDS-A-BT-4	MDS-A-BT-6	MDS-A-BT-8
Lithium battery series			ER	6V	
Nominal	voltage		3.	6V	
Nominal	capacity	4000mAh	8000mAh	12000mAh	16000mAh
Hazard class			Cla	ss 9	
Dattami	Battery shape	Set battery			
Battery safety	Number of batteries used	ER6V x 2	ER6V x 4	ER6V x 6	ER6V x 8
Salety	Lithium alloy content	1.3g	2.6g	3.9g	5.2g
	Mercury content		1g o	rless	•
Number of	of connectable axes	Up to 2 axes	Up to 4 axes	Up to 6 axes	Up to 8 axes
Battery c	ontinuous backup time	Approx. 20000 hours			
Battery u (From da	seful life te of unit manufacture)	7 years			
Data save time in battery replacement		Approx. 20 hours at time of delivery, approx. 10 hours after 5 years			
Back up time from battery warning to alarm occurrence (Note)		Approx. 100 hours			
Mass		600g			

(Note) This time is a guideline, so does not guarantee the back up time. Replace the battery with a new battery as soon as a battery warning occurs.

(b) Outline dimension drawings MDS-A-BT-2/-4/-6/-8



(4) Battery box (MDS-BTBOX-36)

(a) Specifications

Battery option type	Battery box	
Battery option type	MDS-BTBOX-36	
Battery model name	size-D alkaline batteries LR20 x 4 pieces (Note1)	
Nominal voltage	3.6V (Unit output), 1.5V (Isolated battery)	
Number of connectable axes	Up to 8 axes	
Battery continuous backup time	Approx. 10000 hours (when 8 axes are connected, cumulative time in non-energized state) (Note2)	
Back up time from battery warn-	Approx. 336 hours (when 8 axes are connected) (Note2)	
ing to alarm occurrence	, approximate (which a axes are commenced) (recez)	


- (Note 1) Install commercially-available alkaline dry batteries into MDS-BTBOX-36. The batteries should be procured by customers.
- (Note 2) These backup periods are estimated based on the JIS standard, assuming that the product is used at a room temperature. The actual backup period may vary depending on the batteries (type and storage period after production, etc.) and the operating environment. Thus, regard these values only as a guide.


(b) Outline dimension drawings

		Name	Description
(1)	Power supply output for absolute position detector	BT	3.6V output for absolute position detector backup
(2)	backup	LG	Ground
	Power supply input for battery voltage drop detection circuit	+5V	5V power supply input for battery voltage drop detection circuit
(4)		LG	Ground
(5)	Battery voltage drop warning signal output	DO(ALM)	Battery voltage drop warning output
(6)	battery voltage Grop warning signal output	DOCOM	DO output common

(c) Outline dimension drawings

[Unit: mm]







As soon as the battery warning has occurred, replace the batteries with new ones.


Make sure to use new batteries that have not passed the expiration date. We recommend you to replace the batteries in the one-year cycle.

(d) Wiring of the battery voltage drop warning output

The battery voltage drop warning is detected in the MDS-BTBOX-36 and output to the servo drive unit as digital signal. Connect the battery voltage drop warning signal to one of the servo drive units supported by MDS-BTBOX-36. For the connected servo axis, set the servo parameter "SV082/bitF-C" to "2" to enable this signal input. When using 2 or 3-axis drive unit, set the value to one of the axes and set other axes in the same unit to "0" (No signal).

(e) When backing up for more than 8 axes

Add a MDS-BTBOX-36 so that the number of connectable axes for a battery unit is 8 axes or less. For all of servo drive units supported by one MDS-BTBOX-36, start the control powers ON simultaneously.



Battery voltage drop warning signal connection diagram

- The battery voltage drop warning signal and safety observation function door state signal cannot be connected to the same drive unit. To use these function together as a system, connect to the different drive unit.
- 2. Battery voltage drop warning (9F) can also occur when the cable between the battery box and drive unit is broken.
- 3. For 2-axis or 3-axis drive unit, the parameter error "E4" or drivers communication error "82" occurs at all the axes when the setting of SV082(SSF5)/bitF-C differs according to axes (except 0 setting).

⚠ CAUTION

- 4. The drive unit which is connected to the battery box and cell battery cannot be used together.
- 5. Replace the batteries with new ones without turning the control power of the drive unit OFF immediately after the battery voltage drop alarm (9F) has been detected.
- 6. Replace the batteries while applying the control power of all drive units which are connected to the battery box.
- 7. When changing the wiring of the CN9 control input, change after SV082(SSF5)/bitF-C is set to 0. Otherwise unexpected alarms can be detected because of a mismatch of the control input signal and setting parameter.


(5) Converged battery option

When using the following battery options, the wiring between units which configure an absolute position system is required.

Battery option type	Installation type	Battery charge
A6BAT (MR-BAT)	Dedicated case type (built-in MDS-BTCASE)	Possible
MDS-A-BT series	Unit and battery integration type	Unit exchange
MDS-BTBOX-36	Unit and battery integration type	Possible

System configuration

< A6BAT(MR-BAT), MDS-A-BT Series >






- 1. This wiring is not required for the drive unit or spindle drive unit which is not an absolute system.
- 2. Use a shield cable for wiring between drive units. The drive unit could malfunction.

< MDS-BTBOX-36 >

(a) MDS-D/DH-V1/V2 Series connected in serial




1.24V power for DO output must always be turned ON before the NC power input.

⚠ CAUTION

- 2. Spindle drive unit has no battery voltage drop warning function. Wiring to CN9 of drive unit must be always connected to servo drive unit.
- 3. The total length of battery cable (from the battery unit to the last connected drive unit) must be 3m or less.

(b) MDS-D/DH-V1/V2 Series connected in parallel



1. 24V power for DO output must always be turned ON before the NC power input.



- 2. Spindle drive unit has no battery voltage drop warning function. Wiring to CN9 of drive unit must be always connected to servo drive unit.
- 3. The total length of battery cable (from the battery unit to the last connected drive unit) must be 3m or less.

5-1-3 Ball screw side detector (OSA105ET2, OSA166ET2N)


(1) Specifications

	Detector type	OSA105ET2	OSA166ET2N
	Detector resolution	1,000,000 pulse/rev	16,000,000 pulse/rev
Electrical	Detection method	Absolute position method (battery backup method)	
characteristics	Tolerable rotation speed at power off (Note)	500r	/min
	Detector output data	Serial data	
	Power consumption	0.0	BA .
	Inertia	0.5 x 10 ⁻⁴ k	gm ² or less
Mechanical characteristics for	Shaft friction torque	0.1Nm	or less
rotation	Shaft friction torque O.1Nm or less Shaft angle acceleration Tolerable continuous rotation speed 4 x 10 ⁴ rad/s ² or less 4 x 10 ⁴ rad/s ² or less 4000r/min Shaft amplitude (position 15mm from end) Tolerable load	/s ² or less	
	Tolerable continuous rotation speed	4000	r/min
		0.02mm or less	
Mechanical	Tolerable load (thrust direction/radial direction)	9.8N/19.8N	
configuration	Mass	0.6	ikg
	Degree of protection	IP65 (The shaft-throug	h portion is excluded.)
	Recommended coupling	bellows	coupling
	Ambient temperature	0°C to	+55°C
	Storage temperature	-20°C to) +85°C
Working environment	Humidity	95%	6Ph
environment	Vibration resistance	5 to 50Hz, total vibration width	1.5mm, each shaft for 30min
	Impact resistance	490m/s	² (50G)

⚠ CAUTION

If the tolerable rotation speed at power off is exceeded, the absolute position cannot be repaired.

(2) Outline dimension drawings OSA105ET2 / OSA166ET2N



(3) Explanation of connectors



Connector pin layout

Pin	Function	Pin	Function
1	RQ	6	SD
2	RQ*	7	SD*
3	-	8	P5(+5V)
4	BAT	9	-
5	LG(GND)	10	SHD

5-1-4 Machine side detector

The machine side detectors are all other manufacturer's parts, and must be prepared by the user.

(1) Relative position detector

Depending on the output signal specifications, select a machine side relative position detector with which the following (a), (b) or (c) is applied.

(a) Serial signal type (serial conversion unit made by each manufacture)

The following serial conversion unit converts the detector output signal and transmits the signal to the drive unit in serial communication.

For details on the specifications of each conversion unit scale and for purchase, contact each corresponding manufacture directly.

Manufacturer	Detector type	Interface unit type	Minimum detection resolution	Tolerable maxi- mum speed
Manuscasia Co. 14d	SR75	Not an accion d	0.1µm	200/
Magnescale Co., Ltd	SR85	Not required	0.05µm 0.01µm	200m/min
	LS187, LS187C	EIB192M A4 20µm	, , , , , , , , , , , , , , , , , , ,	
	LS487, LS487C	EIB392M A4 20µm	0.0012µm	120m/min
HEIDENHAIN	ERM280 1200	EIB192M C4 1200	0.0000183°	20000r/min
TEIDENTAIN	LIXIW200 1200	EIB392M C4 1200	(19,660,800p/rev)	200001/111111
	ERM280 2048	EIB192M C6 2048	0.0000107°	11718r/min
	2230 20 10	EIB392M C6 2048	(33,554,432p/rev)	

<Contact information about machine side detector>

- Magnescale Co., Ltd: http://www.mgscale.com/mgs/
- HEIDENHAIN CORPORATION: http://www.heidenhain.de/

CAUTION!


The above value does not guarantee the accuracy of the system.

(b) SIN wave output (using MDS-B-HR)

When using a relative position detector that the signal is the SIN wave output, the detector output signal is converted in the detector conversion unit (MDS-B-HR), and then the signal is transmitted to the drive unit in the serial communication. Select a relative position detector with A/B phase SIN wave signal that satisfies the following conditions. For details on the specifications of MDS-B-HR, refer to the section "MDS-B-HR".

<Detector output signal>

- 1Vp-p analog A-phase, B-phase, Z-phase differential output
- Output signal frequency 200kHz or less



A/B phase output signal waveform during forward run

- Combination speed / rotation speed

In use of linear scale:

Maximum speed (m/min) = scale analog signal frequency (m) x 200,000 x 60

In use of rotary encoder:

Maximum rotation speed (r/min) = 200,000 / numbers of encoder scale (1/rev) x 60

An actual Maximum speed/ rotary speed is limited by the mechanical specifications and electrical specifications, etc. of the connected scale, so contact the manufacture of the purchased scale.

- Division number 512 divisions per 1 cycle of signal

In use of linear scale:

Minimum resolution (m) = scale analog signal frequency (m) / 512

In use of rotary encoder:

Minimum resolution (pulse/rev) = numbers of encoder scale $(1/rev) \times 512$


CAUTION!

The above value does not guarantee the accuracy of the system.

(c) Rectangular wave output

Select a relative position detector with an A/B phase difference and Z-phase width at the maximum feedrate that satisfies the following conditions.

Use an A, B, Z-phase signal type with differential output (RS-422 standard product) for the output signal



For a scale having multiple Z phases, select the neighboring Z phases whose distance is an integral mm.

(Note)The above value is minimum value that can be received normally in the servo drive unit side. In an actual selection, ensure margin of 20% or more in consideration of degradation of electrical wave and speed overshoot.

< Example of scale specifications >

The example of using representative rectangular wave scale is shown below.

For specifications of each conversion unit and scale and for purchase, Contact each corresponding manufacture directly.

Manufacturer	Detector type	Interface unit type	Minimum detection	Tolerable maximum
	monacc and spe		resolution	speed
		Not required	1.0µm	180m/min
Magnescale Co., Ltd	SR74		0.5µm	125m/min
Magnescale Co., Ltu	SR84		0.1µm	25m/min
			0.05µm	12m/min
	LS187	IBV 101 (10 divisions)	0.5µm	120m/min
HEIDENHAIN	HAIN LS187	IBV 102 (100 divisions)	0.05µm	24m/min
	L0407	IBV 660B (400 divisions)	0.0125μm	7.5m/min

<Contact information about machine side detector>

- Magnescale Co., Ltd: http://www.mgscale.com/mgs/
- HEIDENHAIN CORPORATION: http://www.heidenhain.de/

(2) Absolute position detector

The applicable absolute position detectors are as follows.

Manufacturer	Detector type	Interface unit type	Minimum detection resolution	Tolerable maximum speed
	SR77 SR87	Not required	0.1µm	200m/min
			0.05µm	
	0.10.		0.01µm	
Magnescale Co., Ltd			0.0000429°	2,000r/min
	RU77	Not required	(8,388,608p/rev)	2,000////////
	1.077	110t roquirou	0.0000107	2,000r/min
			(33,554,432p/rev)	2,000////////
	LC193M	Not required	0.05µm	180m/min
	LC493M	Not required	0.01µm	10011/111111
HEIDENHAIN	RCN223M	Not required	0.0000429° (8,388,608p/rev)	1,500r/min
MitutoyoAT343Not required0.05µm120m/min	RCN227M	Not required	0.0000027° (134,217,728p/rev)	1,500r/min
	RCN727M RCN827M	Not required	0.0000027° (134,217,728p/rev)	300r/min
	AT343	Not required	0.05µm	120m/min
Mitutoyo	AT543	Not required	0.05µm	150m/min
	AT545	Not required	0.005μm	150m/min
MHI MACHINE TOOL	MPRZ series	ADB-20J71	0.000043° (8,388,608p/rev)	10,000r/min
ENGINEERING CO., LTD	MPS Series	ADB-20J60	0.05µm	3600m/min
ENGINEERING CO., ETD	MPI Series	ADB-20J60	0.00005°(7,200,000p/rev) or 0.000025°(14,400,000p/rev)	5,000r/min
	SAM Series	Not required	0.05μm	120m/min
FAGOR	SVAM Series	Not required	0.05μm	120m/min
TAGUN	GAM Series	Not required	0.05μm	120m/min
	LAM Series	Not required	0.1µm	120m/min

- <Contact information about machine side detector>
- Magnescale Co., Ltd: http://www.mgscale.com/mgs/
- HEIDENHAIN CORPORATION: http://www.heidenhain.de/
- Mitutoyo Corporation: http://www.mitutoyo.co.jp/
- MHI MACHINE TOOL ENGINEERING CO., LTD: http://www.mme-e.co.jp/
- FAGOR Automation: http://www.fagorautomation.com/

CAUTION!

Confirm specifications of each detector manufacturer before using the machine side detector.

5-2 Spindle options

According to the spindle control to be adopted, select the spindle side detector based on the following table.

(a) No-variable speed control(When spindle and motor are directly coupled or coupled with a 1:1 gear ratio)

Spindle control item	Control specifications	Without spindle side detector	With spindle side detector
	Normal cutting control	•	
Spindle control	Constant surface speed control (lathe)	•	
	Thread cutting (lathe)	•	
	1-point orientation control	•	
Orientation control	Multi-point orientation control	•	This normally is not used for novariable speed control.
	Orientation indexing	•	
Synchronous tap	Standard synchronous tap	•	
control	Synchronous tap after zero point return	•	
Spindle synchro-	Without phase alignment function	•	
nous control	With phase alignment function		
C-axis control	C-axis control	• (Note 2)	•

(Note 1) ● :Control possible

x: Control not possible

(Note 2) When spindle and motor are coupled with a 1:1 gear ratio, use of a spindle side detector is recommended to assure the precision.

(b) Variable speed control (When using V-belt, or when spindle and motor are connected with a gear ratio other than 1:1)

Spindle		Without spindle side	With s	spindle side dete	ctor
control item	Control specifications	detector	TS5690/ERM280/ MPCI Series	OSE-1024	Proximity switch
	Normal cutting control	•	•	•	-
Spindle control	Constant surface speed control (lathe)	• (Note 2)	•	•	х
	Thread cutting (lathe)	х	•	•	х
	1-point orientation control	Х	•	•	•
Orientation control	Multi-point orientation control	х	•	•	х
	Orientation indexing	Х	•	•	х
Synchronous	Standard synchronous tap	• (Note 3)	•	•	х
tap control	Synchronous tap after zero point return	х	•	•	х
Spindle syn-	Without phase alignment function	• (Note 2)	•	•	х
control	With phase alignment function	х	•	•	х
C-axis control	C-axis control	х	•	Х	х

(Note 1) • :Control possible

x :Control not possible

(Note 2) Control not possible when connected with the V-belt.

(Note 3) Control not possible when connected with other than the gears.

- (c) Cautions for connecting the spindle end with an OSE-1024 detector
 - [1] Confirm that the gear ratio (pulley ratio) of the spindle end to the detector is 1:1.
 - [2] Use a timing belt when connecting by a belt.

5-2-1 Spindle side ABZ pulse output detector (OSE-1024 Series)

When a spindle and motor are connected with a V-belt, or connected with a gear ratio other than 1:1, use this spindle side detector to detect the position and speed of the spindle. Also use this detector when orientation control and synchronous tap control, etc are executed under the above conditions.

(1) Specifications

	Detector type	OSE-1024-3-15-68	OSE-1024-3-15-68-8	
	Inertia	0.1x10 ⁻⁴ kgm ² or less	0.1x10 ⁻⁴ kgm ² or less	
Mechanical characteristics for	Shaft friction torque	0.98Nm or less	0.98Nm or less	
rotation	Shaft angle acceleration	10 ⁴ rad/s ² or less	10 ⁴ rad/s ² or less	
	Tolerable continuous rotation speed	6000 r/min	8000 r/min	
	Bearing maximum non-lubrication time	20000h/6000r/min	20000h/8000r/min	
	Shaft amplitude (position 15mm from end)	0.02mm or less	0.02mm or less	
Mechanical configuration	Tolerable load (thrust direction/radial direction)	10kg/20kg Half of value during operation	10kg/20kg Half of value during operation	
	Mass	1.5kg	1.5kg	
	Squareness of flange to shaft	0.05mm	or less	
	Flange matching eccentricity	0.05mm or less		
	Ambient temperature range	-5°C to	+55°C	
	Storage temperature range	-20°C to) +85°C	
Working	Humidity	95%	6Ph	
environment	Vibration resistance	5 to 50Hz, total vibration width 1.5mm, each shaft for 30min.		
	Impact resistance	294.20m	/s ² (30G)	

(Note) Confirm that the gear ratio (pulley ratio) of the spindle end to the detector is 1:1.


(2) Detection signals

Signal name	Number of detection pulses
A, B phase	1024p/rev
Z phase	1p/rev

Connector pin layout

Pin	Function	Pin	Function
Α	A+ signal	K	0V
В	Z+ signal	L	-
С	B+ signal	M	-
D	-	N	A- signal
E	Case grounding	Р	Z- signal
F	-	R	B- signal
G	-	S	-
Н	+5V	T	-
J	-		

(3) Outline dimension drawings




Spindle side detector (OSE-1024-3-15-68, OSE-1024-3-15-68-8)


5-2-2 Spindle side PLG serial output detector (TS5690, MU1606 Series)

This detector is used when a more accurate synchronous tapping control or C-axis control than OSE detector is performed to the spindle which is not directly-connected to the spindle motor.

(1) Type configuration <Sensor type>



<Detection gear type>



(2) Specifications

Series type		TS5690N64xx				TS5690N12xx				TS5690N25xx						
Sensor	xx (The end of the type name)	10	20	30	40	60	10	20	30	40	60	10	20	30	40	60
	Length of lead [mm]	400 ±10	800 ±20	1200 ±20	1600 ±30	2000 ±30	400 ±10	800 ±20	1200 ±20	1600 ±30	2000 ±30	400 ±10	800 ±20	1200 ±20	1600 ±30	2000 ±30
	Туре		MU	11606N6	501	•		MU	J1606N	709			MU	J1606N	305	
	The number of teeth		64						128					256		
Detection	Outer diameter [mm]		φ52.8				φ104.0			φ206.4						
gear	Inner diameter [mm]			φ40Η5			φ80H5			φ140H5						
	Thickness [mm]	12				12			14							
	Shrink fitting [mm]		0.020 to 0.040				0.030 to 0.055			0.050 to 0.085						
Notched fit-	Outer diameter [mm]	φ72.0			φ122.0			φ223.6								
ting section	Outer diameter toler- ance [mm]	+0.010 to +0.060				-0.025 to +0.025			-0.025 to +0.025							
The number	A/B phase			64			128					256				
of output pulse	Z phase 1		1					1								
Detection res	Detection resolution [p/rev]			2 million	1		4 million				8 million					
Absolute accuracy at stop		150"			100"			95"								
Tolerable spe	eed [r/min]	40,000				20,000			10,000							
Signal outpu	t						Mitsubishi high-speed serial									

CAUTION!

- 1. Selected detectors must be able to tolerate the maximum rotation speed of the spindle.
- 2.Please contact your Mitsubishi Electric dealer for the special products not listed above.


(3) Outline dimension drawings

CAUTION!

Always apply the notched fitting section machining with the specified dimensions to the sensor installation surface.

<TS5690N64xx + MU1606N601>


[Unit: mm]



- (Note 2) In installing the sensor, keep the protruding fitting of ϕ 72 $^+_{+\,0.010}^{+\,0.060}$ mm on the machine side, and push the C part of the sensor mounting seat against the fitting.
- (Note 3) In installing the detection gear, make sure that the D part side comes the opposite side of the sensor installation side (sensor's lead wire side).
- (Note 4) The diviation of the center of the detection gear is 16.5±0.25mm from the sensor mounting face.

(Note 5) A connector of the signal cable side (one plug and nine pins) is attached.

Se	Detection gear	
Parts name	Lead wire length A [mm]	Parts name
TS5690N6410	400±10	
TS5690N6420	800±20	
TS5690N6430	1200±20	MU1606N601
TS5690N6440	1600±30	
TS5690N6460	2000±30	



Encoder mounting face of machine side


<TS5690N12xx + MU1606N709>

TS5690N1230

TS5690N1240

TS5690N1260

[Unit: mm]



MU1606N709

Seen from Arrow A

connector


1200±20

1600±30

2000±30

<TS5690N25xx + MU1606N805>

[Unit: mm]




(Note 3) In installing the detection gear, make sure that the D part side comes the opposite side of the sensor installation side (sensor's lead wire side).

(Note 4) The diviation of the center of the detection gear is 16.5±0.25mm from the sensor mounting face.

(Note 5) A connector of the signal cable side (one plug and nine pins) is attached.

S	Detection gear		
Parts name	Parts name Lead wire length A [mm]		
TS5690N2510	400±10		
TS5690N2520	800±20		
TS5690N2530	1200±20	MU1606N805	
TS5690N2540	1600±30		
TS5690N2560	2000±30		



5-2-3 Spindle side accuracy serial output detector (ERM280, MPCI Series)

C-axis control detector is used in order to perform an accurate C-axis control.

Manufacturer	Detector type	Interface unit type	Minimum detection resolution	Tolerable maximum speed
HEIDENHAIN	ERM280 1200	EIB192M C4 1200 EIB392M C4 1200	0.0000183° (19,660,800p/rev)	20000 r/min
HEIDERHAIN	ERM280 2048	EIB192M C6 2048 EIB392M C6 2048	0.0000107° (33,554,432p/rev)	11718 r/min
MHI MACHINE TOOL ENGINEERING CO., LTD	MPCI series	ADB-20J20	0.00005° (7200000p/rev)	10000 r/min

<Contact information about machine side detector>

- HEIDENHAIN CORPORATION: http://www.heidenhain.de/
- MHI MACHINE TOOL ENGINEERING CO., LTD: http://www.mme-e.co.jp/

CAUTION!


Confirm specifications of each detector manufacturer before using the machine side detector.

5-3 Detector interface unit

5-3-1 Serial output interface unit for ABZ analog detector MDS-B-HR

This unit superimposes the scale analog output raw waves, and generates high resolution position data.Increasing the detector resolution is effective for the servo high-gain. MDS-B-HR-12(P) is used for the synchronous control system that 1-scale 2-drive operation is possible.

(1) Type configuration



(2) Specifications

Type MDS-B-HR-	11	12	11P	12P				
Compatible scale (example)	LS186 / LS486 (HEIDENHAIN)							
Signal 2-division function	-	- * - *						
Analog signal input	A-	phase, B-phase, Z-ph	nase (Amplitude 1Vp	-p)				
specifications	, ,		, , , ,	۴/				
Compatible frequency		Analog raw wavef	orm max. 200kHz					
Scale resolution		Analog raw wave	form/512 division					
Input/output communication style	High-spe	eed serial communica	ation I/F, RS485 or e	quivalent				
Working ambient temperature		0 to :	55°C					
Working ambient humidity	Ç	90%RH or less (with r	no dew condensatior	1)				
Atmosphere		No toxio	c gases					
Tolerable vibration		98.0 m/s	s ² (10G)					
Tolerable impact		294.0 m/	's ² (30G)					
Tolerable power voltage	5VDC±5%							
Maximum heating value	2W							
Mass	0.5kg or less							
Degree of protection	IP	65	IP	67				


(3) Explanation of connectors

Connector name	Application	Remarks
CON1	For connection with servo drive unit (2nd system)	Not provided for 1-part system specifications
CON2	For connection with servo drive unit	
CON3	For connection with scale	
CON4	For connection with pole detection unit (MDS-B-MD)	*Used for linear servo system


С	CON1		CON2		CON3	CON4		
Pin No.	Function	Pin No.	Function	Pin No.	Function	Pin No.	Function	
1	RQ+ signal	1	RQ+ signal	1	A+ phase signal	1	A phase signal	
2	RQ- signal	2	RQ- signal	2	A- phase signal	2	REF signal	
3	SD+ signal	3	SD+ signal	3	B+ phase signal	3	B phase signal	
4	SD- signal	4	SD- signal	4	B- phase signal	4	REF signal	
5	P5	5	P5	5	Z+ phase signal	5	P24	
6	P5	6	P5	6	Z- phase signal	6	MOH signal	
7	GND	7	GND	7	-	7	P5	
8	GND	8	GND	8	-	8	P5	
				9	-	9	TH signal	
				10	-	10	GND	
				11	P5			
				12	GND			

<Connector pin layout >

Connector	Туре	
CON1	RM15WTR- 8P(Hirose Electric)	
CON2	TRIVITOV FIX- OF (FINOSE Electric)	
CON3	RM15WTR-12S(Hirose Electric)	
CON4	RM15WTR-10S(Hirose Electric)	



(4) Outline dimension drawings



5-3-2 Serial signal division unit MDS-B-SD

This unit has a function to divide the position and speed signals fed back from the high-speed serial detector and high-speed serial linear scale. This unit is used to carry out synchronized control of the motor with two MDS-D/DH-V1 drive units.

(1) Specifications

Туре	MDS-B-SD	
Compatible servo drive unit	MDS-D/DH-V1-□	
Input/output communication style	High-speed serial communication I/F, RS485 or equivalent	
Working ambient temperature	0 to 55°C	
Working ambient humidity	90%RH or less (with no dew condensation)	
Atmosphere	No toxic gases	
Tolerable vibration	98.0 m/s ² (10G)	
Tolerable impact	294.0 m/s ² (30G)	
Tolerable power voltage	5VDC±10%	
Maximum heating value	4W	
Mass	0.5kg or less	
Degree of protection	IP20	



Always provide one MDS-B-SD unit for one speed command synchronous control operation.

The CN2 system's CN2A and the CN3 system's CN3A cannot be connected to different servo drive units.


(2) Explanation of connectors

Detector connector : CN2					
Pin No.	Name	Pin No.	Name		
1	LG	11	LG		
2		12			
3		13			
4		14			
5		15			
6	SD	16	SD*		
7	RQ	17	RQ*		
8		18			
9	BAT	19			
10	P5 (+5V)	20	P5 (+5V)		

< Connector pin layout >

Detector connector : CN2 Pin No.

(3) Outline dimension drawings



5-3-3 Pulse output interface unit for ABZ analog detector IBV Series (Other manufacturer's product)

(1) Appearance



IBV100 series



IBV600 series


(2) Specifications

Туре	IBV 101	IBV 102	IBV 660B	
Manufacturer	HEIDENHAIN			
Input signal	A-phase	e, B-phase: SIN wave 1Vpp,	Z-phase	
Maximum input frequency		400kHz		
Output signal	Rectangular wave pulse signal			
Interpolation division number	Maximum 10 divisions Maximum 100 divisions Maximum 400 di			
Compatible detector	LS187, LS487 LS187, LS487 LS187, LS48			
Minimum detection resolution	0.5μm 0.05μm 0.0125μm			
Working temperature	0°C to 70°C			
Degree of protection	IP65			
Mass	300g			


CAUTION!

These are other manufacturer's products. When purchasing these product, contact the manufacturer directly.

(3) Outline dimension drawings IBV100 series



IBV600 series



5-3-4 Serial output interface unit for ABZ analog detector EIB192M (Other manufacturer's product)


(1) Appearance



(2) Specifications

Туре	EIB192M A4 20μm	EIB192M C4 1200	EIB192M C4 2048	
Manufacturer		HEIDENHAIN		
Input signal	A-phase	, B-phase: SIN wave 1Vpp,	Z-phase	
Maximum input frequency		400kHz		
Output signal	Mitsubishi high-speed serial signal (MITSU02-4)			
Interpolation division number	Maximum 16384 divisions			
Compatible detector	LS187, LS487	ERM280 1200	ERM280 2048	
Minimum detection resolution	0.00012μm 0.0000183° 0.0000107° (19,660,800p/rev) (33,554,432p/rev)			
Working temperature	0°C to 70°C			
Degree of protection	IP65			
Mass	300g			

(3) Outline dimension drawings



CAUTION!

These are other manufacturer's products. When purchasing these product, contact the manufacturer directly.

5-3-5 Serial output interface unit for ABZ analog detector EIB392M (Other manufacturer's product)


(1) Appearance



(2) Specifications

Туре	EIB392M A4 20μm	EIB392M C4 1200	EIB392M C4 2048	
Manufacturer		HEIDENHAIN		
Input signal	A-phase	, B-phase: SIN wave 1Vpp,	Z-phase	
Maximum input frequency		400kHz		
Output signal	Mitsubishi high-speed serial signal (MITSU02-4)			
Interpolation division number	Maximum 16384 divisions			
Compatible detector	LS187, LS487	ERM280 1200	ERM280 2048	
Minimum detection resolution	0.0012µm 0.0000183° 0.0000107° (19,660,800p/rev) (33,554,432p/rev)			
Working temperature	0°C to 70°C			
Degree of protection	IP40			
Mass	140g			

(3) Outline dimension drawings



CAUTION!

These are other manufacturer's products. When purchasing these product, contact the manufacturer directly.

5-3-6 Serial output interface unit for ABZ analog detector ADB-20J Series (Other manufacturer's product)

(1) Appearance




(2) Specifications

Туре	ADB-20J20	ADB-20J60		ADB-20J71
Manufacturer	MHI MACHINE TOOL ENGINEERING CO., LTD			
Maximum response speed	10,000r/min	3,600m/min	5,000r/min	10,000r/min
Output signal	Mitsubishi high-speed serial signal			
Compatible detector	MPCI series	MPS Series	MPI Series	MPRZ series
Minimum detection resolution	0.00005° (7,200,000p/rev)	0.05µm	0.000025° (1,440,000p/rev)	0.000043° (8,388,608p/rev)
Working temperature	0°C to 55°C			
Degree of protection	IP20			
Mass	0.9kg			

CAUTION!

These are other manufacturer's products. When purchasing these product, contact the manufacturer directly.

(3) Outline dimension drawings



5-4 Drive unit option

5-4-1 Optical communication repeater unit (FCU7-EX022)

When the distance of the optical communication cable between NC control unit and drive unit is over 30m (M700V/M70V Series: maximum 30m, M700/M70/C70 Series: maximum 20m), the communication can be performed by relaying the optical signal.

Using up to two units, relay of the total length of up to 90m (M700V/M70V Series: maximum 90m, M700/M70/C70 Series: maximum 60m) can be performed.

<Product features>

- (a) When the distance of the optical communication cable between NC control unit and drive unit is over 30m, the communication can be performed by relaying the optical signal.
- (b) The relay between NC control unit and drive unit can be performed for up to two channels.
- (c) If the distance between NC control unit and drive unit is even within 30m, the cable can be divided by the relay in transporting the machine.
- (d) Same mounting dimension as the remote I/O unit (DX unit).

CAUTION!

This unit can not be used between drive units.

(1) Specifications

	Item			
	Input voltage		24V±10% (21.6V to 26.4V)	
Inrush current	Inrush current		35A	
DC24V Input	Power consumption	1	10W	
	Consumption curre	nt	0.4A	
Optical interface	Channel number		2 channels	
Optical interface	Connectable number	er	Maximum 2	
	Ambient tempera-	Operation	0°C to +55°C	
	ture	Storage	-20°C to +60°C	
	Ambient humidity	Operation (long term)	+10%RH to +75%RH (with no dew condensation)	
		Operation	+10%RH to +95%RH	
Environment		(short term)	(with no dew condensation. Short term is within about one month.)	
Livironinient		Storage	+10%RH to +75%RH (with no dew condensation)	
	Vibration	Operation	4.9m/s ²	
	Vibration	Transportation	34.3m/s ²	
	Impact resistance	Operation	29.4m/s ²	
	Atmosphere		No corrosive gas, oil mist, or dust	
Dimension			(depth)135mm × (width)40mm × (height)168mm	
Dillicusion	Mounting method		Screw cramp with M5 2 screw cramps	
Mass			0.42kg	

(2) Explanation of connectors

Connector name	Application	Remarks
OPT1IN, OPT1OUT, OPT2IN, OPT2OUT	Optical connector	
DCIN	DC24V Power connector	
DCOUT	DC24V/ Power OFF detection output connector	Relays the PD25/27 output to NC control unit.
ACFAIL	Power OFF detection connector	Relays the power OFF detection signal (ACFAIL) when sharing 24V power from PD25/PD27 for NC control unit and optical communication repeater unit. It will not be used when dedicated general-purpose power supply for optical communication repeater unit is prepared.
FG	FG Faston terminal	


D	CIN		DC	TUC		AC	FAIL
Pin No.	Name	Pin No.	Name	Pin No.	Name	Pin No.	Name
1	DC24V	A1	ACFAIL	B1	DC24V	1	СОМ
2	0V (RG)	A2	COM	B2	0V (RG)	2	ACFAIL
3	FG	A3	NC	В3	FG		

< Connector pin layout >

Optical communication I/F (OPT1IN, OPT1OUT, OPT2IN, OPT2OUT) DC24V input	3 E	output (DCOUT)	Power OFF input ACFAIL erminal name:CF01)	FG terminal (FG)
1	3			
		1 A3	2 1	FG
<cable connector="" side="" type=""> (PCF type) Connector: CF-2D101-S Recommended manufacture: Japan Aviation Electronics (POF type) Connector: PF-2D101 Recommended manufacturer: Japan Aviation Electronics Recommended manufacturer: Tyco Electronics Recommended manufacturer: Tyco Electronics Recommended manufacturer: Tyco Electronics</cable>	93-5 Connector Recomme er: Tyco E ctor type> < Cable sic 88-3 Connector Contact: 1	: 3-178137-5 Inded manufactur- lectronics le connector type> : 2-178127-6 -175218-5 Inded manufactur- Index Connector Index Conn	nector: 53103-0230 ommended manufactur- IOLEX ble side connector type> lector: 51030-0230 lact: 50084-8160 ommended manufactur-	<cable faston="" name="" side="" terminal="" type=""> Type name: 175022-1 (For AWG20-14 250 series) Recommended manufacturer: Tyco Electronics Terminal protection tube: 174817-2 (Yellow) Description of the cable side is a simple lock type. Make sure to insert until the simple lock pin is in the Psecond</cable>

(3) Outline dimension drawings

[Unit: mm]



5-4-2 DC connection bar


When connecting a large capacity drive unit with L+L- terminal of power supply unit, DC connection bar is required. In use of the following large capacity drive units, use a dedicated DC connection bar. The DC connection bar to be used depends on the connected power supply, so make a selection according to the following table.

Series	Large capacity drive unit	Power supply unit	Required connection bar
MDS-D	MDS-D-SP-400 MDS-D-SP-640	MDS-D-CV-300 MDS-D-CV-370 MDS-D-CV-450	D-BAR-B1006
	MDS-D-SP-400 MDS-D-SP-640	MDS-D-CV-550	D-BAR-A1010 (Two-parts set)
	MDS-DH-SP-200 MDS-DH-SP-320 MDS-DH-SP-480	MDS-DH-CV-550 MDS-DH-CV-750	DH-BAR-A0606 (Two-parts set)
MDS-DH	MDS-DH-V1-200 MDS-DH-SP-200 MDS-DH-SP-320	MDS-DH-CV-300 MDS-DH-CV-370 MDS-DH-CV-450	DH-BAR-B0606
	MDS-DH-V1-200	MDS-DH-CV-185	DH-BAR-C0606


(1) Outline dimension drawings

[Unit:mm]

D-BAR-A1010




D-BAR-B1006




(Note) D-BAR-A1010 is a set of two DC connection bars.

DH-BAR-A0606




DH-BAR-B0606



(Note) DH-BAR-A0606 is a set of two DC connection bars.

DH-BAR-C0606






Always install a large capacity drive unit in the left side of power supply unit, and connect with DC connection bar.

5-4-3 Side protection cover


Install the side protection cover outside the both ends of the connected units.

(Installation method 1): Installation of medium capacity unit




- (1): Install the side protection cover (type: D-COVER-1).(2): Close the front cover.

(Installation method 2): Installation of large capacity unit < For MDS-D series >



< For MDS-DH series >



< MDS-D Series >



One side cover for the large capacity unit is supplied per large capacity power supply unit as standard.


< MDS-DH Series >

One side cover for the large capacity unit is supplied per large capacity power supply unit and per large capacity drive unit as standard, respectively.

5-5 Cables and connectors

5-5-1 Cable connection diagram

The cables and connectors that can be ordered from Mitsubishi Electric Corp. as option parts are shown below. Cables can only be ordered in the designated lengths. Purchase a connector set, etc., to create special length cables.



5-5-2 List of cables and connectors

< Optical communication cable>

	Item	Model	Cor	ntents
For CN1A/ CN1B/	Optical communication cable For wiring between drive units (inside panel)	G396-L□M □: Length 0.3, 0.5, 1, 2, 3, 5m	Drive unit side connector (Japan Aviation Electronics Industry) Connector: 2F-2D103	Drive unit side connector (Japan Aviation Electronics Industry) Connector: 2F-2D103
OPT1 A	Optical communication cable For wiring between drive units (outside panel) For optical servo communication repeater unit	G380-L□M □: Length 5, 10, 12, 15, 20, 25, 30m	Drive unit side connector (Tyco Electronics) Connector: 1123445-1	Drive unit side connector (Tyco Electronics) Connector: 1123445-1

- (Note1) For details on the optical communication cable, refer to the section "Optical communication cable specification".
- (Note2) For details on the optical communication cable for wiring between NC and drive unit, refer to the instruction manual for CNC.

<Battery cable and connector>

	Item	Model		Contents
	Battery cable (For drive unit - battery unit)	DG21-□M □: Length 0.3, 0.5, 1, 5m	Drive unit side connector (Hirose Electric) Connector: DF1B-2S-2.5R Contact: DF1B-2428SCA	Battery unit side connector (3M) Connector: 10120-3000VE Shell kit : 10320-52F0-008
For bat- tery unit	Battery cable (For drive unit -Battery box) *The battery box side is connected using a bare conductor or a terminal bar.	DG23-□M □: Length 0.3, 0.5, 1, 2, 3, 5, 7, 10m	Drive unit side connector (Hirose Electric) Connector: DF1B-2S-2.5R Contact: DF1B-2428SCA	Battery box side
	5V supply/DO output cable (For drive unit -Battery box) *The battery box side is connected using a bare conductor or a terminal bar.	DG24-□M □: Length 0.3, 0.5, 1, 2, 3, 5, 7, 10m	Drive unit side connector (3M) Connector: 10120-6000EL Contact: 10320-3210-000	Battery box side
For drive unit	Battery cable (For drive unit - drive unit) *This cable is required to supply the power from the battery unit to multiple drive units.	DG22-□M □: Length 0.3, 0.5, 1, 2, 3, 5, 7, 10m	Drive unit side connector (Hirose Electric) Connector: DF1B-2S-2.5R Contact: DF1B-2428SCA	Drive unit side connector (Hirose Electric) Connector: DF1B-2S-2.5R Contact: DF1B-2428SCA
For CN9	Battery cable Connector set:	FCUA-CS000	Drive unit side connector (3M) Connector: 10120-3000VE Shell kit: 10320-52F0-008	Battery unit side connector (3M) Connector: 10120-3000VE Shell kit: 10320-52F0-008

< Power supply communication cable and connector >

	Item	Model	Cor	ntents
For CN4/9	Power supply communication cable	SH21 Length: 0.35, 0.5, 0.7, 1, 1.5, 2,2.5, 3, 3.5, 4, 4.5, 5, 6, 7, 8, 9, 10, 15, 20, 30m	Drive unit side connector (3M) Connector: 10120-6000EL Shell kit: 10320-3210-000	Power supply unit side connector (3M) Connector: 10120-6000EL Shell kit: 10320-3210-000
For CN4/9	Power supply communication cable connector set	FCUA-CS000	Drive unit side connector (3M) Connector: 10120-3000VE Shell kit : 10320-52F0-008	Power supply unit side connector (3M) Connector: 10120-3000VE Shell kit: 10320-52F0-008
For CN23	Contactor control output / external emergency stop for connector	CNU23S(AWG14)	Power supply unit side connector (DDK) Connector: DK-3200M-06RXY Contact: DK-3REC2LLP1-100	

< Optical communication repeater unit >

	Item	Model	Con	tents
For OPT1/2	Optical communication cable For wiring between drive unit and optical communication repeater unit/ For wiring between optical communication repeater units	G380-L□M □: Length 5, 10, 12, 15, 20, 25, 30m	Drive unit side/ Optical communication repeater unit side connector (Tyco Electronics) Connector: 1123445-1	Optical communication repeater unit side connector (Tyco Electronics) Connector: 1123445-1
For DCIN	For optical communication repeater unit DC24V power cable	F070 : Length 0.5, 1.5, 3, 5, 8, 10, 15, 20m	DC24V power side terminal (J.S.T.) Crimp terminal: V1.25-3 or V1.25-4 x 2	Optical communication repeater unit side connector (Tyco Electronics) Connector: 2-178288-3 Contact: 1-175218-5 x 3 DCIN
For DCIN/ ACFAIL	For optical communication repeater unit/ For connecting Mitsubishi power unit PD25,PD27 DC24V power cable (power OFF detection)	F110 : Length 0.5, 1.5, 3, 5, 8, 10, 15m	DC24V power side connector (Tyco Electronics) Connector: 3-178127-6 Contact: 1-175218-5 (for AWG16) × 3 1-175217-5 (for AWG22) × 2	Optical communication repeater unit side connector <dcin> (Tyco Electronics) Connector: 2-178288-3 Contact: 1-175218-5 × 3 <acfail (cf01)=""> (MOLEX) 51030-0230 50084-8160 × 2 DCIN CF01</acfail></dcin>

< Servo / tool spindle detector cable and connector >

	Item	Model	Contents	
	For HF/HF-H, HP/HP-H Motor side detector	CNV2E-6P- □M □: Length 2, 3, 4, 5, 7, 10, 15, 20, 25, 30m	Drive unit side connector (3M) Receptacle: 36210-0100PL Shell kit : 36310-3200-008 (MOLEX) Connector set: 54599-1019	Motor detector/ Ball screw side detector side connector (DDK) Plug : CM10-SP10S-M(D6) Contact: CM10-#22SC(S1)(D8)
For	cable (for A51/A74N / Ball screw side detector cable	CNV2E-7P-□M □: Length 2, 3, 4, 5, 7, 10, 15, 20, 25, 30m	Drive unit side connector (3M) Receptacle: 36210-0100PL Shell kit : 36310-3200-008 (MOLEX) Connector set: 54599-1019	Motor detector/ Ball screw side detector side connector (DDK) Plug : CM10-AP10S-M(D6) Contact: CM10-#22SC(S1)(D8)
For CN2/3	For HF/HF-H, HP/HP-H / For HF-KP (Tool spin- dle) Motor side detector	CNV2E-8P-□M □: Length 2, 3, 4, 5, 7, 10, 15, 20, 25, 30m	Drive unit side connector (3M) Receptacle: 36210-0100PL Shell kit : 36310-3200-008 (MOLEX) Connector set: 54599-1019	Motor detector/ Ball screw side detector side connector (DDK) Plug : CM10-SP10S-M(D6) Contact: CM10-#22SC(S1)(D8)
	cable (for A48/A51/ A74N)	CNV2E-9P-□M □: Length 2, 3, 4, 5, 7, 10, 15, 20, 25, 30m	Drive unit side connector (3M) Receptacle: 36210-0100PL Shell kit : 36310-3200-008 (MOLEX) Connector set: 54599-1019	Motor detector/ Ball screw side detector side connector (DDK) Plug : CM10-AP10S-M(D6) Contact: CM10-#22SC(S1)(D8)

	ŀ	tem	Model	Con	tents
	tion	For HF-KP (Servo) Motor side detector cable	CNV2E-K1P-□M Lead out in direction of motor shaft □: Length 2, 3, 5, 7, 10,m Compatible with only IP65	Drive unit side connector (3M) Receptacle: 36210-0100PL Shell kit : 36310-3200-008 (MOLEX) Connector set: 54599-1019	Motor detector/ Ball screw side detector side connector (Tyco Electronics) Connector: 1674320-1
			CNV2E-K2P-□M Lead out in opposite direction of motor shaft □: Length 2, 3, 5, 7, 10,m Compatible with only IP65	Drive unit side connector (3M) Receptacle: 36210-0100PL Shell kit : 36310-3200-008 (MOLEX) Connector set: 54599-1019	Motor detector/ Ball screw side detector side connector (Tyco Electronics) Connector: 1674320-1
For CN2/3	Relay type (Note)		CNV22J-K1P-0.3M Lead out in direction of motor shaft Length: 0.3m Compatible with only IP65	Drive unit side connector (DDK) Plug: CM10-CR10P-M	Motor detector/ Ball screw side detector side connector (Tyco Electronics) Plug : 1747464-1 Contact: 1674335-4
			CNV22J-K2P-0.3M Lead out in opposite direc- tion of motor shaft Length: 0.3m Compatible with only IP65	Drive unit side connector (DDK) Plug: CM10-CR10P-M	Motor detector/ Ball screw side detector side connector (Tyco Electronics) Plug : 1747464-1 Contact: 1674335-4
		For HF-KP (Servo) Motor side detector relay cable (Drive unit side)	CNV2E-6P-□M □: Length 15, 20, 25, 30m	Drive unit side connector (3M) Receptacle: 36210-0100PL Shell kit : 36310-3200-008 (MOLEX) Connector set: 54599-1019	Motor detector/ Ball screw side detector side connector (DDK) Plug : CM10-SP10S-M(D6) Contact: CM10-#22SC(S1)(D8)
For motor detector/	Motor side detector connector/ Ball screw side detector connector		CNE10-R10S(9) Applicable cable outline ø6.0 to 9.0mm		Motor detector/ Ball screw side detector side connector (DDK) Plug : CM10-SP10S-M(D6) Contact: CM10-#22SC(S1)(D8)
Ball screw side detector			CNE10-R10L(9) Applicable cable outline Ø6.0 to 9.0mm		Motor detector/ Ball screw side detector side connector (DDK) Plug : CM10-AP10S-M(D6) Contact: CM10-#22SC(S1)(D8)

(Note) When using cable of 15m or longer, use relay cable.

	Item	Model	Cor	ntents
CN3	MDS-B-HR unit cable	CNV2E-HP-□M □: Length 2, 3, 4, 5, 7, 10, 15, 20, 25, 30m	Drive unit side connector (3M) Receptacle: 36210-0100PL Shell kit : 36310-3200-008 (MOLEX) Connector set: 54599-1019	MDS-B-HR unit side connector (Hirose Electric) Plug : RM15WTP-8S Clamp: RM15WTP-CP (10)
For MDS- B-HR unit	MDS-B-HR connector (For CON1,2: 1) (For CON3: 1)	CNEHRS(10) Applicable cable outline ø8.5 to 11mm	MDS-B-HR unit side connector (Hirose Electric) Plug: RM15WTP-8S (for CON1, 2) RM15WTP-12P (for CON3) Clamp: RM15WTP-CP (10)	
CN3	MDS-B-SD unit cable	CNV2E-D-□M □: Length 2, 3, 4, 5, 7, 10, 15, 20, 25, 30m	Drive unit side connector (3M) Receptacle: 36210-0100PL Shell kit : 36310-3200-008 (MOLEX) Connector set: 54599-1019	MDS-B-SD unit side connector (3M) Connector: 10120-3000VE Shell kit: 10320-52F0-008
For MDS- B-SD unit	MDS-B-SD connector (Two-piece set)	FCUA-CS000	MDS-B-SD unit side connector (3M) Connector: 10120-3000VE Shell kit: 10320-52F0-008	MDS-B-SD unit side connector (3M) Connector: 10120-3000VE Shell kit : 10320-52F0-008
For CN2/3	Detector connector	CNU2S(AWG18)	Drive unit side connector (3M) Receptacle: 36210-0100PL Shell kit : 36310-3200-008 (MOLEX) Connector set: 54599-1019	

< Brake cable and connector >

	Item	Model	Contents
	Brake connector for < 200V series > HF,HP < 400V series > HF-H, HP-H	CNB10-R2S(6) Applicable cable outline ø4.0 to 6.0mm	Servomotor side brake connector (DDK) Plug : CM10-SP2S-S(D6) Contact: CM10-#22SC(S2)(D8)
		CNB10-R2L(6) Applicable cable outline ø4.0 to 6.0mm	Servomotor side brake connector (DDK) Plug : CM10-AP2S-S(D6) Contact: CM10-#22SC(S2)(D8)
For motor brake	Brake cable for < 200V series > HF-KP	MR-BKS1CBL□M-A1-H Lead out in direction of motor shaft □: Length 2, 3, 5, 7, 10m	Servomotor side brake connector (Japan Aviation Electronics Industry) Plug : JN4FT02SJ1-R Contact: ST-TMH-S-C1B-100-(A534G)
		MR-BKS1CBL□M-A2-H Lead out in opposite direction of motor shaft □: Length 2, 3, 5, 7, 10m	Servomotor side brake connector (Japan Aviation Electronics Industry) Plug : JN4FT02SJ1-R Contact: ST-TMH-S-C1B-100-(A534G)
For CN20	Brake connector for motor brake control output	CNU20S(AWG14)	Servo drive unit side connector (DDK) Connector : DK-3200S-03R Contact: DK-3REC2LLP1-100

<Reinforcing cover for connector>

	Item	Model	Contents
Reinforc-	Reinforcing cover for CM10-SP2S-S(D6)/CM10-SP10S-M(D6)	CNE10-CVS	Reinforcing cover for straight plug CM10-SP-CV (DDK)
ing cover	Reinforcing cover for CM10-AP2S-S(D6)/ CM10-AP10S-M(D6)	CNE10-CVL	Reinforcing cover for angle plug CM10-AP-D-CV (DDK)

< Power connector >

	Item	Model	Cor	ntents
	Power connector for < 200V series > HF75, 105, 54,104,154, 224, 123, 223, 142	CNP18-10S(14) Applicable cable outline ø10.5 to 14mm		Motor side power connector (DDK) Plug: CE05-6A18-10SD-C-BSS Clamp: CE3057-10A-1 (D240)
	HP54,104,154,224 < 400V series > HF-H54,104,154 HP-H54,104,154,224	CNP18-10L(14) Applicable cable outline ø10.5 to 14mm		Motor side power connector (DDK) Plug: CE05-8A18-10SD-C-BAS Clamp: CE3057-10A-1 (D240)
	Power connector for < 200V series > HF204,354,303, 453, 302	CNP22-22S(16) Applicable cable outline ø12.5 to 16mm		Motor side power connector (DDK) Plug: CE05-6A22-22SD-C-BSS Clamp: CE3057-12A-1 (D240)
	HP204,354,454 < 400V series > HF-H204,354,453,703 HP-H204,354,454,704	CNP22-22L(16) Applicable cable outline ø12.5 to 16mm		Motor side power connector (DDK) Plug: CE05-8A22-22SD-C-BAS Clamp: CE3057-12A-1 (D240)
For motor power	Power connector for < 200V series > HF703,903 HP704,903,1103 < 400V series > HF-H903 HP-H903,1103	CNP32-17S(23) Applicable cable outline ø22 to 23.8mm		Motor side power connector (DDK) Plug: CE05-6A32-17SD-C-BSS Clamp: CE3057-20A-1 (D240)
		CNP32-17L(23) Applicable cable outline ø22 to 23.8mm		Motor side power connector (DDK) Plug: CE05-8A32-17SD-C-BAS Clamp: CE3057-20A-1 (D240)
	Power cable for	MR-PWS1CBL□M-A1-H Lead out in direction of motor shaft □: Length 2, 3, 5, 7, 10m		Motor side power connector (Japan Aviation Electronics Industry) Plug: JN4FT04SJ1-R Contact: ST-TMH-S-C1B-100-(A534G)
	< 200V series > HF-KP	MR-PWS1CBL□M-A2-H Lead out in opposite direc- tion of motor shaft □: Length 2, 3, 5, 7, 10m		Motor side power connector (Japan Aviation Electronics Industry) Plug: JN4FT04SJ1-R Contact: ST-TMH-S-C1B-100-(A534G)
For TE1	Power connector for MDS-D-V1-20 to 80 MDS-D-V2-2020 to 8080 MDS-D-SP-20 to 80 MDS-D-SP2-2020 to 4040 MDS-DH-V1-10 to 80 MDS-DH-V2-1010 to 8080 MDS-DH-SP-20,40	CNU1S(AWG14)	Drive unit side power connector (DDK) Housing: DK-5200S-04R Contact : DK-5RECSLP1-100	
	Power connector for MDS-D-V1-160 MDS-D-V2-16080,160160 MDS-D-SP2-8040,8080 MDS-DH-V1-80,80W MDS-DH-V2-8080W MDS-DH-SP-80	CNU1S(AWG10)	Drive unit side power connector (DDK) Housing: DK-5200S-04R Contact : DK-5RECMLP1-100	

< Spindle detector cable and connector >

	Item	Model	Cor	ntents
For CN2	Motor side PLG cable Spindle side accuracy detector TS5690 cable	CNP2E-1-□M □: Length 2, 3, 4, 5, 7, 10, 15, 20, 25, 30m	Spindle drive unit side connector (3M) Receptacle: 36210-0100PL Shell kit : 36310-3200-008 (MOLEX) Connector set: 54599-1019	Spindle motor side connector (Tyco Electronics) Connector: 172169-1 Contact:170363-1(AWG26-22) 170364-1(AWG22-18)
F ONO	Spindle side detector	CNP3EZ-2P-□M □: Length 2, 3, 4, 5, 7, 10, 15, 20, 25, 30m	Spindle drive unit side connector (3M) Receptacle: 36210-0100PL Shell kit : 36310-3200-008 (MOLEX) Connector set: 54599-1019	Spindle motor side connector (DDK) Connector: MS3106A20-29S(D190) Straight back shell: CE02-20BS-S Clamp: CE3057-12A-3
FOR GN3	OSE-1024 cable	CNP3EZ-3P-□M □: Length 2, 3, 4, 5, 7, 10, 15, 20, 25, 30m	Spindle drive unit side connector (3M) Receptacle: 36210-0100PL Shell kit : 36310-3200-008 (MOLEX) Connector set: 54599-1019	Spindle motor side connector (DDK) Connector: MS3106A20-29S(D190) Angle back shell: CE-20BA-S Clamp : CE3057-12A-3
For spindle motor	Motor side PLG con- nector Spindle side accuracy detector TS5690 con- nector	CNEPGS		Spindle motor side connector (Tyco Electronics) Connector: 172169-1 Contact:170363-1(AWG26-22) 170364-1(AWG22-18)
For spindle	Spindle side detector	Applicable cable outline ø6.8 to 10mm		Spindle motor side connector (DDK) Connector:MS3106A20-29S(D190) Straight back shell: CE02-20BS-S Clamp: CE3057-12A-3
motor	OSE-1024 cable	Applicable cable outline ø6.8 to 10mm		Spindle motor side connector (DDK) Connector:MS3106A20-29S(D190) Angle back shell: CE-20BA-S Clamp: CE3057-12A-3
For CN2/3	Spindle detector drive unit side connector	CNU2S(AWG18)	Spindle drive unit side connector (3M) Receptacle: 36210-0100PL Shell kit : 36310-3200-008 (MOLEX) Connector set: 54599-1019	

5-5-3 Optical communication cable specifications

(1) Specifications

Cable model		G396-L□M	G380-L□M	
Specification application		For wiring inside panel	For wiring outside panel For long distance wiring	
Cable length		0.3, 0.5, 1.0, 2.0, 3.0, 5.0m	5.0, 10, 12, 15, 20, 25, 30m	
	Minimum bend radius	25mm	Enforced covering cable: 50mm cord: 30mm	
	Tension strength	140N	980N (Enforced covering cable)	
	Temperature range for use (Note1)	-40 to 85°C	-20 to 70°C	
	Ambient		(no direct sunlight) solvent or oil	
Optical communication cable	Cable appearance [mm]	7.2 2 2 ± 0.07	4.4±0.4 7.6±0.5	
	Connector appearance [mm]	Protection tube (6.7) (15) (13.4)	20.3	
	,,	(1.7)	22.7	

- (Note1) This temperature range for use is the value for optical cable (cord) only. Temperature condition for the connector is the same as that for drive unit.
- (Note2) Do not see directly the light generated from CN1A/CN1B connector of drive unit or the end of cable.
 When the light gets into eye, you may feel something is wrong for eye.
 (The light source of optical communication corresponds to class1 defined in JISC6802 or IEC60825-1.)

(2) Cautions for using optical communication cable

Optical communication cable is made from optical fiber. If optical fiber is added a power such as a major shock, lateral pressure, haul, sudden bending or twist, its inside distorts or breaks, and optical transmission will not be available. Especially, as optical fiber for G396-L \square M is made of synthetic resin, it melts down if being left near the fire or high temperature. Therefore, do not make it touched the part, which becomes high temperature, such as radiator or regenerative brake option of drive unit.

Read described item in this section carefully and handle it with caution.

(a) Minimum bend radius


Make sure to lay the cable with greater radius than the minimum bend radius. Do not press the cable to edges of equipment or others. For the optical communication cable, the appropriate length should be selected with due consideration for the dimensions and arrangement of drive unit so that the cable bend will not become smaller than the minimum bend radius in cable laying. When closing the door of control box, pay careful attention for avoiding the case that optical communication cable is hold down by the door and the cable bend becomes smaller than the minimum bend radius.

Lay the cable so that the numbers of bends will be less than 10 times.

(b) Bundle fixing

When using optical communication cable of 3m or longer, fix the cable at the closest part to the connector with bundle material in order to prevent optical communication cable from putting its own weight on CN1A/CN1B connector of drive unit. Optical cord should be given loose slack to avoid from becoming smaller than the minimum bend radius, and it should not be twisted.

When tightening up the cable with nylon band, the sheath material should not be distorted. Fix the cable with tightening force of 1 to 2kg or less as a guide.



When laying cable, fix and hold it in position with using cushioning such as sponge or rubber which does not contain plasticizing material.

Never use vinyl tape for cord. Plasticizing material in vinyl tape goes into optical fiber and lowers the optical characteristic. At worst, it may cause wire breakage. If using adhesive tape for cable laying, the fire resistant acetate cloth adhesive tape 570F (Teraoka Seisakusho Co., Ltd) is recommended. If laying with other wires, do not make the cable touched wires or cables made from material which contains plasticizing material.

(c) Tension

If tension is added on optical fiber, the increase of transmission loss occurs because of external force which concentrates on the fixing part of optical fiber or the connecting part of optical connector. At worst, the breakage of optical fiber or damage of optical connector may occur. For cable laying, handle without putting forced tension.

(d) Lateral pressure

If lateral pressure is added on optical communication cable, the optical cable itself distorts, internal optical fiber gets stressed, and then transmission loss will increase. At worst, the breakage of optical cable may occur. As the same condition also occurs at cable laying, do not tighten up optical communication cable with a thing such as nylon band (TY-RAP).

Do not trample it down or tuck it down with the door of control box or others.

(e) Twisting

If optical fiber is twisted, it will become the same stress added condition as when local lateral pressure or bend is added. Consequently, transmission loss increases, and the breakage of optical fiber may occur at worst.

(f) Cable selection

- When wiring is outside the power distribution panel or machine cabinet, there is a highly possibility that external power is added. Therefore, make sure to use the cable for wiring outside panel (G380-L□M)
- If a part of the wiring is moved, use the cable for wiring outside panel.
- In a place where sparks may fly and flame may be generated, use the cable for wiring outside panel.

(g) Method to lay cable

When laying the cable, do not haul the optical fiver or connector of the optical communication cable strongly. If strong force is added between the optical fiver and connector, it may lead to a poor connection.

(h) Protection when not in use

When the CN1A/CN1B connector of the drive unite or the optical communication cable connector is not used such as pulling out the optical communication cable from drive unit, protect the joint surface with attached cap or tube for edge protection. If the connector is left with its joint surface bared, it may lead to a poor connection caused by dirty.

(i) Attaching /Detaching optical communication cable connector

With holding the connector body, attach/detach the optical communication cable connector. If attaching/detaching the optical communication cable with directly holding it, the cable may be pulled out, and it may cause a poor connection.

When pulling out the optical communication connector, pull out it after releasing the lock of clock lever.

(j) Cleaning

If CN1A and CN1B connector of the drive unit or optical communication cable connector is dirty, it may cause poor connection. If it becomes dirty, wipe with a bonded textile, etc. Do not use solvent such as alcohol.

(k) Disposal

When incinerating optical communication cable, hydrogen fluoride gas or hydrogen chloride gas which is corrosive and harmful may be generated. For disposal of optical communication cable, request for specialized industrial waste disposal services that has incineration facility for disposing hydrogen fluoride gas or hydrogen chloride gas.

(I) Return in troubles

When asking repair of drive unit for some troubles, make sure to put a cap on CN1A/CN1B connector. When the connector is not put a cap, the light device may be damaged at the transit. In this case, exchange and repair of light device is required.

6

Specifications of Peripheral Devices

6-1 Selection of wire

6-1-1 Example of wires by unit

Selected wires must be able to tolerate rated current of the unit's terminal to which the wire is connected.

How to calculate tolerable current of an insulated wire or cable is shown in "Tolerable current of electric cable" (1) of Japanese Cable Makers' Association Standard (JCS)-168-E (1995), its electric equipment technical standards or JEAC regulates tolerable current, etc. wire.

When exporting wires, select them according to the related standards of the country or area to export. In the UL standards, certification conditions are to use wires of 60°C and 75°C product. (UL508C)

Wire's tolerable current is different depending on conditions such as its material, structure, ambient temperature, etc. Check the tolerable current described in the specification of the wire to use.

Example of wire selections according to each standard is as follows.

(1) 600V vinyl insulated wire (IV wire) 60°C product (Example according to IEC/EN60204-1, UL508C) < MDS-D Series >

				Termin	al name		
			E1		E2	TE	
U	Jnit type	(U,V,\	N , ⊕)		, L-)	(L11, L21, L1	2, L22, MC1)
		mm ²	AWG	mm ²	AWG	mm ²	AWG
	MDS-D-CV-37	2	14	3.5	12		
	MDS-D-CV-75	5.5	10	5.5	10		
	MDS-D-CV-110	14	6	22	4		
Power supply	MDS-D-CV-185	30	3	38	2	2	14
unit	MDS-D-CV-300	-	-	-	-] -	14
	MDS-D-CV-370	-	-	-	-		
	MDS-D-CV-450	-	-	-	-		
	MDS-D-CV-550	-	-	Bar enclosed			
	MDS-D-SP-20	2	14				
	MDS-D-SP-40	2	14				
	MDS-D-SP-80	5.5	10	Match with Ti	E2 of selected		
Spindle drive	MDS-D-SP-160	8	8		upply unit		
unit	MDS-D-SP-200	22	4		apply and	2	14
	MDS-D-SP-240	38	2				
	MDS-D-SP-320	-	-				
	MDS-D-SP-400	-	-	Bar en	nclosed		
	MDS-D-SP-640	-	-	Dai Ci	1010300		
	MDS-D-SP2-2020	2 (2)	14 (14)				
	MDS-D-SP2-4020	2 (2)	14 (14)	Match with TE2 of selected power supply unit			
Spindle drive	MDS-D-SP2-4040S	2 (2)	14 (14)				
unit	MDS-D-SP2-4040	2 (2)	14 (14)			2	4
(2-axis)	MDS-D-SP2-8040	5.5 (2)	10 (14)			_	
(=)	MDS-D-SP2-16080S	8 (5.5)	8 (10)				
	MDS-D-SP2-8080	5.5 (5.5)	10 (10)				
	MDS-D-SP2-16080	8 (5.5)	8 (10)				
	MDS-D-V1-20	2	14				
	MDS-D-V1-40	2	14				
Servo drive	MDS-D-V1-80	2	14	Match with TE	E2 of selected		
unit	MDS-D-V1-160	5.5	10		upply unit	2	14
	MDS-D-V1-160W	14	6		apply and		
	MDS-D-V1-320	22	4				
	MDS-D-V1-320W	38	2				
	MDS-D-V2-2020	2 (2)	14 (14)				
	MDS-D-V2-4020	2 (2)	14 (14)				
Servo drive	MDS-D-V2-4040	2 (2)	14 (14)				
unit	MDS-D-V2-8040	2 (2)	14 (14)		E2 of selected	2	14
(2-axis)	MDS-D-V2-8080	2 (2)	14 (14)	power su	upply unit		
(3 25.10)	MDS-D-V2-16080	5.5 (2)	10 (14)				
	MDS-D-V2-160160	5.5 (5.5)	10 (10)				
	MDS-D-V2-160160W	14 (14)	6 (6)				
(Note) The	values inside of () a	. ,	- (-/	<u> </u>		ļ	<u> </u>

< MDS-DH Series >

		Terminal name TE1 TF2 TF3									
		TE	E1	Т	E2	TE					
U	nit type	(U,V,V	N, ⊕)	(L+	-, L-)	(L11, L21, L1	2, L22, MC1)				
		mm ²	AWG	mm ²	AWG	mm ²	AWG				
	MDS-DH-CV-37	2	14	2	14						
	MDS-DH-CV-75	2	14	3.5	12						
	MDS-DH-CV-110	3.5	12	5.5	10						
Power supply	MDS-DH-CV-185	8	8	14	6						
unit	MDS-DH-CV-300	22	4	38	2	2	14				
	MDS-DH-CV-370	30	3	50	-						
	MDS-DH-CV-450	38	2	60	-						
	MDS-DH-CV-550	=	-	Bar e	nclosed						
	MDS-DH-CV-750	-	-	Bai Ci							
	MDS-DH-SP-20	2	14								
	MDS-DH-SP-40	2	14				14				
Spindle drive	MDS-DH-SP-80	5.5	10		E2 of selected						
	MDS-DH-SP-100	8	8	power s	upply unit	2					
unit	MDS-DH-SP-160	22	4				1-7				
	MDS-DH-SP-200	38	2								
	MDS-DH-SP-320	-	-	Bar enclosed							
	MDS-DH-SP-480	-	-	- Bai Ci	1010304						
	MDS-DH-V1-10	2	14								
	MDS-DH-V1-20	2	14								
	MDS-DH-V1-40	2	14								
Servo drive	MDS-DH-V1-80	2	14		E2 of selected	2	14				
unit	MDS-DH-V1-80W	5.5	10	power s	upply unit	_	14				
	MDS-DH-V1-160	5.5	10								
	MDS-DH-V1-160W	14	6								
	MDS-DH-V1-200	22	4								
	MDS-DH-V2-1010	2 (2)	14 (14)								
	MDS-DH-V2-2010	2 (2)	14 (14)								
Camus duive	MDS-DH-V2-2020	2 (2)	14 (14)								
Servo drive unit	MDS-DH-V2-4020	2 (2)	14 (14)	Match with T	E2 of selected	2	14				
(2-axis)	MDS-DH-V2-4040	2 (2)	14 (14)	power s	upply unit		14				
()	MDS-DH-V2-8040	2 (2)	14 (14)								
	MDS-DH-V2-8080	2 (2)	14 (14)								
	MDS-DH-V2-8080W	5.5 (5.5)	10(10)	7							

(2) 600V double (heat proof) vinyl insulated wire (HIV wire) 75°C product (Example according to IEC/EN60204-1, UL508C) < MDS-D Series >

				Termir	nal name		
		TI	E1	Т	E2	TE	
ι	Init type		N , ⊕)	(L+	⊦, L-)	(L11, L21, L1	2, L22, MC1)
		mm ²	AWG	mm ²	AWG	mm ²	AWG
	MDS-D-CV-37	2	14	3.5	12		
	MDS-D-CV-75	5.5	10	5.5	10		
	MDS-D-CV-110	8	8	14	6		
Power supply	MDS-D-CV-185	22	4	22	4	2	14
unit	MDS-D-CV-300	38	2	60	-	2	14
	MDS-D-CV-370	50	-	60	-		
	MDS-D-CV-450	60	-	60	-		
	MDS-D-CV-550	85	-	Bar er	nclosed		
	MDS-D-SP-20	2	14				
	MDS-D-SP-40	2	12				
	MDS-D-SP-80	3.5	12	Motob with T	EQ of coloots d		
Cuindle daire	MDS-D-SP-160	8	8		E2 of selected upply unit		
Spindle drive unit	MDS-D-SP-200	14	6	Powers	apply unit	2	14
unit	MDS-D-SP-240	22	4	7			
	MDS-D-SP-320	60	-				
	MDS-D-SP-400	70	-	Dor or	nclosed	1	
	MDS-D-SP-640	85	-	– bai ei	iciosea		İ
	MDS-D-SP2-2020	2 (2)	14 (14)				
	MDS-D-SP2-4020	2 (2)	14 (14)	Match with TE2 of selected power supply unit			
	MDS-D-SP2-4040S	2 (2)	14 (14)				
Spindle drive	MDS-D-SP2-4040	2 (2)	14 (14)			2	14
unit (2-axis)	MDS-D-SP2-8040	3.5 (2)	12 (14)			2	14
(L uxis)	MDS-D-SP2-16080S	8 (3.5)	8 (12)	1			
	MDS-D-SP2-8080	3.5 (3.5)	12 (12)	1			
	MDS-D-SP2-16080	8 (3.5)	8 (12)	1			
	MDS-D-V1-20	2	14				
	MDS-D-V1-40	2	14	1			
Comes deles	MDS-D-V1-80	2	14	Matabasis T	E0 -f!! - !		
Servo drive unit	MDS-D-V1-160	5.5	10		E2 of selected upply unit	2	14
unit	MDS-D-V1-160W	8	8	powers	uppiy unit		
	MDS-D-V1-320	14	6	7			
	MDS-D-V1-320W	22	4	7			
	MDS-D-V2-2020	2 (2)	14 (14)				
	MDS-D-V2-4020	2 (2)	14 (14)	7			
	MDS-D-V2-4040	2 (2)	14 (14)	7			
Servo drive	MDS-D-V2-8040	2 (2)	14 (14)	Match with T	E2 of selected	2	1.1
unit (2-axis)	MDS-D-V2-8080	2 (2)	14 (14)	power s	upply unit	2	14
(Z-dxis)	MDS-D-V2-16080	5.5 (2)	10 (14)	7			
	MDS-D-V2-160160	5.5 (5.5)	10 (10)	7			
	MDS-D-V2-160160W	8 (8)	8 (8)	1			

< MDS-DH Series >

		Terminal name TE1 TF2 TF3								
				- 1	E2	TE				
U	nit type	(U,V,V	V, ⊕)	-	, L-)	(L11, L21, L1	2, L22, MC1)			
		mm ²	AWG	mm ²	AWG	mm ²	AWG			
	MDS-DH-CV-37	2	14	2	14					
	MDS-DH-CV-75	2	14	3.5	12					
	MDS-DH-CV-110	3.5	12	5.5	10					
Power supply	MDS-DH-CV-185	8	8	8	8					
unit	MDS-DH-CV-300	14	6	22	4	2	14			
	MDS-DH-CV-370	22	4	38	2					
	MDS-DH-CV-450	22	4	50	-					
	MDS-DH-CV-550	38	2	Bar er	nclosed					
	MDS-DH-CV-750	60	-	Bai cholocca						
	MDS-DH-SP-20	2	14							
	MDS-DH-SP-40	2	14							
	MDS-DH-SP-80	5.5 10 Match with TE2 of selected								
Spindle drive unit	MDS-DH-SP-100	8	8	power si	upply unit	2	14			
	MDS-DH-SP-160	14	6			_	1-7			
	MDS-DH-SP-200	22	4							
	MDS-DH-SP-320	38	2	Bar enclosed						
	MDS-DH-SP-480	60	-	Barer	1010300					
	MDS-DH-V1-10	2	14							
	MDS-DH-V1-20	2	14							
	MDS-DH-V1-40	2	14							
Servo drive	MDS-DH-V1-80	2	14		E2 of selected	2	14			
unit	MDS-DH-V1-80W	5.5	10	power su	upply unit	_	1-7			
	MDS-DH-V1-160	5.5	10							
	MDS-DH-V1-160W	8	8							
	MDS-DH-V1-200	22	4							
	MDS-DH-V2-1010	2 (2)	14 (14)							
	MDS-DH-V2-2010	2 (2)	14 (14)							
Servo drive	MDS-DH-V2-2020	2 (2)	14 (14)							
unit	MDS-DH-V2-4020	2 (2)	14 (14)		E2 of selected	2	14			
(2-axis)	MDS-DH-V2-4040	2 (2)	14 (14)	power si	upply unit	_	17			
, , , , , , , , , , , , , , , , , , , ,	MDS-DH-V2-8040	2 (2)	14 (14)							
	MDS-DH-V2-8080	2 (2)	14 (14)							
	MDS-DH-V2-8080W	5.5 (5.5)	10 (10)							

(3) 600V bridge polyethylene insulated wire (IC) 105 °C product (Example according to JEAC8001)

< MDS-D Series >

		Terminal name TE1 TF2 TF3								
		TE	≣1	-	E2	TE	-			
U	nit type		V , ⊕)	(L	+, L-)	(L11, L21, L1	2, L22, MC1)			
		mm ²	AWG	mm ²	AWG	mm ²	AWG			
	MDS-D-CV-37	2	14	2	14					
	MDS-D-CV-75	3.5	12	3.5	12]				
	MDS-D-CV-110	5.5	10	14	6					
Power supply	MDS-D-CV-185	14	6	22	4	1.25 to 2	16 to 14			
unit	MDS-D-CV-300	38	2	50	-	1.20 to 2	10 10 14			
	MDS-D-CV-370	38	2	60	-					
	MDS-D-CV-450	60	-	60	-					
	MDS-D-CV-550	60	-	Bar enclosed						
	MDS-D-SP-20	2	14							
	MDS-D-SP-40	2	14							
	MDS-D-SP-80	3.5	12	Match with T	E2 of selected					
Spindle drive	MDS-D-SP-160	8	8		upply unit	1.25 to 2				
unit	MDS-D-SP-200	14	6				16 to 14			
	MDS-D-SP-240	22	4							
	MDS-D-SP-320	38	2							
	MDS-D-SP-400	60	-	Bar e	nclosed					
	MDS-D-SP-640	85	-							
	MDS-D-SP2-2020	2 (2)	14 (14)							
	MDS-D-SP2-4020	2 (2)	14 (14)	Match with TE2 of selected						
Spindle drive	MDS-D-SP2-4040S	2 (2)	14 (14)							
unit	MDS-D-SP2-4040	2 (2)	14 (14)			1.25 to 2	16 to 14			
(2-axis)	MDS-D-SP2-8040	3.5 (2)	12 (14)	powers	power supply unit					
	MDS-D-SP2-16080S	8 (3.5)	8 (12)	4						
	MDS-D-SP2-8080	3.5 (3.5)	12(12)	4						
	MDS-D-SP2-16080	8 (3.5)	8(12)							
	MDS-D-V1-20	2	14	4						
	MDS-D-V1-40	2	14	4						
Servo drive	MDS-D-V1-80 MDS-D-V1-160	2 3.5	14 12	Match with T	E2 of selected	1 25 10 2	16 to 14			
unit	MDS-D-V1-160W	5.5	10	power s	upply unit	1.25 to 2	16 to 14			
	MDS-D-V1-160W MDS-D-V1-320	5.5 14	6	-						
	MDS-D-V1-320W	22	4	-						
	MDS-D-V1-320W	2 (2)								
	MDS-D-V2-2020 MDS-D-V2-4020	2 (2)	14 (14) 14 (14)	-						
	MDS-D-V2-4040	2 (2)	14 (14)	-						
Servo drive	MDS-D-V2-8040	2 (2)	14 (14)	Motob with T	E2 of solootod					
unit	MDS-D-V2-8080	2 (2)	14 (14)		E2 of selected upply unit	1.25 to 2	16 to 14			
(2-axis)	MDS-D-V2-16080	3.5 (2)	12 (14)		apply unit					
	MDS-D-V2-160160	3.5 (2)	12 (14)	-						
	MDS-D-V2-160160W	5.5 (5.5)	10 (10)	-						
	IVIDS-D-V2-100100VV	ა.ა (ა.ა)	10 (10)	1						

< MDS-DH Series >

				Termin	al name		
		TI	E1		E 2	TE	-
U	nit type		N , ⊕)		, L-)	(L11, L21, L1	2, L22, MC1)
		mm ²	AWG	mm ²	AWG	mm ²	AWG
	MDS-DH-CV-37	2	14	2	14		
	MDS-DH-CV-75	2	14	2	14		
	MDS-DH-CV-110	2	14	3.5	12		
Power supply	MDS-DH-CV-185	5.5	10	5.5	10		
unit	MDS-DH-CV-300	14	6	14	6	1.25 to 2	16 to 14
	MDS-DH-CV-370	14	6	22	4		
	MDS-DH-CV-450	22	4	30	3		
	MDS-DH-CV-550	22	4	Bar en	closed		
	MDS-DH-CV-750	38	2	= 5			
	MDS-DH-SP-20	2	14	_]			
	MDS-DH-SP-40	2	14	_			
	MDS-DH-SP-80	3.5	12	Match with TE2 of selected			
Spindle drive unit	MDS-DH-SP-100	5.5	10	power su	apply unit	1.25 to 2	16 to 14
	MDS-DH-SP-160	14	6	_			
	MDS-DH-SP-200	22	4				
	MDS-DH-SP-320	38	2	Bar enclosed			
	MDS-DH-SP-480	60	-				
	MDS-DH-V1-10	2	14	_			
	MDS-DH-V1-20	2	14	_			
	MDS-DH-V1-40	2	14	_			
Servo drive	MDS-DH-V1-80	2	14		2 of selected	1.25 to 2	16 to 14
unit	MDS-DH-V1-80W	2	14	power su	apply unit		-
	MDS-DH-V1-160	3.5	12	_			
	MDS-DH-V1-160W	5.5	10	_			
	MDS-DH-V1-200	14	6				
	MDS-DH-V2-1010	2	14	4			
	MDS-DH-V2-2010	2	14	_			
Servo drive	MDS-DH-V2-2020	2	14	1			
unit	MDS-DH-V2-4020	2	14		2 of selected	1.25 to 2	16 to 14
(2-axis)	MDS-DH-V2-4040	2	14	power su	apply unit		-
	MDS-DH-V2-8040	2	14	_			
	MDS-DH-V2-8080	2	14	_			
	MDS-DH-V2-8080W	2	14				

(Note) The values inside of () are M side.

- 1. Selection conditions follow IEC/EN60204-1, UL508C, JEAC8001.
 - Ambient temperature is maximum 40°C.
 - Cable installed on walls without ducts or conduits.

⚠ CAUTION

To use the wire under conditions other than above, check the standards you are supposed to follow.

- 2. The maximum wiring length to the motor is 30m.
 If the wiring distance between the drive unit and motor is 20m or longer, use a thick wire so that the cable voltage drop is 2% or less.
- 3. Always wire the grounding wire.

6-2 Selection of circuit protector and contactor

Always select the circuit protector and contactor properly, and install them to each power supply unit to prevent disasters.

6-2-1 Selection of circuit protector

Calculate a circuit protector selection current from the rated output and the nominal input voltage (voltage supplied to the power supply unit) as in the expression below. And then select the minimum capacity circuit protector whose rated current meets the circuit protector selection current.

< MDS-D Series >

Circuit protector selection current [A] = $(Circuit protector selection current for 200V input [A] / Nominal input voltage [V]) <math>\times 200 [V]$

Selection of circuit protector for 200V input

Unit type	37	75	110	185	300	370	450	550
MDS-D-CV-	31	/3	110	103	300	370	450	330
Rated output	3.7kW	7.5kW	11kW	18.5kW	30kW	37kW	45kW	55kW
Circuit protector selection	15A	31A	45A	76A	124A	153A	186A	224A
current for 200V input	10/1	0171	40/1	70/1	12471	100/1	100/1	22-77
Selection example of circuit protector	NF63-	NF63-	NF63-	NF125-	NF250-	NF250-	NF250-	NF250-
•	CW3P-	CW3P-	CW3P-	CW3P-	CW3P-	CW3P-	CW3P-	CW3P-
(Mitsubishi Electric Corp.)	20A	40A	50A	100A	125A	175A	200A	225A
Rated current of the selection example	20A	40A	50A	100A	125A	175A	200A	225A
of circuit protector	20/	40/4	557	100/4	120/1	1757	2007	2207

Option part: A circuit protector is not prepared as an NC unit accessory, so purchase the part from your dealer, etc.

(Example)

Select a circuit protector for using the MDS-D-CV-110 with a 220V nominal input voltage.

Circuit protector selection current = $45/220 \times 200 = 40.9[A]$

According to the table above, select "NF63-CW3P-50A".

< MDS-DH Series >

Circuit protector selection current [A] =

(Circuit protector selection current for 380V input [A] / Nominal input voltage [V]) × 380 [V]

Selection of circuit protector for 380V input

Unit type MDS-DH-CV-	37	75	110	185	300	370	450	550	750
Rated output	3.7kW	7.5kW	11kW	18.5kW	30kW	37kW	45kW	55kW	75kW
Circuit protector selection current for 380V input	8A	16A	24A	40A	65A	80A	98A	119A	163A
Selection example of circuit protector (Mitsubishi Electric Corp.)	NF63- CW3P- 10A	NF63- CW3P- 20A	NF63- CW3P- 30A	NF63- CW3P- 40A	NF125- CW3P- 75A	NF125- CW3P- 100A	NF125- CW3P- 100A	NF250- CW3P- 125A	NF250- CW3P- 200A
Rated current of the selection example of circuit protector	10A	20A	30A	40A	75A	100A	100A	125A	200A

Option part: A circuit protector is not prepared as an NC unit accessory, so purchase the part from your dealer, etc.

(Example)

Select a circuit protector for using the MDS-DH-CV-450 with a 480V nominal input voltage.

Circuit protector selection current = 98/480×380 = 77.6[A]

According to the table above, select "NF125-CW3P-100A".

1. It is dangerous to share a circuit protector for multiple power supply units, so do not share it.

Always install the circuit protectors for each power supply unit.



2. If the control power (L11, L21) must be protected, select according to the section "6-4-1 Circuit protector".

6-2-2 Selection of contactor

Select the contactor selection current that is calculated from the rated output and the nominal input voltage (voltage supplied to the power supply unit) as in the expression below. And then select the contactor whose conventional free-air thermal current meets the contactor selection current.

< MDS-D Series >

Contactor selection current [A]=

(Contactor selection current for 200V input [A] / Nominal input voltage [V]) x 200 [V]

Selection of contactor for 200V input

Unit type MDS-D-CV-	37	75	110	185	300	370	450	550
Rated output	3.7kW	7.5kW	11kW	18.5kW	30kW	37kW	45kW	55kW
Contactor selection current for 200V input	15A	31A	45A	76A	124A	153A	186A	224A
Selection example of contactor (Mitsubishi Electric Corp.)	S-N12 -AC200V	S-N25 -AC200V	S-N25 -AC200V	S-N65 -AC200V	S-N80 -AC200V	S-N150 -AC200V	S-N150 -AC200V	S-N180 -AC200V
Conventional freeair thermal current of the selection example of contactor	20A	50A	50A	100A	135A	200A	200A	260A

Option part: A contactor is not prepared as an NC unit accessory, so purchase the part from your dealer, etc.

(Example)

Select a contactor for using the MDS-D-CV-110 with a 220V nominal input voltage.

Contactor selection current = $45/220 \times 200 = 40.9[A]$

According to the table above, select "S-N25-AC200V".

< MDS-DH Series >

Contactor selection current [A] =

(Contactor selection current for 380V input [A] / Nominal input voltage [V]) × 380 [V]

Selection of contactor for 380V input

Unit type MDS-DH-CV-	37	75	110	185	300	370	450	550	750
Rated output	3.7kW	7.5kW	11kW	18.5kW	30kW	37kW	45kW	55kW	75kW
Contactor selection current for 380V input	8A	16A	24A	40A	65A	80A	98A	119A	163A
Selection example of contactor	S-N12-	S-N12-	S-N21-	S-N25-	S-N50-	S-N65-	S-N65-	S-N80-	S-N150-
(Mitsubishi Electric Corp.)	AC400V								
Conventional freeair thermal current of the selection example of contactor	20A	20A	32A	50A	80A	100A	100A	135A	200A

Option part: A contactor is not prepared as an NC unit accessory, so purchase the part from your dealer, etc.

(Example)

Select a contactor for using the MDS-DH-CV-450 with a 480V nominal input voltage.

Contactor selection current = 98/480×380 = 77.6[A]

According to the table above, select "S-N50-AC400V".

1. Use an alternating contactor.



- 2. If the contactor selection current is 20A or less, select the S-N12 product for the contactor.
- 3. Select a contactor whose excitation coil does not operate at 15mA or less.

6-3 Selection of earth leakage breaker

When installing an earth leakage breaker, select the breaker on the following basis to prevent the breaker from malfunctioning by the higher frequency earth leakage current generated in the servo or spindle drive unit.

(1) Selection

Obtaining the earth leakage current for all drive units referring to the following table, select an earth leakage breaker within the "rated non-operation sensitivity current".

Usually use an earth leakage breaker for inverter products that function at a leakage current within the commercial frequency range (50 to 60Hz).

If a product sensitive to higher frequencies is used, the breaker could malfunction at a level less than the maximum earth leakage current value.

Earth leakage current for each unit

Series	Drive unit	Earth leakage current	Maximum earth leakage current
	MDS-D-SP-20 to 640	6mA	15mA
MDS-D	MDS-D-SP2-2020 to 16080	6mA	30mA
MD3-D	MDS-D-V1-20 to 320W	1mA	2mA
	MDS-D-V2-2020 to 160160	1mA	4mA (for two axes)
	MDS-DH-SP-20 to 480	6mA	15mA
MDS-DH	MDS-DH-V1-10 to 200	1mA	2mA
	MDS-DH-V2-1010 to 8080	1mA	4mA (for two axes)

(Note1) Maximum earth leakage current: Value that considers wiring length and grounding, etc.(Commercial frequency 50/60Hz)

(Note2) The earth leakage current in the power supply unit side is included in the drive unit side.

(2) Measurement of earth leakage current

When actually measuring the earth leakage current, use a product that is not easily affected by the higher frequency earth leakage current. The measurement range should be 50 to 60Hz.

1. The earth leakage current tends to increase as the motor capacity increases.



- 2. A higher frequency earth leakage current will always be generated because the inverter circuit in the drive unit switches the transistor at high speed. Always ground to reduce the higher frequency earth leakage current as much as possible.
- 3. An earth leakage current containing higher frequency may reach approx. several hundreds of mA. According to IEC479-2, this level is not hazardous to the human body.


6-4 Branch-circuit protection (for control power supply)

6-4-1 Circuit protector

This breaker is used to switch the control power and to provide overload and short-circuit protection.

When connecting a circuit protector to the power input (TE3 terminals L11 and L21) for the control circuit, use a product that does not trip (incorrectly activate) by a rush current when the power is turned ON. A circuit protector with inertial delay is available to prevent unnecessary tripping. Select the product to be used according to the machine specifications.

The rush current and rush conductivity time differ according to the power impedance and power ON timing, so select a product that does not trip even under the conditions listed in the following table.



Note) Rush current of MDS-D-37/75 is 38A.



When collectively protecting the control circuit power for multiple units, select a circuit protector that satisfies the total sum of the rush current lp.

The largest value is used for the rush conductivity time T.

6-4-2 Fuse protection

The fuse of branch-circuit protection must use UL class CC, J or T. In the selection, please consider rush current and rush conductive time.

Selection of branch-circuit protection fuse

Connected total of unit	Fuse (C	Wire Size	
Connected total of unit	Rated [V]	Current [A]	AWG
1 - 4	600	20	16 to 14
5 - 8	000	35	10 10 14



For continued protection against risk of fire, replace only with same type 600 V, 20 or 35 A (UL CLASS CC) fuse.



Before replacing fuse, confirm all power controlling the drive system is shut-OFF. Be sure to look out the power source to prevent the power from being turned ON while maintenance is being performed.


6-5 Noise filter

(1) Selection

Use an EMC noise filter if the noise conducted to the power line must be reduced. Select an EMC noise filter taking the power supply unit's input rated voltage and input rated current into consideration.

(2) Noise filter mounting position

Install the noise filter to the power supply unit's power input as the diagram below indicates.



(Note) The noise filter must be prepared by the user.

Recommended devices:

MDS-D Series

Densei-lambda MX13 Series

Soshin Electric HF3000C-TM Series

MDS-DH Series

Okaya Electric Industries 3SUP-HL-ER-6B Series

Soshin Electric HF3000C-TMA Series

Contact:

Densei-lambda Co., Ltd. Telephone: 0120-507039 http://www.densei-lambda.com

Soshin Electric Co., Ltd. Telephone: 03-3775-9112 (+81-3-3775-9112) http://www.soshin.co.jp

(Note) The above devices may be changed at the manufacturer's discretion.

Contact each manufacturer for more information.

6-6 Surge absorber

When controlling a magnetic brake of a servomotor in DC OFF circuit, a surge absorber must be installed to protect the relay contacts and brakes. Commonly a varistor is used.

(1) Selection of varistor

When a varistor is installed in parallel with the coil, the surge voltage can be adsorbed as heat to protect a circuit. Commonly a 120V product is applied. When the brake operation time is delayed, use a 220V product. Always confirm the operation with an actual machine.

(2) Specifications

Select a varistor with the following or equivalent specifications. To prevent short-circuiting, attach a flame resistant insulation tube, etc., onto the leads as shown in the following outline dimension drawing.

Varistor specifications

	Varistor voltage rating (range)	Rating							Electro-	
Varistor type		Tolerabl volt	e circuit age	withsta	current nd level A)	Ener withstar (J	nd level	Power	Max.limit voltage	static capacity (reference value)
	(V)	AC(V)	DC(V)	1 time	2 times	10/ 1000µs	2ms	(W)	(V)	(pF)
ERZV10D121 TND10V-121K	120 (108 to 132)	75	100	3500	2500	20	14.5	0.4	200	1400
ERZV10D221 TND10V-221K	220 (198 to 242)	140	180	3500	2500	39	27.5	0.4	360	410

(Note 1) Selection condition: When ON/OFF frequency is 10 times/min or less, and exciting current is 2A or less

(Note 2) ERZV10D121 and ERZV10D221 are manufactured by Matsushita Electric Industrial Co., Ltd. TNR10V121K and TNR10V221K are manufactured by MARCON Electronics Co., Ltd.

Contact: Matsushita Electronic Components Co., Ltd: http://www.panasonic.co.jp/ maco/

MARCON Electronics Co., Ltd. Telephone:


(Kanto) 03-3471-7041 (+81-3-3471-7041)

(Kinki) 06-6364-2381 (+81-3-6364-2381)

(Chubu) 052-581-2595 (+81-52-581-2595)

(3) Outline dimension drawing

ERZV10D121, ERZV10D221






Normally use a product with 120V varistor voltage. If there is no allowance for the brake operation time, use the 220V product. A varistor whose voltage exceeds 220V cannot be used, as such varistor will exceed the specifications of the relay in the unit.

6-7 Relay

The input/output circuit to control the external signal such as external emergency stop input and relay changeover signal output is wired.

The input/output circuit for each unit is as follows.



(Note) Do not connect "(1)" or "(2)".

If a ground of the external 24V power is same as the 24V power in the drive unit, a fault or abnormal operation could occur.

Connector	Inpu	ut condition	Connector	Output condition		
CN9	Switch ON	18VDC to 25.2VDC 4.3mA or more	CN9	Output voltage	24VDC ±5%	
0143	Switch OFF	4VDC or less 2mA or less	- ONS	Tolerable output current to	50mA or less	
CN23A	Switch ON	18VDC to 25.2VDC 9mA or more				
OHLON	Switch OFF	4VDC or less 2mA or less				

For a switch or relay to be wired, use a switch or relay that satisfies the input/output (voltage, current) conditions.

Interface name	Selection example		
For digital input signal (CN23,CN9)	Use a minute signal switch which is stably contacted and operated even with low voltage or current. <example> OMRON: G2A, G6B type, MY type, LY type</example>		
For digital output signal (CN9)	Use a compact relay operated with rating of 24VDC, 50mA or less. <example> OMROM: G6B type, MY type</example>		

Selection

7 Selection

7-1 Selection of the servomotor

7-1-1 Outline

It is important to select a servomotor matched to the purpose of the machine that will be installed. If the servomotor and machine to be installed do not match, the motor performance cannot be fully realized, and it will also be difficult to adjust the parameters. Be sure to understand the servomotor characteristics in this chapter to select the correct motor.

(1) Motor inertia

The servomotor series is mainly categorized according to the motor inertia size. The features in Table 7-1 are provided according to the motor inertia size.

Motor model	Medium inertia motor	Low inertia motor		
Motor series	HF, HF-H Series	HP, HP-H, HF-KP Series		
Inertia	The flange size is large. The inertia is comparatively large.	The flange size is small. The inertia is small.		
Acceleration/ deceleration	The acceleration/deceleration time constant does not change much even for a low inertia load. The effect of the motor inertia is large.	Acceleration/deceleration is possible with a short time constant in respect to low inertia loads. The effect of the motor inertia is small.		
Installation	The motor size in respect to the output capacity is large, and the installation space is large.	The motor size in respect to the output capacity is small, and the installation space is smaller.		
Disturbance characteristics	The effect of disturbance is small.	The effect of disturbance is large.		
Speed fluctuation	The effect of the torque ripple and cogging torque is small, and speed fluctuation does not occur easily.	The effect of the torque ripple and cogging torque is large, and speed fluctuation occurs easily.		
Suitability	Suitable for high precision interpolation control.	Suitable for high speed high frequency positioning.		

Table 7-1 Motor inertia

Select a medium inertia motor when interpolation precision is required, or for machines having a large load inertia. Select a low inertia motor when a shorter positioning time is required by machines having a small amount of inertia. In general, use a medium inertia motor for basic feed axis of machine tools, and use a low inertia motor for machine tool auxiliary axes, peripheral axes, and general industrial machine positioning. The servomotor has an optimum load inertia scale. If the load inertia exceeds the optimum range, the control becomes unstable and the servo parameters become difficult to adjust. When the load inertia is too large, decelerate with the gears (The motor axis conversion load inertia is proportional to the square of the deceleration ratio.), or change to a motor with a large inertia.

(2) Rated speed

Even with motors having the same capacity, the rated speed will differ according to the motor. The motor's rated output is designed to be generated at the rated speed, and the output P (W) is expressed with expression (7-1). Thus, even when the motors have the same capacity, the rated torque will differ according to the rated speed.

$$P = 2\pi NT \text{ (W)} \qquad \qquad ---(7-1)$$

$$N: \text{Motor speed (1/sec)}$$

$$T: \text{Output torque (N.m)}$$

In other words, even with motors having the same capacities, the one with the lower rated speed will generate a larger torque. If generated torque is the same, the drive unit capacity can be downsized. When actually mounted on the machine, if the positioning distance is short and the motor cannot reach the maximum speed, the motor with the lower rated speed will have a shorter positioning time. When selecting the motor, consider the axis stroke and usage methods, and select the motor with the optimum rated speed.

7-1-2 Selection of servomotor capacity

The following three elements are used to determine the servomotor capacity.

- 1. Load inertia ratio
- 2. Short time characteristics (acceleration/deceleration torque)
- 3. Continuous characteristics (continuous effective load torque)

Carry out appropriate measures, such as increasing the motor capacity, if any of the above conditions is not fulfilled.

(1) Load inertia ratio

Each servomotor has an appropriate load inertia ratio (load inertia/motor inertia). The control becomes unstable when the load inertia ratio is too large, and the servo parameter adjustment becomes difficult. It becomes difficult to improve the surface precision in the feed axis, and the positioning time cannot be shortened in the positioning axis because the settling time is longer.

If the load inertia ratio exceeds the recommended value in the servo specifications list, increase the motor capacity, and select so that the load inertia ratio is within the recommended range.

Note that the recommended value for the load inertia ratio is strictly one guideline. This does not mean that controlling of the load with inertia exceeding the recommended value is impossible.



- 1. When selecting feed axis servomotors for NC unit machine tools, place importance on the surface precision during machining. To do this, always select a servomotor with a load inertia ratio within the recommended value. Select the lowest value possible within that range.
- 2. The load inertia ratio for the motor with brakes must be judged based on the motor inertia for the motor without brakes.

7 Selection

(2) Short time characteristics

In addition to the continuous operation range, the servomotor has the short time operation range that can be used only in a short time such as acceleration/deceleration. This range is expressed by the maximum torque and the torque characteristics. The maximum torque or the torque characteristics differ according to each motor, so confirm the specifications in section "2-1 Servomotor".

The torque required for the servomotor's acceleration/deceleration differs according to the CNC's command pattern or the servo's position control method.

Determine the required maximum motor torque from the following expression, and select the servomotor capacity.

(a) Selection with the maximum torque characteristics

In a low-speed rotation range (approximately less than half of the servomotor maximum speed), the linear acceleration/deceleration time constant "ta" that can be driven depends on the motor maximum torque. That can be approximated from the machine specifications using the expression (7-2).

ta =
$$\frac{1.05 \times 10^{-2} \times (J_L/\eta + J_M) \times N}{(0.8 \times T_{MAX} - T_L)}$$
 (ms) ••• (7-2)

 $\begin{array}{lll} N & : Motor \ reach \ speed & (r/min) \\ J_L & : Motor \ shaft \ conversion \ load \ inertia & (kg•cm²) \\ J_M & : Motor \ inertia & (kg•cm²) \\ \end{array}$

 η $\,\,\,\,\,$: Drive system efficiency (Normally 0.8 to 0.95)

 T_{MAX} : Maximum motor torque (N•m) T_L : Motor shaft conversion load (friction, unbalance) torque (N•m)

Using the approximate linear acceleration/deceleration time constant "ta" calculated above, confirm the torque characteristics of the high-speed rotation range in the CNC's command pattern or the servo's position control method.

(b) Approximation when using the NC command linear acceleration/deceleration pattern + servo standard position control

This is a normal command pattern or servo standard position control method.

Using the expression (7-3) and (7-4), approximate the maximum torque "Ta1" and maximum torque occurrence speed "Nm" required for this acceleration/deceleration pattern.

$$T_{a}1 = \frac{1.05 \times 10^{-2} \times (J_{L}/\eta + J_{M}) \times N}{t_{a}} \times (1 - e^{\frac{-K_{D} \times t_{a}}{1000}}) + T_{L} \quad (N \cdot m) \qquad \bullet \bullet \bullet (7-3)$$

Nm = N × {1-
$$\frac{1000}{\text{Kp} \times \text{ta}}$$
 × (1- $e^{\frac{-\text{Kp} \times \text{ta}}{1000}}$)} (r/min) •••(7-4)

 $\begin{array}{lll} N & : Motor \ reach \ speed & (r/min) \\ J_L & : Motor \ shaft \ conversion \ load \ inertia & (kg•cm²) \\ J_M & : Motor \ inertia & (kg•cm²) \\ \eta & : Drive \ system \ efficiency \ (Normally \ 0.8 \ to \ 0.95) \end{array}$

T_{MAX} : Maximum motor torque (N•m)

T_L : Motor shaft conversion load (friction, unbalance) (N•m)




Fig.1 Speed, acceleration and torque characteristics when using the NC command linear acceleration/deceleration pattern + servo standard position control

7 Selection

(c) Approximation when using the NC command linear acceleration/deceleration pattern + servo SHG control (option)

This is a servo's position control method to achieve a normal command pattern and high precision. SHG control improves the position loop gain by stably controlling a delay of the position loop in the servo system. This allows the settling time to be reduced and a high precision to be achieved. Using the expression (7-5) and (7-6), approximate the maximum torque "Ta1" and maximum torque occurrence speed "Nm" required for this acceleration/deceleration pattern.

$$T_{a}1 = \frac{1.05 \times 10^{-2} \times (J_{L}/\eta + J_{M}) \times N}{ta} \times (1 - 0.586 \times e^{\frac{-2 \times K_{P} \times ta}{1000}}) + T_{L} \qquad (N \cdot m) \quad \bullet \bullet \bullet (7-5)$$

Nm =N × {1-
$$\frac{1000}{1.3 \times \text{Kp} \times \text{ta}} \times (1-1.5 \times e^{\frac{-2 \times \text{Kp} \times \text{ta}}{1000}})$$
} (r/min) ••• (7-6)

 $\begin{array}{lll} N & : Motor \ reach \ speed & (r/min) \\ J_L & : Motor \ shaft \ conversion \ load \ inertia & (kg•cm²) \\ J_M & : Motor \ inertia & (kg•cm²) \\ \eta & : Drive \ system \ efficiency \ (Normally \ 0.8 \ to \ 0.95) \end{array}$

 T_{MAX} : Maximum motor torque (N $^{\bullet}$ m) T_{L} : Motor shaft conversion load (friction, unbalance) torque (N $^{\bullet}$ m)




Fig.2 Speed, acceleration and torque characteristics when using the NC command linear acceleration/deceleration pattern + servo SHG control

(d) Approximation when using the NC command soft acceleration/deceleration pattern + feed forward (high-speed accuracy) control

If the feedforward amount is set properly, the delay of the servo position loop is guaranteed. Therefore, this command acceleration pattern can be approximated to the NC command and does not depend on the servo position control method.

Using the expression (7-7) and (7-8), approximate the maximum torque "Ta1" and maximum torque occurrence speed "Nm" required for this acceleration/deceleration pattern.

$$T_a 1 = \frac{1.05 \times 10^{-2} \times (J_L/\eta + J_M) \times N}{ta} + T_L$$
 (N·m) ••• (7-7)

Nm = N × (1-
$$\frac{1}{2}$$
 × $\frac{\text{tb}}{\text{ta}}$) (r/min) ••• (7-8)

: Linear acceleration/deceleration time constant (ms) : Acceleration/deceleration time constant (ms) : Position loop gain (rad/sec) Ν : Motor reach speed (r/min) J_{l} : Motor shaft conversion load inertia (kg•cm²) : Motor inertia (kg•cm²) : Drive system efficiency (Normally 0.8 to 0.95) η

T_L : Motor shaft conversion load (friction, unbalance) torque (N•m)





Fig 3. Speed, acceleration and torque characteristic when using the NC command soft acceleration/deceleration pattern + feedforward (high-speed accuracy) control

(e) Confirmation in the torque characteristics

Confirm whether the maximum torque "Ta1" and maximum torque occurrence speed "Nm" required for this acceleration/deceleration pattern calculated in the item "(b)" to "(d)" are in the short time operation range of the torque characteristics.



Motor torque characteristics

If they are not in the short time operation range, return to the item "(b)" to "(d)" and make the linear acceleration/deceleration time constant "ta" large.

If the acceleration specification cannot be changed (the linear acceleration/deceleration time constant cannot be increased), reconsider the selection, such as increasing the motor capacity.

- 1. In selecting the maximum torque "Ta1" required for this acceleration/deceleration pattern, the measure of it is 80% of the motor maximum torque " T_{MAX} "
- 2. In high-speed rotation range, confirm that the maximum torque "Ta1" and maximum torque occurrence speed "Nm" required for this acceleration/deceleration is in the short time operation range.



- 3. The drive system efficiency is normally approx. 0.95 in the ball screw mechanism and approx. 0.8 in the gear mechanism
- 4. For the torque characteristics in the motor high-speed rotation range, the AC input voltage is 200V (200V series) or 380V (400V series). If the input voltage is low or if the power wire connecting the servomotor and drive unit is long (20m length), the short time operation range is limited. In this case, an allowance must be provided for the selection of the high-speed rotation range.

(3) Continuous characteristics

A typical operation pattern is assumed, and the motor's continuous effective load torque (Trms) is calculated from the motor shaft conversion and load torque. If numbers <1> to <8> in the following drawing were considered a one cycle operation pattern, the continuous effective load torque is obtained from the root mean square of the torque during each operation, as shown in the expression (7-9).




Fig. 1 Continuous operation pattern

$$Trms = \sqrt{\frac{T1^2 \cdot t1 + T2^2 \cdot t2 + T3^2 \cdot t3 + T4^2 \cdot t4 + T5^2 \cdot t5 + T6^2 \cdot t6 + T7^2 \cdot t7 + T8^2 \cdot t8}{t0}} \quad \bullet \bullet \bullet \quad (7-9)$$

Select a motor so that the continuous effective load torque Trms is 80% or less of the motor stall torque Tst.

Trms
$$\leq 0.8 \cdot \text{Tst} \cdot (7-10)$$

The amount of acceleration torque (Ta) shown in tables 7-3 and 7-4 is the torque to accelerate the load inertia in a frictionless state. It can be calculated by the expression (7-11). (For linear acceleration/deceleration)

$$T_{a} = \frac{1.05 \times 10^{-2} \times (J_{L}/\eta + J_{M}) \times N}{t_{a}} \qquad (N \cdot m) \bullet \bullet \bullet (7-11)$$

For an unbalance axis, select a motor so that the motor shaft conversion load torque (friction torque + unbalance torque) is 60% or less of the stall.

$$TL \le 0.6 \cdot Tst \cdot (7-12)$$

: Drive system efficiency (Normally 0.8 to 0.95)

(a) Horizontal axis load torque

When operations [1] to [8] are for a horizontal axis, calculate so that the following torques are required in each period.

Table 7-3 Load torques of horizontal axes

Period	Load torque calculation method	Explanation
[1]	(Amount of acceleration torque) + (Kinetic friction torque)	Normally the acceleration/deceleration time constant is calculated so that this torque is 80% of the maximum torque of the motor.
[2]	(Kinetic friction torque)	
[3]	(Amount of deceleration torque) + (Kinetic friction torque)	The absolute value of the acceleration torque amount is same as the one of the deceleration torque amount. The signs for the amount of acceleration torque and amount of deceleration torque are reversed.
[4]	(Static friction torque)	Calculate so that the static friction torque is always required during a stop.
[5]	- (Amount of acceleration torque) - (Kinetic friction torque)	The signs are reversed with period <1> when the kinetic friction does not change according to movement direction.
[6]	- (Kinetic friction torque)	The signs are reversed with period <2> when the kinetic friction does not change according to movement direction.
[7]	- (Amount of deceleration torque) - (Kinetic friction torque)	The signs are reversed with period <3> when the kinetic friction does not change according to movement direction.
[8]	- (Static friction torque)	Calculate so that the static friction torque is always required during a stop.

(b) Unbalance axis load torque

When operations [1] to [8] are for an unbalance axis, calculate so that the following torques are required in each period. Note that the forward speed shall be an upward movement.

Table 7-4 Load torques of unbalance axes

Period	Load torque calculation method	Explanation
[1]	(Amount of acceleration torque) + (Kinetic friction torque) + (Unbalance torque)	Normally the acceleration/deceleration time constant is calculated so that this torque is 80% of the maximum torque of the motor.
[2]	(Kinetic friction torque) + (Unbalance torque)	
[3]	(Amount of deceleration torque) + (Kinetic friction torque) + (Unbalance torque)	The absolute value of the acceleration torque amount is same as the one of the deceleration torque amount. The signs for the amount of acceleration torque and amount of deceleration torque are reversed.
[4]	(Static friction torque) + (Unbalance torque)	The holding torque during a stop becomes fairly large. (Upward stop)
[5]	- (Amount of acceleration torque) - (Kinetic friction torque) + (Unbalance torque)	
[6]	- (Kinetic friction torque) + (Unbalance torque)	The generated torque may be in the reverse of the movement direction, depending on the size of the unbalance torque.
[7]	- (Amount of deceleration torque) - (Kinetic friction torque) + (Unbalance torque)	
[8]	- (Static friction torque) + (Unbalance torque)	The holding torque becomes smaller than the upward stop. (Downward stop)



During a stop, the static friction torque may constantly be applied. The static friction torque and unbalance torque may be applied during an unbalance axis upward stop, and the torque during a stop may become extremely large. Therefore, caution is advised.

7-1-3 Motor shaft conversion load torque

The calculation method for a representative load torque is shown.

Туре	Mechanism	Calculation expression
Linear movement	Servo- motor Z ₂ W	$T_L = \frac{F}{2\times 10^3\pi\eta} \cdot (\frac{V}{N}) = \frac{F\cdot\Delta S}{2\times 10^3\pi\eta}$ $T_L: \text{Load torque (N•m)}$ $F: \text{Force in axial direction of the machine that moves linearly (N)}$ $\eta: \text{ Drive system efficiency}$ $V: \text{Speed of object that moves linearly (mm/min)}$ $N: \text{Motor speed (r/min)}$ $\Delta S: \text{Object movement amount per motor rotation (mm)}$ $Z_1, Z_2: \text{Deceleration ratio}$ $F \text{ in the above expression is obtained from the expression below when the table is moved as shown on the left.}$ $F=Fc+\mu \text{ (W•g+F_0)}$ $F_c: \text{Force applied on axial direction of moving section (N)}$ $F_0: \text{Tightening force on inner surface of table guide (N)}$ $W: \text{Total mass of moving section (kg)}$ $g: \text{Gravitational acceleration} = 9.8 \text{ (m/s}^2)$ $\mu: \text{Friction coefficient}$
Rotary movement	Z ₁ Z ₂ Servomotor	$\begin{split} T_L &= \frac{Z_1}{Z_2} \cdot \frac{1}{\eta} \cdot T_{L0} + T_F = \frac{1}{n} \cdot \frac{1}{\eta} \cdot T_{L0} + T_F \\ T_L: \text{Load torque (N•m)} \\ T_{L0}: \text{Load torque on load shaft (N•m)} \\ T_F: \text{Motor shaft conversion load friction torque (N•m)} \\ \eta: \text{Drive system efficiency} \\ Z_1, Z_2: \text{Deceleration ratio} \\ \text{n:Deceleration ratio} \end{split}$
Vertical movement	Servomotor 1/n Load V W2	When rising $T_L = T_U + T_F$ When lowering $T_L = -T_U - \eta^2 + T_F$ T_L :Load torque (N-m) T_U :Unbalanced torque (N-m) T_F :Friction torque on moving section (N-m) $T_U = \frac{(W_1 - W_2) \cdot g}{2 \times 10^3 \pi \eta} \cdot (\frac{V}{N}) = \frac{(W_1 - W_2) \cdot g \cdot \Delta S}{2 \times 10^3 \pi \eta}$ $T_F = \frac{\mu \cdot (W_1 + W_2) \cdot g \cdot \Delta S}{2 \times 10^3 \pi \eta}$ W_1 :Load mass (kg) W_2 :Counterweight mass (kg) η : Drive system efficiency g :Gravitational acceleration = 9.8 (m/s²) V :Speed of object that moves linearly (mm/min) N :Motor speed (r/min) ΔS :Object movement amount per motor rotation (mm) μ :Friction coefficient

7-1-4 Expressions for load inertia calculation

The calculation method for a representative load inertia is shown.


Туре	Mechanism	Calculation expression
	Rotary shaft is cylinder center	$J_{L} = \frac{\pi \cdot \rho \cdot L}{32} \cdot (D_{1}^{4} - D_{2}^{4}) = \frac{W}{8} \cdot (D_{1}^{2} + D_{2}^{2})$
	φ D2.	T _L :Load inertia (kg•cm²)
		ρ: Density of cylinder material (kg/cm ³)
		L:Length of cylinder (cm)
	111	D ₁ :Outer diameter of cylinder (cm)
	(7<'>「)	D ₂ :Inner diameter of cylinder (cm)
		W:Mass of cylinder (kg)
Cylinder	Rotary shaft	<reference (material="" data="" densities)=""> Iron:7.80×10⁻³(kg/cm³) Aluminum:2.70×10⁻³(kg/cm³)</reference>
		Copper:8.96×10 ⁻³ (kg/cm ³)
	When rotary shaft and cylinder	$J_L = \frac{W}{8} \cdot (D^2 + 8R^2)$
	shaft are deviated	8
		J _L :Load inertia (kg•cm²)
		W:Mass of cylinder (kg)
		D:Outer diameter of cylinder (cm)
	Rotary shaft	R:Distance between rotary axis and cylinder axis (cm)
	R 🖊	$J_L = W(\frac{a^2 + b^2}{3} + R^2)$
		$JL = VV(\frac{3}{3} + R)$
Column	a a b b	J _L : Load inertia (kg•cm²)
		W:Mass of cylinder (kg)
	Rotary shaft	a,b,R:Left diagram (cm)
		$J_L = W(\frac{1}{2\pi N} \cdot \frac{V}{10})^2 = W(\frac{\Delta S}{20\pi})^2$
	N V	$3L - VV(\frac{1}{2\pi N} \cdot \frac{10}{10}) - VV(\frac{1}{20\pi})$
Object that moves		J _L :Load inertia (kg•cm²)
linearly	Servo manana mananana	W:Mass of object that moves linearly (kg)
	motor W	N:Motor speed (r/min)
		V:Speed of object that moves linearly (mm/min)
		ΔS:Object movement amount per motor rotation (mm)
	D	$J_L = W(\frac{D}{2})^2 + J_p$
Suspended object		J _L :Load inertia (kg•cm²)
		W:Object mass (kg)
	↓ W	D:Diameter of pulley (cm)
	"	Jp:Inertia of pulley (kg•cm²)
	Load B	$J_{L} = J_{11} + (J_{21} + J_{22} + J_{A}) \cdot \left(\frac{N_{2}}{N_{1}}\right)^{2} + (J_{31} + J_{B}) \cdot \left(\frac{N_{3}}{N_{1}}\right)^{2}$
Converted load	Servo	J _L :Load inertia (kg•cm²)
	motor J ₂₂ Load A	J _A ,J _B :Inertia of load A, B (kg•cm²)
	—	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1

J₁₁~J₃₁:Inertia (kg•cm²) N₁~N₃:Each shaft's speed (r/min)

7-2 Selection of the spindle motor

(1) Calculation of average output for spindle

In the machine which carries out the spindle's acceleration/deceleration frequently (example: tapping center), short-time rating is frequently used, and a rise in temperature become significant on the spindle motor or drive unit. Thus, calculate the average output (P_{AV}) from one cycle operation pattern and confirm that the calculated value is less than the continuous rating output of the selected spindle motor.



Output during acceleration/deceleration(kw) = Short-time rating ×1.2

Continuous operation pattern (example)

$$P_{AV} = \sqrt{\frac{P1^2 \cdot t1 + P2^2 \cdot t2 + P3^2 \cdot t3 + P4^2 \cdot t4 + P5^2 \cdot t5 + P6^2 \cdot t6 + P7^2 \cdot t7 + P8^2 \cdot t8}{t0}}$$

$$P1 \text{ to P8} \quad : \text{Output}$$

$$t1 \text{ to t8} \quad : \text{Time}$$

$$t0 \quad : \text{One cycle operation time}$$

Continuous rated output ≥ One cycle operation pattern average output (Pav)

 Calculate acceleration/deceleration time by the accurate load inertia because even if the rotation speed is the same, acceleration/deceleration time varies with a tool or workpiece mounted to the spindle.

Refer to the section "Adjusting the acceleration/deceleration operation" (1) in Instruction Manual.



2. Calculation method of synchronous tapping

The acceleration/deceleration number of times is twice, for forward run and reverse run are carried out in one machining. The output guideline is 50% of the short-time rating. The time is tapping time constant.

Calculation method of spindle synchronization
 The output guideline is 70% of the short-time rating. The time is spindle synchronization time constant.

7-3 Selection of the power supply unit

For the power supply unit, calculate the spindle motor output and servo motor output each, and select the capacity satisfying the required rated capacity and the maximum momentary output.

7-3-1 Calculation of spindle output

The spindle rated output and spindle maximum momentary rated output are calculated.

(1) Calculation of spindle rated output

The spindle rated output is calculated according to the following procedure.

(a) Spindle motor rated output

The spindle motor rated output is calculated from the following expression.

Spindle motor rated output =

MAX (continuous rated output, short-time rated output $\, x \,$ short-time rated output coefficient $\, \alpha \,$)

(Note) For the spindle motor rated output, use the larger one of "continuous rated output" and "short-time rated output x short-time rated output coefficient α ".

For the spindle short-time rated output coefficient α , use the value in the "table 1.".

Table1. List of short-time rated output time and short-time rated output coefficient

Short-time rated output time	Short-time rated out- put coefficient α	Short-time rated output time	Short-time rated output coefficient α
1 minute	0.2	5 minutes	0.7
2 minutes	0.4	6 to 7 minutes	0.8
3 minutes	0.5	8 to 9 minutes	0.9
4 minutes	0.6	10 minutes or more	1.0

- (Note1) Select the set time for the short-time rated output of your spindle motor from the list. E.g.) When the set time for the short-time rated output is "1/12h", it means "5 minutes".
- (Note2) For the motor with coil changeover specification, select the set time for the short-time rated output of the high-speed coil.

(b) Spindle rated output

The spindle rated output is calculated from the following expression.

Spindle rated output

=Spindle motor rated output x motor output coefficient β of the combined spindle drive unit

For the spindle motor rated output of the above expression, use the value calculated in (a).

For the motor output coefficient of the combined spindle drive unit, use the value corresponding to the used spindle drive unit in the table 2.

Table 2. Motor output coefficient list of combined spindle drive unit

< MDS-D Series >

Spindle motor			Con	nbined spir	ndle drive u	ınit MDS-D	-SP-		
rated output	20	40	80	160	200	240	320	400	640
~ 1.5kW	1.00	1.15	1.25	-	-	-	-	-	-
~ 2.2kW	-	1.00	1.15	1.30	-	-	-	-	-
~ 3.7kW	-	1.00	1.05	1.20	-	-	-	-	-
~ 5.5kW	-	-	1.00	1.10	1.20	-	-	-	-
~ 7.5kW	-	-	-	1.00	1.15	1.20	-	-	-
~ 11.0kW	-	-	-	1.00	1.05	1.10	1.15	-	-
~ 15.0kW	-	-	-	-	1.00	1.05	1.10	-	-
~ 18.5kW	-	-	-	-	1.00	1.00	1.05	1.10	-
~ 22kW	-	-	-	-	-	1.00	1.00	1.05	1.15
~ 26kW	-	-	-	-	-	-	1.00	1.00	1.10
~ 30kW	-	-	-	-	-	-	1.00	1.00	1.05
~ 37kW	-	-	-	-	-	-	-	1.00	1.05
~ 45kW	-	-	-	-	-	-	-	-	1.0
~ 55kW	-	-	-	-	-	-	-	-	1.0

< MDS-DH Series >

Spindle motor			Combine	d spindle dr	ive unit MD	S-DH-SP-		
rated output	20	40	80	100	160	200	320	480
~ 2.2kW	1.00	1.15	1.30	-	-	-	-	-
~ 3.7kW	1.00	1.05	1.20	-	-	-	-	-
~ 5.5kW	-	1.00	1.10	1.20	-	-	-	-
~ 7.5kW	-	-	1.00	1.15	-	-	-	-
~ 11.0kW	-	-	1.00	1.05	1.15	-	-	-
~ 15.0kW	-	-	-	1.00	1.10	-	-	-
~ 18.5kW	-	-	-	1.00	1.05	1.10	-	-
~ 22kW	-	-	-	-	1.00	1.05	1.15	-
~ 26kW	-	-	-	-	1.00	1.00	1.10	1.20
~ 30kW	-	-	-	-	1.00	1.00	1.05	1.15
~ 37kW	-	-	-	-	-	1.00	1.05	1.10
~ 45kW	-	-	-	-	-	-	1.00	1.05
~ 55kW	-	-	-	-	-	-	1.00	1.00
~ 75kW	-	-	-	-	-	-	-	1.00



- 1. When the spindle motor applies to the wide range constant output specification or the high-torque specification, the spindle rated output may become large.
- 2. The spindle rated output is calculated from the motor output coefficient of the spindle drive unit used in combination with the spindle motor.

(2) Calculation of spindle maximum momentary output

The spindle maximum momentary output is calculated from the following expression.

Spindle maximum momentary output

=MAX (short-time rated output x 1.2, output at acceleration/deceleration x 1.2)

(Note) For the spindle rated output, use the larger one of "short-time rated output x 1.2" and "output at acceleration/deceleration x 1.2".

7-3-2 Calculation of servo motor output

(1) Selection with rated output

(2) Selection with maximum momentary output

For the rated output and maximum momentary output of the servo motor, use the value corresponding to the servo motor in the table 3.

Table 3. Data for servo motor output selection

< 200V series >

Motor HF	75	105	54	104	154	224	204	354		
Rated output (kW)	0.75	1.0	0.5	1.0	1.5	2.2	2.0	3.5	•	
Maximum momentary output (kW)	2.6	3.6	2.3	5.0	9.0	12.3	8.0	18.0		
Motor HP	123	223	303	453	703	903	142	302		
Rated output (kW)	1.2	2.2	3.0	4.5	7.0	9.0	1.4	3.0	_	
Maximum momentary output (kW)	4.0	7.5	12.0	22.0	28.0	41.0	3.8	7.4	-	
Motor HP	54	104	154	224	204	354	454	704	903	1103
Rated output (kW)	0.5	1.0	1.5	2.2	2.0	3.5	4.5	7.0	9.0	11.0
Maximum momentary output		1.0	1.0	2.2	2.0	0.0	4.0	7.0	5.0	11.0
(kW)	2.3	4.3	8.0	11.0	11.0	15.0	21.0	27.0	33.0	50.0
Motor HF-KP	23	43	73	1						
	-		-							
Rated output (kW)	0.2	0.4	0.75	_						
Maximum momentary output										

< 400V series >

Motor HF-H	75	105	54	104	154	204	354	453	703	903
Rated output (kW)	0.75	1.0	0.5	1.0	1.5	2.0	3.5	4.5	7.0	9.0
Maximum momentary output (kW)	2.6	3.6	2.3	5.0	9.0	8.0	18.0	22.0	28.0	41.0
Mater IID II	FA	404	454	201	204	254	454	704	000	4400
Motor HP-H	54	104	154	224	204	354	454	704	903	1103
Rated output (kW)	0.5	1.0	1.5	2.2	2.0	3.5	4.5	7.0	9.0	11.0
Maximum momentary output (kW)	2.3	4.3	8.0	11.0	11.0	15.0	21.0	27.0	33.0	50.0

Motor HC-H	1502S-S10
Rated output (kW)	15.0
Maximum momentary output (kW)	59.0

(Note) The maximum momentary output in this table is reference data for selecting the power supply unit and is not data which guarantees the maximum output.

7-3-3 Selection of the power supply unit

Select the power supply unit from the total sum of the rate output and the maximum momentary output.

(1) Calculation of required rated output

(a) When there is only one servomotor axis

Power supply unit rated capacity $> \Sigma$ (Spindle rated output) + (Servomotor rated output)

(b) When there are two or more servomotor axes

Power supply unit rated capacity $> \Sigma$ (Spindle rated output) + 0.7 Σ (Servomotor rated output)

Substitute the output calculated from "7-2-1(1)" and "7-2-2(1)" to the expression (a) and (b), and calculate the total sum of the spindle rated output and servo motor rated output. According to this, select the power supply unit satisfying the rated capacity from the table 4.

(2) Calculation of required maximum momentary output

Maximum momentary rated capacity of power supply unit ≧

 Σ (Spindle maximum momentary output) + Σ (Maximum momentary output of servomotor accelerating/ decelerating simultaneously)

Substitute the output calculated from "7-2-1(2)" and "7-2-2(2)" to the above expression, and calculate the total sum of the "spindle maximum momentary output" and "output of servomotor accelerating/ decelerating simultaneously". According to this, select the power supply unit satisfying the maximum momentary rated capacity from the table 4.

(3) Selection of power supply unit

Select the power supply unit of which the capacity is larger than that selected in the item (1) and (2).

Table 4. Power supply unit rated capacity and maximum momentary rated capacity

< MDS-D Series >

Unit	MDS-D-CV-	37	75	110	185	300	370	450	550
Rated	capacity (kW)	4.2	8	11.5	19	31	38	46	56
Maximum mom	entary rated capacity (kW)	16	23	39	60	92	101	125	175

< MDS-DH Series >

Unit	MDS-DH-CV-	37	75	110	185	300	370	450	550	750
Rated	capacity (kW)	4.2	8	11.5	19	31	38	46	56	76
Maximum momen	tary rated capacity (kW)	16	23	39	60	92	101	125	175	180

1. When two or more servomotor axes are connected, do the calculation with the largest rated capacity of the servomotor if a value obtained by multiplying the total sum of the servomotor rated output by "0.7" is smaller than the largest rated capacity of the servomotors.

Example: HF Series

- (1)For "HF903 (9.0kW) + HF104 (1.0kW)", " $0.7 \times (9.0 + 1.0) = 7.0 < 9.0$ " is applied.
 - So, do the calculation with applying "9.0kW" to the total sum of the servomotor's rated output.
- (2) For "HF903 (9.0kW) + HF903 (9.0kW)", "0.7 x (9.0 + 9.0) = 12.6 > 9.0" is applied.
- So, do the calculation with applying "12.6kW" to the total sum of the servomotor's rated output. Example: HF-H Series
- (1)For "HF-H903 (9.0kW) + HF-H104 (1.0kW)", " $0.7 \times (9.0 + 1.0) = 7.0 < 9.0$ " is applied.
 - So, do the calculation with applying "9.0kW" to the total sum of the servomotor's rated output.
- (2)For "HF-H903 (9.0kW) + HF-H903 (9.0kW)", "0.7 x (9.0 + 9.0) = 12.6 > 9.0" is applied.
 - So, do the calculation with applying "12.6kW" to the total sum of the servomotor's rated output.

CAUTION!

- 2. When reducing the time constant replacing the conventional motor with the HF, HP, HF-KP, HF-H, HP-H or HC-H Series motor, the power supply capacity may rise because the motor maximum momentary output increases more than the conventional motor. Therefore, make sure to check the selection with maximum momentary rated capacity.
- 3. When the large capacity drive unit (MDS-D-SP-400/640, MDS-DH-SP-200/320/450, MDS-DH-V1-200) is connected to the power supply unit, always install the drive unit proximally in the left side of the power supply unit and connect PN terminal with the dedicated DC connection bar.
- 4. When using two large capacity drive units or more, the power supply unit is required for each drive unit.
- 5. This power supply selection is calculated with the servomotor effective load rate of approximate 80%. Considering the operation pattern, if the servomotor effective load rate is lower than this, the required rated capacity of the power supply can be decreased.

7-3-4 Required capacity of power supply

For the power supply capacity, calculate the required spindle rated output and servo motor rated output each, and select the power supply capacity satisfying them.

(1) Spindle rate output required for power supply

The spindle rate output required for power supply is calculated from the following expression.

Spindle rate output required for power supply =

MAX (Spindle motor continuous rated output, Spindle motor output at accelerating/decelerating, Spindle motor short-time output) x motor output coefficient β of combined spindle drive unit

(Note) For the spindle rate output required for the power supply, multiply the largest one of "spindle motor continuous rate output", "spindle motor output at acceleration/deceleration" and "spindle motor short-time output" by the motor output coefficient β of the combined spindle drive unit.

For the motor output coefficient of the combined spindle drive unit, use the value corresponding to the used spindle drive unit in the table 2. of 7-2-1 (1).

(2) Servo motor rate output required for power supply

For the servo motor rate output required for power supply, use the value calculated in 7-2-2 (1).

(3) Calculation of rate output required for power supply

(a) When there is only one servomotor axis

Rated capacity required for power supply =

 Σ (Spindle rate output required for power supply) + (servo motor rate output required for power supply)

(b) When there are two or more servomotor axes

Rated capacity required for power supply =

 Σ (Spindle rate output required for power supply) + 0.7 Σ (servo motor rate output required for power supply)

Substitute the output calculated from the item (1) and (2) to the expression (a) and (b), and calculate the rated capacity required for the power supply.

(4) Calculation of required power supply

Power supply capacity (kVA) = Σ {(Required rated capacity calculated in the item (3)(kW) / Capacity of selected power supply unit (kW)) x Power supply capacity base value (kVA)}

The power supply capacity base value corresponding to the capacity of the selected power supply unit is as the following table.

< MDS-D Series >

Unit	MDS-D-CV-	37	75	110	185	300	370	450	550
Power supply capacity base value (kVA)		5.3	11.0	16.0	27.0	43.0	53.0	64.0	78.0

< MDS-DH Series >

Unit	MDS-DH-CV-	37	75	110	185	300	370	450	550	750
Power supply ca	5.3	11.0	16.0	27.0	43.0	53.0	64.0	78.0	107.0	

7-3-5 Example for power supply unit and power supply facility capacity

< MDS-D Series >

(Example 1)

Axis name	Motor	Drive unit	Rated output	Maximum momentary output	
X-axis	HF354	(MDS-D-V2-160160)	3.5kW	18kW	
Y-axis	HF354	(MDS-D-V2-160160)	3.5kW	18kW	
Z-axis	HF354	(MDS-D-V1-160)	3.5kW	18kW	
Spindle	Spindle motor 22kW	MDS-D-SP-320 (Output coefficient 1.0)	22kW	26.4kW	
	Total		0.7 x (3.5 x 3) + 22 = 29.35kW < 31kW (D-CV-300)	(18 x 3) + 26.4 = 80.4kW < 92kW (D-CV-300)	

The power supply unit satisfying the total of the rate output and the maximum momentary output is MDS-D-CV-300.

Required power supply capacity (kVA) = $(29.35 / 30) \times 43 = 42.1 \text{ (kVA)}$

(Example 2)

Axis name	Motor	Drive unit	Rated output	Maximum momentary output
X1-axis	HF453	(MDS-D-V2-160160)	4.5kW	22kW
X2-axis	HF453	(MDS-D-V2-160160)	4.5kW	22kW
Y-axis	HF354	(MDS-D-V2-160160)	3.5kW	18kW
Z-axis	HF354	(MDS-D-V2-160160)	3.5kW	18kW
Spindle	Spindle motor 15kW	MDS-D-SP-200 (Output coefficient 1.0)	15kW	18kW
	Total		0.7 x (4.5 x 2 + 3.5 x 2) + 15 = 26.2kW < 31kW (D-CV-300)	22 x 2 + 18 x 2 + 18 = 98.0kW < 101kW (D-CV-370)

The power supply unit satisfying the total of the rate output and the maximum momentary output is MDS-D-CV-370.

Required power supply capacity (kVA) = $(26.2 / 37) \times 53 = 37.5$ (kVA)

(Example 3))

Axis name	Motor	Drive unit	Rated output	Maximum momentary output	
X-axis	HF354	MDS-D-V1-160	3.5kW	18kW	
Y-axis	HF204	MDS-D-V2-8080	2.0kW	8kW	
Z-axis	HF204	MDS-D-V2-8080	2.0kW	8kW	
Spindle	Spindle motor 15kW (High-torque motor)	MDS-D-SP-320 (Output coefficient 1.1)	16.5kW	18kW	
	Total		0.7 x (3.5 + 2.0 x 2) + 16.5 = 21.75kW < 31kW (D-CV-300)	18 + 8 x 2 + 18 = 52kW < 60kW (D-CV-185)	

The power supply unit satisfying the total of the rate output and the maximum momentary output is MDS-D-CV-300.

Required power supply capacity (kVA) = $(21.75 / 30) \times 43 = 31.2 \text{ (kVA)}$

< MDS-DH Series > (Example 1)

Axis name	Motor	Drive unit	Rated output	Maximum momentary output	
X-axis	HF-H354	(MDS-DH-V2-8080)	3.5kW	18kW	
Y-axis	HF-H354	(MDS-DH-V2-8080)	3.5kW	18kW	
Z-axis	HF-H354	(MDS-DH-V1-80)	3.5kW	18kW	
Spindle	Spindle motor 22kW	MDS-DH-SP-160 (Output 22kW)	22kW	26.4kW	
	Total		0.7×(3.5×3)+22 =29.35kW <31kW(DH-CV-300)	(18×3)+26.4 =80.4kW <92kW(DH-CV-300)	

The power supply unit satisfying the total of the rate output and the maximum momentary output is MDS-DH-CV-300.

Required power supply capacity (kVA) = $(29.35 / 30) \times 43 = 42.0 \text{ (kVA)}$

(Example 2)

Axis name	Motor	Drive unit	Rated output	Maximum momentary output
X1-axis	HF-H453	(MDS-DH-V2-8080)	4.5kW	22kW
X2-axis	HF-H453	(MDS-DH-V2-8080)	4.5kW	22kW
Y-axis	HF-H354	(MDS-DH-V2-8080)	3.5kW	18kW
Z-axis	HF-H354	(MDS-DH-V2-8080)	3.5kW	18kW
Spindle	Spindle motor 15kW	MDS-DH-SP-100 (Output coefficient 1.0)	15kW	18kW
	Total		0.7x(4.5x2+3.5x2)+15 =26.2kW <31kW(DH-CV-300)	22x2+18x2+18 =98.0kW <101kW(DH-CV-370)

The power supply unit satisfying the total of the rate output and the maximum momentary output is MDS-DH-CV-370.

Required power supply capacity (kVA) = $(26.2 / 30) \times 43 = 37.6 \text{ (kVA)}$

(Example 3)

Axis name	Motor	Drive unit	Rated output	Maximum momentary output
X-axis	HF-H354	MDS-DH-V1-160	3.5kW	18kW
Y-axis	HF-H204	MDS-DH-V2-8080	2.0kW	8kW
Z-axis	HF-H204	MDS-DH-V2-8080	2.0kW	8kW
Spindle	Spindle motor 15kW (High-torque motor)	MDS-DH-SP-320 (Output coefficient 1.1)	16.5kW	18kW
	Total		0.7×(3.5+2.0×2)+16.5 =21.75kW <31kW(DH-CV-300)	18+8×2+18 =52kW <60kW(DH-CV-185)

The power supply unit satisfying the total of the rate output and the maximum momentary output is MDS-DH-CV-370.

Required power supply capacity (kVA) = (21.75 / 30) x 43 = 31.2 (kVA)

Appendix 1

Cable and Connector Specifications

Appendix 1-1 Selection of cable

Appendix 1-1-1 Cable wire and assembly

(1) Cable wire

The specifications of the wire used for each cable, and the machining methods are shown in this section. When manufacturing the detector cable and battery connection cable, use the recommended wires shown below or equivalent products.

(a) Heat resistant specifications cable

						Wire cha	racteristics		
Wire type (other manufactur- er's product)	Finish outer diameter	Sheath material	No. of pairs	Configura- tion	Conduc- tive resistor	With- stand voltage	Insulation resistance	Heat resistance tempera- ture	Flexibility 70×10 ⁴ times or more at R200
BD20288 Compound 6-pair shielded cable	8.7mm	Heat re-	2 (0.5mm ²)	100 strands/ 0.08mm	40.7Ω/km or less	500VAC/	1000 MΩ/km	105°C	
Specification No. Bangishi-17145 (Note 1)	0.711111	PVC	4 (0.2mm ²)	40 strands/ 0.08mm	103Ω/km or less	1min	or more	100 0	

(b) General-purpose heat resistant specifications cable

						Wire cha	racteristics			
Wire type (other manufactur- er's product)	Finish outer diameter	Sheath material	No. of pairs	Configura- tion	Conductive resistor	With- stand voltage	Insulation resistance	Heat resistance tempera-ture	Flexibility	
BD20032 Compound 6-pair				2 (0.5mm ²)	100strands/ 0.08mm	40.7Ω/km or less		4000		
shielded cable Specification No. Bangishi-16903 Revision No. 3 (Note 2))		PVC	4 (0.2mm ²)	40strands/ 0.08mm	103Ω/km or less	500VAC/ 1min	1000 MΩ/km or more	60°C	100×10 ⁴ times or more at R200	

(Note 1) Bando Electric Wire (Contact: 81+48-461-0561 http://www.bew.co.jp)

(Note 2) The Mitsubishi standard cable is the (a) Heat resistant specifications cable. For MDS-C1/CH series, (b) or equivalent is used as the standard cable.

Cable core

Cable core

L1

L2


Conductor Insulator

Core identification

Pair No.	Insulate	or color
i ali No.	L1	L2
A1 (0.5mm ²)	Red	White
A2 (0.5mm ²)	Black	White
B1 (0.2mm ²)	Brown	Orange
B2 (0.2mm ²)	Blue	Green
B3 (0.2mm ²)	Purple	White
B4 (0.2mm ²)	Yellow	White


(2) Cable assembly

Assemble the cable with the cable shield wire securely connected to the ground plate of the connector.



(3) Battery connection cable

	Finish					Wire ch	aracteristics		
Wire type (other manufactur- er's product)	outer diame- ter	Sheath material	No. of pairs	Configura- tion	Conduc- tive resistor	With- stand voltage	Insulation resistance	Heat resistance temperature	Minimum bend radius
J14B101224-00 Two core shield ca- ble	3.3mm	PVC	1 (0.2mm ²)	7strands / 0.2mm	91.2Ω/km or less	AC500V/ 1min	1000MΩ/ km or less	80°C	R33mm



Two core shield cable structure drawing

Core identification

No.	Insulator color
1	Red
2	Black

Appendix 1-2 Cable connection diagram


⚠ CAUTION

- 1. Take care not to mistake the connection when manufacturing the detector cable. Failure to observe this could lead to faults, runaway or fire.
- 2. When manufacturing the cable, do not connect anything to pins which have no description.


Appendix 1-2-1 Battery cable

<DG21 cable connection diagram</p>


(Connection cable between drive unit and MDS-A-BT/A6BAT (MR-BAT) (MDS-BTCASE)>



<DG22 cable connection diagram (Connection cable between drive unit and drive unit)>




<DG23 cable connection diagram (Connection cable between drive unit and MDS-BTBOX-36)>



<DG24 cable connection diagram

(Connection cable for alarm output between drive unit and MDS-BTBOX-36)>







When DG24 cable is used, proximity switch or external emergency stop cannot be wired, so these functions cannot be used.

Appendix 1-2-2 Power supply communication cable and connector

<SH21 cable connection diagram>




<CNU23S connector connection diagram>




Appendix 1-2-3 Optical communication repeater unit cable

< F070 cable connection diagram >





< F110 cable connection diagram >




Appendix 1-2-4 Servo / tool spindle detector cable

<CNV2E-6P, CNV2E-7P cable connection diagram>






<CNV2E-8P, CNV2E-9P cable connection diagram>



<For 15m or less>




< CNV2E-K1P, CNV2E-K2P cable connection diagram (Direct connection type) >

Servo drive unit side connector

(3M) Receptacle : 36210-0100PL Shell kit : 36310-3200-008 (MOLEX) Connector set: 54599-1019

Servo motor detector connector (Tyco Electronics)

Connector: 1674320-1




< CNV22J-K1P, CNV22J-K2P cable connection diagram (Relay type) >

Drive unit side connector (DDK)


Plug: CM10-CR10P-M

Motor detector/ Ball screw side detector side connector (Tyco Electronics)


Plug: 1747464-1 Contact: 1674335-4



<CNV2E-HP cable connection diagram>




<CNV2E-D cable connection diagram>



<Cable connection diagram between scale I/F unit and scale (CNLH3 cable, etc.) >


Detector conversion unit side connector (Hirose Electric)

Plug: RM15WTP-12P Clamp: RM15WTP-CP (10)



(Note) This cable must be prepared by the user.


<Rectangular wave communication detector (linear scale, etc.) cable connection diagram>



Contact the detector manufacture for the details.

(Note) This cable must be prepared by the user.

<Serial communication detector (linear scale, etc.) cable connection diagram>



Contact the detector manufacture for the details.

(Note) This cable must be prepared by the user.



For compatible detector, refer to the section "Servo option" in Specifications Manual.

Appendix 1-2-5 Brake connector (Brake connector for motor brake control output)

<CNU20S connector connection diagram>


• For MDS-D-V1-320 or smaller and MDS-DH-V1-160 or smaller



• For MDS-D-V1-320W or larger and MDS-DH-V1-160W or larger




<MR-BKS1CBL□M-A1-H, MR-BKS1CBL□M-A2-H cable connection diagram>




Appendix 1-2-6 Spindle detector cable

<CNP2E-1 cable connection diagram>



(Note) For the pin "7" or "8", use the contact "170364-1". For the other pins, use the contact "170363-1".


<For 15m or less>




(Note) For the pin "7" or "8", use the contact "170364-1". For the other pins, use the contact "170363-1".

<For 15m to 30m>

<CNP3EZ-2P, CNP3EZ-3P cable connection diagram>






Appendix 1-3 Main circuit cable connection diagram

The methods for wiring to the main circuit are shown below.

<DRSV1/DRSV2 cable connection diagram>


These cables are used to connect the drive unit's TE1 terminal and HF, HP, HF-H, HP-H series motor.

- DRSV1 cable: This is the power line for the single-axis unit (MDS-D/DH-V1-) and dual-axis integrated unit (MDS-D/DH-V2-) L axis.
- DRSV2 cable: This is the power line for the dual-axis integrated unit (MDS-D/DH-V2-) M axis.



<HF-KP motor cable connection diagram>

This cable is used to connect the drive unit's TE1 terminal and HF-KP series motor.



1. The main circuit cable must be manufactured by the user.



- 2. Refer to the section "Specification of Peripheral Devices" in Specifications Manual when selecting the wire material.
- 3. Lay out the terminal block on the drive unit side as shown in "DRIVE SYSTEM DATA BOOK".
- 4. Refer to "DRIVE SYSTEM DATA BOOK" for details on the motor's connectors and terminal block.

Appendix 1-4 Connector outline dimension drawings

Appendix 1-4-1 Connector for drive unit

Optical communication cable connector


Optical communication connector

[Unit:mm]

For wiring between drive units (inside panel)

Manufacturer: Japan Aviation Electronics Industry
<Type>

Connector:2F-2D103



(15) (13.4)


Cable appearance

<Type>

Connector: 2F-2D103 (Japan Aviation

Electronics Industry)
Optical fiber: ESKA Premium

(MITSUBISHI RAYON)





(Note 1) The POF fiber's light amount will drop depending on how the fibers are wound. So, try to avoid wiring the fibers.

(Note 2) Do not wire the optical fiber cable to moving sections.

[Unit:mm]

For wiring between drive units (outside


panel)

Manufacturer: Tyco Electronics

<Type>

Connector: 1123445-1







Cable appearance

<Type>

Connector: 1123445-1 (Tyco Electronics)

Optical fiber: ESKA Premium (MITSUBISHI RAYON)



(Note 1) The PCF fiber's light amount will drop depending on how the fibers are wound. So, try to avoid wiring the fibers.

(Note 2) Do not wire the optical fiber cable to moving sections.

For wiring between NC and drive unit

Refer to the instruction manual for CNC.

Connector for detector cable

Spindle drive unit Connector for CN2/3

[Unit:mm]


Manufacturer: 3M

<Type>

Receptacle: 36210-0100PL Shell kit: 36310-3200-008 Manufacturer: MOLEX

<Type>

Connector set: 54599-1019



Connector for CN4/9


Connector for CN4/9

[Unit:mm]

Manufacturer: 3M

<Type>

Connector: 10120-3000VE Shell kit: 10320-52F0-008



[Unit:mm]


Manufacturer: 3M

<Type>

Connector: 10120-6000EL Shell kit:10320-3210-000

This connector is integrated with the cable, and is not available as a connector

set option.





Motor power connector


Power connector for drive unit TE1

[Unit:mm]

Manufacturer: DDK

<Type>

Housing: DK-5200S-04R



Connector for motor brake control output


Brake connector for motor brake control output

[Unit:mm]

Manufacturer: DDK

<Type>

Connector: DK-3200S-03R



Power supply unit connector for CN23 (Contactor control output / external emergency stop)


Power supply unit connector for CN23 (Connector for contactor control output / external emergency stop)

[Unit:mm]

Manufacturer: DDK

<Type>

Connector: DK-3200M-06RXY



Battery power input connector


Battery connector for drive unit

[Unit:mm]

Manufacturer: Hirose Electric

<Type>

Connector: DF1B-2S-2.5R



Appendix 1-4-2 Connector for servo and tool spindle

Motor detector connector


Motor side detector connector / Ball screw side detector for connector

[Unit:mm]

Manufacturer: DDK

<Type>

Plug:CM10-SP10S-M(D6)




[Unit:mm]

Manufacturer: DDK

<Type>


Plug:CM10-AP10S-M(D6)





(Note) For the manufacturing method of CM10 series connector, refer to the section "Cable and connector assembly" in Instruction Manual.

Motor side detector connector

[Unit:mm]







Manufacturer: Tyco Electronics

<Type>

Assembly: 1674320-1

Appendix 1 Cable and Connector Specifications

Brake connector


Brake connector

[Unit:mm]

Manufacturer: DDK

<Type>

Plug: CM10-SP2S-S(D6)




[Unit:mm]

Manufacturer: DDK

<Type>


Plug: CM10-AP2S-S(D6)



(Note) For the manufacturing method of CM10 series connector, refer to the section "Cable and connector assembly" in Instruction Manual.

[Unit:mm]

Manufacturer: Japan Aviation Electronics Industry
<Type>
JN4FT02SJ1-R



Reinforcing cover for connector

Reinforcing cover for connector

[Unit:mm]




Manufacturer: DDK


<Type>

Reinforcing cover for straight plug:

CM10-SP-CV



[Unit:mm]





Manufacturer: DDK

<Type>

Reinforcing cover for angle plug:

CM10-AP-D-CV





- (Note 1) For the manufacturing method of CM10 series connector, refer to the section "Cable and connector assembly" in Instruction Manual.
- (Note 2) Use the reinforcing cover if thumping vibration and strong impacts could be applied on the connector.


Appendix 1 Cable and Connector Specifications

Motor power connector

Motor power connector

[Unit:mm]

Manufacturer: DDK




Plug:

Type	Δ	В	+0	C±0.8	D or less	w
Туре			-0.38	010.0	D 01 1033	••
CE05-6A18-10SD-C-BSS	1 ¹ / ₈ -18UNEF-2B	3	34.13	32.1	57	1-20UNEF-2A
CE05-6A22-22SD-C-BSS	1 ³ / ₈ -18UNEF-2B	40.48		38.3	61	1 ³ / ₁₆ -18UNEF-2A
CE05-6A32-17SD-C-BSS	2-18UNS-2B	5	6.33	54.2	79	1 ³ / ₄ -18UNS-2A

[Unit:mm]

Manufacturer: DDK




Plug:

Туре	Α	В	+0 -0.38	D or less	w	R±0.7	U±0.7	(S)±1	Y or more
CE05-8A18-10SD-C-BAS	1 ¹ / ₈ -18UNEF-2B	3	34.13	69.5	1-20UNEF-2A	13.2	30.2	43.4	7.5
CE05-8A22-22SD-C-BAS	1 ³ / ₈ -18UNEF-2B	40.48		75.5	1 ³ / ₁₆ -18UNEF-2A	16.3	33.3	49.6	7.5
CE05-8A32-17SD-C-BAS	2-18UNS-2B	5	6.33	93.5	1 ³ / ₄ -18UNS-2A	24.6	44.5	61.9	8.5

[Unit:mm]

Manufacturer: DDK




Clamp:

Туре	Shel I size	Total length A	Outer dia. B	Avail. screw length C	D	E	F	G	н	Fitting screw V	Bushing	Applicable cable
CE3057-10A-1(D240)	18	23.8	30.1	10.3	41.3	15.9	14.1	31.7	3.2	1-20UNEF-2B	CE3420-10-1	φ10.5 to φ14.1
CE3057-12A-1(D240)	20	23.8	35	10.3	41.3	19	16.0	37.3	4	1 ³ / ₁₆ -18UNEF-2B	CE3420-12-1	φ12.5 to φ16.0
CE3057-20A-1(D240)	32	27.8	51.6	11.9	43	31.7	23.8	51.6	6.3	1 ³ / ₄ -18UNS-2B	CE3420-20-1	φ22.0 to φ23.8

Motor power connector

[Unit:mm]

Manufacturer: Japan Aviation Electronics Industry
<Type>
JN4FT04SJ1-R



MDS-B-HR connector


MDS-B-HR connector

[Unit:mm]

Manufacturer: Hirose Electric

<Type>
Plug:

RM15WTP-8S (for CON1,2) RM15WTP-12P (for CON3)




[Unit:mm]

Manufacturer: Hirose Electric

<Type>

Clamp: RM15WTP-CP(10)



Appendix 1-4-3 Connector for spindle


Motor detector connector

Motor side PLG (TS5690) connector

[Unit:mm]

Manufacturer: Tyco Electronics

<Type>
Plug: 172169-1



Appendix 1 Cable and Connector Specifications


Spindle side detector connector (for OSE-1024)

Spindle side detector connector (for OSE-1024) [Unit:mm] Gasket | 18.26±0.12 | 1 / 4-18UNEF-2B |

Manufacturer: DDK

<Type>

Connector: MS3106A20-29S(D190)




[Unit:mm]

Manufacturer: DDK

<Type>

Straight back shell: CE02-20BS-S




[Unit:mm]

Manufacturer: DDK

<Type>

Angle back shell: CE-20BA-S




[Unit:mm]

Manufacturer: DDK

<Type>

Cable clamp:CE3057-12A-3



Appendix 2

Restrictions for Lithium Batteries

Appendix 2 Restrictions for Lithium Batteries

Appendix 2-1 Restriction for Packing

The United Nations Dangerous Goods Regulations "Article 12" became effective from 2003. When transporting lithium batteries with means subject to the UN Regulations, such as by air transport, measures corresponding to the Regulations must be taken.

The UN Regulations classify the batteries as dangerous goods (Class 9) or not dangerous goods according to the lithium metal content. To ensure safety during transportation, lithium batteries (battery unit) directly exported from Mitsubishi are packaged in a dedicated container (UN package) for which safety has been confirmed. When the customer is transporting these products with means subject to the UN Regulations, such as air transport, the shipper must follow the details explained in the section "Transportation Restrictions for Lithium Batteries: Handling by User".

The followings are restrictions for transportation. Each restriction is specified based on the recommendation of the United Nations.

Area	Transportation method	Restriction	Special clause
World	Air	ICAO, IATA	-
World	Marine	IMO	188
United States	All (air, marine, land)	DOT	49 CFR 173.185
Europe	land	RID, ADR	188

Appendix 2-1-1 Target Products

The following Mitsubishi NC products use lithium batteries. If the lithium metal content exceeds 1g for battery cell and 2g for battery, the battery is classified as dangerous good (Class9).

In order to avoid an accidental actuation during the transportation, all lithium battery products incorporated in a machinery or device must be fixed securely and must be shipped with wrapped over the outer package as to prevent damage or short-circuits.

(1) Materials falling under Class 9


Mitsubishi type (Type for arrangement)	Battery type	Lithium metal content	Number of incorporated ER6V batteries	Application (Data backup)	Battery class	Outline dimension drawing
MDS-A-BT-4	ER6-B4-11	2.6g	4 batteries	For servo detector		
MDS-A-BT-6	ER6-B6-11	3.9g	6 batteries	For servo detector		Refer to "Battery Op-
MDS-A-BT-8	ER6-B8-11	5.2g	8 batteries	For servo detector	Battery	tion" in the specifica-
FCU6-BT4-D1	Combination of ER6-B4D-11 and ER6V battery cell	2.6g+0.65g	5 batteries	For servo detector/ NC SRAM	Dationy	tion manual for drive unit you are using for the outline dimension
CR23500SE-CJ5	CR23500SE-CJ5	1.52g	-	For NC SRAM (M500)	Battery cell	drawing for servo.

(2) Materials not falling under Class 9

Mitsubishi type (Type for arrangement)	Battery type	Lithium metal content	Number of incorporated ER6V batteries	Application (Data backup)	Battery class	Outline dimension drawing
MDS-A-BT-2	ER6-B2-12	1.3g	2 batteries	For servo detector		
FCU6-BTBOX series	2CR5	1.96g	-	For NC SRAM/ servo detector	Battery	
CR2032 (for built-in battery)	CR2032	0.067g	-	For NC SRAM/		Refer to "Battery Op-tion" in the specifica-
CR2450 (for built-in battery)	CR2450	0.173g	-	For NC SRAM	Dettem	tion manual for drive unit you are using for
ER6, ER6V series (for built-in battery)	ER6, ER6V	0.65g	-	For NC SRAM/ servo detector	Battery cell	the outline dimension drawing for servo.
A6BAT(MR-BAT)	ER17330V	0.48g	-	For servo detector		
Q6BAT	Q6BAT	0.49g	-	For NC SRAM		
MR-J3BAT	ER6V	0.65g	-	For servo detector		

(Note) If the number of batteries exceeds 24 batteries for the battery cell or 12 batteries for the battery, the dedicated packing (for materials falling under Class 9) is required.

(Example) Rating nameplate for battery units



Appendix 2-1-2 Handling by User

The following technical opinion is solely Mitsubishi's opinion. The shipper must confirm the latest IATA Dangerous Goods Regulations, IMDG Codes and laws and orders of the corresponding export country. These should be checked by the company commissioned for the actual transportation.

IATA: International Air Transport Association

IMDG Code: A uniform international code for the transport of dangerous goods by seas determined by IMO (International Maritime Organization).

■ When shipping isolated lithium battery products

- (1) Reshipping in Mitsubishi UN packaging (Class 9) Mitsubishi packing applies package specifications complying with the UN Packing Instruction. The user only needs to add the following details before shipping. (Consult with the shipping company for details.)
 - (a) Indication of container usage mark on exterior box (Label with following details recorded.)
 - [1] Proper shipping name (Lithium batteries)
 - [2] UN NO. (UN3090 for isolated battery, UN3091 for battery incorporated in a device or included)
 - [3] Shipper and consignee's address and name

Example of completing form

SHIPPER:			CONSIGNEE:
Shipper info	ormation		Consignee information
PROPER SHIPPING NAME	LITHIUM B	BATTERIES	
UN NO.: UN3090	CLASS: 9	SUBSIDIARY	RISK
PACKING GROUP: 11	PACKING 1	INST.: 903	

Appendix 2 Restrictions for Lithium Batteries

[4] A care label with a telephone number for additional information (120×110mm) (A care label is to be attached on the outer package. Shipping less than or equal to 4 isolated batteries incorporated in machinery does not need care label.)

Lithium battery care label (Air transportation sample)



- (b) Preparation of shipping documents and declaration of dangerous goods For information required in description, refer to "Appendix2-2 Product information data sheet".
- (2) When packaged by user

The user must follow UN Regulations when packing, preparing for shipping and preparing the indications, etc.

- (a) Packing a lithium battery falling under Class 9
 - [1] Consult with The Ship Equipment Inspection Society of Japan for details on packaging.
 - [2] Prepare for shipping as explained in "(1) Reshipping in Mitsubishi UN packaging".

 The Ship Equipment Inspection Society of Japan Headquarters Telephone: 03-3261-6611 Fax: 03-3261-6979
- (b) Packing a lithium battery not falling under Class 9
 - [1] Cells and batteries are separated so as to prevent short circuits and are stored in a strong outer packaging (12 batteries or less, 24 battery cells or less).
 - [2] Prepare for the certificates or test results showing compliance to drop test from 1.2m in height. (The safety test results have been obtained from the battery manufacturer. Consult with Mitsubishi when the safety test results are required.)
 - [3] Prepare for shipping as explained in "(1) Reshipping in Mitsubishi UN packaging (Class 9)".

■ When shipping lithium batteries incorporating in a device or machinery

Dedicated packaging (UN packaging) is not required for batteries incorporated in device or machinery. Yet, make sure to fix the contents securely before the transportation as to prevent damage and short-circuit. If machinery and devices which incorporates lithium battery is not waterproof, package must be waterproof material.

Check with your shipping company for details on packing and transportation.

Appendix 2-1-3 Reference

Refer to the following materials for details on the regulations and responses.

Guidelines regarding transportation of lithium batteries and lithium ion batteries (Edition 2)..... Battery Association of Japan

Appendix 2-2 Products information data sheet (ER battery)

MSDS system does not cover the product used in enclosed state. The ER battery described in this section applies to that product.

This description is applied to the normal use, and is provided as reference but not as guarantee.

This description is based on the lithium battery's (ER battery) hazardous goods data sheet (Products information data sheet) which MITSUBISHI has researched, and will be applied only to the ER batteries described in "Transportation Restrictions for Lithium Batteries: Restriction for Packing".

(1) Outline of hazard

Principal hazard and effect	Not found.
Specific hazard	As the chemical substance is stored in a sealed metal container, the battery itself is not hazardous. But when the internal lithium metal attaches to human skin, it causes a chemical skin burn. As a reaction of lithium with water, it may ignite or forms flammable hydrogen gas.
Environmental effect	Not found.
Possible state of emergency	Damages or short-circuits may occur due to external mechanical or electrical pressures.

(2) First-aid measure

Inhalation	If a person inhales the vapor of the substance due to the battery damage, move the person immediately to fresh air. If the person feels sick, consult a doctor immediately.
Skin contact	If the content of the battery attaches to human skin, wash off immediately with water and soap. If skin irritation persists, consult a doctor.
Eye contact	In case of contact with eyes due to the battery damage, rinse immediately with a plenty of water for at least 15 minutes and then consult a doctor.
Ingestion	If swallowed, consult a doctor immediately.

(3) Fire-fighting measure

Appropriate fire-extinguisher	Dry sand, dry chemical, graphite powder or carbon dioxide gas
Special fire-fighting measure	Keep the battery away from the fireplace to prevent fire spreading.
Protectors against fire	Fire-protection gloves, eye/face protector (face mask), body/skin protective cloth

(4) Measure for leakage

Environmental precaution	Dispose of them immediately because strong odors are produced when left for a long time.
How to remove	Get them absorbed into dry sand and then collect the sand in an empty container.

(5) Handling and storage

Han- dling	Cautions for safety han- dling	Do not peel the external tube or damage it. Do not dispose of the battery in fire or expose it to heat. Do not immerse the battery in water or get it wet. Do not throw the battery. Do not disassemble, modify or transform the battery. Do not short-circuit the battery.
Stor- age	Appropriate storage condition Material to avoid	Avoid direct sunlight, high temperature and high humidity. (Recommended temp. range: +5 to +35C°, humidity: 70%RH or less) Flammable or conductive material (Metal: may cause a short-circuit)

Appendix 2 Restrictions for Lithium Batteries

(6) Physical/chemical properties

Appearance	Physical form	Solid
	Shape	Cylinder type
	Smell	Odorless
	pH	Not applicable (insoluble)
	Boiling point/Boiling range, Melting point, De- composition tempera- ture, Flash point	No information

(7) Stability and reactivity

Stability	Stable under normal handling condition.	
Condition to avoid	Do not mix multiple batteries with their terminals uninsulated. This may cause a short-circuit, resulting in heating, bursting or ignition.	
Hazardous decomposition products	Irritative or toxic gas is emitted in the case of fire.	

(8) Toxicological information

As the chemical substance is stored in a sealed metal container, the battery has no harmfulness. Just for reference, the table below describes the main substance of the battery.

< Lithium metal >

Acute toxicity	No information
Local effect	Corrosive action in case of skin contact

< Thionyl chloride >

Acute toxicity	Lc ₅₀ : 500ppm (inhaled administration to rat)	
Local effect	The lungs can be damaged by chronic cough, dyspnea and asthma.	

< Aluminum chloride >

Acute toxicity	L _{D50} : 3700ppm (oral administration to rat)
Local effect	Not found.

< Lithium chloride >

Acute toxicity	L _{D50} : 526ppm (oral administration to rat)
Local effect	The central nerves and kidney can be influenced.

< Carbon black >

Acute toxicity	L_{D50} : 2,000mg/kg > (rat)
Carcinogenicity	LARC group 2 (suspected of being carcinogenic)

(9) Ecological information

Mobility, Persistence/Decom-	
posability, Bio-accumulation po-	Not found.
tential, Ecological toxicity	

(10) Caution for disposal

Dispose of the battery following local laws or regulations.

Pack the battery properly to prevent a short-circuit and avoid contact with water.

Appendix 2-3 Issuing Domestic Law of the United States for Primary Lithium Battery Transportation

Federal Aviation Administration (FAA) and Research and Special Programs Administration (RSPA) announced an additional regulation (interim final rule) for the primary lithium batteries transportation restrictions item in "Federal Register" on Dec.15 2004.

This regulation became effective from Dec.29, 2004. This law is a domestic law of the United States, however if also applies to the domestic flight and international flight departing from or arriving in the United States. Therefore, when transporting lithium batteries to the United State, or within the United State, the shipper must take measures required to transport lithium batteries. Refer to the Federal Register and the code of Federal Regulation ("Transportation Restrictions for Lithium Batteries: Reference") for details.

Appendix 2-3-1 Outline of Regulation

- (1) Transporting primary lithium battery by passenger aircraft is forbidden.
 - (a) Excluding primary lithium battery for personal use in a carry-on or checked luggage (Lithium metal content should be not more than 5g for cell and 25g for battery. For details on the lithium metal content, refer to "Transportation Restrictions for Lithium Batteries: Target Products".)
- (2) When transporting primary lithium battery by cargo aircraft, indicate that transportation by passenger aircraft is forbidden on the exterior box.

Appendix 2-3-2 Target Products

All NC products for which the lithium batteries are used are subject to the regulation. (Refer to the table "Transportation Restrictions for Lithium Batteries: Target Products".)

Appendix 2-3-3 Handling by User

The "Transportation Restrictions for Lithium Batteries: Outline of Regulation" described above is solely Mitsubishi's opinion. The shipper must confirm orders of "Transportation Restrictions for Lithium Batteries: Reference" described below for transportation method corresponding the regulation.

These should be checked by the company commissioned for the actual lithium battery transportation.

(1) Indication of exterior box

When transporting primary lithium battery by cargo aircraft, indicate that transportation by passenger aircraft is forbidden on the exterior box.

Display example

 $\label{eq:primary lithium batteries} FOR BIDDEN FOR TRANSPORT ABOARD PASSENGER AIRCRAFT.$

- (a) The character color must be displayed with contrast. (black characters against white background, black characters against yellow background, etc.)
- (b) The height (size) of characters to be displayed is prescribed depending on the packaging mass. (When the total mass is over 30kg: at least 12mm, When the total mass is less than 30kg: at least 6mm)

Appendix 2-3-4 Reference

- 49CFR (Code of Federal Regulation, Title49) (173.185 Lithium batteries and cells.)
 Search from the following URL.
 - http://www.gpoaccess.gov/cfr/index.html
- (2) DOT regulation body (Department of Transportation) Search "69fr-75207.pdf" from the following URL. http://phmsa.dot.gov/hazmat

Appendix 2 Restrictions for Lithium Batteries

Appendix 2-4 Restriction related to EU Battery Directive

EU Battery Directive (2006/66/EC) has been enforced since September 26th in 2008. Hereby, battery and machinery incorporating battery marketed in European Union countries must be in compliance with the EU Battery Directive.

Lithium battery provided by MITSUBISHI are subjected to this restriction.

Appendix 2-4-1 Important Notes

Follow the instruction bellow as shipping products incorporating MITSUBISHI device.

- (1) When shipping products incorporating MITSUBISHI device any time later than September 26th, 2008, the symbol mark shown as Figure 1 in section "Information for end-user" is required to be attached on the machinery or on the package. Also, the explanation of the symbol must be added.
- (2) Machinery with battery and maintenance battery produced before the EU Battery Directive are also subjected to the restriction. When shipping those products to EU countries later than September 26th, 2008, follow the instruction explained in (1).

Appendix 2-4-2 Information for end-user



Figure 1

Note: This symbol mark is for EU countries only. This symbol mark is according to the directive 2006/66/EC Article 20 Information for end-users and Annex II.

Your MITSUBISHI ELECTRIC product is designed and manufactured with high quality materials and components which can be recycled and/or reused. This symbol means that batteries and accumulators, at their end-of-life, should be disposed of separately from your household waste.

If a chemical symbol is printed beneath the symbol shown above, this chemical symbol means that the battery or accumulator contains a heavy metal at a certain concentration. This will be indicated as follows:Hg: mercury (0,0005%), Cd: cadmium (0,002%), Pb: lead (0,004%)

In the European Union there are separate collection systems for used batteries and accumulators. Please, dispose of batteries and accumulators correctly at your local community waste collection/recycling centre.

Please, help us to conserve the environment we live in!

Appendix 3

Compliance to EC Directives

Appendix 3 Compliance to EC Directives

Appendix 3-1 Compliance to EC Directives

Appendix 3-1-1 European EC Directives

In the EU Community, the attachment of a CE mark (CE marking) is mandatory to indicate that the basic safety conditions of the Machine Directives (issued Jan. 1995), EMC Directives (issued Jan. 1996) and the Low-voltage Directives (issued Jan. 1997) are satisfied. The machines and devices in which the servo and spindle drive are assembled are the targets for CE marking.

(1) Compliance to EMC Directives

The servo and spindle drive are components designed to be used in combination with a machine or device. These are not directly targeted by the Directives, but a CE mark must be attached to machines and devices in which these components are assembled. The next section "EMC Installation Guidelines", which explains the unit installation and control panel manufacturing method, etc., has been prepared to make compliance to the EMC Directives easier.

(2) Compliance to Low-voltage Directives


Each unit is targeted for the Low-voltage Directives. An excerpt of the precautions given in this specification is given below. Please read this section thoroughly before starting use.

For the EMC Directives and Low-voltage Directives, Self-Declaration Documents has been prepared. Contact Mitsubishi or your dealer when required.

Appendix 3-1-2 Cautions for EC Directive compliance

Use the Low-voltage Directive compatible parts for the servo/spindle drive and servo/spindle motor. In addition to the items described in this instruction manual, observe the items described below.

(1) Configuration



Insert a type B circuit breaker (RCD) in the power supply side of the unit.

(2) Environment

Use the units under an Overvoltage Category III (MDS-DH)/II (MDS-D) and Pollution Class of 2 or less environment as stipulated in IEC60664.

- (a) To adjust the units to the Overvoltage Category II, insert an isolating transformer of the star connection complying with EN or IEC standard in the input of the power supply unit.
- (b) To adjust the units to the Pollution Class of 2, install the units in a control panel having a structure (IP54 or higher) in which water, oil, carbon or dust cannot enter.

	H	n	ī	٠
·	,,		ı	ı

	During operation	Storage	During transportation	
Ambient temperature	0°C to 55°C	-15°C to 70°C	-15°C to 70°C	
Humidity	90%RH or less	90%RH or less	90%RH or less	
Altitude	1000m or less	1000m or less	13000m or less	

Motor

	During operation	Storage	During transportation	
Ambient temperature	0°C to 40°C	-15°C to 70°C	-15°C to 70°C	
Humidity	80%RH or less	90%RH or less	90%RH or less	
Altitude	1000m or less	1000m or less	13000m or less	

(3) Power supply

- [1] Use the power supply and servo/spindle drive unit under an Overvoltage Category III (MDS-DH)/ II (MDS-D) as stipulated in IEC60664.
- [2] Earth the PE terminal of the units to the neutral point of the star connection.
- [3] Do not omit the circuit breaker and electromagnetic contactor.


(4) Earthing

- [1] To prevent electric shocks, always connect the servo/spindle drive unit protective earth (PE) terminal (terminal with \bigoplus mark) to the protective earth (PE) on the control panel.
- [2] When connecting the earthing wire to the protective earth (PE) terminal, do not tighten the wire terminals together. Always connect one wire to one terminal.




(5) Wiring

[1] Always use crimp terminals with insulation tubes so that the connected wire does not contact the neighboring terminals.



[2] Do not connect the wires directly.



[3] Always install the power supply unit and servo/spindle drive unit on the metal panel.


Appendix 3 Compliance to EC Directives

(6) Peripheral devices

- [1] Use EN/IEC Standards compliant parts for the circuit protector and contactor.
- [2] Select type B circuit protector manufactured by RCD.Apply Annex C of EN60204-1 for sizing of the circuit protector.

(7) Miscellaneous

- [1] Refer to the next section "EMC Installation Guidelines" for methods on complying with the EMC Directives.
- [2] Ground the facility according to each country's requirements.
- [3] The control circuit connector (\bigcirc) is safely separated from the main circuit (\bigcirc) and ground (lacktriangle).
- [4] Inspect the appearance before installing the unit. Carry out a performance inspection of the final unit, and save the inspection records.



Appendix 4

EMC Installation Guidelines

Appendix 4-1 Introduction

EMC Instructions became mandatory as of January 1, 1996. The subject products must have a CE mark attached indicating that the product complies with the Instructions.

As the NC unit is a component designed to control machine tools, it is believed to be out of the direct EMC Instruction subject. However, we would like to introduce the following measure plans to backup EMC Instruction compliance of the machine tool as the NC unit is a major component of the machine tools.

- [1] Methods for installation in control/operation panel
- [2] Methods of wiring cable outside of panel
- [3] Introduction of countermeasure parts

Mitsubishi is carrying out tests to confirm the compliance to the EMC Standards under the environment described in this manual. However, the level of the noise will differ according to the equipment type and layout, control panel structure and wiring lead-in, etc. Thus, we ask that the final noise level be confirmed by the machine manufacturer.

For measures for CNC, refer to "EMC INSTALLATION GUIDELINES" of each NC Connection Manual.

Appendix 4-2 EMC instructions

The EMC Instructions regulate mainly the following two withstand levels.

Emission Capacity to prevent output of obstructive noise that adversely affects external sources.

Immunity Capacity not to malfunction due to obstructive noise from external sources.

The details of each level are classified as Table 1. It is assumed that the Standards and test details required for a machine are about the same as these.

Table 1

Class	Name	Details	Generic Standard	Standards for determining test and measurement
Emission	Radiated noise	Electromagnetic noise radiated through the air	EN61000-6-4	
	Conductive noise	Electromagnetic noise discharged from power line	EN61800-3 (Industrial environment)	
Immunity	Static electricity electrical discharge immunity test	(Example) Withstand level of discharge of electricity charged in a human body.		EN61000-4-2
	Radiated radio-frequency magnetic field immunity test	(Example) Simulation of immunity from digital wireless transmitters		EN61000-4-3
	Electrical fast transient/burst immunity test	(Example) Withstand level of noise from relays or connecting/disconnecting live wires		EN61000-4-4
	Immunity to conducted disturbance induced by radio-frequency magnetic field	(Example) Withstand level of noise entering through power line, etc.	EN61000-6-2 EN61800-3 (Industrial	EN61000-4-6
	Power supply frequency field immunity test	(Example) 50/60Hz power frequency noise	environment)	EN61000-4-8
	Immunity test for voltage dip, short- time power failure and voltage fluc- tuation	(Example) Power voltage drop withstand level		EN61000-4-11
	Surge immunity test	(Example) Withstand level of noise caused by lightning		EN61000-4-5

Appendix 4-3 EMC measures

The main items relating to EMC measures include the following.


- [1] Store the device in an electrically sealed metal panel.
- [2] Earth all conductors that are floating electrically. (Lower the impedance.)
- [3] Wire the power line away from the signal wire.
- [4] Use shielded wires for the cables wired outside of the panel.
- [5] Install a noise filter.

Ensure the following items to suppress noise radiated outside of the panel.

- [1] Securely install the devices.
- [2] Use shielded wires.
- [3] Increase the panel's electrical seal. Reduce the gap and hole size.
 Note that the electromagnetic noise radiated in the air is greatly affected by the clearance of the panel and the quality of the cable shield.


Appendix 4-4 Measures for panel structure

The design of the panel is a very important factor for the EMC measures, so take the following measures into consideration.




Appendix 4-4-1 Measures for control panel unit

- [1] Use metal for all materials configuring the panel.
- [2] For the joining of the top plate and side plates, etc., mask the contact surface with paint, and fix with welding or screws.
 - In either case, keep the joining clearance to a max. of 20cm for a better effect.
- [3] Note that if the plate warps due to the screw fixing, etc., creating a clearance, noise could leak from that place
- [4] Plate the metal plate surface (with nickel, tin) at the earthing section, such as the earthing plate.
- [5] The max. tolerable hole diameter of the openings on the panel surface, such as the ventilation holes, must be 3cm to 5cm. If the opening exceeds this size, use a measure to cover it. Note that even when the clearance is less than 3cm to 5cm, noise may still leak if the clearance is long.



Appendix 4-4-2 Measures for door

- [1] Use metal for all materials configuring the door.
- [2] Use an EMI gasket or conductive packing for the contact between the door and control panel unit.
- [3] The EMI gasket or conductive packing must contact at a uniform and correct position of the metal surface of the control panel unit.
- [4] The surface of the control panel unit contacted with the EMI gasket or conductive packing must have conductance treatment.
 - (Example) Weld (or screw) a plate that is plated (with nickel, tin).




[5] As a method other than the above, the control panel unit and door can be connected with a plain braided wire. In this case, the panel and door should be contacted at as many points as possible.

Appendix 4-4-3 Measures for operation board panel


- [1] Always connect the operation board and indicator with an earthing wire.
- [2] If the operation board panel has a door, use an EMI gasket or conductive packing between the door and panel to provide electrical conductance in the same manner as the control panel.
- [3] Connect the operation board panel and control panel with a sufficiently thick and short earthing wire.

Appendix 4-4-4 Shielding of the power supply input section

- [1] Separate the input power supply section from other parts in the control panel so that the input power supply cable will not be contaminated by radiated noise.
- [2] Do not lead the power line through the panel without passing it through a filter.



The power supply line noise is eliminated by the filter, but cable contains noise again because of the noise radiated in the control panel.



Use a metal plate, etc., for the shielding partition. Make sure not to create a clearance.


Appendix 4-5 Measures for various cables

The various cables act as antennas for the noise and discharge the noise externally. Thus appropriate treatment is required to avoid the noise.


The wiring between the drive unit and motor act as an extremely powerful noise source, so apply the following measures.

Appendix 4-5-1 Measures for wiring in panel

[1] If the cables are led unnecessarily in the panel, they will easily pick up the radiated noise. Thus, keep the wiring length as short as possible.



[2] The noise from other devices will enter the cable and be discharged externally, so avoid internal wiring near the openings.



[3] Connect the control device earthing terminal and earthing plate with a thick wire. Take care to the leading of the wire.

Appendix 4-5-2 Measures for shield treatment

Common items

Use of shield clamp fittings is recommended for treating the shields. The fittings are available as options, so order as required. (Refer to the section "Shield clamp fitting" in this chapter.)


Clamp the shield at a position within 10cm from the panel lead out port.

1. When leading the cables, including the grounding wire (FG), outside of the panel, clamp the cables near the panel outlet (recommendation: within 10cm).




- 2. When using a metal duct or conduit, the cables do not need to be clamped near the panel outlet.
- 3. When leading cables not having shields outside the panel, follow the instructions given for each cable. (Installation of a ferrite core, etc., may be required.)

Appendix 4-5-3 Servo/spindle motor power cable




Power cable for servo motor




Power cable for spindle motor

- [1] Use four wires (3-phase + earthing) for the power cable that are completely shielded and free from breaks.
- [2] Earth the shield on both the control panel side and motor chassis side.
- [3] Earth the shield with a metal P clip or U clip.(A cable clamp fitting can be used depending on the wire size.)
- [4] Directly earth the shield. Do not solder the braided shield onto a wire and earth the end of the wire.




- [5] When not using a shield cable for the power cable, use a conventional cabtyre cable. Use a metal conduit outside the cable.
- [6] Earth the power cable on the control panel side at the contact surface of the conduit connector and control panel. (Mask the side wall of the control panel with paint.)
- [7] Follow the treatment shown in the example for the conduit connector to earth the power cable on the motor side. (Example: Use a clamp fitting, etc.)



Appendix 4-5-4 Servo/spindle motor feedback cable

Use a shield pair cable for feed back cable of the servo motor to earth on NC side (inside the control panel.) Mounting a ferrite core directly behind the unit connector is also effective in suppressing noise.




Feed back cable for servomotor

Appendix 4-6 EMC countermeasure parts

Appendix 4-6-1 Shield clamp fitting

The effect can be enhanced by connecting the cable directly to the earthing plate. Install an earthing plate near each panel's outlet (within 10cm), and press the cable against the earthing plate with the clamp fitting. If the cables are thin, several can be bundled and clamped together. Securely earth the earthing plate with the frame ground. Install directly on the cabinet or connect with an earthing wire.




	Α	В	С	Enclosed fittings
Ground Plate #D	100	86	30	Clamp fitting A x 2
Ground Plate #E	70	56	-	Clamp fitting B x 1

	L1 (maximum dimension when it is open)	L2 (reference dimension)
Clamp fitting A	25	(77)
Clamp fitting B	12	(54)

Appendix 4-6-2 Ferrite core

A ferrite core is integrated and mounted on the plastic case. Quick installation is possible without cutting the interface cable or power cable. This ferrite core is effective against common mode noise, allowing measures against noise to be taken without affecting the signal quality.



Part name	Fig	Α	В	С	D	E	Applicable cable outline	Mass	Recommended ferrite core
ZCAT3035-1330(-BK)*1	1	39	34	13	30	-	13	63	0
ZCAT2035-0930-M(-BK)	2	35	29	13	23.5	22	10 to 13	29	
ZCAT2017-0930-M(-BK)	3	21	17	9	20	28.5	9	12	
ZCAT2749-0430-M(-BK)	4	49	27	4.5	19.5	-	4.5	26	

^{*1} A fixing band is enclosed when shipped.

ZCAT-B type: Cabinet fixed type, installation hole ø4.8 to 4.9mm, plate thickness 0.5 to 2mm

ZCAT-C type: Structured so that it cannot be opened easily by hand once closed.

Appendix 4-6-3 Power line filter


< Power line filter for 200V > HF3000A-TM Series for 200V

■ Features

- (a) 3-phase 3-wire type (250V series, 500V series)
- (b) Compliant with noise standards German Official Notice Vfg243, EU Standards EN55011 (Class B)
- (c) Effective for use with IGBT inverter and MOS-FET inverter.
- (d) Easy mounting with terminal block structure, and outstanding reliability.

■ Application


- (a) Products which must clear noise standards German Official Notice Vfg243 and EU Standards EN55011 (Class B).
- (b) For input of power converter using advanced high-speed power device such as IGBT MOS-FET.




■ Specifications (250V series)

Part name	HF3005A -TM	HF3010A -TM	HF3015A -TM	HF3020A -TM	HF3030A -TM	HF3040A -TM	HF3050A -TM	HF3060A -TM	HF3080A -TM	HF3100A -TM	HF3150A -TM		
Rated voltage	250V AC												
Rated current	5A	10A	15A	20A	30A	40A	50A	60A	80A	100A	150A		
Leakage current		1.5mA MAX 250V AC 60Hz											


<Example of measuring voltage at noise terminal>•••Measured with IGBT inverter





German Official Notice Vfg243 measurement data




EU Standards EN55011 (Class B) measurement data







■ Outline dimensions



Model	Dimen	sion [Uni	t: mm]
Wodel	Α	В	С
HF3005A-TM			
HF3010A-TM	180	170	130
HF3015A-TM	100	170	100
HF3020A-TM			
HF3030A-TM	260	155	140
HF3040A-TM	200	100	140
HF3050A-TM	290	190	170
HF3060A-TM	250	150	230
HF3080A-TM	405	220	
HF3100A-TM	400	220	210
HF3150A-TM	570	230	

MX13 Series 3-phase high attenuation noise filter for 200V



■ Features

- (a) Perfect for mounting inside control panel: New shape with uniform height and depth dimensions
- (b) Easy mounting and maintenance work: Terminals are centrally located on the front
- (c) Complaint with NC servo and AC servo noise: High attenuation of 40dB at 150KHz
- (d) Safety Standards:UL1283, CSAC22.2 No.8, EN60939(SEMKO)
- (e) Patent and design registration pending

■ Specifications

	Item		Ту	pe						
	item	MX13030	MX13050	MX13100	MX13150					
1	Rated voltage (AC)		3-phase 250V	AC (50/60Hz)						
2	Rated current (AC)	30A	50A	100A	150A					
3	Test voltage (AC for one minute across terminal and case)	2500VAC (100mA) at 25°C, 70% RH								
4	Insulation resistance (500VDC across terminal and case)	100MΩ min. at 25°C, 70% RH								
5	Leakage current (250V, 60Hz)	3.5m	A max	8mA	max					
6	DC resistance	30mΩ max	11mΩ max	5.5mΩ max	3.5mΩ max					
7	Temperature rise		30°C	max						
8	Working ambient temperature		−25°C t	o +85°C						
9	Working ambient humidity		30% to 95% RH	(non condensing)						
10	Storage ambient temperature		−40°C t	o +85°C						
11	Storage ambient humidity		10% to 95% RH	(non condensing)						
12	Mass (typ)	2.8kg	3.9kg	11.5kg	16kg					

(Note) This is the value at $Ta \leq 50$ °C.

Refer to the following output derating for Ta > 50°C.

Contact: Densei-lambda Co., Ltd. Telephone: 03-3447-4411 (+81-3-3447-4411)

Fax: 03-3447-7784 (+81-3-3447-7784) http://www.densei-lambda.com


■ Example of using MX13 Series

This is a noise filter with the same dimensions as the drive unit depth (200mm) and height (380mm).


This unit can be laid out easily in the device by arraigning it in a row with the servo unit.

As with the servo unit, the terminals are arranged on the front enabling ideal wire lead-out. Refer to the following figure for details.


[Unit:mm]




■ Example of noise terminal voltage attenuation



■ Output derating




■ Outline dimension drawings MX13030, MX13050



	MX13030	MX13050
Α	66	81
В	45	55
С	10.5	13
D	50	67
Е	13	16
F	10	13
G	177	179
Н	M4 screw	M6 screw
ı	70	85
J	M4 screw	M6 screw
K	195	200


MX13100, MX13150



	MX13100	MX13150					
Α	130	165					
В	90	110					
С	20	27.5					
D	115	150.5					
Е	37.5	57.5					
F	18	23					
G	174	176					
Н	M6 screw	M8 screw					
ı	21	27					
J	37.5	56.5					
K	115	149.5					
L	276	284					

< 400V power line filter > 400V 3SUP-HL-ER-6B Series





■ Features

- (a) 3-phase, 3-wire type high attenuation characteristics
- (b) CE marking compatible
- (c) Rated current value 30A to 200A
- (d) For EN55011 Class A, B measures
- (e) Application: Primary side of inverter power supply, UPS, CNC machine tool, etc.

■ Specifications

Туре	3SUP-HL30-ER-6B	3SUP-HL50-ER-6B	3SUP-HL75-ER-6B	3SUP-HL100-ER-6B	3SUP-HL150-ER-6B									
Rated current	30A (50°C)	50A (50°C)	75A (50°C)	100A (50°C)	150A (50°C)									
Maximum operation voltage		500Vrms (50°C)												
Operation frequency	50 / 60Hz													
Leakage current	[A leakage curren		BmA (at 500Vrms 60Hz no phase failure in a p) ower supply grounded a	at a neutral point.]									
Connection terminal	M4	M6	M6	M6	M8									
Mass	5.2kg	6.5kg	12.0kg	12.5kg	23.5kg									
Nominal inductance	6 x 1.4mH	6 x 1.4mH	6 x 1.0mH	6 x 0.56mH	6 x 0.6mH									
Safety standards			EN133200 (compatible))										

These specifications are for reference. Contact the filter manufacturer for detailed data.


Other matters

- If the leakage current is limited, use 3SUP-HL □ -ER-6B-4 (leakage current 4mA product).
- When using with the peripheral device and a higher attenuation characteristics are required, use the 3SUP-HL \square -ER-6.

Contact: Okaya Electric Industries Co., Ltd. Telephone: 03-3424-8120 (+81-3-3424-2110) http://www.okayaelec.co.jp

■ Outline dimensions

[Unit: mm] General tolerance: ± 1.5mm



	Α	В	С	D	E	F	G	Н	1	J	K	L
3SUP-HL30-ER-6B	246	230	215	200	100	85	13	18	140	4.5x7	4.5	M4
3SUP-HL50-ER-6B	286	270	255	240	120	90	13	18	150	5.5x7	5.5	M6
3SUP-HL75-ER-6B	396	370	350	330	170	140	18	23	155	6.5x8	6.5	M6
3SUP-HL100-ER-6B	396	370	350	330	170	140	18	23	155	6.5x8	6.5	M6
3SUP-HL150-ER-6B	484	440	420	400	200	170	30	25	200	6.5x8	6.5	M8
3SUP-HL200-ER-6B	484	440	420	400	200	170	30	25	200	6.5x8	6.5	M8

400V HF3000C-TMA Series

■ Features

3-phase, 3-wire type high attenuation characteristics

■ Specifications


Туре	HF3030C-TMA	HF3050C-TMA	HF3060C-TMA	HF3080C-TMA	HF3100C-TMA	HF3150C-TMA	HF3200C-TMA							
Rated current	30A	50A	60A	80A	100A	150A	200A							
Rated voltage				460VAC (50°C)										
Operation frequency		50 / 60Hz												
Leakage current	[A leakag	5.3mA (at 460Vrms 60Hz) [A leakage current will not flow if there is no phase failure in a power supply grounded at a neutral point.]												
Overload current			Rated cu	ırrent × 150% for	1 minute									
Connection terminal	M5 / M4(E)	M5 / M4(E) M6 / M4(E)		M6 / M4(E) M8 / M6(E)		M10 /M8(E)	M10 / M8(E)							
Mass	3.2kg	6.7kg	10.0kg	13.0kg 14.5kg		23.0kg	23.5kg							
Safety standards			EN	133200 (compatil	ole)									


These specifications are for reference. Contact the filter manufacturer for detailed data.


Contact: Soshin Electric Co., Ltd. Telephone: 03-5730-8001 (+81-3-5730-8001) http://www.soshin.co.jp


■ Outline dimensions

[Unit: mm] General tolerance: ±1.5mm









	Α	В	С	D	E	F	G	Н	J	K	L	M	N
HF3030C-TMA	260	210	85	155	140	125	44	140	70	R3.25 / L8	M5	M4	
HF3050C-TMA	290	240	100	190	175	160	44	170	100	R3.25 / L8	M6	M4	
HF3060C-TMA	290	240	100	190	175	160	44	230	160	R3.25 / L8	M6	M4	
HF3080C-TMA	405	350	100	220	200	180	56	210	135	R4.25 / L12	M8	M6	
HF3100C-TMA	405	350	100	220	200	180	56	210	135	R4.25 / L12	M8	M6	
HF3150C-TMA	570	550	530	230	190	100	15	210	140	100	M10	M8	33
HF3200C-TMA	570	550	530	230	190	100	15	210	140	100	M10	M8	33

Appendix 4-6-4 Surge protector

Insert a surge protector in the power input section to prevent damage to the control panel or power supply unit, etc. caused by the surge (lightning or sparks, etc.) applied on the AC power line.


Use a surge protector that satisfies the following electrical specifications.

< Surge protector for 200V >

200V R•A•V-BYZ Series (for protection between lines)

Part name	Circuit voltage 50/60Hz	Maximum tolerable circuit voltage	Clamp voltage	Surge withstand level 8/20 µs	Surge withstand voltage 1.2/50 µs	Electrostatic capacity	Service temperature
RAV-781BYZ-2	3AC 250V	300V	783V±10%	2500A	20kV	75pF	-20 to 70°C


(Note) Refer to the manufacturer's catalog for details on the surge protector's characteristics and specifications.



200V R•A•V-BXZ Series (for protection between line and earth)

Part name	Circuit voltage 50/60Hz	Maximum tolerable circuit voltage	Clamp voltage	Surge withstand level 8/20 µs	Surge withstand voltage 1.2/50 µs	Electrostatic capacity	Service temperature
RAV-781BXZ-4	3AC 250V	300V	1700V±10%	2500A	2kV	75pF	-20 to 70°C

(Note) Refer to the manufacturer's catalog for details on the surge protector's characteristics and specifications.




< Surge protector for 400V >

R•A•V-BYZ series for 400V (for protection between lines)

Part name	Circuit voltage 50/60Hz	Maximum tolerable circuit voltage	Clamp voltage	Surge withstand level 8/20µs	Surge withstand voltage 1.2/50µs	Electrostatic capacity	Service temperature
RAV-152BYZ-2A	3AC 430V	500V	1476V±10%	2500A	20kV	35pF	-20 to 70°C


(Note) Refer to the manufacturer's catalog for details on the surge protector's characteristics and specifications, etc.



RCM Series for 400V (for protection between line and earth)

Part name	Rated voltage	AC discharge start voltage (V) ±20%	Surge withstand level 8/20µs (A)	Surge withstand voltage 1.2/50µs (V)	
RCM-781BUZ-4	3AC 250/430V	AC700V±20%	2500A	2kV	
RCM-801BUZ-4	3AC 290/500V	AC800V±20%	2500A	2.32kV	

(Note) Refer to the manufacturer's catalog for details on the surge protector's characteristics and specifications, etc.



Contact: Okaya Electric Industries Co., Ltd. Telephone: 03-3424-8120 (+81-3-3424-2110) http://www.okayaelec.co.jp

< Surge protector for both between phases and between phase and earth >

■ Features

This surge protector can protect both between phases and between phase and earth.

This contains a fuse and has windows to check malfunction or device degradation.

■ Specifications

LT-C Series 200V

	Part name	Circuit voltage 50/60Hz	Maximum tolerable circuit voltage	AC operation start voltage (between line and earth)	AC operation start voltage (between lines)	Voltage protection level (Up)	Nominal discharge current (8/20µs)	Maximum discharge current (8/20µs)
Ī	LT-C32G801WS	3AC 250Vrms	275Vrms	560V±20%	410V±20%	1.5kV	2500A	5000A


(Note) Refer to the manufacturer's catalog for details on the surge protector's characteristics and specifications, etc.

LT-C Series 500V

Part name	Circuit voltage 50/60Hz	Maximum tolerable circuit voltage	AC operation start voltage (between line and earth)	AC operation start voltage (between lines)	Voltage protection level (Up)	Nominal discharge current (8/20µs)	Maximum discharge current (8/20µs)
LT-C35G102WS	3AC 500Vrms	550Vrms	700V±20%	800V±20%	2.0kV	2500A	5000A

(Note) Refer to the manufacturer's catalog for details on the surge protector's characteristics and specifications, etc.

■ Outline dimensions




Contact: Soshin Electric Co., Ltd. Telephone: 03-5730-8001 (+81-3-5730-8001) http://www.soshin.co.jp

< Example of surge protector installation >

An example of installing the surge protector in the machine control panel is shown below.

A short-circuit fault will occur in the surge protector if a surge exceeding the tolerance is applied. Thus, install a circuit protector in the stage before the surge protector. Note that almost no current flows to the surge protector during normal use, so a circuit protector installed as the circuit protection for another device can be used for the surge protector.



Installing the surge absorber

1. The wires from the surge protector should be connected without extensions.

CAUTION!

- 2. If the surge protector cannot be installed just with the enclosed wires, keep the wiring length of A and B to 2m or less. If the wires are long, the surge protector's performance may drop and inhibit protection of the devices in the panel.
- 3. Surge protector to be selected varies depending on input power voltage.

Appendix 5

EC Declaration of Conformity

Appendix 5 EC Declaration of Conformity


Appendix 5-1 Compliance to EC Directives

Each series can respond to LVD and EMC directive.


Approval from a third party certification organization has been also acquired for the Low Voltage Directive. The declaration of conformity of each unit is shown below.

Appendix 5-1-1 Low voltage equipment

MDS-D/DH-CV Series




MDS-D/DH-V1/V2 Series



Appendix 5 EC Declaration of Conformity

MDS-D/DH-SP Series



Appendix 6

Instruction Manual for Compliance with UL/c-UL Standard

Appendix 6 Instruction Manual for Compliance with UL/c-UL

The instructions of UL/c-UL listed products are described in this manual.

The descriptions of this manual are conditions to meet the UL/c-UL standard for the UL/c-UL listed products. To obtain the best performance, be sure to read this manual carefully before use.

To ensure proper use, be sure to read specification manual, connection manual and maintenance manual carefully for each product before use.

Appendix 6-1 Operation surrounding air ambient temperature

The recognized operation ambient temperature of each unit are as shown in the table below. The recognized operation ambient temperatures are the same as an original product specification for all of the units.

Classification	Unit name	Operation ambient temperature	
	Power supply unit, AC Reactor	0 to 55°C	
AC servo/spindle system	Servo, Spindle drive unit	0 to 55°C	
AC servo/spinule system	Option unit, Battery unit	0 to 55°C	
	Servo motor, Spindle motor	0 to 40°C	

Appendix 6-2 Notes for AC servo/spindle system

Appendix 6-2-1 General Precaution

It takes 15 minutes maximum to discharge the bus capacitor. (The capacitor discharge time is one minute for Models MDS-D-SVJ3-03; two min. for Models MDS-D-SVJ3-04, three min. for Model MDS-D-SVJ3-07, 9 min. for Models MDS-D-SVJ3-10, -20 and -35, 10 min. for Models MDS-D/DH/DM-CV/Vx/SPx.) When starting wiring or inspection, shut the power off and wait for more than 15 minutes to avoid a hazard of

When starting wiring or inspection, shut the power off and wait for more than 15 minutes to avoid a hazard of electrical shock.

Appendix 6-2-2 Installation

MDS-D/DH/DM Series are UL/c-UL listed "open type" drives and must be installed into an end-use electrical enclosure.

The minimum enclosure size is based on 150 percent of each MDS-D/DH/DM Series combination.

And also, design the enclosure so that the ambient temperature in the enclosure is 55°C (131° F) or less, refer to the specifications manual.

Appendix 6-2-3 Short-circuit ratings (SCCR)

Suitable for use in a circuit capable of delivering not more than 100kA rms symmetrical amperes, 500 volts maximum.

Appendix 6-2-4 Peripheral devices

To comply with UL/c-UL Standard, use the peripheral devices which conform to the corresponding standard.

Circuit Protector, Fuses, Magnetic contactor and AC Reactor

Applicable power supply unit	UL489 Circuit Protector	UL Fuse Class K5	Magnetic contactor (AC3)	AC Reactor
MDS-D-CV-37	20A	30A	S-N12	D-AL-7.5K
MDS-D-CV-75	40A	60A	S-N25	D-AL-7.5K
MDS-D-CV-110	60A	70A	S-N35	D-AL-11K
MDS-D-CV-185	100A	125A	S-N65	D-AL-18.5K
MDS-D-CV-300	150A	200A	S-N95	D-AL-30K
MDS-D-CV-370	200A	225A	S-N150	D-AL-37K
MDS-D-CV-450	225A	250A	S-N300	D-AL-45K
MDS-D-CV-550	300A	400A	S-N300	D-AL-55K
MDS-DH-CV-37	10A	10A	S-N12	DH-AL-7.5K
MDS-D-HCV-75	20A	25A	S-N12	DH-AL-7.5K
MDS-DH-CV-110	30A	35A	S-N21	DH-AL-11K
MDS-DH-CV-185	50A	70A	S-N25	DH-AL-18.5K
MDS-DH-CV-300	75A	110A	S-N50	DH-AL-30K
MDS-DH-CV-370	100A	125A	S-N65	DH-AL-37K
MDS-DH-CV-450	125A	150A	S-N80	DH-AL-45K
MDS-DH-CV-550	150A	200A	S-N95	DH-AL-55K
MDS-DH-CV-750	200A	300A	S-N150	DH-AL-75K

Applicable drive unit	UL 489 Circuit Protector (240Vac)	UL Fuse Class T (300Vac)	Magnetic contactor (AC3)
MDS-D-SVJ3(#)-03(##)	5A	10A	S-N12
MDS-D-SVJ3(#)-04(##)	5A	20A	S-N12
MDS-D-SVJ3(#)-07(##)	5A	20A	S-N12
MDS-D-SVJ3(#)-10(##)	10A	20A	S-N12
MDS-D-SVJ3(#)-20(##)	15A	40A	S-N21
MDS-D-SVJ3(#)-35(##)	20A	70A	S-N21
MDS-D-SPJ3(#)-075(##)	5A	15A	S-N12
MDS-D-SPJ3(#)-22(##)	15A	40A	S-N12
MDS-D-SPJ3(#)-37(##)	30A	60A	S-N21
MDS-D-SPJ3(#)-55(##)	40A	90A	S-N25
MDS-D-SPJ3(#)-75(##)	50A	125A	S-N25
MDS-D-SPJ3(#)-110(##)	75A	175A	S-N50

Circuit Protector for spindle motor Fan

Select the Circuit Protector by doubling the spindle motor fan rated.

A rush current that is approximately double the rated current will flow, when the fan is started

<Notice>

- For installation in United States, branch circuit protection must be provided, in accordance with the National Electrical Code and any applicable local codes.
- For installation in Canada, branch circuit protection must be provided, in accordance with the Canadian Electrical Code and any applicable provincial codes.

Appendix 6-2-5 Field Wiring Reference Table for Input and Output (Power Wiring)

Use the UL-approved Round Crimping Terminals to wire the input and output terminals of MDS-D/DH Series. Crimp the terminals with the crimping tool recommended by the terminal manufacturer. Please protect terminal ring by the insulation cover.

Following described crimping terminals and tools type are examples of Japan Solderless Terminal Mfg. Co., Ltd.

This wire size is each unit maximum rating. The selection method is indicated in each specification manual. (See Manual: No. IB-1500003, 1500011, 1500158, 1500875 or 1500891)

(1) Power Supply Unit (MDS-D/DH-CV)

Unit Type	MDS-D-CV-	37 to 75	110 to 185	300 to 450	55	50
Onit Type	MDS-DH-CV-		37 to 185	300 to 750		
	TE2 (L+, L-)	M6	M6	M6	M6	M10
	Torque [lb in/ N m]	35.4/4.0	<-	<-	<-	97.3/11.0
Terminal Screw	TE3 (L11, L21)	M4	M4	M4	M4	
Size	Torque [lb in/ N m]	10.6/1.2	<-	<-	<-	
Size	TE1 (L1, L2, L3, ()	M4	M5	M8	M10	
	Torque [lb in/ N m]	10.6/1.2	17.7/2.0	53.1/6.0	97.3/11.0	

TE2 (L+, L-)

Unit Type	MDS-D-CV-		37	75	110	185		300 to 550
	MDS-DH-CV-	37, 75		110	185	300, 370	450	550, 750
V	Vire Size (AWG)	#14	#12	#10	#8	#4	#3	Bus-bar.
/Те	emp Rating ^{Note 1}	/75°C	/75°C	/75°C	/75°C	/75°C	/75°C	Bus-bar.
Crimp	ping Terminals Type	R2-6	R5.5-6	R5.5-6	R8-6	R22-6	R38-6	
Criı	mping Tools Type	YHT-2210	<-	<-	YPT-60-21	<-	YPT-60-21	

TE3 (L11, L21)

Unit Type MDS-D/DH-CV-	37 to 750
Wire Size (AWG)	#14
/Temp Rating Note 1	/75°C
Crimping Terminals Type	R2-4
Crimping Tools Type	YHT-2210

Appendix 6 Instruction Manual for Compliance with UL/c-UL

TE1 (L1, L2, L3, ⊕)

Unit Type MDS-D-CV-	MDS-D-CV-	37		75	110	185
Offic Type	MDS-DH-CV-	37, 75	110		185	
	ire Size (AWG)	#14	#12	#10	#8	#6
/Tei	mp Rating ^{Note 1}	/75°C	/75°C	/75°C	/75°C	/75°C
Crimpi	ng Terminals Type	R2-4	R5.5-5	5.5-S4	R8-5	R14-5
Crimping Tools Type		YHT-2210	<-	<-	YPT-60-21	<-
Crim	iping roots rype	1111-2210	\- <u>-</u>	•	11 1 00 21	`
Crim	iping roots type	1111-2210		<u> </u>	11 1 00 21	
	MDS-D-CV-			300	370, 450	550
Unit Type		-	· · · · · · · · · · · · · · · · · · ·	-		
Unit Type	MDS-D-CV-			300	370, 450	550
Unit Type	MDS-D-CV- MDS-DH-CV-	300	 370, 450	300 550	370, 450 750	550
Unit Type W	MDS-D-CV- MDS-DH-CV- ire Size (AWG)	300 #6	370, 450 #4	300 550 #2	370, 450 750 #1/0	550 #3/0

(Note) 75 °C:Grade heat-resistant polyvinyl chloride insulated wires (HIV).

Use copper wire only.

Above listed wire are for use in the electric cabinet on machine or equipment.

(2) Spindle Drive Unit (MDS-D/DH-SP/SP2, MDS-D-SPJ3)

	MDS-D-SP(#)-	160 to 200	240 to 320	400 to 600			
Unit Type	MDS-D-SPJ3(#)-				22, 37(##)	22(##)	55(##) to 110(##)
	MDS-DH-SP(#)-	100 to 160	200 to 480				
	TE2 (L+, L-)	M6	M6	M10			
	Torque [lb in/ N m]	35.4/4.0	<-	97.3/11.0			
	TE3 (L11, L21)	M4	M4	M4			M3.5
Terminal	Torque [lb in/ N m]	10.6/1.2	<-	<-			<-
Screw	TE1 (L1, L2, L3, (=))	M5	M8	M10			M4
Size	Torque [lb in/ N m]	17.7/2.0	53.1/6.0	97.3/11.0			17.7/2.0
	CNP1 (L1,L2,L3,N,P1,P2)						
	and CNP3 (U,V,W)) Torque [lb in/ N m]				5.3/0.6	-	

TE2 (L+, L-)

Wire size depends on the Power Supply Unit (MDS-D/DH-CV Series).

TE3 or CNP2 (L11, L21)

Hnit Typa	MDS-D/DH-SP(#)-	20 to 640	
Offic Type	MDS-D-SPJ3(#)-	55(##) to 110(##)	075(##) to 37(##)
Wi	re Size (AWG)	#14	#14
/Ten	np Rating ^{Note 1}	/75°C	/60 or 75°C
Crimpi	ng Terminals Type	R2-4	
Crim	ping Tools Type	YHT-2210	

TE1 (U, V, W, ⊕)

Unit Type	MDS-D-SP(#)-	20, 40	80	160		200
Office Type	MDS-DH-SP(#)-	20, 40	80	100		160
	re Size (AWG)	#14	#12	#10	#8	#6
/Ter	mp Rating ^{Note 1}	/75°C	/75°C	/75°C	/75°C	/75°C
Crimpi	ng Terminals Type			R5.5-5	R8-5	R14-5
Crim	ping Tools Type			YHT-2210	YPT-60-21	<-
			•	•		
Unit Type	MDS-D-SP(#)-	240		320	400	640
Offic Type	MDS-DH-SP(#)-	200	320	480		
	re Size (AWG)	#4	#2	#1/0	#2/0	#3/0
/Ter	np Rating ^{Note 1}	/75°C	/75°C	/75°C	/75°C	/75°C
Crimpi	ng Terminals Type	R22-8	38-S8	60-S8	70-10	80-10
Crim	ping Tools Type	YPT-60-21	YPT-60-21	<-	YPT-150-1	<-

CNP1 (L1, L2, L3), CNP3 (U, V, W) and (

Unit Type MDS-D-SPJ3(#)-	075(##) to 37(##)	55(##)	75(##)	110(##)
Wire Size (AWG) /Temp Rating ^{Note 1}	#14 /60 or 75°C	#12 /75°C	#10 /75°C	#8 /75°C
Crimping Terminals Type		R5.5-5	R5.5-5	R8-5
Crimping Tools Type		YHT-2210	<-	YPT-60-21

(Note) 75 °C:Grade heat-resistant polyvinyl chloride insulated wires (HIV).

Use copper wire only.

Above listed wire are for use in the electric cabinet on machine or equipment.

(3) Servo Drive Unit (MDS-D/DH/DM-V1/V2/V3/D-SVJ3)

	MDS-D-V1(#)-	160W, 320	320W		
Unit Type	MDS-DH-V1(#)-	160, 160W	200		
Omit Type	MDS-D-SVJ3(#)-			10 to 35(##)	10(##) 20(##)
	TE2 (L+, L-)	M6	M6		
	Torque [lb in/ N m]	35.4/4.0	<-		
	TE3 (L11, L21)	M4	M4		
Terminal	Torque [lb in/ N m]	10.6/1.2	<-		
Screw	TE1 (L1, L2, L3, (=))	M5	M8		
Size	Torque [lb in/ N m]	17.7/2.0	53.1/6.0		
	CNP1 (L1,L2,L3,N,P1,P2) and				
	CNP3 (U,V,W)) Torque [lb in/ N m]			5.3/0.6	

TE2 (L+, L-)

Wire size depends on the Power Supply Unit (MDS-D/DH-CV Series).

TE3 or CNP2 (L11, L21)

Unit Type	MDS-D/DH/DM-V1(#)/V2(#)/V3(#)-	10 to 320W	
	MDS-D-SVJ3(#)-		03(##) to 35(##)
	Wire Size (AWG) /Temp Rating Note 1	#14/75°C	#14/60 or 75°C
Crimping Terminals Type		R2-4	
Crimping Tools Type		YHT-2210	

TE1 (U, V, W, ⊕)

Unit Type	MDS-D-V1(#)- MDS-DH-V1(#)-		o 80 o 80	160 80W		
	Wire Size (AWG) /Temp Rating ^{Note 1}	"	14 5°C		10 5°C	
Unit Type	MDS-D-V1(#)- MDS-DH-V1(#)-	 160	160W 160W	320	320W 200	
	Wire Size (AWG) /Temp Rating Note 1	#10 /75°C	#8 /75°C	#6 /75°C	#4 /75°C	
	Crimping Terminals Type Crimping Tools Type	R5.5-5 YHT-2210	R8-5 YPT-60-21	R14-5	R22-8	

CNP1 (L1, L2, L3), CNP3 (U, V, W) and $\mbox{\textcircled{=}}$

Unit Type	MDS-D-SVJ3(#)-	03(##) to 20(##)	35(##)
	Wire Size (AWG)	#14	#12
	/Temp Rating Note 1	/60 or 75°C	/60 or 75°C

(Note) 75 °C:Grade heat-resistant polyvinyl chloride insulated wires (HIV).

Use copper wire only.

Above listed wire are for use in the electric cabinet on machine or equipment.

Appendix 6 Instruction Manual for Compliance with UL/c-UL

(4) AC Reactor (D/DH-AL)

Type	D-AL-	7.5K, 11K	18.5K to 45K	55K
Турс	DH-AL-	7.5K, 11K	18.5K to 75K	
Terminal	L11, L12, L13, L21, L22, L23	M5	M6	M10
Screw Size	Torque [lb in/ N m]	17.7/2.0	35.4/4.0	97.3/11.0


Input/Output (L11, L12, L13, L21, L22, L23)

The wire connected with AC Reactor becomes same size as TE1 of the selected Power supply unit.

(5) Notes of Round Crimping Terminals and Terminal Block

The non-insulation ring tongue must have the insulated sleeving described below to prevent electric shock.

The insulated sleeve must be provided with SUMITOMO ELECTRIC FINE POLYMER INC. (File No.: E48762, Catalogue No.: SUMITUBE F(Z) or 939) per the illustration below.



Appendix 6-2-6 Motor Over Load Protection

Spindle drive unit MDS-D/DH-SP/SP2/SPJ3 and Servo drive unit MDS-D/DH/DM-V1/V2/V3/SVJ3 series have each solid-state motor over load protection. (The motor full load current is the same as rated current.) When adjusting the level of motor over load, set the parameter as follows.

(1) MDS-D/DH-SP/SP2/SPJ3 (Spindle drive unit)

Parameter No.	Parameter abbr.	Parameter Name	Setting Procedure	Standard Setting Value	Setting Range
SP021	OLT*	Overload time constant	Set the time constant for overload detection. (Unit: 1 second.) 60s		0 to 15300s
SP022	OLL	Overload detection level	Set the overload current detection level with a percentage (%) of the rating.	120%	1 to 200%

(2) MDS-D/DH/DM-V1/V2/V3/SVJ3 (Servo drive unit)

Parameter No.	Parameter abbr.	Parameter Name	Setting Procedure	Standard Setting Value	Setting Range
SV021	OLT	Overload time constant	Set the time constant for overload detection. (Unit: 1 second.)	60s	1 to 300s
SV022	OLL	Overload detection level	Set the overload current detection level with a percentage (%) of the stall rating.		1 to 500%

Appendix 6-2-7 Flange of servo motor

Mount the servo motor on a flange which has the following size or produces an equivalent or higher heat dissipation effect:

Flange size	Servo Motor
(mm)	HF, HF-H, HP, HP-H, HF-KP, HF-MP, HF-SP
150x150x6	50 to 100W
250x250x6	200 to 400W
250x250x12	0.5 to 1.5kW
300x300x20	2.0 to 7.0kW
800x800x35	9.0 to 11.0kW

Appendix 6-2-8 Spindle Drive/Motor Combinations

Following combinations are the Standard combinations

Drive Unit	Rating Output (kW) of Applicable Spindle Motor			
Drive Unit	SJ, SJ-V/VL Series Note: 1			
MDS-D-SP(#)-20	0.75			
MDS-D-SP(#)-40	0.75, 1.5, 2.2			
MDS-D-SP(#)-80	2.2, 3.7, 7.5			
MDS-D-SP(#)-160	7.5, 11			
MDS-D-SP(#)-200	11, 15, 18.5			
MDS-D-SP(#)-240	18.5, 22			
MDS-D-SP(#)-320	22, 26, 30			
MDS-D-SP(#)-400	30, 37, 45			
MDS-D-SP(#)-640	37, 45, 55			
MDS-D-SP2(#)-2020	0.75, 1.5 / 0.75, 1.5			
MDS-D-SP2(#)-8040	2.2, 3.7, 7.5 / 0.75, 1.5, 2.2			
MDS-D-SP2(#)-8080	2.2, 3.7, 7.5 / 2.2, 3.7, 7.5			
MDS-D-SP2(#)-16080	7.5, 11 / 2.2, 3.7, 7.5			

Drive Unit	Rating Output (kW) of Applicable Spindle Motor		
Drive Offic	SJ-4, SJ-4-V/VL Series Note: 1		
MDS-DH-SP(#)-20	0.75, 1.5, 2.2, 3.7		
MDS-DH-SP(#)-40	2.2, 3.7, 5.5, 7.5		
MDS-DH-SP(#)-80	2.2, 3.7, 7.5, 11		
MDS-DH-SP(#)-100	7.5, 11, 15, 18.5		
MDS-DH-SP(#)-160	18.5, 22, 26, 30		
MDS-DH-SP(#)-200	26, 30, 37, 45		
MDS-DH-SP(#)-320	30, 37, 45, 55		
MDS-DH-SP(#)-480	45, 55, 60		
MDS-D-SP2(#)-2020	0.75, 1.5, 2.2, 3.7 / 0.75, 1.5, 2.2, 3.7		
MDS-D-SP2(#)-4040	2.2, 3.7, 5.5, 7.5 / 2.2, 3.7, 5.5, 7.5		
MDS-D-SP2(#)-8040	2.2, 3.7, 7.5, 11 / 2.2, 3.7, 5.5, 7.5		

(Note) Applicable unit depends on the range of power constant of motor. Inquire of Mitsubishi about the detail of the combinations.

Drive Unit	Spindle Motor			
Drive Onit	SJ-V	SJ-VL		
MDS-D-SPJ3(#)-075(##)	-	SJ-VL0.75		
MDS-D-SPJ3(#)-22(##)	SJ-V2.2	SJ-VL1.5, SJ-VL2.2		
MDS-D-SPJ3(#)-37(##)	SJ-V3.7	-		
MDS-D-SPJ3(#)-55(##)	SJ-V5.5	-		
MDS-D-SPJ3(#)-75(##)	SJ-V7.5	-		
MDS-D-SPJ3(#)-110(##)	SJ-V11	-		

Appendix 6-2-9 Servo Drive/Motor Combinations

Following combinations are the Standard combinations

Drive Unit	Servomotor					
Drive offic	HF-KP	HF-SP	HF-MP	HF		
MDS-D-SVJ3(#)-03(##)	053, 13, 23	-	053, 13, 23	-		
MDS-D-SVJ3(#)-04(##)	43	-	43	-		
MDS-D-SVJ3(#)-07(##)	73	51, 52	73	54		
MDS-D-SVJ3(#)-10(##)	-	81, 102	-	75, 104, 105		
MDS-D-SVJ3(#)-20(##)	-	121, 152, 201, 202	-	154, 204		
MDS-D-SVJ3(#)-35(##)	-	352	-	354		

(Note #: may be followed by S)

(Note ##: may be followed by N or NA)


(Note) Our drive system complies with UL508C (Power Conversion Equipment), but accessory products (motor, AC reactor, regenerative resistor, etc.) excluding drive units are not provided with UL marking (Listed 88R2) for UL580C.

However, the safety of these accessory products including the motors has been confirmed by UL Follow-Up Service.


Appendix 6 Instruction Manual for Compliance with UL/c-UL

Appendix 6-3 AC Servo/Spindle System Connection

Appendix 6-3-1 MDS-D/DH/DM-Vx/SP Series



Appendix 6-3-2 MDS-D-SVJ3/SPJ3 Series



Appendix 7

Compliance with Restrictions in China

Appendix 7 Compliance with Restrictions in China

Appendix 7-1 Compliance with China CCC certification system

Appendix 7-1-1 Outline of China CCC certification system

The Safety Certification enforced in China included the "CCIB Certification (certification system based on the "Law of the People's Republic of China on Import and Export Commodity Inspection" and "Regulations on Implementation of the Import Commodities Subject to the Safety and Quality Licensing System" enforced by the State Administration of Import and Export Commodity Inspection (SACI) on import/export commodities, and the "CCEE Certification" (certification system based on "Product Quality Certification Management Ordinance" set forth by the China Commission for Conformity Certification of Electrical Equipment (CCEE) on commodities distributed through China.

CCIB Certification and CCEE Certification were merged when China joined WTO (November 2001), and were replaced by the "China Compulsory Product Certification" (hereinafter, CCC Certification) monitored by the State General Administration of Quality Supervision, Inspection and Quarantine (AQSIQ) of the People's Republic of China.

The CCC Certification system was partially enforced from May 2002, and was fully enforced from May 2003. Target commodities which do not have CCC Certification cannot be imported to China or sold in China. (Indication of the CCIB or CCEE mark has been eliminated from May 1, 2003.)

CCIB: China Commodity Inspection Bureau

CCEE: China Commission for Conformity Certification of Electrical Equipment

CCC: China Compulsory Certification

Appendix 7-1-2 First catalogue of products subject to compulsory product certification

The First Catalogue of Products subject to Compulsory Product Certification, covering 132 items (19 categories) based on the CCIB products (104 items), CCEE products (107 items) and CEMC products (Compulsory EMC Certification products) was designated on December 3, 2001.

Class	Product catalogue		Class	Product catalo	gue
1	Electric Wires and Cables (5 items)		5	Electric tools	(16 items)
2	Switches, Installation protective and connection devices (6 items)			Welding machines	(15 items)
	Low-voltage Electrical Apparatus (9 items)	Compulsory Certification Regulations	7	Household and similar electrical appliances	(18 items)
	Circuit-breakers (including RCCB, RCBO, MCB)		8	Audio and video equipment	(16 items)
	Low-voltage switchers (disconnectors, switch-disconnectors, and fuse-combination devices.		9	Information technology equipment	(12 items)
	Other protective equipment for circuits		10	Lighting apparatus	(2 items)
	(Current limiting devices, circuits protective devices, over current protective devices, thermal protectors, over load relays, low-voltage electromechanical contactors and motor starters)		11	Telecommunication terminal equipment	(9 items)
	Relays (36V < Voltage ≦ 1000V)	CNCA -01C -011: 2001 (Switch and Control Equipment) CNCA -01C -012: 2001 (Installation Protective Equipment)	12	Motor vehicles and Safety Parts	(4 items)
	Other switches		13	Tyres	(4 items)
3	(Switches for appliances, vacuum switches, pressure switches,		14	Safety Glasses	(3 items)
	proximity switches, foot switches, thermal sensitive switches,		15	Agricultural Machinery	(1 item)
	hydraulic switches, push-button switches, position limit switches, micro-gap switches, temperature sensitive switches,		16	Latex Products	(1 item)
	travel switches, change-over switches, auto-change-over switches,		17	Medical Devices	(7 items)
	knife switches)		18	Fire Fighting Equipment	(3 items)
	Other devices (contactors, motor starters, indicator lights, auxiliary contact		19	Detectors for Intruder Alarm Systems	(1 item)
	assemblies, master controllers, A.C. Semiconductor motor controllers and starters)				
	Earth leakage protectors	1			
	Fuses				
	Low-voltage switchgear	CNCA-01C-010:2001 (Low-voltage switchgear)			
4 (Note)	Small power motors (1 item)	CNCA-01C-013:2001 (Small power motors)			

(Note) When the servomotor or the spindle motor of which output is 1.1kW or less (at 1500 r/min) is used, NC could have been considered as a small power motor. However, CQC (China Quality Certification Center) judged it is not.

Appendix 7-1-3 Precautions for shipping products

As indicated in Appendix 7-1-2, NC products are not included in the First Catalogue of Products subject to Compulsory Product Certification. However, the Customs Officer in China may judge that the product is subject to CCC Certification just based on the HS Code.(Note2)

NC cannot be imported if its HS code is used for the product subject to CCC Certification. <u>Thus, the importer must apply for a "Certification of Exemption" with CNCA.</u>(Note3) Refer to Appendix 7-1-4. Application for Exemption for details on applying for an exemption.

- (Note 1) The First Catalogue of Products subject to Compulsory Product Certification (Target HS Codes) can be confirmed at http://www.cqc.com.cn/Center/html/60gonggao.htm.
- (Note 2) HS Code: Internationally unified code (up to 6 digits) assigned to each product and used for customs.
- (Note 3) CNCA: Certification and Accreditation Administration of People's Republic of China (Management and monitoring of certification duties)

Appendix 7-1-4 Application for exemption

Following "Announcement 8" issued by the Certification and Accreditation Administration of the People's Republic of China (CNCA) in May 2002, a range of products for which application for CCC Certification is not required or which are exempt from CCC marking has been approved for special circumstances in production, export and management activities.

An application must be submitted together with materials which prove that the corresponding product complies with the exemption conditions. Upon approval, a "Certification of Exemption" shall be issued.

<Range of products for which application is exempt>

Range of products not requiring application

- (a) Items brought into China for the personal use by the foreign embassies, consulates, business agencies and visitors
 - (Excluding products purchased from Service Company for Exporters)
- (b) Products presented on a government-to-government basis, presents
- (c) Exhibition products (products not for sale)
- (d) Special purpose products (e.g., for military use) Products not requiring application for CCC Certification are not required to be CCC marked or certified.

Range of products for which application is exempted

- (e) Products imported or manufactured for research and development and testing purposes
- (f) Products shipped into China for integration into other equipment destined for 100% re-export to a destination outside of China
- (g) Products for 100% export according to a foreign trade contract (Excluding when selling partially in China or re-importing into China for sales)
- (h) Components used for the evaluation of an imported product line
- (i) The products imported or manufactured for the service (service and repairs) to the end-user. Or the spare parts for the service (service and repairs) of discontinued products.
- (j) Products imported or manufactured for research and development, testing or measurements
- (k) Other special situations

Appendix 7 Compliance with Restrictions in China

The following documents must be prepared to apply for an exemption of the "Import Commodity Safety and Quality License" and "CCC Certification".

- (1) Formal Application
 - (a) Relevant introduction and description of the company.
 - (b) The characteristics of the products to be exempted.
 - (c) The reason for exemption and its evidence (ex. customs handbook).
 - (d) The name, trademark, quantity, model and specification of the products to be exempted. (Attach a detail listing of these items for a large quantity of products. When importing materials for processing and repair equipments, submit a list of the importing materials for each month and repair equipments.)
 - (e) Guarantee for the safety of the products; self-declaration to be responsible for the safety during the manufacturing and use.
 - (f) To be responsible for the authenticity and legitimacy of the submitted documents. Commitment to assist CNCA to investigate on the authenticity of the documents (When CNCA finds it necessary to investigate on the authenticity of the documents.)
- (2) Business license of the company (Copy)
- (3) Product compliance declaration Indicate which standard's requirements the products comply with or submit a test report (Copy is acceptable. The report can be prepared in a manufacturer's laboratory either at home or overseas.)
- (4) Import license (Only if an import license is needed for this product. Copy is acceptable.)
- (5) Quota certificate (Only if a quota certificate is needed for this product. Copy is acceptable.)
- (6) Commercial contract (Copy is acceptable.)
- (7) If one of item (4), (5) or (6) cannot be provided, alternative documents, such as bill of lading, the invoice, and other evidential documents must be submitted.

Appendix 7-1-5 Mitsubishi NC product subject to/not subject to CCC certification

The state whether or not Mitsubishi NC products are subject to the CCC Certification is indicated below, based on the "First Catalogue of Products subject to Compulsory Product Certification" issued by the State General Administration of Quality Supervision, Inspection and Quarantine (AQSIQ) of the People's Republic of China and the Certification and Accreditation Administration of the People's Republic of China (CNCA) on July 1, 2002.

Model	China HS Code (Note 1)	Judgment on whether or not subject to CCC Certification	
Power supply unit	85044090	Not subject to CCC Certification	
Servo/spindle drive unit	85371010	Not subject to CCC Certification	
Servo/spindle	85015100	Not subject to CCC Certification	
	85015200		
NC	-	Not subject to CCC Certification	
Display unit	-	Not subject to CCC Certification	

- (Note 1) The China HS Code is determined by the customs officer when importing to China. The above HS Codes are set based on the HS Codes used normally when exporting from Japan.
- (Note 2) Reference IEC Standards are used as the actual IEC Standards may not match the GB Standards in part depending on the model.

Whether or not the NC products are subject to CCC Certification was judged based on the following five items.

- (a) Announcement 33 (Issued by AQSIQ and CNCA in December 2001)
- (b) HS Codes for the products subject to CCC Certification (Export Customs Codes)
 - * HS Codes are supplementary materials used to determine the applicable range. The applicable range may not be determined only by these HS Codes.
- (c) GB Standards (This is based on the IEC Conformity, so check the IEC. Note that some parts are deviated.)
- (d) Enforcement regulations, and products specified in applicable range of applicable standards within
- (e) "Products Excluded from Compulsory Certification Catalogue" (Issued by CNCA, November 2003)

Reference

- Outline of China's New Certification System (CCC Mark for Electric Products), Japan Electrical Manufacturers' Association
- Outline of China's New Certification System (CCC Mark for Electric Products) and Electric Control Equipment, Nippon Electric Control Equipment Industries Association

Appendix 7 Compliance with Restrictions in China

Appendix 7-2 Response to the China environment restrictions

Appendix 7-2-1 Outline of the law on the pollution prevention and control for electronic information products

Ministry of Information Industry (information industry ministry) issued this law on Feb.28, 2006 (Note) (effective from Mar.1, 2007.) in order to protect the environment and the health of the people with restricting and reducing the environmental pollution caused by the electronic information product wastes. The restrictions are applied to containing lead (Pb), hydrargyrum (Hg), cadmium (Cd), hexavalent chromium (Cr (VI)), polybrominated biphenyl (PBB) and polybrominated diphenyl ether (PBDE) in two stages.

(Note)For the details, refer to the following.

http://www.mii.gov.cn/art/2006/03/02/art_524_7343.html

(1) First stage: Requirement of indicating contained substance

The producer and importer of the electronic information product are required to indicate the hazardous substance. The concrete categories of the products belonging in the following eleven main categories are described as subjected product list (electronic information product category note).

- Radar device Communication device Radio/TV device industry product Computer product
- Consumer-electronics device Electronic measuring apparatus
- Electronics industry dedicated device Electronic parts Electronics device
- Electronics application product Electronics dedicated material

(2) Second stage: Suppressing the amount of contained substances and compulsory CCC Certification The product listed in the "Electronic information product pollution priority control list" cannot be sold in China unless it conforms to the Compulsory Product Certification System (CCC Certification) and its cadmium usage is suppressed to 0.01w% and other substances usage less than 0.1w%. Note that the timing when this is effective is unmentioned.

Appendix 7-2-2 Response to the drive product for Mitsubishi NC

The drive product for NC has no items falling under the subjected product list (electronic information product category note). However, for use with the drive product included in the subjected product or for treating the product properly, information based on the law on the pollution prevention and control for electronic information products" are described in the section "Appendix 7-2-3" for reference.

Appendix 7-2-3 Indication based on "Pollution suppression marking request for electronic information product"

(1) Electronic information product pollution suppression marking



Note: This symbol mark is for China only.

This marking indicates the environmental protection expiration date applied to the electronic information products sold in China according to the law on the pollution prevention and control for electronic information products issued on Feb.28, 2006. As long as you keep safety for this product and follow the precautions for use, there are no serious effects on the environment pollution, human body or property within its term reckoned from the manufacturing date.

(Note) Equate the environmental protection expiration date of consumables, such as enclosed battery and cooling fan, with the product life. When disposing the product after using it properly, obey each local laws and restrictions for collecting and recycling of the electronic information product.

(2) The names of contained six hazardous substances and the parts containing them

The names of six substances contained in this product and the parts containing them are shown below.

	Toxic/hazardous substance or element					
Parts name	Lead (Pb)	Hydrargyrum (Hg)	Cadmium (Cd)	Hexavalent chromium (Cr (VI))	(PBB)	(PBDE)
Drive unit	-	**	**	**	**	**
Servo motor/spindle motor	-	**	**	**	**	**
Dedicated options (cable/connector)	-	**	**	-	**	**
Dedicated Options (detector/AC reactor)	-	**	**	-	**	**
Dedicated Options (battery)	-	**	**	**	**	**

^{**:} This mark means that toxic/hazardous substance content in all homogeneous materials of corresponding parts does not exceed the standard specified in the standard of SJ/T11363-2006.

-: This mark means that toxic/hazardous substance content in the homogeneous materials of corresponding parts exceeds the standard specified in the standard of SJ/T11363-2006.

Appendix 7 Compliance with Restrictions in China

Revision History

Date of revision	Manual No.	Revision details
Oct. 2008	IB(NA)1500875-A	First edition created. MDS-D Specifications Manual (IB1500010) and MDS-DH Specifications Manual (IB1500002) were integrated.
Sep. 2009	IB(NA)1500875-B	- The following servomotors were added.
		HF224, HF123, HF223, HF303, HF142, HF302
		- The following drive units were added.
		MDS-D-V2-160160W, MDS-DH-V2-8080W
		- MDS-D-SP2 Series spindle drive units were added.
		- Lineup and specifications of 200V system spindle motors were overall
		revised.
		- "Function specifications" (function specifications list and explanation of each
		function) were added.
		- Explanation of the system establishment in the full closed loop control was
		revised.
		- Explanation of the speed command synchronization control system
		configuration was added.
		- "Machine side detector" was revised.
		- "Spindle side accuracy detector (TS5690 series)" was added.
		- "C-axis control detector" was revised.
		- The following detector interface units were added.
		IBV series, EIB192M, EIB392M, ADB-20J series
		- "Optical servo communication repeater unit (FCU7-EX022)" was added.
		- The type names of HF/HF-H, HP/HP-H Detector connector were changed.
		- Specifications of HF-KP motor cable and connector were added.
		- "Restrictions for Lithium Batteries" was revised.
		- "Compliance to EC Directives" was revised.
		- "EMC Installation Guidelines" was revised.
		- "EC Declaration of conformity" was revised.
		- "Instruction Manual for Compliance with UL/c-UL Standard" was revised.
		- "Grobal service network" was revised.
		- The outline dimension drawings were deleted form this manual.
		For the outline dimension drawings, refer to "DRIVE SYSTEM DATA BOOK
		(IB-1500273(ENG))".
Feb. 2010	IB(NA)1500875-C	- "Outline for MDS-D/DH Series Instruction Manual (IB-1500025-F)" was
		added.
		- "Speed monitoring function" was revised to "Safety monitoring function" .
		- "High-speed READY ON sequence" was added.
		- "Monitor output function" was revised.
		- Descriptions of MDS-D-SP2 Series spindle drive unit was added.

Date of revision	Manual No.	Revision details
Feb. 2010	IB(NA)1500875-C	- The section titles were revised in "Servo options" and "Detector interface
		unit".
		- Explanation of connectors was added to "Serial output interface unit for ABZ
		analog detector MDS-B-HR", "Serial signal division unit MDS-B-SD", and
		"Optical communication repeater unit (FCU7-EX022)".
		- "List of cables and connectors" was revised.
		- Input circuit diagram in "Relay" was revised.
		- Notes were added to "Calculation of spindle output".
		- "Cable and Connector Specifications" was revised.
		- "Compliance to EC Directives" was revised.
		- "EMC Installation Guidelines" was revised.
		- "EC Declaration of Conformity" was revised.
		- "Instruction Manual for Compliance with UL/c-UL Standard" was revised.
		- "Global service network" was revised.
		- Miswrite is corrected.
Mar. 2011	IB(NA)1500875-D	- "Introduction" was revised.
		- "System configuration" was revised.
		- SJ- D Series and SJ- DJ Series were added.
		- Notes were added to "Spindle motor type".
		- MDS-D-SP2- 4040S and MDS-D-SP2-16080S were added.
		- MDS-D-V2-160160W was added as the compatible drive unit for the
		servomotors, HF354, HF453, HP354 and HP454.
		- MDS-DH-V2-8080W was ad ded as the co mpatible drive unit for the
		servomotors, HF-H354, HF-H453, HP-H354, and HP-H454.
		- Descriptions for tool spindle motor was added.
		- Specifications list of servomotor and spindle motor were revised.
		- "Output characteristics" in "Spindle motor" was revised.
		- Function specifications list was revised.
		- "Proximity switch orientation control" was added.
		- "Variable speed loop gain control", "High- speed synchronous tapping control
		(OMR- DD control)", "Dual feedback control" were revised.
		- "High frequency current control" was added.
		- "Spindle motor temperature compensation function" was revised.
		- Spindle channel 120,121,122 and 123 were added.
		- "D/A output specifications" was revised.
		- A caution was added to "Shaft characteristics" in "Spindle motor".
		- "Sony Manufacturing Systems Corporation" was changed to " Magnescale
		Co., LTD".
		- SAM/SVAM/GAM/LAM Series (FAGOR) and MPS/MPI Series (MHI) were
		added.
		- "Dynamic brake unit (MDS- D- DBU)" was revised.

Date of revision	Manual No.	Revision details
Mar. 2011	IB(NA)1500875-D	- "FCU6- BTBOX- 36" was replaced by "MDS- BTBOX- 36".
		- "System configuration" in "Converged battery option" was revised.
		- "Spindle options" was revised.
		- "(MITSU02-4)" was added to EIB192M and EIB392M.
		- ADB- 20J60 was added.
		- "Optical communication repeater unit (FCU7- EX022)" was revised.
		- "Cable connection diagram" was revised.
		- "List of cable and connectors" was revised.
		- The values of M side were added to "Example of wires".
		- "Selection of circuit protector and contactor" was revised.
		- "Relay" was revised.
		- "Selection of the servomotor" was revised.
		- "Cable and Connector Specifications" was revised.
		- "Compliance to EC Directives" was revised.
		- "EMC Installation Guidelines" was revised.
		- "EC Declaration of Conformity" was revised.
		- "Instruction Manual for Compliance with UL/c- UL Standard" was revised.
		- Miswrite is corrected.
Jan. 2012	IB(NA)1500875-E	- "Introduction" was revised.
		- "Handling of our product" was added.
		- "HF*-A74" and "HP*-A74" were replaced by "-A74N".
		- "OSA105-ET2" was replaced by "OSA105ET2".
		- "OSA166-ET2" was replaced by "OSA166ET2N".
		- "Servomotor type", "Servo drive unit type", "Spindle motor type" and "Tool
		spindle motor type" were revised.
		- Specifications lists in "Servomotor", "Spindle motor" and "Tool spindle motor"
		were revised.
		- "Explanation of each part" was revised.
		- Function specifications list was revised.
		- "Power regen eration control", "Resistor regeneration control", "Fan stop
		detection", "Open-phase detection", "Contactor weld detection" and "Power
		supply voltage display function" were added in "Function specifications".
		- "High frequency current control" was deleted
		- "Installation of servo motor" was revised.
		- Overload protection characteristics for HF104, HF204, HF354, HP54, HP104,
		HP903, HP1103, HF-H104, HP-H54, HP-H903 and HP-H1103 were revised.
		- "Machine accuracy" and "Installation of spindle motor" were added in "Spindle
		motor".
		- "Servo options" and "Spindle options" were revised.

Date of revision	Manual No.	Revision details
Jan. 2012	IB(NA)1500875-E	- "Optical communication repeater unit (FCU7-EX022)" and "DC connection
		bar" were revised.
		- "List of cable and connectors" and "Relay" were revised.
		- "Cable and Connector Specifications" was revised.
		- "Restrictions for Lithium Batteries" was revised.
		- "Compliance to EC Directives" was revised.
		- "EMC Installation Guidelines" was revised.
		- "Instruction Manual for Compliance with UL/c- UL Standard" was revised.
		- "Compliance with Restrictions in China" was revised.
		- Miswrite is corrected.

Global Service Network

MITSUBISHI ELECTRIC AUTOMATION INC. (AMERICA FA CENTER)

Central Region Service Center
500 CORPORATE WOODS PARKWAY, VERNON HILLS, ILLINOIS 60061, U.S.A.
TEL: +1-847-478-2500 / FAX: +1-847-478-2650

Michigan Service Satellite ALLEGAN, MICHICAN 49010, U.S.A. TEL: +1-847-478-2500 / FAX: +1-269-673-4092

Ohio Service Satellite

DNIO Service Satellite
LIMA, OHIO 45801, U.S.A.
TEL: +1-847-478-2500 / FAX: +1-847-478-2650
CLEVELAND, OHIO 44114, U.S.A.
TEL: +1-847-478-2500 / FAX: +1-847-478-2650

Minnesota Service Satellite
MINNEAPOLIS, MINNESOTA 55413, U.S.A.

TEL: +1-847-478-2500 / FAX: +1-847-478-2650

West Region Service Center 5665 PLAZA DRIVE, CYPRESS, CALIFORNIA 90630, U.S.A. TEL: +1-714-220-4796 / FAX: +1-714-229-3818

East Region Service Center 200 COTTONTAIL LANE SOMERSET, NEW JERSEY 08873, U.S.A. TEL: +1-732-560-4500 / FAX: +1-732-560-4531

Pennsylvania Service Satellite ERIE, PENNSYLVANIA 16510, U.S.A. TEL: +1-814-897-7820 / FAX: +1-814-987-7820

Massachusetts Service Satellite BOSTON, MASSACHUSETTS 02108, U.S.A.

TEL: +1-508-216-6104

South Region Service Center
2810 PREMIERE PARKWAY SUITE 400, DULUTH, GEORGIA 30097, U.S.A.
TEL: +1-678-258-4500 / FAX: +1-678-258-4519

Texas Service Satellites

EAS SEVICE SECTION SEVEN SE

Florida Service Satellite

WEST MELBOURNE, FLORIDA 32904, U.S.A. TEL: +1-321-610-4436 / FAX: +1-321-610-4437

Canada Region Service Center 4299 14TH AVENUE MARKHAM, ONTARIO L3R OJ2, CANADA TEL: +1-905-475-7728 / FAX: +1-905-475-7935

Mexico City Service Center

MARIANO ESCOBEDO 69 TLALNEPANTLA, 54030 EDO. DE MEXICO
TEL: +52-55-9171-7662 / FAX: +52-55-9171-7649

Monterrey Service Satellite MONTERREY, N.L., 64720, MEXICO TEL: +52-81-8365-4171 / FAX: +52-81-8365-4171

Brazil Region Service Center ACESSO JOSE SARTORELLI, KM 2.1 CEP 18550-000, BOITUVA-SP, BRAZIL TEL: +55-15-3363-9900 / FAX: +55-15-3363-9911

Brazil Service Satellites

PORTO ALEGRE AND CAXIAS DO SUL BRAZIL TEL: +55-15-3363-9927

SANTA CATARINA AND PARANA STATES

MITSUBISHI ELECTRIC EUROPE B.V. (EUROPE FA CENTER)

GOTHAER STRASSE 10, 40880 RATINGEN, GERMANY TEL: +49-2102-486-0 / FAX: +49-2102-486-5910

Germany Service Center KURZE STRASSE. 40, 70794 FILDERSTADT-BONLANDEN, GERMANY TEL: + 49-711-3270-010 / FAX: +49-711-3270-0141

France Service Center

25, BOULEVARD DES BOUVETS, 92741 NANTERRE CEDEX FRANCE
TEL: +33-1-41-02-83-13 / FAX: +33-1-49-01-07-25

France (Lyon) Service Satellite 120, ALLEE JACQUES MONOD 69800 SAINT PRIEST FRANCE TEL: +33-1-41-02-83-13 / FAX: +33-1-49-01-07-25

Italy Service Center
VIALE COLLEONI 7-PALAZZO SIRIO CENTRO DIREZIONALE COLLEONI,
20041 AGRATE BRIANZA MILANO ITALY
TEL: +39-039-60531-342 / FAX: +39-039-6053-206

Italy (Padova) Service Satellite
VIA SAVELLI 24 - 35129 PADOVA ITALY
TEL: +39-039-60531-342 / FAX: +39-039-6053-206

U.K. Service Center
TRAVELLERS LANE, HATFIELD, HERTFORDSHIRE, AL10 8XB, U.K.
TEL: +44-1707-27-6100 / FAX: +44-1707-27-8992

Spain Service Center CTRA. DE RUBI, 76-80-APDO. 420

08190 SAINT CUGAT DEL VALLES, BARCELONA SPAIN TEL: +34-935-65-2236 / FAX: +34-935-89-1579

Poland Service Center UL.KRAKOWSKA 50, 32-083 BALICE, POLAND TEL: +48-12-630-4700 / FAX: +48-12-630-4727

Poland (Wroclaw) Service Center UL KOBIERZYCKA 23, 52-315 WROCLAW, POLAND TEL: +48-71-333-77-53 / FAX: +48-71-333-77-53

Turkey Service Center
BAYRAKTAR BULVARI, NUTUK SOKAK NO.5, YUKARI DUDULLU

ISTANBUL, TURKEY TEL: +90-216-526-3990 / FAX: +90-216-526-3995

Czech Republic Service Center
TECHNOLOGICKA 374/6,708 00 OSTRAVA-PUSTKOVEC, CZECH REPUBLIC
TEL: +420-59-5691-185 / FAX: +420-59-5691-199

Russia Service Center 213, B.NOVODMITROVSKAYA STR., 14/2, 127015 MOSCOW, RUSSIA

TEL: +7-495-748-0191 / FAX: +7-495-748-0192

weden Service Center STRANDKULLEN, 718 91 FROVI, SWEDEN TEL: +46-581-700-20 / FAX: +46-581-700-75

Bulgaria Service Center 4 A. LYAPCHEV BOUL., 1756 - SOFIA, BULGARIA

TEL: +359-2-8176000 / FAX: +359-2-9744061

Ukraine (Kharkov) Service Center APTEKARSKIY LANE 9-A, OFFICE 3, 61001 KHARKOV, UKRAINE TEL: +380-57-732-7774 / FAX: +380-57-731-8721

Ukraine (Kiev) Service Center 4-B, M. RASKOVOYI STR., 02660 KIEV, UKRAINE TEL: +380-044-494-3355 / FAX: +380-044-494-3366

Belarus Service Center 703, OKTYABRSKAYA STR., 16/5, 220030 MINSK, BELARUS

TEL: +375-17-210-4626 / FAX: +375-17-227-5830

South Africa Service Center
P.O. BOX 9234, EDLEEN, KEMPTON PARK GAUTENG, 1625 SOUTH AFRICA
TEL: +27-11-394-8512 / FAX: +27-11-394-8513

Denmark Service Center
KARETMAGERVEJ. 7A, DK-7000, FREDERICIA, DENMARK

TEL: +45-7620-7514

MITSUBISHI ELECTRIC ASIA PTE. LTD. (ASEAN FA CENTER)

307 ALEXANDRA ROAD #05-01/02 MITSUBISHI ELECTRIC BUILDING SINGAPORE 159943 TEL: +65-6473-2308 / FAX: +65-6476-7439

Indonesia Service Center
THE PLAZZA OFFICE TOWER, 28TH FLOOR JL.M.H. THAMRIN KAV.28-30, JAKARTA, INDONESIA TEL: +62-21-2992-2333 / FAX: +62-21-2992-2555

Malaysia (KL) Service Center

60, JALAN USJ 10 /18 47620 UEP SUBANG JAYA SELANGOR DARUL EHSAN, MALAYSIA TEL: +60-3-5631-7605 / FAX: +60-3-5631-7636

Malaysia (Johor Baru) Service Center
NO. 16, JALAN SHAH BANDAR 1, TAMAN UNGKU TUN AMINAH, 81300 SKUDAI, JOHOR MALAYSIA
TEL: +60-7-557-6218 | FAX: +60-7-557-3404

Vietnam Service Center-1

ROOM 1004, 1005, FLOOR 10, 255 TRAN HUNG DAO CO GIANG WARD, DIST. 1, HCMC, VIETNAM TEL: +84-8-3838-6931 / FAX: +84-8-3838-6932

Vietnam Service Center-2 LOT G10 - AREA 4 - HIEP BINH CHANH WARD - THU DUC DISTRICT - HCMC, VIETNAM TEL: +84-8-2240-3587 / FAX: +84-8-3726-7968

Vietnam (Hanoi) Service Center 5FL, 59 - XA DAN STR., DONG DA DIST., HN, VIETNAM TEL: +84-4-3573-7646 / FAX: +84-4-3573-7650

Philippines Service Center
UNIT NO.411, ALABAMG CORPORATE CENTER KM 25. WEST SERVICE ROAD SOUTH SUPERHIGHWAY, ALABAMG MUNTINLUPA METRO MANILA, PHILIPPINES 1771 TEL: +63-2-807-2416 / FAX: +63-2-807-2417

MITSUBISHI ELECTRIC AUTOMATION (THAILAND) CO., LTD. (THAILAND FA CENTER)

BANG-CHAN INDUSTRIAL ESTATE NO. 111 SOI SERITHAI 54 T.KANNAYAO, A.KANNAYAO, BANGKOK 10230, THAILAND TEL: +66-2906-8255 / FAX: +66-2906-3239

Thailand Service Center 898/19,20,21,22 S.V. CITY BUILDING OFFICE TOWER 1, FLOOR 7 RAMA III RD, BANGPONGPANG, YANNAWA, BANGKOK 10120, THAILAND TEL: +66-2-682-6522 / FAX: +66-2-682-9750

INDIA

MITSUBISHI ELECTRIC INDIA PVT. LTD.

India Service Center
2nd FLOOR, TOWER A & B, DLF CYBER GREENS, DLF CYBER CITY, DLF PHASE-III,
GURGAON- 122 002, HARYANA, INDIA TEL: +91-124-4630300 / FAX: +91-124-4630399

India (Bangalore) Service Center
FIRST & SECOND FLOOR, AVR BASE, MUNICIPAL NO.BC-308,
HENNURE BANASWADI ROAD, HRBR RING ROAD, BANGALORE-560 043, INDIA TEL: +91-80-4020-1600 / FAX: +91-80-4020-1699

Chennai satellite office Coimbatore satellite office

India (Pune) Service Cente TEL: +91-998-7997651 Baroda satellite office

OCEANIA

MITSUBISHI ELECTRIC AUSTRALIA LTD.

Oceania Service Center 348 VICTORIA ROAD, RYDALMERE, N.S.W. 2116 AUSTRALIA TEL: +61-2-9684-7269 / FAX: +61-2-9684-7245

MITSUBISHI ELECTRIC AUTOMATION (CHINA) LTD. (CHINA FA CENTER) MITSUBISHI ELECTRIC AUTOMATION (CHINA) LTD. (CHIN China (Shangha)) Service Center 1-3,5-10,18-23/F, NO.1386 HONG QIAO ROAD, CHANG NING QU, SHANGHAI 200336, CHINA TEL: +86-2-12322-3030 / FAX: +86-21-2308-2830 China (Ningbo) Service Dealer China (Wuxi) Service Dealer China (Jinan) Service Dealer China (Wuhan) Service Satellite

China (Beijing) Service Center

9/F, OFFICE TOWER 1, HENDERSON CENTER, 18 JIANGUOMENNEI DAJIE,
DONGCHENG DISTRICT, BELJING 100005, CHINA
TEL: +88-10-6518-8830 / FAX: +98-10-6518-3907

China (Beijing) Service Dealer

China (Tianjin) Service Center
B-2 801/802, YOUYI BUILDING, NO.50 YOUYI ROAD, HEXI DISTRICT,
TIANJIN 300061, CHINA
TEL: +86-22-2813-1015 / FAX: +86-22-2813-1017
China (Shenyang) Service Satellite
China (Changchun) Service Satellite

China (Chengdu) Service Center

ROOM 407-408, OFFICE TOWER AT SHANGRI-LA CENTER, NO. 9 BINJIANG DONG ROAD, JINJIANG DISTRICT, CHENGDU, SICHUAN 610021, CHINA TEL: +86-28-8446-8030 / FAX: +86-28-8446-8630

China (Shenzhen) Service Center

inina (anenizieri) service center ROOM 2512-2516, 251F., GREAT CHINA INTERNATIONAL EXCHANGE SQUARE, JINTIAN RD.S., FUTIAN DISTRICT, SHENZHEN 518034, CHINA

China (Xiamen) Service Dealer
China (Dongguan) Service Dealer

MITSUBISHI ELECTRIC AUTOMATION KOREA CO., LTD. (KOREA FA CENTER)

Korea Service Center 1480-6, GAYANG-DONG, GANGSEO-GU SEOUL 157-200, KOREA TEL: +82-2-3660-9602 / FAX: +82-2-3664-8668

Korea Taegu Service Satellite

603 CRYSTAL BUILDING 1666, SANBYEOK-DONG, BUK-KU, DAEGU, 702-010, KOREA TEL: +82-53-604-6047 / FAX: +82-53-604-6049

MITSUBISHI ELECTRIC TAIWAN CO., LTD. (TAIWAN FA CENTER)

Taiwan (Taichung) Service Center

NO.8-1, GONG YEH 16TH RD., TAICHUNG INDUSTRIAL PARK TAICHUNG CITY, TAIWAN R.O.C.
TEL: +886-4-2359-0688 / FAX: +886-4-2359-0689

Taiwan (Taipei) Service Center

3RD. FLOOR, NO.122 WUKUNG 2ND RD., WU-KU HSIANG, TAIPEI HSIEN, TAIWAN R.O.C. TEL: +886-2-2299-2205 / FAX: +886-2-2298-1909

Taiwan (Tainan) Service Center 2F(C),1-1, CHUNGHWA-RD., YONGKANG CITY, TAINAN HSIEN, TAIWAN R.O.C. TEL: +886-6-313-9600 / FAX: +886-6-313-7713

Notice

Every effort has been made to keep up with software and hardware revisions in the contents described in this manual. However, please understand that in some unavoidable cases simultaneous revision is not possible.

Please contact your Mitsubishi Electric dealer with any questions or comments regarding the use of this product.

Duplication Prohibited

This manual may not be rep roduced in any form, in part or in whole, without written permission from Mitsubishi Electric Corporation.

© 2008 - 2012 Mitsubishi Electric Corporation ALL RIGHTS RESERVED

MITSUBISHI CNC



MODEL	MDS-D/DH Series	
MODEL CODE	100-151	
Manual No.	IB-1500875	