

Intel[®] Server Boards S3210SH/S3200SH

Tested Hardware and Operating System List

Revision 2.2

November 2008

Enterprise Platforms and Services Marketing

Revision History

| Date | Revision Number | Modifications |
|----------|--------------------|--|
| Sep 2007 | 1.0 | Initial release. |
| Nov 2007 | 1.1 | Added updates to NIC adapters. |
| Dec 2007 | 1.2 | Added updates to RAID adapters. |
| Jan 2008 | 1.3 | Removed HDDs and added updates to RAID adapters. |
| Mar 2008 | 1.4 | Removed Microsoft Windows 2000* support due to ICH9R |
| | | compatibility issues. |
| Mar 2008 | 1.5 | Added SAS HW RAID adapters. |
| Apr 2008 | 1.6 | Removed 3 HW RAID adapters and added Windows XP |
| Apr 2008 | 1.7 | Added SAS HW RAID adapters. |
| May 2008 | 1.8 | Added Windows 2008 |
| Jun 2008 | 1.9 | Added several Adaptec SAS RAID cards |
| Sep 2008 | 2.0 | Added Solaris 10U5 as P2 OS |
| Oct 2008 | 2.1 | Added Teac DV-28S-VZ3 |
| Nov 2008 | 2.2 | Added RAID adapters |

ii Revision 2.2

Disclaimers

THE INFORMATION IN THIS DOCUMENT IS PROVIDED "AS IS" WITH NO WARRANTIES WHATSOEVER, INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR ANY PARTICULAR PURPOSE, OR ANY WARRANTY OTHERWISE ARISING OUT OF ANY PROPOSAL SPECIFICATION. OR SAMPLE.

Information in this document is provided in connection with Intel® products. No license, express or implied, by estoppel or otherwise, to any intellectual property rights is granted by this document. Except as provided in Intel's Terms and Conditions of Sale for such products, Intel assumes no liability whatsoever, and Intel disclaims any express or implied warranty, relating to sale and/or use of Intel products including liability or warranties relating to fitness for a particular purpose, merchantability, or infringement of any patent, copyright or other intellectual property right. Intel products are not intended for use in medical, life saving, or life sustaining applications.

Intel retains the right to make changes to its test specifications at any time, without notice.

The hardware vendor remains solely responsible for the design, sale and functionality of its product, including any liability arising from product infringement or product warranty.

Copyright © Intel Corporation 2008. All rights reserved.

Intel, the Intel logo, and EtherExpress are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

*Other names or brands may be claimed as the property of others.

Table of Contents

| 1. Introd | luction | |
|-----------|---|----|
| 1.1 | Test Overview | 1 |
| 1.1.1 | Basic Installation Testing | 1 |
| 1.1.2 | Adapter / Peripheral Compatibility and Stress Testing | 2 |
| 1.2 | Pass/Fail Test Criteria | 3 |
| 2. Base | System Configurations | 4 |
| 3. Supp | orted Operating Systems | 5 |
| 3.1 | Operating System Certifications | 6 |
| 4. Adapt | ters and Peripherals | 9 |
| 5. Hard | Disk Drives | 17 |

1. Introduction

This document is intended to provide users of the Intel[®] Server Boards S3210SH/S3200SH with a guide to the different operating systems, adapter cards, and peripherals tested by Intel on this platform.

This document will continue to be updated as new adapters, peripherals, and operating systems are tested or until the Intel[®] Server Boards S3210SH/S3200SH are no longer in production. Each new release of the document will present updated information as well as continue to provide the information from previous releases.

Intel will only provide support for those adapters and peripherals under the specified system configuration (System BIOS and Firmware revisions) and operating systems versions with which they were tested.

1.1 Test Overview

Testing performed on the Intel® Server Boards S3210SH/S3200SH are classified under two separate categories: Basic Installation Testing, and Adapter / Peripheral Compatibility and Stress Testing.

1.1.1 Basic Installation Testing

Basic installation testing is performed with each supported operating system. Basic installation testing validates that the server board can install the operating system and that the base hardware feature set is functional. A small set of peripherals is used for installation purposes only. No add-in adapter cards are tested. Testing includes network connectivity and running of proprietary and industry standard test suites.



The latest version of an operating system signifies the latest supported version at the time of the actual test run. Each new release of this document may have a newly supported release of a given operating system. Previous releases of a supported operating system may not be tested beyond the basic installation test process.

1.1.1.1 Support Commitment for Basic Installation Testing

Intel commits to provide the following level of customer support for operating systems that receive only basic installation testing:

- Intel will provide and test operating system drivers for each of the server board's
 integrated controllers, provided that the controller vendor has a driver available upon
 request. Vendors will not be required by Intel to develop drivers for operating systems
 that they do not already support. This may limit the functionality of certain server board
 integrated controllers.
- Intel will support customer issues that involve installation and/or functionality of operating system with the server board's integrated controllers only if a driver has been made available.

- Intel will NOT provide support for issues related to use of any add-in adapters or peripherals installed in the server system when an operating system that received basic installation testing only is in use.
- Support is defined as assistance in root causing issues, and determining a customer
 acceptable resolution to the issue associated with the operating system. The resolution
 may include, but is not limited to, on-board controller driver changes, engaging the
 vendor for resolution, BIOS changes, firmware changes, or determining a customer
 acceptable workaround for the issue.

1.1.2 Adapter / Peripheral Compatibility and Stress Testing

Adapter / Peripheral Compatibility and Stress testing is performed only on the most current release of a supported operating system at the time of a given validation run. The Adapter / Peripheral Compatibility and Stress testing process consists of three areas: Base Platform, Adapter Compatibility, and Stress.

Base Platform: Each base platform will successfully install a given operating system, successfully run a disk stress test, and successfully run a network stress test.

Adapter Compatibility: Adapter compatibility validation (CV) testing uses test suites to gain an accurate view of how the server performs with a wide variety of adapters under the primary supported operating systems. These tests are designed to show hardware compatibility between the cards and the server platform and include functional testing only. No heavy stressing of the systems or the cards is performed for CV testing.

Stress Testing: This test sequence uses configurations that include add-in adapters in all available slots, (depending on chassis used) for a minimum 72-hour test run without injecting errors. Each configuration passes an installation test, a Network/Disk Stress test, and tape backup test. Any fatal errors that occur will require a complete test restart.

1.1.2.1 Support Commitment for Adapter / Peripheral Compatibility and Stress Testing

Intel commits to provide the following level of customer support for operating systems that receive Adapter / Peripheral Compatibility and Stress testing:

- Intel will provide support for customer issues with these operating systems involving
 installation and/or functionality of the server board with or without the adapters and
 peripherals listed in this document as having been tested under the particular operating
 system.
- Support is defined as assistance in root causing issues, and determining a customer
 acceptable resolution to the issue associated with the operating system. The resolution
 may include, but is not limited to, on-board controller driver changes, engaging the
 vendor for resolution, BIOS changes, firmware changes, or determining a customer
 acceptable workaround for the issue.
- Intel will provide and test operating system drivers for each onboard video, network, and storage controller.
- Intel will enable vendors to provide driver support for add-in adapters using these operating systems.

Intel will go through some of the steps to achieve certification to ensure its customers do
not run across any problems, but the actual certification is the responsibility of the
individual customer.



For operating systems, adapter cards, and peripherals not listed in this document, there is no support commitment. Intel will consider support requests on a case-by-case basis.

1.2 Pass/Fail Test Criteria

For each operating system, adapter, and peripheral configuration, a test passes if specific criteria are met. Specific configurations may have had particular characteristics that were addressed on a case-by-case basis. In general, a configuration passes testing if the following conditions are met:

- The operating system installed without error.
- Manufacturer's installation instructions or Intel's best-known methods were used for the operating system installation.
- No extraordinary workarounds were required during the operating system installation.
- The server system behaved as expected during and after the operating system installation.
- Application software installed and executed normally.
- Hardware compatibility tests ran to completion without error.
- Test software suites executed successfully
- Test and data files were created in the correct directories without error.
- Files copied from client to server and back compare to the original with zero errors reported.
- Clients remain connected to the server system.
- Industry standard test suites run to completion with zero errors reported.

All testing with the Intel[®] Server Boards S3210SH/S3200SH was performed using the Intel[®] Entry Server Chassis SC5295-E.

2. Base System Configurations

The following table lists the base system configurations tested. Base system configurations will change as new revisions of the Intel[®] Server Boards S3210SH/S3200SH are released and/or new system BIOS is cut onto the board in the factory. Each base system configuration is assigned an identifier number that is referenced in the tables throughout this document. New base system configurations are added with each new release of this document.



Intel will only provide support for adapters and peripherals under the specified base system configuration and operating systems versions with which they were tested.

| Base System Configuration Identifier # | Board Type | PBA Number | BIOS Revision | Notes |
|--|------------|------------|------------------|-------|
| 1 | S3200SHL | 204 | 26 | |
| 2 | S3210SHLC | 204 | 26 | |
| 3 | S3210SHLX | 204 | 26 | |
| 4 | S3200SHL | 204 | 26 | |
| 5 | S3200SHV | 204 | 26 | |
| 6 | S3210SHLX | 204 | 26 | |
| 7 | S3200SHLC | 204 | 26 | |
| 8 | S3200SHL | 202 | 23 | |
| 9 | S3200SHC | 201 | 33 | |
| 10 | S3200SHL | 204 | 39 | |
| 11 | S3210SHLC | 204 | 39 | |
| 12 | S3210SHLX | 204 | 39 | |
| 13 | S3200SHL | 204 | 39 | |
| 14 | S3200SHC | 201 | 42 | |
| 15 | S3200SHL | 301 | 44 | |

3. Supported Operating Systems

The following table provides a list of supported operating systems for the Intel® Server Boards S3210SH/S3200SH. Each of the listed operating systems was tested for compatibility with the Intel® Server Boards S3210SH/S3200SH base system configuration listed in Section 2 of this document. Operating systems are supported only with the specified base system configuration(s) with which they were tested.

The following table also indicates whether each operating system received Basic Installation Testing, or Adapter / Peripheral Compatibility and Stress Testing. For information on the support commitments for Basic Installation Testing vs. Adapter / Peripheral Compatibility and Stress Testing, please reference Section 1 of this document.

Any variations to the standard operating system installation process are documented in the Installation Guidelines section of this document. If there is no installation guidelines noted in the following table, then the operating system installed as expected using manufacturer's installation instructions or Intel's best-known methods.



Operating systems supported by Intel® System Management software or LANDesk* Client Manager software may be different than the operating systems supported by the Intel® Server Boards S3210SH/S3200SH. Please reference the Readme and User Guide documents that are included as part of each Intel Server Management and LANDesk* Client Manager distribution for operating systems that are supported by that release.

| Operating System | Base System Configuration Tested & Type of Testing | Notes |
|--|--|-------------------------|
| | Configuration 1, 4, 5, 6 – | |
| Microsoft Windows Server 2003* Enterprise Edition, SP2 | Compatibility & Stress | |
| · | Compatibility 9 | |
| | Configuration 1, 4, 5, 6 – | |
| Microsoft Windows Server 2003* Enterprise Edition for EM64T, SP2 | Compatibility & Stress | |
| | Compatibility 9 | |
| CuCE* Linux Enterprise Compand CD4 | Configuration 1 – | Note: SP1 required. |
| SuSE* Linux Enterprise Server 10 , SP1 | Compatibility & Stress | |
| SuSE* Linux Enterprise Server 10, SP1, EM64T | Configuration 1 – Compatibility & Stress | Note: SP1 required. |
| RedHat* Enterprise Linux 5.0 AS, Update1 | Configuration 1 – | Note: Update1 required. |
| | Compatibility & Stress | |
| | Compatibility 9 | |
| RedHat* Enterprise Linux 5.0 AS, Update1 EM64T | Configuration 1 – | Note: Update1 required. |
| LIVIOTT | Compatibility & Stress | |
| | Compatibility 9 | |

| Operating System | Base System Configuration Tested & Type of Testing | Notes |
|---|--|---|
| | Configuration 1, 4, 5, 6 – | |
| Microsoft Windows Server 2008* Enterprise Edition | Compatibility & Stress | |
| | Compatibility 9 | |
| | Configuration 1, 4, 5, 6 – | |
| Microsoft Windows Server 2008* Enterprise Edition for EM64T | Compatibility & Stress | |
| Landon for Livio 11 | Compatibility 9 | |
| | | |
| RedHat* Enterprise Linux 4.0 AS, UP4 | Configuration 1, 4, 5, 6 – Basic Installation | |
| RedHat* Enterprise Linux 4.0 AS, UP4, EM64T | Configuration 1, 4, 5, 6 – Basic Installation | |
| SuSE* Linux Enterprise Server 9 , SP4 | Configuration 4, 5 and 6 – Basic Installation | |
| SuSE* Linux Enterprise Server 9, SP4, EM64T | Configuration 4, 5 and 6 – Basic Installation | |
| Novell* NetWare 6.5, SP6 | Configuration 1, 4, 5, 6 – Basic Installation | |
| Windows XP Professional, SP2, 32-bit | Configuration 1, 4, 5, 6 – Basic Installation | Note: Doesn't support install from an external USB DVD drive when RAID mode is enabled. |
| Solaris 10U5 | Configuration 15 – Basic Installation | Note: To use X-Windows GUI, edit the script /usr/bin/X11/Xserver and use the following arguments to make color depth not larger than 16 bit |
| | | SERVERARGS="-depth 16 -fbbpp 16" |

3.1 Operating System Certifications

Listed below are the operating systems that Intel will certify with the Intel[®] Server Boards S3210SH/S3200SH. However, the customer is responsible for their own certification from the individual operating system vendors. In many cases, the customer may leverage their operating system certifications from Intel's testing. See the "Comments" section next to each operating system in the table below for additional information. Intel's certifications, pre-certification, and operating system testing may help reduce some of the risk in achieving customer certifications with the operating system vendors.

| Operating System | Certification Listing | Comments |
|---|--|----------|
| Microsoft Windows 2003*, Enterprise Edition, SP2 | WHQL ID: S3210SHL (Ref: 1271761) S3210SHLC (Ref: 1270915) S3200SHV (Ref: 1270922) S3210SHLX (Ref: 1271050) | |

| Operating System | Certification Listing | Comments |
|--|--|--|
| Microsoft Windows 2003*, Enterprise Edition, SP2, EM64T | WHQL ID: S3210SHL(Ref: 1271761) S3210SHLC(Ref: 1270915) S3200SHV(Ref: 1270922) S3210SHLX(Ref: 1271050) | |
| Microsoft Windows 2008*, Enterprise Edition | WHQL ID: S3210SHL (Ref: 1289590) S3210SHLC (Ref: 1288951) S3200SHV (Ref: 1289590) S3210SHLX (Ref: 1290388) | |
| Microsoft Windows 2008*, Enterprise Edition, EM64T | WHQL ID: S3210SHL (Ref: 1289590) S3210SHLC (Ref: 1288951) S3200SHV (Ref: 1289590) S3210SHLX (Ref: 1290388) | |
| RedHat* Enterprise Linux 5.0 AS | Certified ID: TBD(S3210SHLX) TBD (S3200SH) TBD (S3200SHV) | |
| RedHat* Enterprise Linus 5.0 AS , EM64T | Certified ID: TBD(S3210SHLX) TBD (S3200SH) TBD (S3200SHV) | |
| SuSE* Linux Enterprise Server 10 | Certified ID: S3210SHLC (Ref: 92437, 92438) S3210SHLX (Ref: 92467, 92471) | |
| SuSE* Linux Enterprise Server 10, EM64T | Certified ID: \$3210\$HLC (Ref: 92468, 92469) \$3210\$HLX (Ref: 92472, 92470)) | |
| SCO OpenServer 6 | S3200SHL | http://wdb1.sco.com/chwp/owa/hch model cert page?f model id=9931 1&f release id=601&f vendor sear ch_corp_id= |

| Operating System | Certification Listing | Comments |
|----------------------|-----------------------|---|
| SCO UnixWare 7.1.4 | S3200SHL | http://wdb1.sco.com/chwp/owa/hch model_cert_page?f_model_id=9931 1&f_release_id=600&f_vendor_sear ch_corp_id%20= |
| SCO OpenServer 5.0.7 | S3200SHL | http://wdb1.sco.com/chwp/owa/hch_model_cert_page?f_model_id=9931 1&f_release_id=378&f_vendor_sear_ch_corp_id%20= |

4. Adapters and Peripherals

Add-in adapter card and peripheral compatibility and stress testing will only be performed with the latest version of an operating system at the time the validation testing occurred. The following table shows the operating system and base system configurations used to validate each device. The adapters are divided into categories based on their functionality. All integrated on-board devices are tested by default and are therefore not included in the following tables.

Note that not all adapter cards were tested under all operating systems. The following notation is used in the tested adapters and peripherals table below to indicate the support level that Intel provides for a particular adapter under a particular operating system:

| Number (i.e. 1) | This adapter or peripheral has been tested and is supported under the specific configuration identified in the Base System Configurations Table in Section 2 of this document. |
|-------------------------------|--|
| Number in brackets (i.e. [1]) | This adapter or peripheral has been tested, but is NOT supported under the specific configuration identified in the Base System Configurations Table in Section 2 of this document. |
| NT | This adapter or peripheral has not been tested under this operating system and is not supported under this operating system. |
| ND | This adapter or peripheral has not been tested under this operating system due to limitations in IHV driver availability, and is not suported under this operating system. |
| SA (Similar Adapter) | This adapter is supported, but not tested. This adapter model has not been tested with this server board, but Intel will support it based on successful testing of a similar adapter from the same adapter family. Intel has high confidence that this adapter will function correctly with the server board. This adapter uses the same firmware and drivers, and has a nearly identical system interface to another adapter of the same family that has been successfully tested with this server board. In addition, Intel has secured IHV commitment to support the similar adapters equally. Customers should always test adapters as part of the final system configuration prior to deployment. All installation guidelines for the tested adapter also apply to the similar adapter. |

Any variations to the standard adapter installation process or to expected adapter functionality are documented in the Installation Guidelines section of this document. If there are installation guidelines affecting a particular adapter and operating system combination, these are referenced in the following table. If there are no installation guidelines noted in the following table, then the adapter installed and functioned as expected using manufacturer's installation instructions or Intel's best-known methods.



Testing of adapters cards normally is performed with unused add-in adapters and onboard controller expansion ROMs disabled in BIOS Setup. Intel recommends that customers disable the option ROM for add-in controllers and/or the on-board controllers when not booting from the controller or needing to use its built in utilities.

| Vendor | Model | Description | Interface | Keying | Form Factor | Microsoft Windows 2003* EE SP2 | Microsoft Windows Server 2003* FE FM64T SP2 | RedHat* EL5 U1 | RedHat* EL5 EM64T U1 | SuSE* Linux ES10 SP1 | SuSE* Linux ES10 EM64T SP1 | Microsoft Windows 2008* EE | Microsoft Windows Server 2008* EE EM64T |
|--------------------|---------------|--|-------------|-----------|----------------|--------------------------------------|---|---------------------------------|---------------------------------|-------------------------|----------------------------------|----------------------------------|--|
| | rface Control | | | | | | | | | | | | |
| Intel [®] | PILA8470D3 | PRO100+ S Server | PCI-32/33 | Universal | PCI-Short | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | | |
| Intel | PILA8472C3 | Pro/100+ Dual Port | PCI-64/66 | Universal | PCI-Short | 3, 10, 11 12, 13 | , 3, 10, 11 12, 13 | 3, 10, 11, 12, 13 | 3, 10, 11, 12, 13 | 3, 10, 11 12, 13 | ,3, 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 |
| Intel | PWLA8490MT | Pro/1000MT Gigabit Server | PXI-X 133 | Universal | PCI-LP/RP | 3, 10, 11 12, 13 | | ,3, 10, 11, 12, 13 | 3, 10, 11, 12, 13 | 3, 10, 11 12, 13 | ,3, 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 |
| Intel | PWLA8492MT | Pro/1000MT Dual Port Gigabit Server | PXI-X 133 | Universal | PCI-LP/RP | 3, 10, 11 12, 13 | , 3, 10, 11 12, 13 | 3, 10, 11, 12, 13 | 3, 10, 11, 12, 13 | 3, 10, 11, 12, 13 | ,3, 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 |
| Intel | EXPI9300PT | 1 port, 1GbE | PCI Express | X1 | PCI-Short | 1, 2, 3, 4,10, 11 12, 13 | | 1, 2, 3, 4,10, 11, 12, 13 | 1, 2, 3, 4,10, 11, 12, 13 | | 1, 2, 3, 4,10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 |
| Intel | EXPI9400PT | 1 port 1000Base-T, 1Gb | PCI Express | X1 | PCI-Short | 1, 2, 3, | 1, 2, 3, , 4,10, 11, | 1, 2, 3, 4,10, 11, 12, 13 | 1, 2, 3, 4,10, 11, | 1, 2, 3, | 1, 2, 3, | 10, 11, 12, 13 | 10, 11, 12, 13 |
| Intel | EXPI9402PT | 2 port 1000Base-T, 1Gb | PCI Express | X4 | PCI-Short | 1, 2, 3, 4,10, 11 | 1, 2, 3, , 4,10, 11, 12, 13 | 1, 2, 3, | 1, 2, 3, | 1, 2, 3, 4,10, 11, | 1, 2, 3, | 10, 11, 12, 13 | 10, 11, 12, 13 |
| Intel | EXPI9404PT | 4 port 1000Base-T, 1GbE | PCI Express | X4 | PCI-Short | 1, 2, 3, | 1, 2, 3, , 4,10, 11, | 1, 2, 3, | 1, 2, 3, 4,10, 11, | 1, 2, 3, | 1, 2, 3, 4,10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 |
| Syskonnect* | SK-9E21D | 1 port 10/100/1000 LAN | PCI Express | X1 | PCI-Short | 1, 2, 3, 4,10, 11 12, 13 | | 1, 2, 3, 4,10, 11, 12, 13 | | | 1, 2, 3, 4,10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 |
| Syskonnect | SK-9E22 | 2 port 10/100/1000 LAN | PCI Express | X4 | PCI-Short | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | | |
| SCSI RAID C | ontrollers | | | | | | | | | | | | |
| Intel | SRCU42E | 2 channel, U320 | PCI Express | X8 | PCI-Med | 5, 6, 7 | 1, 2, 3, 4 5, 6, 7 | | | | | | |
| Intel | SRCU41L | 1 channel, U320 | PCI-64/66 | Universal | PCI-LP/RP | | , 3, 6, 10, 3 11, 12,13 | | 3, 10, 11, 12,13 | 3, 10, 11 12,13 | ,3, 10, 11, 12,13 | 10, 11, 12, 13 | 10, 11, 12, 13 |
| Intel | SRCU42X | 2 channel, U320 | PCI-X 133 | Universal | PCI-Short | 3, 6, 10 | , 3, 6, 10, | 3, 10, 11, | 3, 10, 11, | 3, 10, 11 | ,3, 10, 11, | 10, 11, | 10, 11, |

10 Revision 2.2 Revision 2.2

Adapters and Peripherals

| | | | | | | 11, 12,13 | 11, 12,13 | 12,13 | 12,13 | 12,13 | 12,13 | 12, 13 | 12, 13 |
|-------------|-------------------------|---|-------------|-----------|-----------|---------------------------------|------------------------|---------------------------------|---------------------------------|-----------------------|---------------------------------|-------------------|-------------------|
| LSI Logic | MegaRAID SCSI 320-2 | 2 channel, U320 | PCI-64/66 | Universal | PCI-Short | 3, 6, 10, 11, 12,13 | | | ,3, 10, 11, 12,13 | ,3, 10, 11, 12,13 | ,3, 10, 11, 12,13 | 10, 11, 12, 13 | 10, 11, 12, 13 |
| LSI Logic | MegaRAID SCSI 320-1 | 1 channel, U320 | PCI-64/66 | Universal | PCI-Short | SA | SA | SA | SA | SA | SA | 10, 11, 12, 13 | 10, 11, 12, 13 |
| LSI Logic* | MegaRAID SCSI 320-2E | 2 channel, U320 | PCI Express | X8 | PCI-Med | 1, 2, 3, 4, 5, 6, 7 | 1, 2, 3, 4, 5, 6, 7 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | | |
| LSI Logic* | MegaRAID SCSI 320-2X | 2 channel, U320 | PCI-X133 | Universal | PCI-Med | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 |
| Adaptec | ASC-29320 LPE | 1 channel U320 1 external / 1 internal | PCI Express | X1 | PCI-LP/RP | | 8, 10, 11, 12, 13 | | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 |
| Adaptec | ASR-2230S | | PCI-X133 | Universal | | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 |
| SCSI Contro | ollers | | | | | • | | | • | | | | • |
| Adaptec | ASC-39320A- R | 2 channel U320 2 external / 2 internal connectors | PCI-X133 | Universal | PCI-Short | 3, 10, 11, 12, 13 | 3, 10, 11, 12, 13 | 3, 10, 11, 12, 13 | ,3, 10, 11, 12, 13 | ,3, 10, 11, 12, 13 | ,3, 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 |
| Adaptec | ASC-29160 | 1 channel U160, for tape drive only | PCI-64/66 | Universal | PCI-Short | 3 | 3 | 3 | 3 | 3 | 3 | | |
| Adaptec | ASC- 29320ALP-R | 1 channel U320 SCSI, 1 external / 1 internal | PCI-X 133 | Universal | PCI-LP/RP | 3, 10, 11, 12, 13 | 3, 10, 11, 12, 13 | 3 | 3 | 3, 10, 11, 12, 13 | ,3, 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 |
| LSI Logic | LSI20160 | 1 channel U160 SCSI, for tape drive only | PCI-32/33 | Universal | PCI-LP/RP | 1, 2, 3, 4,10, 11, 12, 13 | 4,10, 11, | 1, 2, 3, 4,10, 11, 12, 13 | 1, 2, 3, 4,10, 11, 12, 13 | 4,10, 11, | 1, 2, 3, 4,10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 |
| LSI Logic | LSI22320-R | 2 channel U320 SCSI | PCI-X 133 | Universal | PCI-Short | 3, 10, 11, 12, 13 | | 3 | 3, 10, 11, 12, 13 | ,3, 10, 11, 12, 13 | ,3, 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 |
| SATA RAID | Controllers | | | | | | | | | | | | |
| Intel | SRCS16 | 6 port, SATA 1.5G, RAID 0, 1, 10, 5, 50 | PCI-64/66 | Universal | PCI-Med | 3 | 3 | 3 | 3 | 3 | 3 | | |
| Intel | SRCS28X | 8 port SATA 3.0G, RAID 0, 1, 10, 5, 50 | PCI-X 133 | Universal | PCI-Short | 3, 10, 11, 12, 13 | 3, 10, 11, 12, 13 | 3, 10, 11, 12, 13 | ,3, 10, 11, 12, 13 | | ,3, 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 |
| Intel | SRCSATAWB | 8 port SATA 3.0G | PCI Express | X4 | PCI-Med | 1, 2, 3, 4, 5, 6, 7 | 1, 2, 3, 4, 5, 6, 7 | 1, 2, 3, 4, 5, 6, 7 | | | 1, 2, 3, 4, 5, 6, 7 | | |
| LSI Logic | MegaRAID SATA 150-6 | 6 port SATA 1.5G, RAID 0, 1, 10, 5 | PCI-64/66 | Universal | PCI-Short | 3 | 3 | 3 | 3 | 3 | 3 | | |

| Adaptec* | AAR-2410SA | 4-port, SATA 1.0, RAID 0, 1. 2x Silicon Image w/Zion | PCI-64/66 | Universal | PCI-LP | 3 | 3 | 3 | 3 | 3 | 3 | | |
|------------|------------------|--|-------------|-----------|---------|---------------------------------|---------------------------------|--|---------------------------------|-------------------------|---------------------------------|-------------------|-------------------|
| AMCC/3Ware | 9650SE-12ML | SATA 3GB 12 ports | PCI Express | X8 | PCI-Med | | 8 | | | 8 | | | |
| AMCC/3Ware | 9650SE-16ML | SATA 3GB 16 ports | PCI Express | X8 | PCI-Med | | SA | | | SA | | | |
| AMCC/3Ware | 9650SE-24M8 | SATA 3GB 24 ports | PCI Express | X8 | PCI-Med | | SA | | | SA | | | |
| AMCC/3Ware | 9650SE-2LP | SATA 3GB 2 ports | PCI Express | X1 | PCI-Med | | SA | | | SA | | | |
| AMCC/3Ware | 9650SE- 4LPML | SATA 3GB 4 ports | PCI Express | X4 | PCI-Med | | SA | | | SA | | | |
| AMCC/3Ware | 9650SE- 8LPML | SATA 3GB 8 ports | PCI Express | X4 | PCI-Med | | SA | | | SA | | | |
| SAS RAID C | ontrollers | | | | | | | | | | | | |
| Intel | SRCSAS18E | SAS 3GB 8 internal ports | PCI Express | X8 | PCI-Med | 1, 2, 3, 4,10, 11, 12, 13 | 1, 2, 3, 4,10, 11, 12, 13 | 4,10, 11, | 1, 2, 3, 4 | | 1, 2, 3, 4,10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 |
| Intel | SRCSAS144E | | PCI Express | X4 | PCI-Med | 1, 2, 3, | 1, 2, 3, | 1, 2, 3, 4,10, 11, | 1, 2, 3, 4,10, 11, 12, 13 | 1, 2, 3, | 1, 2, 3, | 10, 11, 12, 13 | 10, 11, 12, 13 |
| Intel | SRCSASPH16 I | SAS 3GB 16 internal ports | PCI Express | X8 | | | | 1, 2, 3, 4, 5, 6, 7, 10, 11, 12, 13 | | | | | |
| Intel | SRCSASBB8I | SAS 3GB 8 internal ports | PCI Express | X8 | PCI-Med | _ | | 1, 2, 3, 4, 5, 6, 7, 10, 11, | | | | | |
| Intel | SRCSASLS4I | SAS 3GB 4 internal ports | PCI Express | X8 | PCI-Med | · | · | 1, 2, 3, 4, 5, 6, 7 | | | | | |
| Intel | SASMF8I | SAS 3GB 8 internal ports | PCI Express | X4 | PCI-LP | 1, 2, 3, 4, 5, 6, 7 | 1, 2, 3, 4, 5, 6, 7 | 1, 2, 3, 4, | | | 1, 2, 3, 4, 5, 6, 7 | | |
| Intel | SRCSASRB | SAS 3GB 8 internal ports | PCI Express | X4 | PCI-Med | 1, 2, 3, 4, 5, 6, 7 | | 1, 2, 3, 4, 5, 6, 7 | | | | | |
| Intel | SRCSASJV | SAS 3GB 8 ports | PCI Express | X8 | PCI-Med | | 1, 2, 3, 4, 5, 6, 7, | 1, 2, 3, 4, | 1, 2, 3, 4, 5, 6, 7, | 1, 2, 3, 4, 5, 6, 7, | 1, 2, 3, 4, 5, 6, 7, | 10, 11, 12, 13 | 10, 11, 12, 13 |

12 Revision 2.2 Revision 2.2

Adapters and Peripherals

| | | | | | | 12, 13 | 12, 13 | 12, 13 | 12, 13 | 12, 13 | 12, 13 | | |
|------------|-------------------------|---|-------------|-----------|-----------|-------------------|-------------------|-------------------|-------------------|-------------------|-------------------|-------------------|-------------------|
| Intel | SASWT4I | SAS 3GB 4 internal | PCI Express | X4 | PCI-Med | 10, 11, | 10, 11, | 10, 11, | 10, 11, | 10, 11, | 10, 11, | 10, 11, | 10, 11, |
| | 0.4.01.100; | ports | 5015 | | 50114 | 12, 13 | 12, 13 | 12, 13 | 12, 13 | 12, 13 | 12, 13 | 12, 13 | 12, 13 |
| Intel | SASUC8I | SAS 3GB 8 internal ports | PCI Express | X8 | PCI-Med | 10, 11, 12, 13 |
| Adaptec | ASC-48300 | 8 port SAS | PCI-X 133 | Universal | PCI-LP/RP | | | | | | | | 10, 11, |
| | | | | | | 12, 13 | 12, 13 | 12, 13 | 12, 13 | 12, 13 | 12, 13 | 12, 13 | 12, 13 |
| LSI Logic | 3442E | 8 port SW SAS RAID | PCI Express | X8 | PCI-LP/RP | | | | | | | | 10, 11, |
| LOLLasia | MariaDAID | Dr. al.t. a. /4.000.00.0 | DOL E | | DOL Mark | 12, 13 | 12, 13 | 12, 13 | 12, 13 | 12, 13 | 12, 13 | 12, 13 | 12, 13 |
| LSI Logic | MegaRAID SAS 8480E | Brockton/1068 SAS 3GB 8 external ports | PCI Express | X8 | PCI-Med | 2, 3, 4 | 2, 3, 4 | 2, 3, 4 | 2, 3, 4 | 2, 3, 4 | 2, 3, 4 | | |
| LSI Logic | MegaRAID | | PCI Express | X4 | PCI-LP/RP | SA | SA | SA | SA | SA | SA | 10, 11, | 10, 11, |
| LOLLania | SAS 8308ELP | 3GB 8 internal ports | DOL E | X4 | DOLL D/DD | SA | SA | SA | SA | SA | SA | 12, 13 | 12, 13 |
| LSI Logic | MegaRAID SAS 8344ELP | Brockton/1068 SAS 3GB 4 internal / 4 external ports | PCI Express | Х4 | PCI-LP/RP | SA | SA | SA | SA | SA | SA | | |
| LSI Logic | MegaRAID | Brockton/1068 SAS | PCI Express | X8 | PCI-Med | SA | SA | SA | SA | SA | SA | | |
| | SAS 8408E | 3GB 8 internal ports | | | | | | | | | | | |
| AMCC/3Ware | 9690SA-8I | • | PCI Express | X8 | PCI-Med | 8 | 8 | | | 8 | | | |
| AMCC/3Ware | 9690SA-8E | SAS 3GB 8 ports | PCI Express | X8 | PCI-Med | SA | SA | | | SA | | | |
| AMCC/3Ware | 9690SA-414E | SAS 3GB 8 ports | PCI Express | X8 | PCI-Med | SA | SA | | | SA | | | |
| Adaptec | ASR-31205 | SAS 3GB 12 ports | PCI Express | X8 | PCI-Med | | 8 | | 8 | | 8 | | |
| Adaptec | ASR-3405 | SAS 3GB 4 ports | PCI Express | X4 | PCI-Med | | 8 | | 8 | | 8 | | |
| Adaptec | ASR-31605 | SAS 3GB 16 ports | PCI Express | X8 | PCI-Med | | 8 | | 8 | | 8 | | |
| Adaptec | ASR-3805 | SAS 3GB 8 ports | PCI Express | X4 | PCI-Med | | 8 | | 8 | | 8 | | |
| Adaptec | ASR-3085 | SAS 3GB 8 ports | PCI Express | X8 | PCI-Med | | SA | | SA | | SA | | |
| Adaptec | 5805 | SAS 3GB 8 ports | PCI Express | X8 | PCI-Med | 9 | 9 | 9 | 9 | | | | |
| Adaptec | 5445 | SAS 3GB 4 ports | PCI Express | X8 | PCI-Med | SA | SA | SA | SA | | | | |
| Adaptec | 5405 | SAS 3GB 4 ports | PCI Express | X8 | PCI-Med | SA | SA | SA | SA | | | | |
| Adaptec | 5085 | SAS 3GB 8 ports | PCI Express | X8 | PCI-Med | SA | SA | SA | SA | | | | |
| Adaptec | 52245 | SAS 3GB 30 ports | PCI Express | X8 | PCI-Med | 9 | 9 | 9 | 9 | | | | |

| Adaptec | 51245 | SAS 3GB 16 ports | PCI Express | X8 | PCI-Med | SA | SA | SA | SA | | | | |
|-------------------|----------------------|---------------------|-------------------|-----------|----------|---------------------------------|------------------------------|---------------------------------|---------------------------------|------------------------------|---------------------------------|-------------------|-------------------|
| Adaptec | 51645 | SAS 3GB 20 ports | PCI Express | X8 | PCI-Med | SA | SA | SA | SA | | | | |
| Adaptec | 2405 | SAS 3GB | PCI Express | X8 | PCI-Med | 14 | 14 | 14 | 14 | | | 14 | 14 |
| Adaptec | 2045 | SAS 3GB | PCI Express | X8 | PCI-Med | 14 | 14 | 14 | 14 | | | 14 | 14 |
| Adaptec | 2445 | SAS 3GB | PCI Express | X8 | PCI-Med | 14 | 14 | 14 | 14 | | | 14 | 14 |
| Video Contr | ollers | l | | | | | 1 | | I | L | | | |
| Matrox | G55- MDDE32LPD | PCI-E Video Adapter | PCI- ExpressX1 | Universal | PCI-Med | 2, 3, 4,10, 11, 12, 13 | 2, 3, 4,10, 11, 12, 13 | 2, 3, 4,10, 11, 12, 13 | 2, 3, 4,10, 11, 12, 13 | 2, 3, 4,10, 11, 12, 13 | 2, 3, 4,10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 |
| USB Drives | | | | | | | | | | | | | |
| Maxtor* | E01G300 | Maxtor One Touch II | USB 2.0 | | External | 1, 2, 3, 4,10, 11, 12, 13 | 4,10, 11, | 1, 2, 3, 4,10, 11, 12, 13 | 1, 2, 3, 4,10, 11, 12, 13 | 4,10, 11, | 1, 2, 3, 4,10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 |
| Slim Line D | /D±R/RW | | | | | | | | | | | | |
| Samsung | TS-L333A | TS-L333A | SATA/Slimlin e | | 5.25x0.5 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 |
| Samsung | TS-L633A | TS-L633A | SATA/Slimlin e | | 5.25x0.5 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 |
| Teac | DV-28S-VZ3 | DV-28S-VZ3 | SATA/Slimlin e | | 5.25x0.5 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 |
| CD-RW/DVI | ROM Combo | Drives | | | | | | | | | | | |
| Addonics | AEPDVRW888 UM | AEPDVRW888UM | USB2.0 | | 5.25x1.6 | 1, 2, 3, 4,10, 11, 12, 13 | 4,10, 11, | 1, 2, 3, 4,10, 11, 12, 13 | 1, 2, 3, 4,10, 11, 12, 13 | 4,10, 11, | 1, 2, 3, 4,10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 |
| DVD+R/RW | | | | | | , - | , - | , - | , - | , - | , - | | |
| Plextor | PX-740UF | PX-740UF | USB 2.0 | | 5.25x1.6 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | | |
| Plextor | PX-755SA | PX-755SA | SATA | | 5.25x1.6 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | | |
| Plextor | PX-810UF | PX-810UF | USB 2.0 | | 5.25x1.6 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 |
| Sony | Optiarc AD- 7170S | Optiarc AD-7170S | SATA | | 5.25x1.6 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 |
| Lite-On | LH-20A1S | LH-20A1S | SATA | | 5.25x1.6 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 |
| DVD ROM D | rives | | | | | • | • | • | • | • | • | | |

Adapters and Peripherals

| Sony | DRX-720UL | DRX-720UL | USB 2.0 | External | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | | |
|--------------|------------------------|----------------------------|-----------------|----------|---------------------------------|-----------------------|---------------------------------|---------------------------------|-----------------------|---------------------------------|-------------------|-------------------|
| Input Device | es | | | | | | | | | | | |
| AOpen* | KB858 Keyboard PS/2 | KB-858 | PS/2 | External | 1, 2, 3, 4,10, 11, 12, 13 | 4,10, 11, | 1, 2, 3, 4,10, 11, 12, 13 | 1, 2, 3, 4,10, 11, 12, 13 | 4,10, 11, | 1, 2, 3, 4,10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 |
| AOpen | O 35M | Mini Optical Mouse | PS/2 and USB | External | 1, 2, 3, | 1, 2, 3, 4,10, 11, | 1, 2, 3, | 1, 2, 3, | 1, 2, 3, 4,10, 11, | 1, 2, 3, 4,10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 |
| Logitech* | 931145-403 | Logitech Optical Mouse | PS/2 and USB | External | 1, 2, 3, 4,10, 11, 12, 13 | 1, 2, 3, 4,10, 11, | 1, 2, 3, | 1, 2, 3, 4,10, 11, 12, 13 | 4,10, 11, | 1, 2, 3, 4,10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 |
| Logitech | 967415-0403 | Logitech Media Keyboard | PS/2 and USB | External | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | | | 1, 2, 3, 4 | | |
| Microsoft* | B75-00092 | Intellimouse Optical | PS/2 and USB | External | 1, 2, 3, 4,10, 11, 12, 13 | 4,10, 11, | 1, 2, 3, 4,10, 11, 12, 13 | 1, 2, 3, 4,10, 11, 12, 13 | 4,10, 11, | 1, 2, 3, 4,10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 |
| KVM Switch | es | <u> </u> | | <u>.</u> | | | | | | | | |
| Belkin* | F1DA108T | Omniview Pro2 Series | PS/2 | External | 1, 2, 3, 4,10, 11, 12, 13 | 4,10, 11, | 1, 2, 3, 4,10, 11, 12, 13 | | | 1, 2, 3, 4,10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 |
| Removable | Media Devices | | | | , - | , - | , - | , - | , - | , - | I | 1 |
| lomega* | SKU 33136 | Micro Mini™ 1GB Drive | USB 2.0 | External | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | | |
| Lexar* | JD1GB-80-231 | 1GB USB Flash Drive | USB 2.0 | External | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | | |
| Memorex | 32509363 | 1GB Travel Drive | USB 2.0 | External | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 |
| Mitsumi | D353FUE | D353FUE | USB | External | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | | |
| Sony | PCGA-UFD5 | VAIO External USB floppy | USB | External | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | | |
| Sony | VPG-UFD1 | VAIO External USB floppy | USB | External | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 |
| TEAC | FD-235HF | FD-235HF | Floppy | 3.5x1 | 1 | 1 | 1 | 1 | 1 | 1 | | |
| TEAC | FD05PUW268 | FD05PUW268 | Floppy | 3.5x1 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 | 10, 11, 12, 13 |
| San Disk* | SDCZ2-4096 | Cruzer 4GB | USB 2.0 | External | | | 1, 2, 3, | 1, 2, 3, | 1, 2, 3, | 1, 2, 3, 4,10, 11, | 10, 11, 12, 13 | 10, 11, 12, 13 |

Adapters and Peripherals

Intel® Server Boards S3210SH/S3200SH

| | | | | | | 12, 13 | 12, 13 | 12, 13 | 12, 13 | 12, 13 | 12, 13 | |
|-------------|-------------|-----------------|-----------|--|---------|---------------------------------|------------|---------------------------------|---------------------------------|------------|---------------------------------|--|
| Tape Drives | | | | | | | | | | | | |
| Certance* | STD2401LW-S | Certance DAT 40 | SCSI-U2 | | 3.5x1.6 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | |
| Sony | SDX-700C/BM | AIT-3 Desktop | SCSI-U160 | | 3.5x1.6 | 1, 2, 3, 4,10, 11, 12, 13 | 4,10, 11, | 1, 2, 3, 4,10, 11, 12, 13 | 1, 2, 3, 4,10, 11, 12, 13 | 4,10, 11, | 1, 2, 3, 4,10, 11, 12, 13 | |
| Quantum | CD72SH-SB | DAT72 | SATA 300 | | 3.5X1.6 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | 1, 2, 3, 4 | |

Revision 2.2 Revision 2.2

5. Hard Disk Drives

The hard drives previously in this section have now been listed separately in the *Server Hard Drive Validation Test Report*, which includes the qualified hard drives for the Intel[®] Server Boards S3210SH/S3200SH. It is located on Intel's secure website IBL and at the web link below: http://www.intel.com/support/motherboards/server/sb/CS-025416.htm