




QUICK SET UP GUIDE 2055A




Remove **all** cardboard pieces from the disc pack.




Finding the ideal location for your unit: Do not place the humidifier directly next to a heating or air vent.



The unit should be placed on a dry, level surface. Keep it away from walls, doors or windows.




The unit should not be placed too close to plants or other objects. Keep a distance of at least 20 inches (50cm).




Place the Ionic Silver Stick in the water base of the unit.


FILL THE TANK WITH FRESH COLD WATER




Take off the water tank cap to fill the tank with water.




Fill the tank with clean, cold water from the tap.



Do not pour water directly into the appliance. Use the water tank only.




Close the cap of the water tank securely, place the water tank onto the base. The water is now running from the tank into the base. The red empty indicator light may stay illuminated for some seconds until the base is filled with water.



Insert the plug into the socket and switch on the appliance using the on/off switch. The blue light comes on.

QUICK OPERATION DESCRIPTION 2055A



- A** Rotary switch On/Off
- B** Position Off
- C** Normal mode
- D** Night mode
- E** Operating light and Automatic Shut-Off «Tank empty» Indicator

WATER QUALITY MAINTENANCE WITH IONIC SILVER STICK®

Water Quality Maintenance

The Ionic Silver Stick® (ISS) keeps the water free of microbial growth. The ISS uses the anti-microbial effect of silver to prevent the growth of microbes in the water base. It begins to function as soon as it comes into contact with water, even if the unit is switched off. The Ionic Silver Stick should be changed every year.




Lifecycle Indicator

Your appliance comes with a lifecycle indicator for changing the Ionic Silver Stick®. To remind yourself when you put the ISS into operation, please check the current month on the stamp and write the current year on the line provided.

DO NOT DISCARD! Save for future reference.


Please read the manual or check our website www.airoswiss.net for further information.

RECOMMENDED TO CLEAN WITH EZCal




What is EZCal?


EZCal from AIR-O-SWISS is an easy and safe cleaning and descaling agent recommended for all humidifiers. It cleans mineral build-up in the water base.



Switch off the appliance and unplug it from the socket before cleaning it. Clean the water tank and the base regularly. Use water only, no detergents.



For best results use EZCal custom cleaning agent for AIR-O-SWISS products to remove deposits from the water base regularly. Do NOT run the unit when using EZCal. This can cause damage to the product and voids the warranty.



Do not submerge the main body in water! The cleaning indicator still appears on the display after cleaning. To reset hold down the two hygrostat buttons until the clean light stops flashing. Thoroughly rinse the base with tap water and make sure no EZCal residue remains in the base!

There is a sample of EZCal included in the packaging of your humidifier!

Only use 1 packet for 32oz of water. Do not change the ratio. Thoroughly rinse the base with tap water and make sure no EZCal residue remains in the base. Instructions for use are on the packet. Please note: EZCal from AIR-O-SWISS is the only recommended cleaning and descaling solution. Do NOT use any other cleaning solutions since it can damage the product. Any use of cleaning solutions apart from EZCal will void the warranty.

EZCal descaling agent is available at selected retail stores and online at www.airoswiss.net.

TROUBLE SHOOTING

If there is no water left in my water tank, for how many hours will the water in the base last?

- An exact answer cannot be given for this as there are many factors that depend on how long the water will last for. It all depends on the size of the room, if it is very dry, among other things to know how quickly water will evaporate into the air. If you notice that there is no water left in the water tank, it is always a good idea to refill the tank to have extra water available.

Red LED light is illuminated – what does it mean?

- The red LED light on the appliance shows you when the unit should be refilled with water. If the water level falls below the minimum level, the appliance automatically switches off. The red LED appears on the display. When water is added, the red LED changes to green and the appliance continues operating. Please note: When lifting the upper part off the housing, the appliance also switches off. In this case, the red LED will also appear on the display. Only when the upper part is replaced on the base does the red LED (E) disappear and the appliance resumes operation.

I fill the water tank, and when I place it back on the unit all of the water goes into the base. Why is that?

- Water is needed in the base of the unit for the removal of particles from the air, and for the humidification of the air. The first time the tank is filled up and placed on the unit, all of the water will go into the base of the unit. The water tank acts as a reserve, and may be filled up a second time to have extra water available.

Is it ok to put my humidifying discs in the dishwasher?

- The manufacturer of this appliance does NOT recommend it. The discs can only be placed in a dishwasher where the temperature is no greater than 131 °F / 55 °C. If the temperature is any hotter than this, the discs will melt. Place

the plates in a sink filled with warm water and white vinegar or EZCal and either let them soak or spin the plates in this solution. Or, add white vinegar or EZCal to the water in the base of the unit and let the unit run for an hour to clean the plates. It is good to have calcium deposits built up on the plates as it will capture more particles from the air and add more moisture to the air.

For troubleshooting, see chapter «Troubleshooting».

Humidity level is not changing or does not reach the desired humidity level

- If the water tank needs refilling more than once per day, the unit is working properly and the climatic condition in the room has an influence on the humidity.

Reasons for low humidity level:

- air circulation is very high (air is fully exchanged several times per day – the humidifier needs to start its work from scratch)
- insulation of home (see air circulation)
- open space with high ceilings (not only the footage of the room counts but also the height) – high-rise buildings require more humidification.
- open windows – works similar to air circulation (if it is very cold outside don't open the window more than 2 times per day for 3 minutes)
- big difference between outside temperature and inside temperature – the colder the air the less moisture it is capable to hold and the more the air is heated up the lower is the percentage of relative humidity (= the amount of water vapor in the air, compared to the amount the air could hold if it was totally saturated)
- position of the unit – if it is placed close to a door, window or air vent. This increases the air circulation.

Can this unit be used all year round?

- Yes, the unit can be used all year round. The unit produces relative humidity which means that the air will only take as much moisture as it can hold. The unit will not over-humidify the air.

ACCESSORIES

What is the Ionic Silver Stick (ISS) and how long is it good for?

- The Ionic Silver Stick® (ISS) keeps the water free of microbial growth. The ISS uses the anti-microbial effect of silver to prevent the growth of microbes in the water base. It begins to function as soon as it comes into contact with water, even if the unit is switched off. The Ionic Silver Stick should be changed every year.

Placement of the Ionic Silver Stick

- Please see the quick set up guide for more instructions.

Replacement reminder

- In each ISS box and on all the new products there is an ISS lifecycle indicator. Check the box of the month when starting to use the ISS and write the year on the line indicated. Exchange it after one year.

DO NOT DISCARD! Save for future reference.

Please read the manual or check our website www.airoswiss.net for further information.