

3-Way HDMI Switcher

HD3HSML


Thank you for buying the **3-In 1-Out HDMI Switcher**. The switcher allows you to easily share a single HDMI display or a HDMI-compatible TV with three HDMI devices.

Features

- Supports 480i, 480p, 720p, 1080i and 1080p screen resolutions.
- Supports HDCP compliant devices.
- Easy to install and simple to operate.

Installation

1. Use HDMI cables to connect the HDMI sources to the HDMI switcher inputs on the rear panel.
2. Connect the cable from your HDMI display to the switcher output.
3. Plug the supplied 5V DC adaptor into the switcher DC input. The LED power indicator lights green. **Note:** The power unit is intended to be correctly oriented in a vertical or floor mount position.
4. Select the desired input sources by pressing the appropriate button on front of the switcher or by using your remote control after programming the Learning function of the switcher outlined in the following section. The related LED indicator on the front panel indicates which input is selected. The default input is INPUT1.



Learning Function

This switcher is equipped with a unique Learning circuit, which allows it to learn the on/off commands from your infrared component remote(s) so that you can use them to toggle through inputs.

Note: After the Learning function is completed, when a component is turned on, the switcher automatically selects that input.

Follow these instructions to activate the Learning function.

1. Press the **LEARN** key on the front of the switcher panel. The **LEARN** LED light turns on.
2. Press the **INPUT** key on the front of the switcher for the component remote you wish to program. For example, if you want to program your DVD remote to operate the switcher and your DVD is connected to **INPUT 2** on the back panel, press the **INPUT 2** key. The LED light for the input you pressed turns on. **NOTE:** When programming the Learning function, be sure to double-check your notes on the reference chart below to determine which component is connected to each input jack.
3. As you connect your components to the input jacks, note which component you have connected to each jack in the space provided below. This information is important to have handy and is necessary when programming remotes to operate the switcher.

INPUT 1	INPUT 2	INPUT 3	INPUT 4	INPUT 5

4. Point your remote at the switcher then press and hold the key on your remote that turns on the component whose content you want to play on your display device (HDTV). The **INPUT** key LED light turns on. A few seconds later, the **LEARN** LED indicator light blinks for five seconds and turns off. The **INPUT** LED indicator light turns back on.
5. The Learn function is complete. Your remote now switches to the appropriate source.
6. Repeat this procedure for each additional remote you wish to program for components connected to the other inputs.

Note: Universal remotes can also be programmed in the same manner to operate the switcher. You must be sure you have the remote in the operational mode that corresponds with the component plugged into that input on the back of the switcher.

Specifications

- Video Amplifier Bandwidth : 1.65 GHz
- Format Support : Up to UXGA(1920x1200)
- HDMI Input/Output Connector Type : Type A
- Power Consumption : 1.2 W(max.)
- Power Supply : 5 Volt(DC)

Care

- Keep the switcher dry.
- Use and store the switcher only in moderate indoor environments. Handle the switcher carefully; do not drop it.

12 MONTH LIMITED WARRANTY

Audiovox Electronics Corporation (the "Company") warrants to the original retail purchaser of this product that should this product or any part thereof, under normal use and conditions, be proven defective in material or workmanship within 12 months from the date of original purchase, such defect(s) will be repaired or replaced (at the Company's option) without charge for parts and repair labor. To obtain repair or replacement within the terms of this Warranty, the product along with any accessories included in the original packaging is to be delivered with proof of warranty coverage (e.g. dated bill of sale), specification of defect(s), transportation prepaid, to the Company at the address shown below. Do not return this product to the Retailer.

This Warranty is not transferable and does not cover product purchased, serviced or used outside the United States or Canada. The Warranty does not extend to the elimination of externally generated static or noise. This Warranty does not apply to costs incurred for installation, removal or reinstallation of the product, or, if in the Company's opinion, the product has been damaged through acts of nature, alteration, improper installation, mishandling, misuse, neglect, accident, or the simultaneous use of different battery types (e.g. alkaline, standard or rechargeable). This Warranty does not cover damage caused by an AC adapter not provided with the product.

THE EXTENT OF THE COMPANY'S LIABILITY UNDER THIS WARRANTY IS LIMITED TO THE REPAIR OR REPLACEMENT PROVIDED ABOVE AND, IN NO EVENT, SHALL THE COMPANY'S LIABILITY EXCEED THE PURCHASE PRICE PAID BY PURCHASER FOR THE PRODUCT.

This Warranty is in lieu of all other express warranties or liabilities. ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO DURATION OF THIS WARRANTY. ANY ACTION FOR BREACH OF ANY WARRANTY HEREUNDER, INCLUDING ANY IMPLIED WARRANTY, MUST BE BROUGHT WITHIN A PERIOD OF 24 MONTHS FROM THE DATE OF ORIGINAL PURCHASE. IN NO CASE SHALL THE COMPANY BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES WHATSOEVER. No person or representative is authorized to assume for the Company any liability other than expressed herein in connection with the sale of this product.

Some states/provinces do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damage so the above limitations or exclusions may not apply to you. This Warranty gives you specific legal rights and you may also have other rights which vary from state/province to state/province.

U.S.A.: Audiovox Electronics Corporation, 150 Marcus Blvd., Hauppauge, New York 11788

CANADA: Audiovox Return Center, c/o Genco, 6685 Kennedy Road, Unit 3, Door 16, Mississauga, Ontario L5T 3A5

©2007 AUDIOVOX CORPORATION
 Trademark(s) ® Registered
 Made in China
 HD3HSML NA IB 01

FCC Declaration of Conformity

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Trade Name: Audiovox
 Model(s): HD3HSML
 Equipment Classification: Class B Digital Device
 Responsible Party: Audiovox Corporation
 111 Congressional Blvd.
 Suite 350
 Carmel, IN 46032
 Customer Service: www.rca.com

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.