# **INSTRUCTIONS MAX. 4310**

Thank you for choosing Panamax . The MAX® 4310 is designed to provide maximum protection for audio/video equipment with external signal connections such as cable TV, rooftop antenna and DBS satellite systems

# **INSTALLING THE MAX® 4310**

**NOTE:** The MAX® 4310 and the connected equipment must be indoors and in the same building.

#### **AC Installation**

- 1. Plug the MAX® 4310 directly into a properly grounded 3-wire AC outlet\*.
- 2. Turn the MAX® 4310 on.
- **3**. Plug in one of the pieces of equipment you want to protect and turn the equipment on.

If the equipment is working correctly, continue to plug in and turn on your equipment. In the extremely unlikely event that everything does not work perfectly, stop and read the troubleshooting section. If you continue to have problems, call PANAMAX Customer Relations Department at 800-472-5555, USA and Canada.

\*Many old buildings are inadequately wired. It is very common for a building to be improperly grounded. Building wiring and grounding must conform to applicable NEC (USA) or CEC (Canada) codes for the PANA-MAX connected equipment policy to be valid.

#### Note to CATV Installer:

This reminder is provided to call the attention to Article 820-40 of the NEC. That article provides specific guidelines for proper grounding. It specifies that the cable ground shall be connected to the grounding system of the building and as close to the point of cable entry as practical.

## Satellite Coax Installation \*\*

- Connect the coax cable from the satellite dish to a Satellite coax terminal on the MAX® 4310.
- 2. Connect the provided coax jumper cable to the other Satellite coax terminal on the
- 3. Connect the other end of the coax jumper cable to the input jack on your satellite receiver.

# Cable TV or Rooftop Antenna Coax Installation \*\*

- 1. Connect the coax cable from the wall or floor plate to a CATV/ANT coax terminal on the MAX® 4310.
- 2. Connect the provided coax jumper cable to the other CATV/ANT coax terminal on the MAX® 4310.
- 3. Connect the other end of the coax jumper cable to the input jack on your television, VCR, or satellite receiver.
- \*\*There is no designated input or output jack for the MAX® 4310 Satelliteand CATV/ANT coax terminals. The coaxial protection circuitry is bi-directional in both signal transmission and protection capabilities.

## Phone Installation

- 1. Connect a phone cable from the wall jack to the LINE terminal on the telephone jack on the MAX® 4310.
- 2. Connect the provided phone line cable from the EQUIP terminal on the MAX® 4310 to the input jack on your satellite receiver. Please note that the protection circuitry will not work if these lines are reversed.

## **Rack Mounting**

An optional rack mount kit is available. Order # GRM2205.

#### **TROUBLESHOOTING**

# There is no AC power to my equipment, or my equipment doesn't turn on.

Make sure that the MAX® 4310 is plugged into a working AC outlet. Check all AC connections

Make sure the MAX® 4310 and connected equipment is turned on. If you are using the 12VDC trigger, make sure that the source is actually supplying the voltage needed to activate the MAX® 4310.

Check to see if the circuit breaker on the MAX® 4310 needs to be reset (press in).

# The MAX® 4310 circuit breaker disconnects AC power from the connected equipment.

You have exceeded the ampere rating for your surge protector. As a temporary fix, disconnect one or more pieces of equipment. Ask your dealer about additional PANAMAX products that may be required.

#### There is no picture or sound on my TV.

Check the coaxial connections, making sure that they are correctly and securely installed. Ensure that the TV set is plugged into a powered AC outlet.

# When running the DBS system test, the DBS connection displays as failed.

Check the appropriate connections to ensure that they are correctly and securely installed.

If you continue to have trouble with your MAX® 4310 or this section has not fixed the problem, please call PANAMAX Customer Relations Department at **800-472-5555**.

## **CONTACTING PANAMAX**

For product and warranty information, dealer information, and other general information contact Customer Relations at

 Email:
 custrelations@panamax.com

 Web:
 www.panamax.com

 Fax:
 707-283-5901

 Phone:
 800-472-5555

or **707-283-5900**, 7:30 a.m.- 5 p.m.PST

#### Switched Outlets LED Ground Fault LED - (red) Unsafe Voltage LED - (red) when Switched Outlets pushbutton Ground OK LED - (green) (green) indicates the staone of two triggers that can indicates that the wall when lit, indicates that the lit, indicates that incoming volttus of the "Switched turn-on or turn-off the switched outlet is properly grounded. wall outlet is improperly ages are unsafe and the surge outlets. Leave this switch in the Outlets" pushbutton and wired protector has disconnected the corresponds with the ON position if the DC trigger is power to protect your equipment. being used switch position 0 II 0 0 Always-on Convenience Outlet 10 Ft. AC Power Cord 15A Circuit Breaker - will Always-On Outlets Switched Outlets Voltage Sense Trigger Cable TV Coax Jacks Telenhone Jacks -Input - 3.5mm Mini-Plug automatically "open" Three Always-On, Four Balanced In/Out connections Single pair of gold for telephone line when the current load is Balanced L Filtered out-L Filtered outlets jack. Connect to a remote plated F-connectors optimized for Cable TV greater than 15 Amperes. lets provide a constant controlled by one trigger device that proor pay-per-view When this happens, the vides 12VDC to trigger a power source for proof the two trigge line protection. and Rooftop Antenna circuit breaker can be grammable analog or startup/ shutdown signal line protection. sources sequence. This is the secmanually reset by simply digital equipment pushing the reset button, ond trigger that will turn-Satellite Coax Jacks - Two pair of which will have "popped" on or turn-off the gold plated F-connectors optimized switched outlets. for Satellite TV signal line protection.

1690 Corporate Circle, Petaluma, 94954 • Phone 707-283-5900 • Toll Free 800-472-5555 • Fax 707-283-5901 • www.panamax.com

### MAY® 4310 PRODUCT SPECIFICATIONS

INS4310 REV. A