Owner's Guide for the

CRATE MIB 15 Bass Amplifier



Congratulations!

You are now the proud owner of the compact but powerful Crate MXB15 Bass Amplifier. Small in size vet big in performance: the 8" Crate Custom speaker makes the most of the amplifier's 12 watts of musical output power. A 4-band rotary EQ and built-in Limiter circuit give you complete control over a wide variety of sounds. In addition, the front panel headphone and external speaker jacks make this amplifier equally suited for practicing as well as perforing in intimate surroundings.

Like all Crate products, your MXB15 is designed by musicians and built using only the best components. Extensive testing confirms that this amplifier is the absolute best it can be.

In order to get the most out of your new amplifier, we strongly urge you to read the information contained in this manual before you begin playing.


And thank you for choosing



TABLE OF CONTENTS:

Important Safeguards and Precautions
The Front Panel
Suggested Settings6
System Block Diagram7
Technical Specifications









IMPORTANT SAFETY INSTRUCTIONS

- READ, FOLLOW, HEED, AND KEEP ALL INSTRUCTIONS AND WARNINGS.
- DO NOT OPERATE NEAR ANY HEAT SOURCE AND DO NOT BLOCK ANY VENTILATION OPENINGS ON THIS APPARATUS.
- DO NOT USE THIS APPARATUS NEAR SPLASHING, FALLING, SPRAYING, OR STANDING LIQUIDS.
- CLEAN ONLY WITH LINT-FREE DAMP CLOTH AND DO NOT USE CLEANING AGENTS.
- ONLY CONNECT POWER CORD TO A POLARIZED, SAFETY GROUNDED OUTLET WIRED TO CURRENT ELECTRICAL CODES AND COMPATIBLE WITH VOLTAGE, POWER, AND FREQUENCY REQUIREMENTS STATED ON THE REAR PANEL OF THE APPARATUS.
- PROTECT THE POWER CORD FROM DAMAGE DUE TO BEING WALKED ON, PINCHED, OR STRAINED.
- UNPLUG THE APPARATUS DURING LIGHTNING STORMS OR WHEN UNUSED FOR LONG PERIODS OF TIME.
- ONLY USE ATTACHMENTS, ACCESSORIES, STANDS, OR BRACKETS SPECIFIED BY THE MANUFACTURER FOR SAFE OPERA-TION AND TO AVOID INJURY
- THIS APPARATUS DOES NOT OPERATE NORMALLY AND REQUIRES SERVICE WITH ANY PHYSICAL DAMAGE FROM IMPACT OR ANY EXPOSURE TO MOISTURE.
- SERVICE MUST BE PERFORMED BY QUALIFIED PERSONNEL.
- OUR AMPLIFIERS ARE CAPABLE OF PRODUCING HIGH SOUND PRESSURE LEVELS. CONTINUED EXPOSURE TO HIGH SOUND PRESSURE LEVELS CAN CAUSE PERMANENT HEARING IMPAIRMENT OR LOSS. USER CAUTION IS ADVISED AND EAR PRO-TECTION IS RECOMMENDED IF UNIT IS OPERATED AT HIGH VOLUME.

EXPLANATION OF GRAPHICAL SYMBOLS: EXPLICACION DE SIMBOLOS GRAFICOS EXPLICATION DES SYMBÔLES GRAPHIQUES



"DANGEROUS VOLTAGE "VOLTAJE PELIGROSO" "DANGER HALITE TENSION"



Important Safeguards and Precautions:

All Crate products are designed for continuous safe operation. Abiding by the following rules can help prevent damage to your amplifier, yourself and others.

- The amplifier is equipped with a three-pronged AC power cord. To reduce the risk of electrical shock, NEVER remove or otherwise attempt to defeat the ground pin of the power cord.
- Connect the amplifier **ONLY** to a properly grounded AC outlet of the proper voltage for your amp.
- Avoid sudden temperature extremes, rain and moisture. Also, avoid sudden and intense impact. (If the unit has been subjected to any of the preceding abuses, have it looked at by an authorized service center.)
- Do not expose the unit to splashing or dripping liquid. Do not place liquid filled objects on the unit.
- NEVER set the amplifier on a support that will not bear its weight.
- Always keep the total speaker impedance at or above the rated load.
- Unplug the amplifier before cleaning it. NEVER spray liquid cleaners onto the amplifier. Wipe it with a slightly dampened, lint-free cloth to remove dirt and film.
- DO NOT use the amplifier if it has sustained damage to the chassis, controls, or power cord. Refer the unit to an authorized service center for inspection.
- Prolonged exposure to high volume levels may cause permanent hearing loss or damage. Such damage is progressive and irreversible!

Declaration Of Conformity

#27, Effective 01-01-2001

Manufacturer's Name: SLM Electronics

Production Facility:11880 Borman Drive, St. Louis, MO 63146, USAProduction Facility:700 Hwy 202 W, Yellville, AR 72687, USAShipping Facility:1400 Ferguson Ave., St. Louis, MO 63133, USAOffice Facility:1400 Ferguson Ave., St. Louis, MO 63133, USA

Product Type: Audio Amplifier

Complies with Standards:

LVD: 92/31/EEC, 93/68/EEC, & 73/23/EWG

Safety: EN60065

EMC: EN55013, EN55020, EN55022, EN61000-3-2,


& EN61000-3-3

Supplementary information provided by: SLM Electronics - R & D Engineering 1901 Congressional Drive, St Louis, MO 63146, USA Tel.: 314-569-0141, Fax: 314-569-0175

The Front Panel:



- **1: INPUT:** Use this 1/4" jack to connect your guitar to the amplifier by means of a shielded instrument cable.
- **2: MASTER GAIN:** Use this control to adjust the overall output of the amplifier.
- **3: LOW:** Use this control to adjust the bass response of the amplifier. Rotating the control counterclockwise reduces the low frequency output. Rotating the control clockwise increases the low frequency output. The Low control provides a range of 15dB of boost or cut at 60Hz. It may be necessary to reduce the Low frequency output at higher volume levels.
- **4: LO MID:** Use this control to adjust the "thickness" or "fatness" of the amplifier. Rotating the control counterclockwise reduces the lower middle frequency output. Rotating the control clockwise increases the lower middle frequency output. The Low Mid control provides a range of 18dB of boost or cut at 630Hz.
- **5: HI MID:** Use this control to adjust the clarity and definition of the string attack. Rotating the control counterclockwise reduces the upper middle frequency output. Rotating the control clockwise increases the upper middle frequency output. The High Mid control provides a range of 19dB of boost or cut at 2kHz.
- **6: HIGH:** Use this control to adjust the high frequency response of the amplifier. Rotating the control counterclockwise reduces the high frequency output. Rotating the control clockwise increases the high frequency output. The High control provides a range of 27dB of boost or cut at 10kHz.



7: SPEAKER: Use this jack to connect the amplifier to an external speaker. The internal speaker is disconnected when this jack is used. The impedance of the external speaker must be 4 ohms or greater.

WARNING: Do not attempt to use headphones in the Speaker jack! Permanent hearing damage could result!

8: HEADPHONES: Use this jack to connect headphones to the amplifier. The internal speaker is disconnected when headphones are used.

CAUTION: To avoid possible damage to your hearing, do not use headphones for extended periods of time at extremely loud levels.

9: ON LED: This LED illuminates when the amplifier is turned on.

10: POWER: Use this switch to turn the amplifier on (top of the switch depressed) and off (bottom of the switch depressed).


11: POWER CORD (rear panel, not shown): The grounded power cord should only be plugged into a grounded power outlet that meets all applicable electrical codes and is compatible with the voltage, power, and frequency requirements stated on the rear panel. Do not attempt to defeat the safety ground connection.

Suggested Settings:


Clean:



Rhythm:



Lead:



System Block Diagram: EQ BUFFER

MXB15 TECHNICAL SPECIFICATIONS:

Output Power Rating	12 watts RMS @ 5% THD 4 ohms, 120 VAC			
Maximum Input Signal Accepted	15 volts peak-to-peak			
Input Impedance	25k ohms			
Signal to Noise Ratio	72dB			
Low Control	15dB Range @ 60Hz			
Low Mid Control	18dB Range @ 630Hz			
High Mid Control	19dB Range @ 2kHz			
High Control	27dB Range @ 10kHz			
Power Requirements	120 VAC, 60Hz, 30VA			
	100/115VAC, 50/60Hz, 30VA	1		
	230VAC, 50Hz, 30VA			
Speaker Size and Rating	Crate Custom Design 8", 15 watts			
Size and Weight	13" H x 13.5" W x 8.25" D, 15 lbs.			
·				

The MXB15 is covered with a durable black Tolex material: wipe it clean with a lint-free cloth.

Never spray cleaning agents onto the cabinet. Avoid abrasive cleansers which would damage the finish.

Crate continually develops new products, as well as improves existing ones. For this reason, the specifications and information in this manual are subject to change without notice.

