




DOUBLE BATTERY 12-Volt Charger Instructions

Types "A" and "H"
For Vehicles Requiring
Two 6-Volt Batteries for Operation
Model 74242



IMPORTANT!

This charger is only for use with 12-volt vehicles with a Type "A" power system or a Type "H" power system equipped with connector covers. If the connector on your batteries do not look like either of the connectors pictured here, do use this charger. Call Power Wheels® Consumer Affairs at 1-800-348-0751 for further information.

- Please keep these instructions for future reference as they contain important information.
- Battery charging must be done by an adult.
- If you have any questions, please refer to the Owner's Manual which came with your vehicle, or call Power Wheels Consumer Affairs toll-free at **1-800-348-0751**.
- This charger is for use with Power Wheels® **Type "A" and Type "H" 12-volt vehicles which require two 6-volt batteries for operation. Use the enclosed Wire Harness Converter with Type "H" vehicles only.**
- Do not use any charger other than the type specified for use with your vehicle's power system. Refer to the Owner's Manual which came with your vehicle to determine which type of charger you should use, or call Power Wheels® Consumer Affairs.
- Use only genuine Power Wheels® parts with your Power Wheels® vehicle.
- This transformer is not a toy.

WARNING

- Never allow children to charge the batteries. Battery charging must be done by adults only. A child could be injured by the electricity involved in charging the batteries.
- Use of the wrong type batteries or charger could cause a fire or explosion, resulting in serious injury.
- Use of Power Wheels® components in or with products other than Power Wheels® vehicles could cause overheating, fire or explosion.
- Examine the batteries, charger and their connectors for excessive wear or damage each time you charge the batteries. If damage or excessive wear is detected, do not use the charger or the vehicle until you have replaced the worn or damaged part.
- Never alter this vehicle or its electrical system in any way. Alterations could cause a fire resulting in serious injury and could also ruin the electrical system.

CAUTION

Use the charger in dry locations only.

Battery Charging




Use with Type "H" Vehicles With Connector Covers

If your battery connector looks like the one pictured above, you have a Type "H" vehicle with connector covers and must use the enclosed Wire Harness Converter with this charger.

Wire Harness Converter

H-Style End



- Remove the connector cover from your old charger and reassemble it on the H-style end of the enclosed Wire Harness Converter.
- Plug the end of the Wire Harness Converter with Connector Cover to your battery connector. The A-Style end of the Wire Harness Converter will plug into the A-Style connector on your new charger.

Important Notes

- Before charging the batteries, examine the battery cases for cracks and other damage which may cause sulfuric acid (electrolyte) to leak during the charging process. If damage is detected, do not charge the batteries or use them in your vehicle. Battery acid is very corrosive and can cause severe damage to surfaces it contacts.

- Do not charge the batteries on a surface which could be damaged by the acid contained inside the batteries. Take precautions to protect the surface on which you charge your batteries.
- The batteries must be upright while charging. You do not need to remove the batteries from your vehicle to charge them.

1

- If your batteries are already installed in your vehicle, unplug the vehicle's motor harness and battery connectors.

2

- To charge the batteries, plug the charger connector and battery connector together. Push firmly to make sure the two connectors are completely joined.

Note: Make sure the two battery connectors are stacked.

- Plug the charger into a standard 120 volt wall outlet. (If power flow to the wall outlet is controlled by a switch, make sure the switch is ON.)

3

- **Charge new batteries at least 18 hours before first use. Recharge the batteries at least 14 hours after each use.** The charger may become warm to the touch while

Battery Charging

charging. New batteries may make a "sizzling" or "bubbling" noise and swell slightly. These are normal conditions and do not indicate a problem.

IMPORTANT! Never charge the batteries longer than 30 hours. Overcharging or undercharging the batteries can shorten battery life and decrease vehicle running time.

4

- After charging, unplug the charger from the wall outlet.
- Unplug the charger connector from the battery connector. Your batteries are now charged and are ready to be installed in your vehicle. Please refer to your vehicle's Owner's Manual for Battery Installation instructions. If your batteries are already installed in your vehicle, plug the vehicle's motor harness connector and battery connector together and secure the battery compartment.

Limited Warranty

For the original purchaser, this one year limited warranty covers the Power Wheels® Double Battery 12-Volt Charger (purchased from Power Wheels®) against defects in materials and workmanship.

This warranty covers normal use and does not cover the Power Wheels® Double Battery 12-Volt Charger if damaged by unreasonable use, neglect, accident, abuse, misuse, improper service or other causes not arising out of defects in materials or workmanship. Evidence at any attempt at consumer repair will void this warranty. This warranty does not cover, and is intended to exclude, any liability on the part of Power Wheels®, whether under this warranty or implied by law for any indirect or consequential damages or breach of warranty. Some states do not allow the exclusion or limitation so this limitation may not apply to you.

This warranty gives you specific legal rights and you may also have other rights which may vary from state to state.

Please save your original sales receipt.



©2000 Fisher-Price, Inc., a subsidiary of Mattel, Inc.,
East Aurora, New York 14052

Printed in the U.S.A.

74242pr-0920