Shiro

SB2112

Basic Phone

SB2112 User Guide

Shiro

> **!** Please ensure the phone is placed in a dry and ventilated place without corrosive air.

FEATURES：

- Last Number Redial
- Tone/Pulse selection (Optional)
- Ringer On/Off selection (Optional)
- Flash and Mute Feature
- Wall Mount Feature

TABLE OF CONTENT

SB2112 User Guide

Shiro

PRODUCT OVERVIEW

Description:
1. FLASH key
2. MUTE key
3. 0-9/*/# key
4. RINGER ON/OFF switch (optional)
5. DIAL TONE/PULSE switch(optional)
6. REDIAL key
7. Handset Cord jack
8. TEL LINE jack

1. SWITCH OPERATION

RINGER ON/OFF switch
You can turn the switch **ON/OFF** using the Ringer switch. This feature is optional depending on the country you have purchased from.

DIAL TONE/PULSE switch
You can switch between **TONE/PULSE** using the Dial switch. This feature is optional depending on the country you have purchased from.

2. FUNCTION KEY OPERATION

FLASH key (600ms)
In the on-hook mode, press this key to auto-hang up for 600ms, after that you can press **REDIAL** key or dial out another number.

MUTE key

While you are on the line, if you do not want the remote party to hear you, just press and hold the **MUTE** key.

REDIAL key

In the handset off-hook mode, press this key to redial the last dialed number.

TROUBLESHOOTING GUIDE

(Q) I do not hear any dial tone from the handset.

(A) Ensure the handset cord is connected correctly to the handset cord jack at the base. Ensure you have plug in the telephone cable from the telephone to the wall socket correctly. If the problem persists, please check with your local dealer.

DECLARATION OF CONFORMITY

The telephone complies with the essential protective requirements and objectives of:

- EC R& TTE Directive 1999/5/EC
- EC Low Voltage Directive 73/23/EEC
- EC EMC Directive 89/336/EEC

And conforms to the following relevant harmonized standards:

- EMC: EN55022, EN55024
- Safety: EN 60950