

Personal Space Air Cleaner

SOLO2

Owner's Guide



English

MODELS
30030, 30031,
30033, 30034

Form# 43057-01
20100609
©2010 Hunter Fan Co.

SINCE 1886
Hunter[®]

Table of Contents

Safety Instructions	2
Introduction	2
Air Filtration System	3
How the HEPAtch® System Works	3
Solo ₂ Components	3
Operation	4
Touch Sensitive Areas	4
Adjusting the Solo ₂	4
Air Cleaner Maintenance	4
Cleaning	4
Changing the Filter	5
Technical Support	5
Troubleshooting	6
Filter Ordering	6
Warranty	6
Other Home Comfort Products From Hunter	7

SAFETY INSTRUCTIONS

IMPORTANT!

READ ALL INSTRUCTIONS BEFORE USING THIS AIR CLEANER!

1. This Air Cleaner is designed for use on a flat level surface and may not work properly otherwise. **ALWAYS** place the SOLO₂ on a firm level surface. **ALWAYS** ensure the SOLO₂ is at least six (6) inches away from walls or computers, and 3 ft. heat sources such as stoves, radiators, or heaters.
2. Before using the SOLO₂, extend the cord and inspect for any signs of damage. DO NOT use the product if the cord has been damaged.
3. **ALWAYS UNPLUG** the SOLO₂ from your power source while it is being cleaned.

4. DO NOT immerse the SOLO₂ in water at any time because permanent damage will occur. To properly clean your SOLO₂, follow the instructions in the Maintenance section of this manual (page. 4).
5. This equipment should be inspected frequently and collected dirt removed from it regularly to prevent excessive accumulation that could result in flashover or risk of fire.

INTRODUCTION

Thank you for purchasing the SOLO₂ Personal Space Air Cleaner from Hunter Fan Company. You have purchased our latest development in portable air cleaning which has been designed to improve the quality of the air that you breathe. The following innovative features are included in your Hunter Air Cleaner.

- **Touch Sensitive Controls:** Your SOLO₂ Air Cleaner utilizes a touch control interface for operation. The touch sensitive pads on the front of the unit only need to be touched with your finger tips to activate. Finger nails, pens, or pencils will not activate the fields for the touch control.
- **Switchable Power Supply:** Your SOLO₂ power adapter meets with all State and Local guidelines for power consumption. With your power adapter being "Switchable", your SOLO₂ can be taken anywhere, even overseas.
- **High Particulate Efficiency:** The HEPAtch® filter will remove micron particles from the air that pass through the filter. The back side of the HEPAtch® filter includes a carbon filter which will also help illuminate odors.
- **Filter Counters:** Filter maintenance is critical to the performance of the SOLO₂. To help you determine when to change the HEPAtch® filter, the unit has a built in life counter to keep track of the life remaining on the filter.

AIR FILTRATION SYSTEM

How the HEPAtech® System Works

Air is pulled in through the bottom of the unit where particles such as dust, dander, and pollen collect on the HEPAtech® filter, leaving the air emitted from the front of the SOLO₂ cleaner and healthier for your personal space. **Figure 1.** The carbon pre-filter on the back of the filter also helps to eliminate odors from the air. The fan within the unit ensures that air is pulled into the unit and forced through the filter to provide fresh air wherever SOLO₂ is setup. Refer to **Figure 2.** for parts breakdown.



Figure 1.

SOLO₂ COMPONENTS





Figure 2.

OPERATION

To turn your SOLO₂ unit on, press the up and down touch pads on the unit simultaneously. Once on, press the up or down arrow buttons to adjust fan speed. To turn your SOLO₂ unit back off, press both touch pads on the front of the unit again. **Figure 3.** There are ten fan speeds on your Solo₂ unit. Once set, your SOLO₂ unit will remember your last setting when it is turned back on.

NOTE: When using the touch panel on the front of the SOLO₂, you must use your fingertips to operate the controls. Finger nails, pens, pencils, etc will not work to activate or control the unit.



ADJUSTING THE SOLO₂

Now that the SOLO₂ is functional, you will need to adjust it to direct the air flow towards you. Holding the top of the SOLO₂, tilt the unit back or forth until you find the angle that will provide the best comfort level. **Figure 4.**




Figure 4.

AIR CLEANER MAINTENANCE

Cleaning

Proper maintenance of your Hunter Air Cleaner will help ensure years of trouble free service. Follow these steps to properly maintain your air purifier:

1. Approximately every 90 days, the outside of the unit should be cleaned with a soft, damp cloth.
2. Follow the instructions for Changing the Filter on this page to determine how to replace the filter. The Hunter Logo on the front of the SOLO₂ will flash amber when it is time to change the filter.

NOTES:

- The air cleaner must be unplugged from the power outlet during the cleaning process.
- Be sure the unit is completely dry before plugging in and using.
- Never immerse unit in water or use harsh chemicals to clean.

Changing the Filter

1. To change the filter in your SOLO₂, turn the unit off and unplug the power cord.
2. Turn the SOLO₂ on it's side and remove the wire base from the bottom of the unit by compressing the hinges on either side of the wire base (a) and gently pulling each out of the bottom of the SOLO₂ unit (b) . **Figure 5.**




Figure 5.

3. Place your fingers in the slots the hinges came out of on either side of the unit and pull the filter out. **Figure 6.**




Figure 6.

4. Install the filter into the unit, using the arrows on the side of the filter, indicating the direction the filter should be placed into the unit (black side out).




Figure 7.

5. Align the bumps on the hinges on the wire base with the holes on the bottom of the unit and snap into place. Ensure once seated that the bumps on the hinges are seated securely in the holes on the bottom of the SOLO₂. **Figure 7.**
6. Set your SOLO₂ upright again and reconnect the power.
7. If the filter light on the front of the unit continues to blink, press the filter reset button on the back of the unit for 3 seconds to reset.

TECHNICAL SUPPORT

If you have any additional questions or problems with your Hunter Solo₂ unit, please call 1-888-830-1326 from 7:00 am to 7:00 pm Monday - Friday and 8:00 am to 5:00 pm on Saturday, Central Time. You may also contact us over the Internet at www.hunterfan.com.

TROUBLESHOOTING

1. I cannot operate SOLO₂ from the controls on the product.

Unplug the power adapter from the wall and allow it to set for one minute. Plug the power adapter back into the wall and press the up and down arrows on the front of the unit at the same time to turn it on.

2. How do I clean the SOLO₂ unit?

Please refer to the cleaning instructions on page 4 of your owner's manual.

3. I need to replace the power adapter.

Please contact our technical support department for replacement parts.

FILTER ORDERING

Depending on usage and the environment, your Hepatech filter should be replaced every 6 months.

Replacement filters are available at most retailers that carry Hunter Air Purifiers. You may also purchase directly from Hunter Fan Company by:

Phone: 1-888-830-1326
Website: www.hunterfan.com

*Applicable state and local taxes may apply.

*Prices are subject to change without notice.

* All orders will be shipped USPS or UPS Ground, allow 12-15 working days for delivery.

Filter#	Type
30811	Hepatech

WARRANTY

Hunter Fan Company SOLO₂ Air Cleaner System 5 YEAR LIMITED WARRANTY

The Hunter Fan Company makes the following limited warranty to the original residential user or consumer purchaser of the SOLO₂ Air Cleaner System:

If any part of your SOLO₂ Air Cleaner System ("Air Cleaner") motor fails during the first five (5) years from the date of installation due to a defect in material or workmanship, we will provide a replacement Air Cleaner free of charge. Installation is deemed to occur at the date of purchase.

If the Air Cleaner cord or wire base fails any time within one (1) year after installation due to a defect in material or workmanship, we will replace or, at our option, repair the unit free of charge at our nearest service center or at our Service Department in Memphis, Tennessee. You will be responsible for all parts and labor costs after this one-year period.

IF THE ORIGINAL RESIDENTIAL USER OR CONSUMER PURCHASER CEASES TO OWN THE AIR PURIFIER, THIS WARRANTY AND ANY IMPLIED WARRANTY WHICH THEN REMAINS IN EFFECT, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE VOIDED.

NO WARRANTY, EXPRESSED OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, IS MADE IN RESPECT TO THE FILTER MATERIAL OR CARBON FILTER.

THIS WARRANTY IS IN LIEU OF ALL OTHER EXPRESS WARRANTIES. THE DURATION OF ANY IMPLIED WARRANTY, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, IN RESPECT TO THE MOTOR IS EXPRESSLY LIMITED TO THE PERIOD OF THE EXPRESS WARRANTY SET FORTH ABOVE.

This warranty is voided if the air cleaner is not purchased and used in the USA or Canada.

This warranty excludes and does not cover defects, malfunctions or failures of the Air Cleaner which were caused by repairs by persons not authorized by us, use of parts or accessories not authorized by us, mishandling, modifications, or damage to the Air Cleaner while in your possession, or unreasonable use, including failure to provide reasonable and necessary maintenance. This warranty does not cover Air Cleaners used in commercial applications. There are no express or implied warranties as to commercial purchasers or users.

To obtain service, contact the nearest Hunter authorized service center or the Hunter Fan Company Service Department, 2500 Frisco Avenue, Memphis, Tennessee 38114, 1-888-830-1326. For the name of our nearest authorized Hunter Fan Company Service Center, write to the Hunter Fan Company at the preceding address. You will be responsible for insurance and freight or other transportation to our factory service center. We will return the Air Cleaner freight prepaid. The Air Cleaner should be properly packaged to avoid damage in transit since we will not be responsible for any such damage. Proof of purchase is required when requesting warranty service. The purchaser must present sales receipt or other document that establishes proof of purchase.

IN NO EVENT SHALL HUNTER FAN COMPANY BE LIABLE FOR DIRECT, INDIRECT, SPECIAL CONSEQUENTIAL OR INCIDENTAL DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE AIR CLEANER. YOUR SOLE REMEDY WILL BE REPAIR OR REPLACEMENT AS PROVIDED ABOVE. SOME AMERICAN STATES AND CANADIAN PROVINCES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.


SOME AMERICAN STATES AND CANADIAN PROVINCES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF DIRECT, INDIRECT SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

SOME AMERICAN STATES AND CANADIAN PROVINCES DO NOT ALLOW THE EXCLUSION OR INVALIDITY OF EXPRESS OR IMPLIED WARRANTIES IF THE USER CEASES TO OWN THE AIR PURIFIER, SO THE ABOVE


LIMITATION MAY NOT APPLY TO YOU.

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE OR PROVINCE TO PROVINCE.


OTHER HOME COMFORT PRODUCTS FROM HUNTER



Hunter Original®
Fans



The Care-Free
Humidifier™



Programmable
Thermostat

To learn more about Hunter Fan Company products, please see our Web page at:
www.hunterfan.com

Hunter
FAN COMPANY
2500 FRISCO AVENUE
MEMPHIS, TN 38114, USA

43057-01 20100609

