

Quick Installation Guide

3.5" USB2.0 SATA Enclosure

Model # AEN-U35SAB



Package Contents:

- 3.5" SATA Enclosure with Stand
- Power adapter
- USB 2.0 Cable
- Quick Installation Guide
- Screwdriver and screw set

Section 1

Hard Drive Installation

Step 1 Use the provided screwdriver to remove the two screws on the right side of the enclosure. Pull out the right panel.



Step 2 Attach the SATA connectors to your hard drive.



Step 3 With the hard drive label facing up, attach the guides to both sides of the hard drive.



The picture below shows how the guide being attached to the hard drive correctly. If the guides are not properly installed, the hard drive cannot be inserted into the enclosure case.



Step 4 Line up the guides with the case, and slide the hard drive back in. The enclosure should slide shut.



Step 5 Secure the two screws that were removed in step 1.

Step 6 Connect one end of the power cord to the back of the enclosure and connect the other end to a power outlet.

Step 7 Connect one end of the USB cable to the enclosure and the other end to your computer.

Step 8 Press the power button to turn the power ON.



The hard drive is now ready to use and you can find it under "My Computer".

Congratulations! The hard drive installation is complete.

Note: If you do not see your hard drive under My Computer, please continue on Section 2.


Section 2

Disk Management


If your disk drive is brand new, you might not be able to see it under "My Computer" before it is formatted. Please go though the following steps to format the new drive.

Step 1 Go to **Control Panel > Administrative Tools** or if you are at category view, go to **Control Panel > Performance and Maintenance > Administrative Tools**, double click on **Computer Management**.


Step 2 Click on **Disk Management** on the left menu bar. The new disk information should be displayed on the right panel.




Step 3 Right click on the Unallocated disk and select **New Partition** from the menu.




Step 4 Click Next to start the New Partition Wizard.



Step 5 Select the desired Partition Type and click **Next**.




Step 6 Enter the desired Partition Size and click Next.




Step 7 Select **Assign the following drive letter** and select a letter for the new disk drive or you can select other options preferred. Click **Next**.



Step 8 Select the File system and change the Volume label or you can select other options preferred. Click **Next** to start formatting the hard drive.



Step 9 Click Finish after the New Partition Wizard completed.



Go to My Computer, the new drive should be listed there.



Section 3

Technical Support

E-mail: support@airlink101.com

Toll Free: 1-888-746-3238

Website: www.airlink101.com

* Specifications are subject to change without notice. Photos of the product may not reflect the actual content. Hard disk compatibility and accessible capacity are not guaranteed.

Copyright ©2010 AirLink101® All rights reserved. AirLink101, the stylized AirLink101 logo, specific product designations, and all other words and logos that are identified as trademarks and/or service marks are, unless noted otherwise, the trademarks and service marks of AirLink101. All other product or service names are the property of their respective holders. AirLink101 products are protected under numerous U.S. and foreign patents and pending applications, mask work rights, and copyrights.