

Precision Weighing Solutions

Escali™

User Manual

Keso

25 Lb / 12 Kg

Digital Scale

www.Escali.com

Selecting the default weight

Before the scale is turned ON, you may select the default weighing units by moving the switch (located on the right side of the scale) to g or oz. Once the scale is activated, the display will show the default-weighing units. You may switch to the other weighing units during use by moving the switch.

How to reset the scale:

If a series of dotted lines appears on the display and/or the scale fails to weigh items placed on the platform:

- 1) Remove the item from the platform and press the "OFF" button
- 3) Press the "ON" button again; your scale is now reset to "0"

How to use the special built-in holder:

- 1) Before activating the scale, lift the built-in holder cover*
- 2) On the left side, press the "ON" button
- 3) Place and secure item slowly into the special holder

*Please note - If the scale is activated before lifting the built-in holder cover, the scale may not operate. If this occurs, simply reset the unit by pressing the "OFF" button and return to step 1.

Battery Replacement/Installation

Replace the battery when the LCD display reads "LO".

- 1) Remove the battery door
- 2) Install the 9-volt battery connections
- 3) Replace the battery door

Power Source: 9-volt battery or 110V AC Adapter

Dimensions: 8" x 8" x 3" (20.3cm x 20.3cm x 7.6cm)

Resolution: 0.1 oz / 2 gr up to 2 Lb / 1 Kg,
0.5 oz / 5 gr over 2 Lb / 1 Kg

Capacity: 25 Lb / 12 Kg

Weight Modes: Kg/gm and lb/oz

Auto Shut Off: Turns off after 3-4 minutes of non-use.

Warranty: Manufacturer's five (5) year warranty, see www.escali.com for full details.

Thank you for purchasing an *Escali* Digital Scale.

Please read the following operation information to ensure the proper function of your new scale.

How to weigh*

- 1) On the right side, move the switch to select the units (g/oz)
- 2) On the left side, press the "ON" soft-touch button
- 3) Place item slowly on the platform

*Please Note: If the scale does not return to "0" g/oz after removing the item from the platform, simply press the "ON" button again. This will reset the scale to "0" g/oz.

How to use the "Tare" feature:

This feature allows you to obtain the exact weight of an item in a container, by subtracting the weight of the container.

- 1) On the right side, select measuring units (g/oz)
- 2) On the left side, press the "ON" button
- 3) Place the container, without the item, slowly on the platform
- 4) Press the "ON" button again. The weight of the container will be removed and the display will reset to "0"
- 5) Slowly add the item to the container. The display will show the weight of the item only

How to clear "Tare" feature:

- 1) Remove all items from the platform.
- 2) Press the "OFF" button
- 3) Press the "ON" button

Now the scale is reset to "0" and the weight of all items on the platform will be displayed.

Reading the unit of measurement for ounces

This unit does not display decimal points, instead it uses oz.

Example: The display will read 1LB 12oz1, which is 1lb 12.1oz

Additional Information


- 1) Make sure your scale is at room temperature and on a stable horizontal surface free of vibration.
- 2) This scale is not waterproof. Do not expose to moisture.
- 3) As this scale is a precision instrument, it must be handled with extreme care. Avoid rough treatment, shaking and vibration.
- 4) Do not disassemble this scale or the warranty will be void.
- 5) The display value may be affected by electromagnetic disturbances such as operating near a radio. If this occurs, move the device that is causing the disturbance and turn the scale off and restart.

Do not place overweight items on scale

Weighing items over the maximum weight capacity will cause an "EE" error to display. Immediately remove overweight items to avoid causing damage to your scale.

Connecting the 110V AC adapter

Insert the adapter's plug into the matching outlet holes. Firmly push and adjust the plug until it is fully inserted into the scale.



Warning – To prevent damage to your scale, use only an Escali adapter or your warranty will be void

Escali's liability is limited to two (2) times the cost of the product

© Copyright Escali LLC, 2003